

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
FACSIMILE SETS AN/TXC-1, AN/TXC-1A, AND
AN/TXC-1B (FSN 5815-164-7107); AN/TXC-1C
(FSN 5815-194-9522); AND AN/TXC-1D (FSN 5815-503-2711)

Headquarters, Department of the Army, Washington, D.C.
28 March 1975

Current as of December 1974

		Paragraph	Page
SECTION	I.	INTRODUCTION	
		Scope	1-1 2
		General	1-2 2
		Explanation of columns	1-3 2
		Special information.....	1-4 4
		Location of repair parts.....	1-5 4
		Abbreviations (Not applicable)	1-6 4
		Reporting of equipment publication improvements	1-7 4
	II.	PRESCRIBED LOAD ALLOWANCE (Not applicable)	
	III.	REPAIR PARTS LIST	6
	IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)	
	V.	INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER.....	8

¹This manual supersedes TM 11-5815-246-20P, 3 June 1964.

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the AN/TXC-1, AN/TXC-1A, AN/TXC-1B, AN/TXC-1C, and AN/TXC-1D. The PCCN for the equipment is GCWANT for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. Prescribed Load Allowance (PLA) - Section II. Not applicable.

b. Repair Parts List - Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

c. Special Tools, Test and Support Equipment - Section IV. Not applicable.

d. Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section V. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists-

a. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are -

<i>Code</i>	<i>Explanation</i>
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.

<i>Code</i>	<i>Explanation</i>
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.
PG -	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD -	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF -	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB -	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO -	Item to be manufactured or fabricated at organizational level.
IMF -	Item to be manufactured or fabricated at direct support maintenance level.
MH -	Item to be manufactured or fabricated at general support maintenance level.
MD -	Item to be manufactured or fabricated at depot maintenance level.
AO -	Item to be assembled at organizational level.
AF -	Item to be assembled at direct support maintenance level.
AH --	Item to be assembled at general support maintenance level.
AD -	Item to be assembled at depot maintenance level.
XA -	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB -	Item is not procured or stocked. If not available through salvage, requisition.
XC -	Installation drawing, diagram instruction

<i>Code</i>	<i>Explanation</i>
	sheet, field service drawing, that is identified by manufacturers' part number.
XD --	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows -

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O -	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

F -	Support item is removed, replaced, used at the direct support maintenance level.
H -	Support item is removed, replaced, used at the general support maintenance.
D -	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code -

<i>Code</i>	<i>Application/Explanation</i>
O -	The lowest maintenance level capable of complete repair of the support item is the organizational

<i>Code</i>	<i>Application/Explanation</i>
	level.
F -	The lowest maintenance level capable of complete repair of the support item is direct support.
H -	The lowest maintenance level capable of complete repair of the support item is general support.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to designated Specialized Repair Activity.
Z -	Non-repairable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows -

<i>Code</i>	<i>Explanation</i>
Z -	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item.

NOTE

For requisitioning purposes, the Federal stock number must be converted to the National stock number by adding "-00-" after the Federal stock classification (FSC) code (first four digits). For example, FSN 6625-553-0142 converts to NSN 6625-00-553-0142.

c. *Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. *Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit.* This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. *15-Day Organizational Maintenance Allowance.*

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-CW, Fort Monmouth, N.J., 07703. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment.

g. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-2258.

(2) *Item number.* Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

<i>Code</i>	<i>Used on</i>
RVT	AN/TXC-1
BXJ	AN/TXC-1A
BXK	AN/TXC-1B
BXL	AN/TXC-1C
BXM	AN/TXC-1D

b. The following publication pertains to the equipment and its components:

TM 11-2258 Facsimile Sets AN/TXC-1, -1A, -1B, -1C, and -1D.

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-CW, Fort Monmouth, NJ 07703.

(Next printed page is 6)

SECTION III

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REFERENCE NUMBER & MFR CODE USABLE ON CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUSTRATION	
					(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIGURE NO.	(b) ITEM NO.
PAOHO	5965-285-0144	LOUDSPEAKER, PERMANENT MAGNET LS..... LS11 (80058)	EA	1	*	*	*	*	5	LS1
PAOZZ	58L5-239-4734	LENS, LIGHT I5 COLORLESS GLASS CLEAR SMOOTH..... FACE & BACK 1 1/16 IN LG X 1-1/8 IN DIA 26-45-00-00 1979831	EA	1	*	*	*	*		15
PAOZZ	3610-282-8858	PAPER, RECORDING. ELECTROSENSITIVE NO-REF-DESIG..... FOR USE WHEN COPIES WILL BE REQUIRED TYPEA (91183)	PG	1	*	*	*	*		
PADZZ	7530-282-8860	PAPER, RECORDING, ELECTROSENSITIVE NO-REF-DESIG PG..... FOR USE WHEN NO COPIES WILL BE REQUIRED TYPEND (97983)		1	*	*	*	*		
XDOZZ		SCALE, DIAL INDICATING NO-REF-DESIG HANGING..... STYLE 0-22 OZ RANGE 2 OZ GRADUATION SMB201387 (80063)	EA	1	*	*	*	*		
PAOZZ	5815-392-8387	BAG MS1 FILTER CLOTH CONSTRUCTION USED AS..... DUST BAG IN EXHAUST SYSTEM V3 (80059)	EA	1	*	*	*	*		MS1
PAOZZ	6810-630-0355	CARBON, GRANULAR MS5 ACTIVATED CARBON 1/2 LB..... CAN	EA	1	*	*	*	*		MS5
PAOZZ	5340-392-8460	130-00-00-04 (13179) CLAMP H44 1.660 IN DIA X 3/4 IN W.....	EA	2	*	*	*	*		H44
PAOZZ	5340-392-8460	936C69 (18915) CLAMP H45 1.660 IN DIA X 3/4 IN W.....	EA	REF	*	*	*	*		H45
PAOZZ	5815-225-4997	936C69 (189L5) CONTAINER 052 ACTIVATED CARBON CYLINDRICAL..... SHAPE 7-1/2 IN LG X 5-1/8 IN DIA 34-50-20-00 (97983)	EA	1	*	*	*	*		052
PAOZZ	5815-392-9652	HOSE, FLEXIBLE H43 F/COLLECTION OF CARBON DUST..... EMITTED BY STYLUS 1-1/4 IN ID X 42 IN LG SMB201668 (80063)	EA	1	*	*	*	*		H43
XDOZZ		THUMBSCREW H47 5/8 IN H X 15/16 IN W 5/16..... THD 34-50-10-02 (91983)	EA	3	*	*	*	*		H47
XDOZZ		THUMBSCREW H48 5/8 IN H X 15/16 IN W 5/16..... THD 34-50-10-02 (97983)	EA	REF	*	*	*	*		H48
XDOZZ		THUMBSCREW H49 5/8 IN H X 15/16 IN W 5/16..... THD 34-50-10-02 (979831)	EA	REF	*	*	*	*		H49
XDOZZ		ELECTRON TUBE E2 U/D ALL TRANSCEIVER MODELS..... 1B59R1130B (81349)	EA	1	*	*	*	*	138	E2
PAOZZ	5960-188-3557	ELECTRON TUBE V4 U/O ALL TRANSCEIVER MODELS..... 7C5 (81349)	EA	4	*	*	*	*	151	V4
PAOZZ	5960-188-3557	ELECTRON TUBE V7 U/O ALL TRANSCEIVER MODELS..... 7C5 (81349)	EA	REF	*	*	*	*	151	V7
PAOZZ	5960-188-3557	ELECTRON TUBE V8 U/O ALL TRANSCEIVER MODELS..... 7C5 (81349)	EA	REF	*	*	*	*	151	V8
PAOZZ	5960-188-3557	ELECTRON TUBE V12 U/O ALL TRANSCEIVER MODELS..... 7C5 (81349)	EA	REF	*	*	*	*	151	V12
PAOZZ	5960-188-3581	ELECTRON TUBE V10 U/O TRANSCEIVERS TT-1,1A,1B..... 1C,1D/TXC-1 7C7 (81349) BXI,BXJ,BXK,BXL	EA	1	*	*	*	*	149	V10
PAOZZ	5960-100-6017	ELECTRON TUBE V9 U/O ALL TRANSCEIVER MODELS..... 7L7 (81350)	EA	3	*	*	*	*	151	V9
PAOZZ	5960-100-6017	ELECTRON TUBE V11 U/O ALL TRANSCEIVER MODELS..... 7I7 (81350)	EA	REF	*	*	*	*	151	V11
PAOZZ	5960-100-6017	ELECTRON TUBE V15 U/O ALL TRANSCEIVER MODELS..... 7L7 (81350)	EA	REF	*	*	*	*	151	V15
PAOZZ	5960-235-9108	ELECTRON TUBE V13 U/O TRANSCEIVERS TT-1,1A,1B..... 1C/TXC-1 7N7 (81349) BXI,BXJ,BXK	EA	1	*	*	*	*	149	V13
PAOZZ	5960-235-9108	ELECTRON TUBE V13 U/O TRANSCEIVERS TT-1D,1E..... 1F/TXC-1 ALL ORDER NOS 7N7 (81349) BXL,BXM	EA	2	*	*	*	*	150	V13
PAOZZ	5960-235-9108	ELECTRON TUBE V26 U/O TRANSCEIVERS TT-1D,1E..... 1F/TXC-1 ALL ORDER NOS 7N7 (81349) BXL,BXM	EA	REF	*	*	*	*	168	V26
PAOZZ	5960-108-0257	ELECTRON TUBE V25 U/O ALL TRANSCEIVER MODELS..... 884 (81349)	EA	1	*	*	*	*	151	V25
PAOZZ	5960-061-1215	ELECTRON TUBE V5 U/O ALL TRANSCEIVER MODELS..... 1635 (81349)	EA	3	*	*	*	*	151	V5
PAOZZ	5960-061-1215	ELECTRON TUBE V6 U/O ALL TRANSCEIVER MODELS..... 1635 (81349)	EA	REF	*	*	*	*	151	V6
PAOZZ	5960-061-1215	ELECTRON TUBE V14 U/O ALL TRANSCEIVER MODELS..... 1635 (81349)	EA	REF	*	*	*	*	151	V14
PAOZZ	5960-262-0286	ELECTRON TUBE V16 U/O ALL TRANSCEIVER MODELS..... 5651WA (81349)	EA	1	*	*	*	*	151	V16
PAOZZ	5960-808-6490	ELECTRON TUBE V10 U/O TRANSCEIVERS TT-1E..... 1F/TXC-1 BOTH ORDER NOS 5879 (81349) BXL,BXM	EA	1	*	*	*	*	151	V10

SECTION III

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REFERENCE NUMBER & MFR CODE USABLE ON CODE		(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUSTRATION	
						(a)	(b)	(c)	(d)	(a)	(b)
						1-5	6-20	21-50	51-100	FIGURE NO.	ITEM NO.
PAOZZ	5815-498-8391	HALF NUT SET H9 C/O 2 HALF NUTS 0.278 IN DIA..... X 47/64 IN LG U/O ALL TRANSCEIVER MODELS SCB67409 (80063)		SE	1	*	*	*	*		H9
PAOZZ	5355-160-5910	KNOB NO-REF-DESIG W/POINTER 1.468 IN LG X..... 0.750 W X 0.656 IN THK U/O ALL TRANSCEIVER MODELS MS90120-2B01 (96906)		EA	1	*	*	*	*		
PAOZZ	5960-273-2460	RETAINER, ELECTRON TUBE 055 2-9/32 IN W X 1-..... 9/32 IN DIA U/O TRANSCEIVER TT-1F/TXC-1 BOTH ORDER NOS 7010 (97983)		EA	4	*	*	*	*		055
PAOZZ	5960-273-2460	RETAINER, ELECTRON TUBE 056 2-9/32 IN W X 1-..... 9/32 IN DIA U/O TRANSCEIVER TT-1F/TXC-1 BOTH ORDER NOS 7010 (97983)		EA	REF	*	*	*	*		056
PAOZZ	5960-273-2460	RETAINER, ELECTRON TUBE 057 2-9/32 IN W X 1-..... 9/32 IN DIA U/O TRANSCEIVER TT-1F/TXC-1 BOTH ORDER NOS 7310 (97983)		EA	REF	*	*	*	*		057
PAOZZ	5960-273-2460	RETAINER, ELECTRON TUBE 058 2-9/32 IN W X 1-..... 9/32 IN DIA U/O TRANSCEIVER TT-1F/TXC-1 BOTH ORDER NOS 7010 (97983)		EA	REF	*	*	*	*		058
XDOZZ		SHIELD, ELECTRON TUBE NO-REF-DESIG 1.750 IN LG..... X 0.953 IN DIA U/O TRANSCEIVERS TT-1B,1C,1D,1E, 1F/TXC-1 BOTH ORDER NOS. TS102U02 (81349)		EA	1	*	*	*	*		
PAOZZ	5815-508-78L9	STYLUS NEEDLE ASSEMBLY H11 STRAIGHT NEEDLE..... 0.125 IN LG 0.625 IN LG O/A U/O TRANSCEIVERS TT-L1,1A,1B,1C/TXC-1 SCB37031 (80063)		EA	1	*	*	*	*		H11
XDOZZ		STYLUS, RECORDING SOUND H11 68 DEG ANGLE 0.004..... IN RAD BRASS SHANK 3/41N LG X 0.062 IN DIA O/A 42-00-10-00 (97983)		EA	1	*	*	*	*		H11
PAOZZ	6140-406-0794	COVER, POWER SUPPLY A1 12-1/2 IN LG X 10-1/2..... IN W X 10 IN H U/O RECT PWR UNITS, ALL MODELS..... 96-15-22 (97983)		EA	1	*	*	*	*		A1
XDOZZ		ELECTRON TUBE V22 U/O RECT PWR UNITS, ALL..... MODELS 5Z3 (81349)		EA	1	*	*	*	*	153	V22
PAOZZ	5960-188-3557	ELECTRON TUBE V19 U/O RECT PWR UNITS, ALL..... MODELS 7C5 (81349)		EA	2	*	*	*	*	153	V19
PAOZZ	5960-188-3557	ELECTRON TUBE V20 U/O RECT PIR UNITS, ALL..... MODELS 7C5 (81349)		EA	REF	*	*	*	*	153	V20
PAOZZ	5960-100-6017	ELECTRON TUBE V21 U/O RECT PWR UNITS, ALL..... MODELS 7L7 (81350)		EA	1	*	*	*	*	153	V21
PAOZZ	5960-235-9108	ELECTRON TUBE V18 U/O RECT PWR UNITS, ALL..... MODELS 7N7 (81349)		EA	1	*	*	*	*	153	V18
XDOZZ		ELECTRON TUBE NO-REF-DESIG U/O RECT PWR UNITS,..... ALL MODELS 7S7 (81350)		EA	1	*	*	*	*	153	V17
PAOZZ	5960-262-0286	ELECTRON TUBE V23 U/O RECT PIR UNITS, ALL..... MODELS 5651WA (81349)		EA	1	*	*	*	*	153	V23
PAOZZ	5960-223-5970	RETAINER, ELECTRON TUBE 044 2-19/32 IN W X 2-..... 1/8 IN DIA U/O RECT PWR UNIT, ALL MODELS SMB166142 (80063)		EA	1	*	*	*	*		044
XDOZZ		SHIELD, ELECTRON TUBE NO-REF-DESIG U/O RECT..... PWR UNIT. ALL MODELS TS102U02 (81349)		EA	1	*	*	*	*		

SECTION V

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER**

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
3610-282-8858			5960-188-3557	151	V8
5340-392-8460		H44	5960-188-3557	153	V19
5340-392-8460		H45	5960-188-3557	153	V20
5355-160-5910			5960-188-3581	149	V10
5815-225-4997		52	5960-223-5970		44
5815-239-4734		I5	5960-235-9108	149	V13
5815-392-8387		MS1	5960-235-9108	150	V13
5815-392-9652		H43	5960-235-9108	153	V18
5815-498-8391		H9	5960-235-9108	168	V26
5815-508-7819		H11	5960-262-0286	151	V16
5960-061-1215	151	V5	5960-262-0286	153	V23
5960-061-1215	151	V6	5960-273-2460		55
5960-061-1215	151	V14	5960-273-2460		56
5960-100-6017	151	V11	5960-273-2460		57
5960-100-6017	151	V15	5960-273-2460		58
5960-100-6017	151	V9	5960-808-6490	151	V10
5960-100-6017	153	V21	5965-285-0744	5	LS1
5960-108-0257	151	V25	6130-406-0794		A1
5960-188-3557	151	V12	6810-630-0355		MS5
5960-188-3557	151	V4	7530-282-8860		
5960-188-3557	151	V7			

REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
LS11	80058	5	LS1	5879	81349	151	V10
MS90120-2B01	96906			7C5	81349	151	V4
SCB37031	80063		H11	7C5	81349	151	V7
SCB67409	80063		H9	7C5	81349	151	V8
SMB166142	80063		044	7C5	81349	151	V12
SMB201387	80063			7C5	81349	153	V19
SMB201668	80063		H43	7C5	81349	153	V20
TS102U02	81349			7C7	81349	149	V10
TYPEA	97983			7L7	81350	151	V9
TYPEND	97983			7L7	81350	151	V11
V3	80059		MS1	7L7	81350	151	V15
1B59R1130B	81349	138	E2	7L7	81350	153	V21
130-00-00-04	13179		MS5	7N7	81349	149	V13
1635	81349	151	V5	7N7	81349	150	V13
1635	81349	151	V6	7N7	81349	153	V18
1635	81349	151	V14	7N7	81349	168	V26
26-45-00-00	97983		I5	7S7	81350	153	V17
34-50-10-02	97983		H47	7010	97983		055
34-50-10-02	97983		H48	7010	97983		056
34-50-10-02	96983		H49	7010	97983		057
34-50-20-00	97983		052	7010	97983		058
42-00-10-00	79983		H11	884	81349	151	V25
5Z3	81349	153	V22	936C69	18915		H44
5651WA	81349	151	V16	936C69	18915		H45
5651WA	81349	153	V23	96-15-22	97983		A1

By Order of the Secretary of the Army:

FRED C. WEYAND
General, United States Army
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

Distribution:

Active Army:

USASA (2)	Ft Richardson (ECOM Ofc) (2)
Dir of Trans (1)	Army Dep (1) except
COE (1)	LBAD (14)
TSG (1)	SAAD (30)
USAARENBD (1)	TOAD (14)
AMC (1)	ATAD (10)
TRADOC (2)	USA Dep (2)
ARADCOAM (2)	Sig Sec USA Dep (2)
ARADCOM Rgn (2)	Sig Dep (2)
OS Maj Comd (4)	Sig FLDMS (1)
LOGCOMDS (3)	USAERDAA (1)
MICOM (2)	USAERDAW (1)
TECOM (2)	MAAG (1)
USACC (4)	USARMIS (1)
USACC-Eur (3)	Units org under fol TOE
USASATC&S (2)	(1 copy each unit)
APC (2)	7
USATC Inf (2)	11-35
USACRRL (2)	11-37
MADW (1)	11-95
Armies (2)	11-97
Corps (2)	11-98
HISA (Ft Monmouth) (43)	11-117
Svc Colleges (1)	11-127
USASESS (5)	11-137
USAADS (2)	11-147
USAFAS (2)	11-302
USAARMS (2)	11-327
USAIS (2)	11-345
USAES (2)	11-500(AA-AC)
USAINTCS (3)	17
WRAMC (1)	29-134
ATS (1)	29-136
Fort Gordon (10)	37
Fort Huachuca (10)	54-12
WSMR (1)	54-22
Fort Carson (5)	

NG: State AG (3)

USAR: None

For explanation of abbreviations used, see AR 310-50.

This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)