

TM 11-6625-1635-35

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DS, GS, AND DEPOT MAINTENANCE
MANUAL INCLUDING REPAIR PARTS
AND SPECIAL TOOLS LIST
MAINTENANCE KIT, ELECTRONIC
EQUIPMENT MK-1004/ARC

This copy is a reprint which includes current
pages from Change 1.

HEADQUARTERS, DEPARTMENT OF THE ARMY
AUGUST 1968

WARNING

DEATH OR SERIOUS INJURY may result from hazards in this equipment unless proper safety measures are observed when operating and maintaining the equipment. 27.5V DC exists when the equipment is energized.

PRINT ORDER 46

CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 7 December 1971

Direct Support, General Support, and Depot Maintenance Manual
Including Repair Parts and Special Tools lists
MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-1004/ARC

TM 11-6625-1635-35, 20 August 1968, is changed as follows:

1. This change reflects modifications incorporated by MWO 11-6625-1635-40/1.
2. New or changed material is indicated by a vertical bar.
3. Remove old pages and insert new pages as indicated in the page list below.

<i>Remove pages-</i>	<i>Insert pages—</i>
i.....i	i.....i
1-1 and 1-2	1-1 and 1-2
	2-1 and 2-2
	2-2.1
2-3 through 2-10	2-3 through 2-10
3-1 and 3-2	3-1 and 3-2
4-1 through 4-6	4-1 through 4-7
4-8 through 4-14	4-8 through 4-14
4-16 through 4-18	4-16 through 4-18
4-20 through 4-22	4-20 through 4-22
4-24 through 4-26	4-24 through 4-26
4-28 through 4-35	4-28 through 4-35
5-1 through 5-4	5-1 through 5-4
	5-13
A-1	A-1

4. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General.

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff.

Distribution:

To redistributed in accordance with DA Form 12-36, direct and general support maintenance requirements for the O-1A, O-1E, OV-1A, OV-1B, OV-1C, U-1A, U-6A, U-8D, CH-21C, CH-34A, CH-34C, CH-47A, UH-1B, UH-1D, UH-19C, UH-19D, AH-1G, and CH-54 aircraft.

TECHNICAL MANUAL

No. 11-6626-1635-35

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 20 August 1968

Direct Support, General Support, and Depot Maintenance Manual

Including Repair Parts and Special Tools Lists

MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-1004/ARC

Chapter 1.	CIRCUIT FUNCTIONING		
Section I.	General	Paragraph	Page
	Scope	1-1	1-1
	Indexes of equipment publications	1-2	
	Report of equipment manual improvements	1-3	1-1
	Purpose and use	1-4	1-1
	Differences in models	1-5	1-1
	Basic two-out-of-five frequency selection system	1-6	1-1
CHAPTER 2.	TROUBLESHOOTING		
	General instructions	2-1	2-1
	Test equipment required	2-2	2-1
	Organization of troubleshooting procedure	2-3	2-1
3.	REPAIRS AND ALIGNMENT		
	General parts replacement techniques	3-1	3-1
	Disassembly of radio set control C-724/ARC	3-2	3-1
	Assembly of radio control	3-3	3-6
	Cleaning	3-4	3-15
4.	GENERAL SUPPORT TESTING PROCEDURES		
	General	4-1	4-1
	Test equipment required	4-2	4-1
	Modification work orders	4-3	4-2
	Physical tests and inspections	4-4	4-2
	Receiver circuit test No. 1	4-5	4-5
	Receiver circuit test No. 2	4-6	4-9
	Transmitter output and control circuit test	4-7	4-13
	Sidetone circuit check	4-8	4-17
	Modulation check, MIKE INPUT circuit	4-9	4-21
	Modulation check, Ø DBM INPUT circuit	4-10	4-25
	Modulation check, DATA LINK INPUT circuit	4-11	4-29
	Detector circuit check	4-12	4-33
	Test data summary	4-13	4-35
5.	DEPOT OVERHAUL STANDARDS		
	Applicability of depot overhaul standards	5-1	5-1
	Applicable references	5-2	5-1
	Test facilities required	5-3	5-1
	General test requirements	5-4	5-1
	Receiver control circuit check at 132.50 MHz	5-5	5-2
	Receiver audio output checks	5-6	5-2
	Squelch control circuit checks	5-7	5-2
	Channel selection checks	5-8	5-2
	Transmitter output and control circuit check	5-9	5-3
	Sidetone check	5-10	5-3
	Modulation checks	5-11	5-3
	Detector circuit checks	5-12	5-3
Appendix A.	REFERENCES	A-1	A-1
B.	DS, GS, AND DEPOT MAINTENANCE REPAIR PARTS	B-1	B-1

CHAPTER 1

CIRCUIT FUNCTIONING

Section I. GENERAL

1-1. Scope

a. This manual describes Maintenance Kit, Electronic Equipment MK-1004/ARC and provides instruction for direct support (DS), general support (GS), and depot maintenance. It includes instructions appropriate to DS, GS, and depot support for troubleshooting, replacement of parts, testing, aligning and repairing the maintenance kit. Depot overhaul standards (DOS) are included in this manual.

b. Appendix B is current as of 10 May 1968.

NOTE

For applicable forms and records, refer to TM 11-6626-1635-12.

1-2. Indexes of Equipment Publications

a. Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

b. Refer to the latest issue of DA Pam 310-7 to determine whether there are modification work orders (MWO'S) pertaining to the equipment.

1-3. Report of Equipment Manual Improvements

The reporting of errors, omissions, and recommendations for improving this equipment publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commanding General, US Army Electronics Command, ATTN: AMSEL-ME-NMP-AD, Fort Monmouth, N.J. 07703.

1-4. Purpose and Use

a. Maintenance Kit, Electronic Equipment MK-1004/ARC (maintenance kit) is a portable equipment used in field testing and adjusting Radio Set AN/ARC-134.

b. The unmodified maintenance kit includes Panel, Test, Electrical SB-3003 (P) /ARC (test panel) mounted on the front of the equipment. The test panel houses Control, Radio Set C-7241/ARC (radio control), various input and output jacks, switches, indicators, and controls that are used to check, and adjust for, the proper operation of the AN/ARC-134.

c. The modified maintenance kit includes a test panel which mounts Control, Radio Set C-7241/ARC (radio control), Control, Intercommunication Set C-1611D/AIC (intercom control), an ammeter, and various input and output jacks, switches, indicators, and controls used to check, and adjust for, the proper operation of the AN/ARC-134.

d. The radio control is used to provide power control, receiver volume control, and channel selection for the AN/ARC-134 under test. A COMM TEST switch on the radio control provides a means of checking the operation of the AN/ARC-134 with the receiver squelch circuit disabled.

1-5. Differences in Models

Specific differences in the unmodified and modified maintenance kits, as a result of MWO 11-6625-163540/1, are given in table 1-1. MWO 11-6625-1635-40/1 is a field modification that improves utilization of the maintenance kit in testing the complete VHF communications network of which the AN/ARC-134 Radio Set is a part.

Table 1-1. Differences in Models

Item	MK-1004/ARC unmodified	MK-1004/ARC modified
Control, Radio Set -----	C-7241/ARC	C-7241/ARC
Intercommunications Control Set	None	C-1611D/AIC
DC Ammeter	None	0-10 Amps. Used to monitor input current to the radio set under test.
Reverse Current Diode	None	1N3890. Prevents damage to the Radio Set due to reverse polarity hookup.
Headset-Microphone	M-52A/U Microphone and H-216U Headset required as additional equipment.	Cord Assembly CX-2556 and Headset-Microphone H-101A/U included, as integral part of maintenance kit.
AC power supply	5-volt power source STANCOR. type P6467 or equal required.	None.

1-6 Basic Two-Out-Of-Five Frequency-Selection System


a. The two-out-of-five (2x5) frequency-selection system requires five control wires for each controlled digit comprising a channel frequency. Frequencies are selected by simultaneously grounding two wires out of each 5-wire group. A, figure 1-1, shows a simplified system for controlling an equipment having only 10 channels. Since each channel may be represented by a single digit, only one group of five control wires is required.

b. For example, when the radio control is set to position 2 (A, fig. 1-1), control wires A and C are grounded. The tuning motor then drives the switch and the frequency-selecting circuits in the controlled equipment to a point where the ground is removed from wires A and C and the operating voltage is removed from the motor. By setting the radio control to the other positions, related two-wire combinations are grounded in accordance with the standard 2 x 5 frequency-selector code shown on figure 1-1.

c. B, figure 1-1, shows a system for controlling an equipment having 100 channels. Since two controlled digits comprise any one frequency channel, two switches are required in both the radio control and the controlled equipment. Two groups of five control wires interconnect the switches. To simplify the ex-

planation, the 100 channels have been assigned frequencies from 100 to 199 megahertz (MHz), with 1-MHz spacing between channels. Switch S1 is the 1-MHz selector and switch S2 is the 10-MHz selector. The radio control is shown set to 112 MHz: Of the 5-wire group interconnecting switch S1 in the radio control and switch S1 in the controlled equipment, wires A and C are grounded, representing the digit 2 (2 MHz). Wires A and B, representing the digit 1 (1 MHz), are grounded in the 5-wire group interconnecting switch S2 in the radio control and switch S2 in the controlled equipment. The tuning motor is driven until the ground is removed from wires A and C of S1 and A and B of S2. The gearing between the tuning motor and the switches in the controlled equipment is such that switch S1 (the 1-MHz switch) makes 10 revolutions for each complete revolution of switch S2. This provides 100 different points (channels) at which the tuning motor may be stopped.

d. Solid-state, frequency-selection circuitry that uses the 2 x 5 selection system can be used in the controlled equipment, either in place of, or in combination with, the motor-driven arrangement shown in figure 1-1. In any case, a group of five wires is required for each controlled digit, with selection being accomplished by grounding two of the five wires.



TM6625-1635-35-35

TM 6625-1635-35-35

Figure 1-1. Basic two-out-of-five frequency-selection system.

CHAPTER 2

TROUBLESHOOTING

2-1. General Instructions

Troubleshooting at GS and depot maintenance categories includes all the techniques outlined for organizational maintenance and any special or additional techniques required to isolate a defective part. The systematic troubleshooting procedure, which begins at organizational, must be completed by means of localizing and isolating techniques. The paragraphs which follow provide intraunit (within the unit) troubleshooting procedures and describe the localizing and isolating techniques that must be performed at general support.

2-2. Test Equipment Required

The only test equipment required is Multimeter TS-352B/U (TM 11-6626-366-15).

2-3. Organization of Troubleshooting Procedure

a. General. The first step in servicing a defective test set is to localize the fault. Locali-

zation means tracing the fault to a defective circuit responsible for the abnormal condition. Some faults, such as burned or loose wires, can often be located by sight. The majority of faults, however, must be localized by resistance measurements.

b. Localization. The tests listed below will aid in isolating the trouble. First, localize the trouble to a single circuit and then isolate the trouble within that circuit by resistance and continuity measurements.

(1) *Visual inspection.* The purpose of visual inspection is to locate faults without testing or measuring circuits. All panel lamp indications or other visual signs should be observed and an attempt made to localize the fault to a particular circuit.

(2) *Operational tests.* Operational tests frequently indicate the general location of trouble. In many cases, the tests will help in determining the exact nature of the fault.




Figure 2-1. Test panel (unmodified), rear view.




Figure 2-1.1 Test panel (modified), rear view.




Figure 2-2. Radio control C-7241/ARC, front view.




Figure 2-3. Radio control C-7241/ARC, top view.

(3) *Troubleshooting.* The trouble symptoms listed in *c* below will aid in localizing the trouble to a part or circuit. For physical location of parts, refer to figures 2-1, 2-1.1, 2-2, and 2-3.

(4) *Resistance and continuity measurements.* Make the resistance and continuity measurements listed in *d* below. Where results other than those indicated are obtained, isolate the faulty part by further resistance measurements,

- (a) Disconnect all cables from the maintenance kit.
- (b) Remove the front and back covers from the maintenance kit.

(c) Set the switches or controls to the position indicated in the *Point of measurement* column (*d* below).

(d) Refer to the schematic diagrams (fig. 2-4; 5-5, page 5-12; and 2-5) and connect the TS-352B/U as indicated in the *Point of measurement* column (*d* below).

(5) *Intermittent troubles.* In all tests, the possibility of intermittent troubles should not be overlooked. If present, this type of trouble often may be made to appear by tapping or jarring the equipment. Check the cables, wiring, and connections of the equipment.





Figure 2-4. Test panel (unmodified), schematic diagram.

Change 1 **2-5** ■



TM 6625-1635-35-48

Figure 2-5. Control, radio set C-7241/ARC, COMM portion, schematic diagram.

c. Troubleshooting Chart.

Symptom	Probable trouble	Correction
1. Radio control panel lamps do not light (unmodified equipment).	POWER switch S5 is at OFF Test panel fuse F3 open Radio control lamps DS5, DS6, and DS7 defective. Test panel switch S5 defective	Set POWER switch to ON. Replace F3. Replace lamps. Replace switch S5.
2. POWER lamp on test panel and panel lamps on radio control and intercom control do not light (modified equipment).	POWER switch S5 at OFF Test panel fuse F1 open Test panel switch S5 defective Radio control lamps DS5, DS6, and DS7 defective.	Set POWER switch to ON. Replace F1. Replace S5. Replace lamps.
3. Panel lamps on radio control and intercom control do not light (modified equipment).	Diode CR2 defective Meter M1 defective	Replace CR2. Replace M1.
4. Test panel lamp DS1 does not light (unmodified equipment).	Test panel lamp DS1 defective	Replace lamp DS1.
5. Test panel lamp DS2 does not light.	Test panel lamp DS2 defective Test panel fuse F1 open Test panel switch S5 defective	Replace lamp DS2. Replace F1. Replace switch S5.
6. VHF COMM frequency indicator not illuminated.	VHF COMM OFF-PWR switch is at OFF. Radio control lamps DS1 and DS2 defective. Radio control switch S6 defective . .	Set VHF COMM OFF-PWR switch to PWR. Replace lamps. Replace switch S6.
7. No output at RECEIVER OUTPUT jacks with proper 132.500-MHz signal to AN/ARC-134.	Open or shorted wiring from connector P3B-35 and P3B-36 to test panel jacks J8 and J9. VHF COMM frequency not set to 132.500 MHz. Contacts of radio control switches S1 and S2 dirty or broken.	Check and correct wiring. Set VHF COMM frequency-selector switch to 132.500 MHz. Clean contacts or replace switch S1 and S2 wafers.
8. No output at DATA LINK OUTPUT jacks with proper 132,500 MHz signal to AN/ARC-134.	Open or shorted wiring from connector P3A-15 and P3A-16 to test panel jacks J16 and J17.	Check and correct wiring.
9. No output at RECEIVER jack with proper signal to AN/ARC-134.	AUDIO switch is at OFF EXT SQUELCH CONT switch at ON. Radio control potentiometer R1 open. Open or shorted wiring from connector P1-b and P1-d to test panel jack J4.	Set AUDIO switch to ON. Set EXT SQUELCH CONT switch to OFF, or readjust EXT SQUELCH CONT. Replace R1. Check and correct wiring.
10. No output at RECEIVER jack when COMM TEST switch is depressed.	EXT SQUELCH CONT misadjusted. Radio control switch S5 defective -- Open or shorted wiring from Pi-g and Pi-h to P3B-30 and P3B-31.	Readjust EXT SQUELCH CONT. Replace switch S5. Check and correct wiring.

Symptom	Probable trouble	Correction
11. EXT SQUELCH CONT has no effect on level at which squelch breaks.	EXT SQUELCH CONT switch at OFF. Test panel potentiometer R1 defective. Open or shorted wiring between R1 and P3B-37, P3B-38, and P3B-39 on test panel.	Set EXT SQUELCH CONT switch to ON. Replace R1. Check and correct wiring.
12. No output from AN/ARC-134 at antenna connector J1.	PTT switch is at OFF . Open or shorted wire between switch S1 and P3A-31 on test panel.	Set PTT switch to ON. Check and correct wiring.
13. No output at SIDETONE jack.	Open or shorted wiring between J22 and P3A-31 and P3A-30 on test panel (unmodified equipment). Open or shorted wiring between J5 and P3B-28 and P3B-29 on test panel. Open or shorted wiring between P3A-31 and P4-26 or P3A-30 and P4-35 (modified equipment). Intercom control defective UG-94A/U defective (modified equipment).	Check and correct wiring. Check and correct wiring. Check and correct wiring. Repair or replace intercom control. Repair or replace UG-94A/U.
14. No evidence of modulation with Generator, Signal AN/URM-127 supplying signal to MIKE INPUT jacks.	Open or shorted wire between J18 and P3A-30 on test panel, or between J19 and ground on test panel.	Check and correct wiring.
15. No output at DETECTOR METER jacks with antenna connector J1 connected to DETECTOR INPUT jack.	Defective detector circuit. . . .	Repair or replace detector circuit.

d. Resistance and Continuity Tests.

Point of measurement	Normal indication	Isolating procedure
Between tip contact of test panel jack J22 and P3A-31.	Short circuit	Check wiring from J22 to P3A-31.
Between ring contact of test panel jack J22 and P3A-30.	Short circuit-----	Check wiring from J22 to P3A-30.
With PTT switch at ON, between sleeve contact of test panel jack J22 and P3A-31.	Short circuit	Check test panel switch S1 and wiring from J22 sleeve contact to P3A-31.
Between test panel jack J18 and P3A-30	Short circuit	Check wiring between J18 and P3A-30.
Between test panel jack J19 and ground	Short circuit	Check wiring between J19 and ground.
Between test panel jack J17 and P3A-16	Short circuit. . . .	Check wiring between J17 and P3A-16.
Between test panel jack J16 and P3A-15	Short circuit	Check wiring between J16 and P3A-15.
Between test panel jack J15 and P3A-23	Short circuit	Check wiring between J15 and P3A-33.
Between test panel jack J14 and P3A-22	0 ohm	Check wiring between J14 and P3A-22.

Point of measurement	Normal Indication	Isolating procedure
Between test panel jack J13 and P3A-21	0 ohm -----	Check wiring between J13 and P3A-21.
Between test panel jack J12 and P3A-28	0 ohm -----	Check wiring between J12 and P3A-28.
Between test panel jack J11 and P3A-27	0 ohm -----	Check wiring between J11 and P3A-27.
Between test panel jack J10 and P3A-26	0 ohm -----	Check wiring between J10 and P3A-26.
Between test panel terminal board TB1-3 and P3A-5 and P3A-6.	0 ohm -----	Check fuse F2 and wiring between TB1-3 and P3A-5 and P3A-6.
Between alligator clip ground and P3A-1 and P3A-2.	0 ohm -----	Check wiring between alligator clip ground and P3A-1 and P3A-2.
With POWER switch at ON, between alligator clip 27.5 Vdc (unmodified) or 28.7 Vdc (modified) and P3A-3 and P3A-4.	0 ohm -----	Check fuse F1, diode CR2, meter M1, and wiring between alligator clip and P3A-3 and P3A-4.
With POWER switch at ON, between alligator clip 5 Vac and P2-n (unmodified equipment).	Approximately 30 ohms ---	Check fuse F3, test panel lamp DS1, and wiring between alligator clip 5 Vac and P2-n.
With POWER switch at ON, between alligator clip 5 Vac and ground (unmodified equipment).	Approximately 90 ohms ---	Check radio control lamps DS5, DS6, and DS7.
With VHF COMM OFF-PWR switch at PWR, POWER switch at ON, between alligator clip 5 Vac and ground (unmodified equipment).	Approximately 36 ohms ---	Check radio control lamps DS1, DS2, and switch S6.
With VHF COMM OFF-PWR switch at PWR, between P3A-9 and ground.	0 ohm -----	Check radio control switch S6 and wiring between S6 and P3A-9.
Between test panel jack J5 sleeve contact and P3B-29.	0 ohm -----	Check wiring between J5 and P3B-29.
Between test panel jack J5 tip contact and P3B-28.	0 ohm -----	Check wiring between J5 and P3B-28.
Between test panel jack J6 and P3B-28	0 ohm -----	Check wiring between J6 and P3B-28.
Between test panel jack J7 and P3B-29	0 ohm -----	Check wiring between J7 and P3B-29.
Between test panel jack J8 and P3B-35	0 ohm -----	Check wiring between J8 and P3B-35.
Between test panel jack J9 and P3B-36	0 ohm -----	Check wiring between J9 and P3B-36.
With AUDIO switch at ON, between P3B-35 and P3B-36.	Approximately 500 ohms ---	Check test panel switch S3, radio control potentiometer R1, and wiring between P3B-35 and P3B-36, and radio control.
With VOL control fully clockwise, between test panel jack J4 tip and sleeve contacts (unmodified equipment).	Approximately 500 ohms ---	Check radio control potentiometer R1 and wiring between test panel jack J4 and R1.
With radio control VOL control fully clockwise, intercom control VOL control fully clockwise between test panel jack J4 tip and sleeve contacts (modified equipment).	Approximately 250 ohms ---	Check radio control potentiometer R1, intercom control, and wiring to jack J4.

Point of measurement	Normal indication	Isolating procedure
Between P3B-37 and P3B-39 -----	Approximately 10,000 ohms	Check test panel potentiometer R1 and wiring between R1 and P3B-37 and P3B-39.
With EXT SQUELCH CONT switch at ON and EXT SQUELCH CONT fully clockwise, between P3B-38 and P3B-39.	Approximately 10,000 ohms	Check test panel switch S2, potentiometer R1, and wiring between R1 and P3B-38.
With SQUELCH DISABLE switch at OFF, between P3B-30 and P3B-31.	Infinite resistance	Check test panel switch S4 and wiring between P3B-30 and P3B-31. Check radio control switch S3.
With SQUELCH DISABLE switch at ON, between P3B-30 and P3B-31.	0 ohm -----	Check test panel switch S4 and wiring between P3B-30 and P3B-31.
With SQUELCH DISABLE switch at OFF, press COMM TEST switch and measure between P3B-30 and P3B-31.	0 ohm -----	Check radio control switch S3 and wiring between P3B-30 and P3B-31.
With U-94A/U transmit switch depressed, between P4-17 and ground (modified equipment).	0 ohm	Check test panel relay K1, wiring between P4-17 and K1, and wiring between U-94A/U and K1.
With U-94A/U transmit switch depressed, between P4-15 and ground (modified equipment).	0 ohm	Check test panel relay K1, and wiring between P4-16 and K1.
With VHF COMM frequency-selector switches set to 116.000, measure from P3B-27 to following points:		
P3B-24	0 ohm	Check radio control switch S1A (front).
P3B-23 -----	0 ohm	Check radio control switch S1A (rear).
P3B-19 ... -----	0 ohm -----	Check radio control switch S1A (rear).
P3B-17	0 ohm	Check radio control switch S1B (front).
P3B-13	0 ohm -----	Check radio control switch S1B (rear).
P3B-9	0 ohm -----	Check radio control switch S2A (front).

Point of measurement	Normal indication	Isolating procedure
P3B-11	0 ohm	Check radio control switch S2A (rear).
P3B-1	0 ohm	Check radio control switch S2B (front).
P3B-2	0 ohm	Check radio control switch S2B (rear).
With VHF COMM frequency-selector switches set to 127.125, measure from P3B-27 to following points:		
P3B-26	0 ohm	Check radio control switch S1A (front).
P3B-18	0 ohm	Check radio control switch S1A (rear).
P3B-21	0 ohm	Check radio control switch S1A (rear).
P3B-12	0 ohm	Check radio control switch S1B (front).
P3B-10	0 ohm	Check radio control switch S2A (front).
P3B-3	0 ohm	Check radio control switch S2B (rear).
With VHF COMM frequency-selector switches set to 138.250, measure from P3B-27 to following points:		
P3B-21	0 ohm	Check radio control switch S1A (rear).
P3B-22 ..	0 ohm	Check radio control switch S1A (rear).
P3B-15	0 ohm	Check radio control switch S1B (rear).
P3B-6	0 ohm	Check radio control switch S2A (rear).
P3B-2	0 ohm	Check radio control switch S2B (front).
With VHF COMM frequency-selector switches set to 149.375, measure from P3B-27 to following points:		
P3B-22	0 ohm	Check radio control switch S1A (rear).
P3B-23	0 ohm	Check radio control switch S1A (rear).
P3B-13	0 ohm	Check radio control switch S1B (front).
P3B-11	0 ohm	Check radio control switch S2A (front).
P3B-4	0 ohm	Check radio control switch S2B (rear).

Point of measurement	Normal indication	Isolating procedure
With VHF COMM frequency-selector switches set to 140.000, measure from P3B-27 to following points: P3B-17 P3B-7	0 ohm 0 ohm	Check radio control switch S1B (rear). Check radio control switch S2A (rear).
With VHF COMM frequency-selector switches set to 141.500, measure from P3B-27 to following points: P3B-15 P3B-6	0 ohm 0 ohm	Check radio control switch S2B (front). Check radio control switch S2A (front).
With VHF COMM frequency-selector switches set to 142.600, measure from P3B-27 to following points: P3B-17 P3B-9.	0 ohm 0 ohm	Check radio control switch S1B (rear). Check radio control switch S2A (rear).
With VHF COMM frequency-selector switches set to 143.700, measure from P3B-27 to following points: P3B-16 P3B-7	0 ohm 0 ohm .	Check radio control switch S1B (front). Check radio control switch S2A (front).
With VHF COMM frequency-selector switches set to 144.800, measure from P3B-27 to following points: P3B-12 P3B-10	0 ohm 0 ohm	Check radio control switch S1B (rear). Check radio control switch S2A (rear).

CHAPTER 3

REPAIRS AND ALIGNMENT

3-1. General Parts Replacement Techniques

Except for the radio control, the parts of the maintenance kit can be easily reached and replaced without special procedures. Disassembly and reassembly of Radio Set Control C-7241/ARC are covered in paragraphs 3-2 and 3-3; and Intercommunications Control Set C-1611 D/AIC is covered in TM 11-5831-201-20. Several parts replacement techniques are presented in *a*, *b*, and *c* below.

a. Before a part is removed, note the position of the part and tag or otherwise identify all wiring that is to be disconnected. Make a note of color coding, placement of wires, and method of insulation before unsoldering wire.

b. Use a pencil-type soldering iron with a 25-watt maximum capacity. If the iron must be used with an alternating current (at) source, use an isolating transformer between the iron and the line.

c. When soldering leads to diodes, solder quickly and use a heat sink (such as long-nose pliers) between the soldered joint and the diode.

3-2. Disassembly of Radio Set Control

C-7241/ARC

(fig. 54)

a. Front Panel Lamps.

(1) Remove three lamp receptacle caps (1), fiber washers (2), and rubber rings (3) from front panel (5).

(2) Extract panel lamps (4) from the body of each receptacle cap (1).

b. Protective Covers.

(1) Remove two screws (6) from each side of the radio control and lift top cover (7) from the unit.

(2) Remove four screws (8) from the bottom of the radio control and lift bottom cover (9) from the unit.

c. Frequency Dial Indicator Lamps.

(1) Remove rubber cover (10) from each of the VHF COMM indicator lamps (13).

(2) Loosen screw (11) at the base of each lamp (13) and position retaining tab (12) off the base of each lamp.

(3) Pull indicator lamps (13) out through holes in rear gear plate (14).

(4) Remove rubber cover from each of the VHF NAV indicator lamps (18).

(5) Loosen screw (16) at the base of each VHF NAV indicator lamp (18) and position retaining tab (17) of the base of each lamp.

(6) Pull VHF NAV indicator lamps (18) out through the holes in rear gear plate (19).

d. Front Panel.

(1) Rotate the front panel, VHF COMM frequency-selector knobs to 116.000 and the VHF NAV frequency-selector knobs to 108.00.

(2) Set the VHF NAV and VHF COMM OFF-PWR switches to OFF and turn the VHF COMM VOL control fully counterclockwise.

(3) Loosen two setscrews in each of four knobs (20); remove knobs.

(4) Loosen two setscrews in knob (22) and in each of three knobs (21); remove knobs.

(5) Remove three receptacle caps (1), if not already removed in *a*, above, and remove front panel (5).

e. Switch S6 and VOL Control R1.

(1) If only switch S6 and VOL control R1 are being replaced, remove front panel (5) (*d* above).

(2) Remove mounting plate (23), with switch S6 (29) and VOL control R1 (33) attached, by removing two screws (24) and stand-off spacers (25) from front gear plate (34).

(3) Remove switch S6 (29) from mounting plate (23) as follows:

(a) Loosen the two setscrews in spur gear (26) and remove the spur gear from the shaft of the switch.

(b) Remove nut (27) and washer (28) from the switch bushing and pull the switch out through the mounting hole in the mounting plate.

(c) Tag and unsolder wires attached to the terminals on the switch.

(4) Remove VOL control R1 (33) as follows :

(a) Loosen the two setscrews in spur gear (30) and remove the gear from the shaft of the control.

(b) Remove nut (31) and washer (32) from the control and pull the control out through the mounting hole in the plate.

(c) Tag and unsolder wires attached to the terminals on the control.

f. Switch S7.

(1) If only switch S7 is being replaced, remove front panel (5) (d above).

(2) Remove mounting plate (35), with switch S7 (41) attached, by removing two screws (36) and standoff spacers (37) from front gear plate (34).

(3) Loosen two setscrews in spur gear (38) and slide the spur gear from the shaft of the switch.

(4) Remove nut (39) and washer (40) from the switch and pull the switch out through the mounting hole in the plate.

(5) Tag and unsolder wires connected to the terminals on the switch.

g. Switch S5

(1) If only switch S5 is being replaced, remove front panel (5) (d above).

(2) Remove nut (42) from the bushing of switch S5 (44) and pull the switch out through the mounting hole in front of the gear plate.

(3) Tag and unsolder wires connected to the terminals on the switch.

h. Connector's J1 and J2.

(1) Remove four screws (45) and lockwashers (46) and pull rear plate (47) from the chassis. Remove lacing from wiring but do not unsolder wires connected to receptacles J1 (52) and J2 (53).

(2) Remove bracket (54) from rear plate (47) by removing two screws (48), self-locking nuts (49), two screws (50), and self-locking nuts (51).

(3) Remove rear plate (47) from connectors J1 (52) and J2 (53) by removing remaining two screws (48), self-locking nuts (49),

two screws (50), and self-locking nuts (51).

(4) Tag and unsolder wires connected to J1 and J2.

i. Switch Sections S1A, S1B, S2A, and S2B.
If the radio control is to be completely disassembled, begin with (3) below. If only the switch sections are to be removed, begin with (1) below.

(1) Make sure that the front panel VHF COMM frequency-selector knobs have been set to 116.000. Remove four screws (45) and lockwashers (46) from rear plate (47).

(2) Pull rear plate (47), with connectors J1 (52) and J2 (53) attached, away from the radio control.

(3) Remove nuts (55) and lockwashers (56) from screws (78 and 79) and lift plate (57) from frequency-selector shaft (77) and screws (78 and 79).

(4) Slide washers (58) and (59) from frequency-selector shaft (77) and spacer insulators (60) from screws (78 and 79).

(5) Tag and unsolder wires connected to switch sections S2B (61). Lift switch section (61) from the hubs of gear assembly (64) and screws (78 and 79).

(6) Remove spacer insulators (62) from screws (78 and 79).

(7) Tag and unsolder wires connected to switch section S2A (63). Lift switch section (63) from the hub of gear assembly (64) and screws (78 and 79).

(8) Slide gear assembly (64) and washers (67 and 68) from frequency-selector shaft (77) and remove spacer insulators (65 and 66) from screws (78 and 79).

(9) Loosen the two setscrews in gear assembly (138) and slide the gear assembly from gear shaft (139).

(10) Tag and unsolder the wires attached to switch section S1B (69). Lift switch section (69) from the hub of gear assembly (72) and screws (78 and 79).

(11) Remove spacer insulators (70) from screws (78 and 79).

(12) Tag and unsolder wires connected to switch section S1A (71). Lift switch section (71) from the hub of gear assembly (72) and screws (78 and 79).

(13) Slide gear assembly (72) from frequency-selector shaft (77) and remove spacer insulators (73) from screws (78 and 79).

(14) Remove frequency-selector shaft (77) from rear gear plate (14) and remove retaining ring (75) and washer (76) from frequency-selector shaft (77).

j. Switch Sections S3A, S4A, and S4B. If the radio control is to be completely disassembled, begin with (3) below. If only switch sections are to be removed, start with (1) below.

(1) Make sure that the front panel VHF NAV frequency-selector knobs are set to 108.00. Remove four screws (45) and lockwashers (46) from rear plate (47).

(2) Pull rear plate (47), with connectors J1 (52) and J2 (53) attached, away from the radio control.

(3) Remove nuts (80) and lockwashers (81) from screws (98 and 99) and lift plate (82) from frequency-selector shaft (97) and screws (98 and 99).

(4) Slide washers (83) from frequency-selector shaft (97) and spacer insulators (84) from screws (98 and 99).

(5) Tag and unsolder wires connected to switch section S4B (85). Lift switch section (85) from the hub of gear assembly (92) and screws (98 and 99).

(6) Remove spacer insulators (86 and 87) from screws (98 and 99).

(7) Tag and unsolder wires connected to switch section S4A (88). Lift switch section (88) from the hub of gear assembly (92) and screws (98 and 99).

(8) Remove spacer insulators (89 and 90) from screws (98 and 99).

(9) Tag and unsolder wires connected to switch section S3A (91). Lift switch section (91) from the hub of gear assembly (92) and screws (98 and 99).

(10) Slide gear assembly (92) from frequency-selector shaft (97) and remove spacer insulators (93) from screws (98 and 99).

(11) Remove frequency-selector shaft (97) from rear gear plate (19) and then remove retaining ring (95) and washer (96) from frequency-selector shaft (97).

k. Panel Light Receptacles and Front Gear Plate. If the radio control is being completely disassembled, begin with (4) below. If only the panel light receptacles are to be removed, begin with (1) below.

(1) Remove front panel (5) as instructed in *d* above.

(2) Remove nut (42) from switch S5 (44).

(3) Remove two screws (24) and two screws (36) from front gear plate (34).

(4) Remove screws (100 through 103) that secure support members (104 through 107) to front gear plate (34).

(5) Remove screws (107A, 109, 111, and 113 and washers 108, 110, 112, and 114) from front gear plate (34).

(6) Pull front gear plate (34) away from chassis until solder terminals on lamp receptacles (115, 116, and 117) are accessible.

(7) Tag and unsolder *wires* connected to each lamp receptacle. Remove front gear plate (34) from radio control.

(8) Remove nuts (118) and washers (119) from lamp receptacles (115 and 116) and nut (120) from lamp receptacle (117). Pull the lamp receptacles out through the holes in front gear plate (34).

1. VHF COMM Detent Wheels. If the radio control is being completely disassembled, begin with (4) below. If only the detent wheels are being removed, begin with (1) below.

(1) Remove front panel (5) *d* above.

(2) Remove nut (42) from switch S5 (44).

(3) Remove front gear plate (34) as instructed in *k* (3) through (7) above.

(4) Slide spur gear (121) and insulator (122) from gear shaft (129), and spur gear (130) and insulator (131) from gear shaft (139).

(5) Loosen two setscrews in helical gears (123 and 132) and slide the gears from shafts (129 and 139).

(6) Detach helical extension spring (145) from detent arm (150) and loosen the two setscrews in detent wheel (124).

(7) Slide detent wheel (124) and flat washer (125) from gear shaft (129).

(8) Loosen two setscrews in gear assembly (128) and pull gear shaft (129) from the front of the radio control until gear assembly (128) and flat washers (126 and 127) are free from gear shaft (129).

(9) Pull gearshaft (129) from rear gear plate (14).

(10) Loosen the two setscrews in detent wheel (133) and slide the detent wheel and washer (134) from gear shaft (139).

(11) Loosen the setscrews in cam (137).

Note. Step (12) is unnecessary if the radio control is being completely disassembled.

(12) Loosen two setscrews in gear assembly (138) and pull gear shaft (139) from the front of the radio control until the gear assembly is free from gear shaft (139).

(13) Slide cam (137), stop washers (136); and washers (135) from gear shaft (139).

(14) Pull gear shaft (139) from rear gear plate (14).

(15) Remove screw (146), washers (147 and 148), and sleeve spacer (149) to remove detent arm (150) from rear gear plate (14).

(16) Remove screw (140), washers (141 and 142), and sleeve spacer (143) to remove detent arm (144) from rear gear plate (14). Detach helical extension spring (145) from detent arm (144).

m. Switch Sections S1A, S1B, S2A, and S2B. If the radio control is to be completely disassembled, begin with (3) below. If only the switch sections are to be removed, begin with (1) below.

(1) Make sure that the front panel VHF COMM frequency-selector knobs have been set to 116.000. Remove four screws (45) and lockwashers (46) from rear plate (47).

(2) Pull rear plate (47) away from the radio control.

(3) Remove nuts (55) and lockwashers (56) from screws (78 and 79) and lift plate (57) from frequency-selector shaft (77), gear shaft (139), and screws (78 and 79).

(4) Slide washers (58 and 59) from frequency-selector shaft (77) and spacer insulators (60) from screws (78 and 79).

(5) Tag and unsolder wires connected to

switch section S2B (61). Lift switch section (61) from the hub of gear assembly (64) and screws (78 and 79).

(6) Remove spacer insulators (62) from screws (78 and 79).

(7) Tag and unsolder the wires connected to switch section S2A (63). Lift switch section (63) from the hub of gear assembly (64).

(8) Slide gear assembly (64) and washers (67) from screws (78 and 79).

(9) Loosen the two setscrews in gear assembly (138) and slide the gear assembly from gear shaft (139).

(10) Tag and unsolder the wires connected to switch section S1B (69). Lift switch section (69) from the hub of gear assembly (72).

(11) Remove spacer insulators (70) from screws (78 and 79).

(12) Tag and unsolder the wires connected to switch sections S1A (71). Lift switch section (71) from the hub of gear assembly (72) and screws (78 and 79).

(13) Slide gear assembly (72) from frequency-selector shaft (77) and remove spacer insulators (73) from screws (78 and 79).

(14) Remove frequency-selector shaft (77) from rear gear plate (14) and then remove retaining ring (75) and washer (76) from shaft (77).

n. VHF NAV Detent Wheels. If the radio control is being completely disassembled, begin with (4) below. If only the detent wheels are being removed, begin with (1) below.

(1) Remove front panel (5) as instructed in *d* above.

(2) Remove nut (42) from switch S5 (44).

(3) Remove front gear plate (34) as instructed in *k* (3) through (7) above.

(4) Slide spur gear (151) and insulator (152) from gear shaft (158).

(5) Loosen two setscrews in helical gears (153 and 159) and slide the gears from gear shafts (158 and 165).

(6) Detach helical extension spring (171) from detent arm (170) and loosen the two setscrews in detent wheel (154).

(7) Slide detent wheel (154) and washer (155) from gear shaft (158).

(8) Loosen the two setscrews in the hub of gear assembly (157) and slide the gear assembly and washer (156) from gear shaft (158).

(9) Pull gear shaft (158) out through the mounting hole in rear gear plate (19).

(10) Loosen the two setscrews in detent wheel (160) and slide the detent wheel and washer (161) from gear shaft (165).

(11) Loosen the two setscrews in the hub of gear assembly (164) and slide the gear assembly and washers (162 and 163) from gear shaft (165).

(12) Pull gear shaft (165) out through the mounting hole in rear gear plate (19).

(13) Remove screw (166), washers (167 and 168), and sleeve spacer (169) to remove detent arm (170) from rear gear plate (19).

(14) Remove screw (172), washers (173 and 174), and sleeve spacer (175) to remove detent arm (176) from rear gear plate (19). Detach helical extension spring (171) from detent arm (176).

o. Switch Sections S3A, S4A, and S4B. If the radio control is being completely disassembled, begin with (3) below. If only the switch sections are to be removed, begin with (1) below.

(1) Make sure that the front panel VHF NAV frequency-selector knobs have been set to 108.000. Remove four screws (45) and lockwashers (46) from rear plate (47).

(2) Pull rear plate (47) away from the radio control.

(3) Remove nuts (80) and lockwashers (81) from screws (98 and 99) and lift plate (82) from frequency-selector shaft (97) and screws (98 and 99).

(4) Slide washers (83) from frequency-selector shaft (97) and spacer insulators (84) from screws (98 and 99).

(5) Tag and unsolder wires connected to switch section S4B (85). Lift switch section from the hub of gear assembly (92) and screws (98 and 99).

(6) Remove spacer insulators (86 and 87) from screws (98 and 99).

(7) Tag and unsolder wires connected to switch section S4A (88). Lift switch section (88) from the hub of gear assembly (92) and screws (98 and 99).

(8) Remove spacer insulators (89 and 90) from screws (98 and 99).

(9) Tag and unsolder wires connected to switch section S3A (91). Lift switch section (91) from the hub of gear assembly (92) and screws (98 and 99).

(10) Remove two setscrews from gear assembly (157) and slide gear assembly (157) and washer (156) from gear shaft (158).

(11) Remove two setscrews from gear assembly (164) and slide gear assembly (164) and washers (162 and 163) from gear shaft (165).

(12) Slide gear assembly (92) from frequency-selector shaft (97) and remove spacer insulators (93) from screws (98 and 99).

(13) Remove frequency-selector shaft (97) from rear gear plate (19) and then remove retaining ring (95) and washer (96) from frequency-selector shaft (97).

p. VHF COMM Frequency Dials. If the radio control is being completely disassembled, begin with (4) below. If only the frequency dials are being removed, begin with (1) below.

(1) Remove front panel (5) as instructed in *d* above.

(2) Remove nut (42) from switch S5 (44).

(3) Remove front gear plate (34) as instructed in *k* (3) through (7) above.

(4) Remove screw (177), washer (178), screw (179), and stop plate (180) from rear gear plate (14).

(5) Remove two screws (181), washers (182), and terminal lug (183) from rear gear plate (14). Carefully lift frequency dials, with gear plates (184 and 185) attached, from the radio control.

(6) Remove two screws (186) that secure segment dial (188) to gear plate (185). Remove the segment dial and sleeve spacers (187) from gear plate (185).

(7) Remove two screws (189) and flat washers (190) that secure detent plate (191)

to gear plate (185). Remove the detent plate and ball bearings (194 and 197).

(8) Remove two screws (198) and flat washers (199) that secure detent plate (200) to gear plate (184). Remove the detent plate and ball bearings (203 and 206).

(9) Remove retaining rings (207 and 208) from the ends of dial support shaft (209).

(10) Remove gear plates (184 and 185) from dial support shaft (209). Slide gear assemblies (210 and 212) and washer (211) from dial support shaft (209).

(11) Loosen the setscrew behind the gear plate (184) and pull flanged hub (213), with pinion gear (214) attached, from the gear plate. Remove pinion gear (214) from flanged hub (213).

(12) Loosen the setscrew in the bottom of gear plate (184) and pull flanged hub (215), with helix gear (216) and washer (217) attached, from the gear plate. Remove helix gear (216) and washer (217) from flanged hub (215).

(13) Loosen the setscrew behind the gear plate (185) and pull flanged hub (218), with pinion gear (219) and washer (220) attached, from the gear plate. Remove pinion gear (219) and washer (220) from flanged hub (218).

(14) Loosen the setscrew in the bottom of gear plate (185) and pull flanged hub (221), with helix gear (222) and washer (223) attached, from the gear plate. Remove helix gear (222) and washer (223) from flanged hub (221).

q. VHF NAV Frequency Dials. If the radio control is being completely disassembled, begin with (4) below. If only the frequency dials are being replaced, begin with (1) below.

(1) Remove front panel (5) as instructed in *d* above.

(2) Remove nut (42) from switch S5 (44).

(3) Remove front gear plate (34) as instructed in *k* (3) through (7) above.

(4) Remove screw (224), washer (225), terminal lug (226), and screw (227) from rear gear plate (19).

(5) Remove two screws (229), washers (230), and stop plate (228) from rear gear plate (19). Carefully lift frequency dials, with gear plates (231 and 232) attached, from the radio control.

(6) Remove two screws that secure segment dial (235) to gear plate (232). Remove segment dial (235) and sleeve spacers (234) from gear plate (232).

(7) Remove two screws (234A) and flat washers (235A) that secure detent plate (236) to gear plate (232). Remove the detent plate and ball bearings (239 and 242).

(8) Remove two screws (243) and flat washers (244) that secure detent plate (245) to gear plate (231). Remove the detent plate and ball bearings (248 and 251).

(9) Remove retaining rings (252 and 253) from the ends of dial support shaft (254).

(10) Remove gear plates (231 and 232) from dial support shaft (254). Slide dial assemblies (255 and 257) and washer (256) from dial support shaft (254).

(11) Loosen the setscrew behind the gear plate (231) and pull flanged hub (258), with pinion gear (259) attached, from the gear plate. Remove pinion gear (259) from flanged hub (258).

(12) Loosen the setscrew in the bottom of gear plate (231) and pull flanged hub (260), with helix gear (261) and washer (262) attached, from the gear plate. Remove washer (262) and helix gear (261) from flanged hub (260).

(13) Loosen the setscrew behind the gear plate (232) and pull flanged hub (263), with pinion gear (264) and washer (265) attached, from the gear plate. Remove washer (265) and pinion gear (264) from flanged hub (263).

(14) Loosen the setscrew in the bottom of gear plate (232) and pull flanged hub (266), with helix gear (267) and washer (268) attached, from the gear plate. Remove washer (268) and helix gear (267) from flanged hub (266).

3-3. Assembly of Radio Control

(fig. 5-4)

Refer to the color coding and lead dress noted

during disassembly, and replace leads or wires that were unsoldered with composition SN60 solder. Liquid-stake the threads of all non-locked screws with blue varnish. If the radio control is completely disassembled, perform the assembly procedures in the order listed. If the radio control is not completely disassembled, perform only the assembly procedure for the components that have been removed.

a. *VHF NAV Frequency Dials.*

(1) Place pinion gear (259) on flanged hub (258) and insert the hub into gear plate (231). Tighten setscrew at the rear of the gear plate.

(2) Slide helix gear (261) and washer (262) onto flanged hub (260) and insert the hub into gear plate (231). Tighten the setscrew at the bottom of the gear plate.

(3) Place pinion gear (264) and washer (265) on flanged hub (263) and insert the hub into gear plate (232). Tighten the setscrew at the rear of the gear plate.

(4) Slide helix gear (267) and washer (268) on flanged hub (266) and insert the hub into gear plate (232). Tighten the setscrew at the bottom of the gear plate.

(5) Place retaining ring (252) on dial support shaft (254).

(6) Rotate the frequency dials on dial assembly (257) until digits 00 are aligned. While holding the frequency dials in the 00 position, engage the gears on dial assembly (257) with pinion gear (259) and helix gear (261) on gear plate (231) so that aligned digits 00 face to the front.

Note. Insure that the gears on the dial assembly and gear plate mesh and that digits 00 remain aligned for correct timing.

(7) With digits 00 aligned, insert dial support shaft (254) through gear plate (231) and dial assembly (257) until retaining ring (252) is seated against gear plate (231). Slide washer (256) onto dial support shaft (254) and carefully set the assembled gear plate and dial assembly on the bench so that the gear teeth remain meshed and digits 00 are aligned.

(8) Rotate the frequency dials on dial assembly (255) until digits 08 are aligned. While holding the frequency dials in the 08 po-

sition, engage the gears on dial assembly (255) with pinion gear (264) and helix gear (267) on gear plate (232).

Note. Insure that the gears on the dial assembly and gear plate mesh and that digits 08 remain aligned for correct timing.

(9) With digits 08 aligned, slide dial assembly (255) and gear plate (232) onto dial support shafts (254) so that digits 08 face to the front and are aligned with digits 00 on dial assembly (257). Place retaining ring (253) on dial support shaft (254).

(10) Mount segment dial (235) on gear plate (232) using two sleeve spacers (234) and screws (233). See that digits 108.00 are aligned on the frequency dials.

(11) Attach detent plate (245) to gear plate (231) using two flat washers (244) and screws (243).

(12) Loosen screw (246) and position detent spring (247) clear of ball bearing mounting hole. Insert ball bearing (248) into mounting hole, position detent spring (247) over hole, and tighten screw (246).

(13) Loosen screw (249) and position detent spring (250) clear of ball bearing mounting hole. Insert ball bearing (251) into mounting hole, position detent spring (250) over hole, and tighten screw (249).

(14) Mount detent plate (236) on gear plate (232) using two flat washers (235A) and screws (234A).

(15) Loosen screw (240) and position detent spring (241) clear of ball bearing mounting hole. Insert ball bearing (242) into mounting hole, position detent spring (241) over hole, and tighten screw (240).

(16) Loosen screw (237) and position detent spring (238) clear of ball bearing mounting hole. Insert ball bearing (239) into mounting hole, position detent spring (238) over hole, and tighten screw (237).

(17) Attach gear plates (231 and 232), with frequency dials attached, and stop plate (228) to rear gear plate (19), using screw (224), washer (225), terminal lug (226), screw (227), two screws (229), and two washers (230).

Note. The procedure given in (18), (19), and (20) below should be performed only if the frequency dials alone are being replaced.

(18) Replace front gear plate (34) as instructed in *g* below.

(19) Mount switch S5 (44) on front gear plate (34) using nut (42).

(20) Replace front panel as instructed in *l* below.

b. VHF COMM Frequency Dials.

(1) Place pinion gear (214) on flanged hub (213) and insert the hub into gear plate (184). Tighten setscrew at the rear of the gear plate.

(2) Slide helix gear (216) and washer (217) onto flanged hub (215) and insert the hub into gear plate (184). Tighten setscrew at the bottom of the gear plate.

(3) Place pinion gear (219) and washer (220) on flanged hub (218) and insert the hub into gear plate (185). Tighten setscrew at rear of the gear plate.

(4) Slide helix gear (222) and washer (223) onto flanged hub (221) and insert the hub into gear plate (185). Tighten setscrew at the bottom of the gear plate.

(5) Place retaining ring (207) on dial support shaft (209).

(6) Rotate the frequency dials on gear assembly (212) until digits 000 are aligned. While holding the frequency dials in the 000 position, engage the gears on gear assembly (212) with pinion (214) and helix gear (216) on gear plate (184) so that aligned digits 000 face to the front.

Note. Insure that the gears on the gear assembly and gear plate mesh and that digits 000 remain aligned for correct timing.

(7) With digits 000 aligned, insert dial support shaft (209) through gear plate (184) and gear assembly (212) until retaining ring (207) is seated against gear plate (184). Slide washer (211) onto dial support shaft (209) and carefully set the assembled gear plate and gear assembly on the bench so that the gear teeth remain meshed and digits 000 are aligned.

(8) Rotate the frequency dials on gear assembly (210) until digits 16 are aligned. While holding the frequency dials in the 16 po-

sition, engage the gears on dial assembly (210) with pinion gear (219) and helix (222) on gear plate (185).

Note. Insure that the gears on the gear assembly and gear plate mesh and that digits 16 remain aligned for correct timing.

(9) With digits 16 aligned, slide dial assembly (210) and gear plate (185) onto dial support shaft (209) so that digits 16 face to the front and are aligned with digits 000 on gear assembly (212). Place retaining ring (208) on dial support shaft (209).

(10) Mount segment dial (188) to gear plate (185), using two sleeve spacers (187) and screws (186). See that digits 116.000 are aligned on the frequency dials.

(11) Attach detent plate (200) on gear plate (184), using two flat washers (199) and screws (198).

(12) Loosen screw (204) and position detent spring (205) clear of ball bearing mounting hole. Insert ball bearing (206) into mounting hole, position detent spring (205) over hole, and tighten screw (204).

(13) Loosen screw (201) and position detent spring (202) clear of ball bearing mounting hole. Insert ball bearing (203) into mounting hole, position detent spring (202) over hole, and tighten screw (201).

(14) Mount detent plate (191) on gear plate (185), using two flat washers (190) and screws (189).

(15) Loosen screw (195) and position detent spring (196) clear of ball bearing mounting hole. Insert ball bearing (197) into hole, position detent spring (196) over hole, and tighten screw (195).

(16) Loosen screw (192) and position detent spring (193) clear of ball bearing mounting hole. Insert ball bearing (194) into mounting hole, position detent spring (193) over hole, and tighten screw (192).

(17) Attach gear plates (184 and 185), with frequency dials attached, and stop plate (180) to rear gear plate (14), using screw (177), washer (178), screw (179), terminal lug (183), two washers (182), and two screws (181).

Note. The procedure given in (18), (19), and (20) below should be performed only if the frequency dials alone are being replaced.

(18) Replace front gear plate (34) as instructed in *g* below.

(19) Mount switch S5 (44) to front gear plate (34), using nut (42).

(20) Replace front panel as instructed in *l* below.

c. Switch Sections S3A, S4A, and S4B.

(1) Place retaining ring (95) on frequency-selector shaft (97) and then slide washer (96) onto the shaft.

(2) Insert frequency-selector shaft (97) into the hole in the center of rear gear plate (19).

(3) If only switch sections are being replaced, loosen the two setscrews in gear assemblies (157 and 164) and make sure that the gears move freely on their shafts.

(4) Place gear assembly (92) on frequency-selector shaft (97). When only switch sections are being replaced, make sure that spur gear (92A) meshes with gear assembly (157) and spur gear (92B) meshes with gear assembly (164).

Note. When rotating spur gear (92A) ((5) below), observe that the gear does not strike mounting nuts on screws (98 and 99). If spur gear (92A) does strike the nuts, slightly reposition nuts to provide the proper clearance.

(5) View rear gear plate (19) from the rear and rotate spur gear (92A) counterclockwise until the stop on the gear face is positioned against stop plate (228). Rotate spur gear (92B) until the flattened sides of the hub on gear assembly (92) are aligned. When only switch sections are being replaced, tighten the setscrews in gear assemblies (157 and 164).

(6) Place spacer insulators (93) on screws (98 and 99).

(7) Position the rotor segment of switch section S3A (91) so that the front moving contacts are made with fixed contacts 10 and 18 and so that the rear moving contacts are made with fixed contacts 7, 30, and 36.

(8) View rear gear plate (19) from the rear. Align the flats of the shaft hole in switch section (91) with the flats on the hubs of gear assembly (92) so that when the switch

section is mounted, fixed contact 18 will be positioned directly above screw (98). Slide the switch section onto the hubs of gear assembly (92) with screws (98 and 99) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded in disassembly. Replace wiring if necessary.

(9) Place spacer insulators (90 and 89) on screws (98 and 99).

(10) Position the rotor segment of switch section S4A (88) so that the front moving contacts are made with fixed contacts 10 and 11 and so that the rear moving contacts are made with fixed contacts 3 and 12.

(11) View rear gear plate (19) from the rear. Align the flats of the shaft hole in switch section (88) with the flats on the hubs of gear assembly (92) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (98). Slide the switch section onto the hubs of gear assembly (92) with screws (98 and 99) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded in disassembly. Replace wiring if necessary.

(12) Place spacer insulators (86 and 87) on screws (98 and 99).

(13) Position the rotor segment of switch section S4B (85) so that the front moving contact is made with fixed contacts 1 and 19 and so that the rear moving contact is made with fixed contact 10.

(14) View rear gear plate (19) from the rear. Align the flats of the shaft hole in switch section (85) with the flats on the hubs of gear assembly (92) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (98). Slide the switch section onto the hubs of gear assembly (92) with screws (98 and 99) passing through the holes in the sides of the switch section. Solder the wires to the switch section as coded in disassembly. Replace wiring if necessary.

(15) Place spacer insulators (84) on screws (98 and 99) and slide washers (83) onto shaft (97).

(16) Mount retaining plate (82) on frequency-selector shaft (97) with screws (98 and 99) passing through the holes in the ends

of the plate. Secure the plate with lockwashers (81) and nuts (80).

Note. Perform the procedure given in (17) below only if switch sections are being replaced.

(17) Attach rear plate (47) to the rear of the radio control, using lockwashers (46) and screws (45).

d. Switch Sections S1A, S1B, S2A, and S2B.

(1) Place retaining ring (75) on frequency-selector shaft (77) and then slide washer (76) onto the shaft.

(2) Insert frequency-selector shaft (77) into the hole in the center of rear gear plate (14).

(3) Align the timing holes in composite gear (72A) and spur (72B) on gear assembly (72).

(4) If only switch sections are being replaced, slide gear assembly (72) onto frequency-selector shaft (77) so that the timing holes in the gear assembly are directly opposite to, and aligned with, the timing dimple punched in gear assembly (128).

(5) If the radio control is being completely reassembled, slide gear assembly (72) onto frequency-selector shaft (77) so that the timing holes in the gear assembly are bisected by an imaginary line drawn between hole A and shaft (77).

(6) Observe that there is ample clearance between the teeth of gear assembly (72) and the mounting nuts on screws (78 and 79).

(7) Place spacer insulators (73) on screws (78 and 79).

(8) Position the rotor segment of switch section S1A (71) so that the front moving contacts are made with fixed contact 5 and so that the rear moving contacts are made with fixed contacts 3 and 11.

(9) View rear gear plate (14) from the rear. Align the flats of the shaft hole in switch section (71) with the flats on the hub of gear assembly (72) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (78). Slide the switch section onto the hubs of gear assembly (72) with screws (78 and 79) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded during

ing disassembly. Replace wiring if necessary.

(10) Place spacer insulators (70) on screws (78 and 79).

(11) Position the rotor segment of switch section S1B (69) so that the front moving contacts are made with fixed contacts 2 and 11 and so that the rear moving contacts are made with fixed contact 7.

(12) View rear gear plate (14) from the rear. Align the flats of the shaft hole in switch section (69) with the flats on the hubs of gear assembly (72) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (78). Slide the switch section onto the hubs of gear assembly (72) with screws (78 and 79) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded in disassembly. Replace wiring if required.

(13) Slide washers (67 and 68) onto frequency-selector shaft (77) and place spacer insulators (66 and 65) on screws (78 and 79).

(14) Align the timing holes in driving gear (64A) and spur gear (64B) on gear assembly (64).

(15) If only the switch sections are being replaced, slide gear assembly (64) onto frequency-selector shaft (77) so that the timing holes in the gear assembly are bisected by an imaginary line drawn between the center of gear shaft (139) and frequency-selector shaft (77). Position gear assembly (138) on gear shaft (139) so that the timing dimple punched in the rear face of the tooth projection of gear assembly (138) is directly opposite to, and is aligned with, the timing holes in gear assembly (64). Tighten setscrews in gear assembly (138).

(16) If the radio control is being completely reassembled, slide gear assembly (64) onto frequency-selector shaft (77) so that the timing holes in the gear assembly are bisected by an imaginary line drawn between hole B and shaft (77).

(17) Position the rotor segment of switch section S2A (63) so that the front moving contacts are made with fixed contact 6 and so that the rear moving contact is made with fixed contacts 1 and 12.

(18) View rear gear plate (14) from the rear. Align the flats of the shaft hole in switch section (63) with the flats of the hubs on gear assembly (64) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (78). Slide the switch section onto the hubs of gear assembly (64) with screws (78 and 79) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded in disassembly. Replace wiring if required.

(19) Place spacer insulators (62) on screws (78 and 79).

(20) Position that rotor segment of switch section S2B (61) so that the front moving contact is made with fixed contacts 10 and 11 and so that the rear moving contact is made with fixed contact 5.

(21) View rear gear plate (14) from the rear. Align the flats of the shaft hole in switch section (61) with the flats on the hubs of gear assembly (64) so that when the switch section is mounted, fixed contact 10 will be positioned directly above screw (78). Then slide the switch section onto the hubs of gear assembly (64) with screws (78 and 79) passing through the holes in the sides of the switch section. Solder wires to the switch section as coded in disassembly. Replace wiring if necessary.

(22) Place spacer insulators (60) on screws (78 and 79) and washers (59 and 58) on frequency-selector shaft (77).

(23) Mount plate (57) on frequency-selector shaft (77) with screws (78 and 79) passing through the holes in the ends of the plate. Secure the plate with lockwashers (56) and nuts (55).

Note. The procedure given in (24) below is necessary only when switch sections are being replaced.

(24) Attach rear plate (47) to the rear of the radio control, using lockwashers (46) and screws (45).

e. VHF NAV Detent Wheels.

(1) Mount detent arm (170) on rear gear plate (19), using sleeve spacer (169), washers (167 and 168), and screw (166).

(2) Mount detent arm (176) on rear gear plate (19), using sleeve spacer (175), washers (173 and 174), and screws (172).

(3) Attach helical extension spring (171) to detent arms (170 and 176).

(4) Slide detent wheel (154) and washer (155) over the plain end of gear shaft (158). Position the wheel and washer approximately 1/16 inch from the plain end of the shaft.

(5) Position the plain end of the shaft against surface of rear gear plate (19) beside hole C so that the teeth of detent wheel (154) are meshed with the roller on detent arm (170). Push the detent wheel toward the center of the gear plate against the detent arm to align gear shaft (158) with hole C. Push gear shaft (158) through hole C until approximately 1/4 inch of the shaft extends from the rear of the gear plate.

(6) Place washer (156) over end of gear shaft (158). While holding spur gear (92A) of gear assembly (92) so that its stop is seated against stop plate (228), slide gear assembly (157) over end of gear shaft (158) and mesh its teeth with the teeth of spur gear (92A) on gear assembly (92).

(7) Hold gear assembly (157) firmly against rear gear plate (19) and position gear shaft (158) so that its end is flush with the end of the hub on gear assembly (157). Tighten the setscrews in the hub of gear assembly (157) and in the hub of detent wheel (154).

(8) Slide helical gear (153) over the recessed end of gear shaft (158) until its teeth mesh with the teeth of helix gear (267). Do not tighten the setscrews in the hub of helical gear (153) at this time. Instructions for tightening the setscrews are given in *g* below.

(9) Place spacer insulator (152) and spur gear (151) on gear shaft (158).

(10) Slide detent wheel (160) and washer (161) over the end of gear shaft (165). Position the detent wheel and the washer approximately 1/16 inch from the end of the shaft,

(11) Position the end of the shaft against the surface of rear gear plate (19) beside hole so that the teeth of detent wheel (160) are meshed with the roller on detent arm (176). Push the detent wheel toward the center of the gear plate against the detent arm to align gear shaft (165) with hole D. Push gear shaft (165) through hole D until approximately 3/8

inch of the shaft extends from the rear of gear plate (19).

(12) Place two washers (162 and 163) over the end of gear shaft (165). While holding spur gear (92B) of gear assembly (92) so that it does not move, slide gear assembly (164) over the end of gear shaft (165) and mesh its teeth with the teeth of spur gear (92 B).

(13) Hole gear assembly (164) firmly against rear gear plate (19) and position gear shaft (165) so that its end is flush with the face of gear assembly (164). Tighten the setscrews in the hub of gear assembly (164) and in detent wheel (160).

(14) Slide helical gear (159) over the end of gear shaft (165) and mesh its teeth with the teeth of helix gear (261). Do not tighten the setscrews in the hub of helical gear (159) at this time. Instructions for tightening the setscrews are given in *g* below.

Note. The procedure given in (15), (16), and (17) below should be performed only if the detent wheels are being replaced.

(15) Replace front gear plate (34) as directed in *g* below.

(16) Mount switch S5 (44) on front gear plate (34), using nut (42).

(17) Replace front panel (5) as directed in *l* below.

f. VHF COMM Detent Wheels.

(1) Mount detent arm (144) on rear gear plate (14), using sleeve spacer (143), washers (142 and 141), and screw (140).

(2) Mount detent arm (150) on rear gear plate (14), using sleeve spacer (149), washers (147 and 148), and screw (146).

(3) Attach helical extension spring (145) to detent arms (144 and 150).

(4) Slide detent wheel (124) and flat washer (125) over the plain end of gear shaft (129).

(5) Position the end of the shaft against the front surface of rear gear plate (14) beside hole A so that the teeth of detent wheel (124) are meshed with the roller on detent arm (150). Push the detent wheel toward the center of the gear plate against the detent arm to align gear shaft (129) with hole A. Push gear shaft (129) through hole A until approximately 1/4

inch of the shaft extends from the rear of the gear plate.

(6) Place flat washers (126 and 127) on gear shaft (129).

(7) Pull gear shaft (129) back through hole A until the end of the shaft is flush with the face of flat washer (127).

(8) Make sure that the timing holes in gear assembly (72) are aligned and are bisected by an imaginary line drawn between gear shaft (129) and frequency-selector shaft (77). Mesh the teeth of gear assembly (128) with the teeth of spur gear (72B) on gear assembly (72) so that the timing dimple punched in its hub is bisected by the imaginary line drawn between gear shaft (129) and frequency-selector shaft (77). Push gear shaft (129) forward into gear assembly (128) until its end is flush with the end of the hub on the gear assembly. Tighten the setscrews in the hub of the gear assembly and in the hub of detent wheel (124).

(9) Slide helical gear (123) over the recessed end of gear shaft (129) and mesh its teeth with the teeth of helix gear (216). Do not tighten the setscrews in the hub of helical gear (123) at this time. Instructions for tightening the setscrews are given in *g* below.

(10) Place spacer insulator (122) and spur gear (121) on gear shaft (129).

(11) Slide detent wheel (133) and washer (134) over the plain end of gear shaft (139). Position the wheel and washer approximately 1/16 inch from the end of the shaft.

(12) Position the end of the shaft against the front surface of rear gear plate (14) beside hole B so that the teeth of detent wheel (133) are meshed with the roller on detent arm (144). Push the detent wheel toward the center of the gear plate against the detent arm to align gear shaft (139) with hole B. Push gear shaft (139) through hole B until approximately 1/4 inch of the shaft extends from the rear of the gear plate.

(13) Place three washers (135) and three stop washers (136) on gear shaft (139). Tabs on stop washers should be pointing forward.

(14) Pull gear shaft (139) back through hole B until the end of the shaft is flush with

the face of stop washer (136). Position cam (137) over the end of the shaft, with the cam stop facing forward, and push the shaft through the cam until approximately 1/4 inch of the shaft extends from the cam.

(15) Make sure that the timing holes in gear assembly (64) are aligned and are bisected by an imaginary line drawn between frequency-selector shaft (77) and gear shaft (139). Mesh the teeth of gear assembly (138) with the teeth of spur gear (64B) on gear assembly (64) so that the timing dimple punched in the rear face of the tooth projection of gear assembly (138) is bisected by the imaginary line drawn between frequency-selector shaft (77) and gear shaft (139). Push gear shaft (139) forward into gear assembly (138) until its end is flushed with the end of the hub on the gear assembly.

(16) Hold cam (137) firmly against stop washers (136) and tighten the setscrews in the cam. While viewing rear gear plate (14) from the front and making sure that gear assembly (138) does not turn, rotate gear shaft (139) counterclockwise until the tabs on washers (136) and the stop on cam (137) are aligned in the stopped position against the inner edge of stop plate (180).

(17) Tighten the setscrews in the hub of gear assembly (138) and in the hub of detent wheel (133). Make sure that the timing holes in gear assembly (64) and the timing dimple on gear assembly (138) are still bisected by an imaginary line drawn between shafts (77 and 139).

(18) Slide helical gear (132) over the recessed end of gear shaft (139) and mesh its teeth with the teeth of helix gear (222). Do not tighten the setscrews in the hub of helical gear (132) at this time. Instructions for tightening the setscrews are given in *g* below.

(19) Place spacer insulator (131) and spur gear (130) on gear shaft (139).

Note. The procedure given in (20), (21), and (22) below should be performed only if the detent wheels are being replaced.

(20) Replace front gear plate (34) as instructed in *g* below.

(21) Mount switch S5 (44) on front gear plate (34), using nut (42).

(22) Replace front panel (5) as directed in 1 below.

g. Panel Light Receptacles and Front Gear Plate.

(1) Place lamp receptacles (115 and 116) in the proper holes in front gear plate (34) and secure with washers (119) and nuts (118).

(2) Mount lamp receptacle (117) in the proper hole in front gear plate (34) and secure with nut (120).

(3) Solder wires to lamp receptacles in accordance with tags attached during disassembly.

(4) Attach front gear plate (34) to gear plates (184, 185, 231, and 232) with washers (108, 110, 112, and 114) and screws (107A, 109, 111, and 113).

(5) Secure the front gear plate to lower support members (105) and (107) with screws (103 and 101). Do not attach gear plate to upper support members (104 and 106) at this time.

(6) View the VHF NAV frequency dials through the front gear plate and check for a frequency indication of 108.00.

(a) If the last two digits of the indicated number are 00, tighten the setscrews in helical gear (159). If digits other than 00 are observed, make sure that the setscrews in helical gear (159) are loose, and rotate the gear until the digits 00 are observed. Tighten the setscrews in the gear.

(b) If the second and third digits of the indicated number are 08, tighten the setscrews in helical gear (153). If digits other than 08 are observed, make sure that the setscrews in helical gear (153) are loose, and rotate the gear until the digits 08 are observed. Tighten the setscrews of the gear.

(c) If the bottom edges of digits 08 are not aligned with the bottom edge of digit 1, loosen screws (234A) in detent plate (236) and adjust the plate until the bottom edges of the numbers are aligned. Retighten screws (234A).

(d) If the bottom edges of digits 00 are not aligned with the bottom edge of digits 108, loosen screws (243) in detent plate (245) and adjust the plate until the bottom edges of the

numbers are aligned. Retighten screws (243).

(7) View the VHF COMM frequency dials through the front gear plate and check for a frequency indication of 116.000.

(a) If the last three digits of the indicated number are 000, tighten the setscrews in helical gear (123). If digits other than 000 are observed, make sure that the setscrews in helical gear (123) are loose, and rotate the gear until digits 000 are observed. Tighten the setscrews in the gear.

(b) If the second and third digits of the indicated number are 16, tighten the setscrews in helical gear (132). If digits other than 16 are observed, make sure that the setscrews in helical gear (132) are loose, and rotate the gear until the digits 16 are observed. Tighten the setscrews in the gear.

(c) If the bottom edges of digits 16 are not aligned with the bottom edge of digit 1, loosen screws (189) in detent plate (191) and adjust the plate until the bottom edges of the numbers are aligned. Retighten screws (189).

(d) If the bottom edges of digits 000 are not aligned with the bottom edges of digits 116, loosen screws (198) in detent plate (200) and adjust the plate until the bottom edges of the digits are aligned. Retighten screws (198).

(8) Secure front gear plate to upper support members (104 and 106) with screws (100 and 102).

Note. The procedure given in (9) through (12) below is necessary only if the front gear plate is being replaced.

(9) Mount mounting plate (23), with switch S6 (29) and VOL control R1 (33) attached, on front gear plate (34); use two screws (24) and standoff spacers (25). Switch S6 and control R1 should be adjusted fully counterclockwise from the front. Spur gears (26 and 30) should mesh with spur gears (130 and 121).

(10) Mount mounting plate (35), with switch S7 (41) attached on front gear plate (34); use two screws (36) and standoff spacers (37). Switch S7 should be adjusted fully counterclockwise from the front. Spur gear (38) should mesh with spur gear (151).

(11) Mount switch S5 (44) on front gear plate with nut (42).

(12) Attach front panel (5) to front gear plate as described in 1 below.

h. Connectors J1 and J2.

(1) Solder wires to J1 (52) and J2 (53) in accordance with tags attached during disassembly.

(2) Slide wires connected to J1 and J2 through slots in rear plate (47).

(3) Attach bracket (54) and connectors J1 and J2 to the rear plate with four screws (48 and 50) and nuts (49 and 51).

(4) Attach rear plate to support members (104 through 107) with four lockwashers (46) and screws (45).

i. Switch S5.

(1) Solder wires to switch S5 (44) in accordance with tags attached during disassembly.

(2) Attach switch S5 to front gear plate (34) with nut (42).

(3) If only switch S5 is being replaced, attach front panel as instructed in 1 below.

j. Switch S7.

(1) Slide shaft on switch S7 (41) through hole in left side of mounting plate (35). Secure with washer (40) and nut (39).

(2) Slide spur gear (38) onto shaft of switch S7 and tighten the setscrews in the hub of the gear.

(3) Solder wires to switch S7 in accordance with tags attached during disassembly.

(4) Rotate spur gear (38) to the full counterclockwise position.

(5) Mount mounting plate (35) to front gear plate (34) with two screws (36) and standoff spacers (37). Spur gear (38) should mesh with spur gear (151).

(6) If only switch S7 is being replaced, attach front panel as instructed in 1 below.

k. Switch S6 and VOL Control R1.

(1) Slide shaft on switch S6 (29) through hole in left side of mounting plate (23). Secure with washers (28) and nut (27).

(2) Place spur gear (26) on shaft of switch S6 and tighten the setscrews in the hub of the gear.

(3) Insert shaft on VOL control R1 (33)

through the hole in the right side of mounting plate (23). Secure with washer (32) and nuts (81).

(4) Place spur gear (30) on shaft of control R1 and tighten the setscrews in the hub of the gear.

(6) Solder wires to switch S6 and control R1 as coded during disassembly.

(6) Rotate spur gears (26 and 30) to the full counterclockwise position.

(7) Mount mounting plate (23) to front gear plate (34) with two screws (24) and standoff spacers (25). Spur gears (26 and 30) should mesh with spur gears (130 and 121).

(8) If only switch S6 and control R1 are being replaced, attach front panel as instructed in / below.

l. Front Panel.

(1) Place front panel (5) on front gear plate (34) so that detent wheel shafts protrude through holes in front panel.

(2) With pointer on knob skirt pointing at OFF on front panel, slide knob (21) onto gear shaft (139) and tighten the setscrews in the knob.

(3) With pointer on knob skirt pointing at 10 o'clock, slide knob (21) onto gear shaft (129) and tighten setscrews in the knob.

(4) With pointer on knob skirt pointing at OFF on front panel, slide knob (21) onto gear shaft (158) and tighten the setscrews in the knob.

(5) Slide knob (22) onto gear shaft

(165) and tighten the setscrews in the knob.

(6) Slide four knobs (20) onto the four shafts protruding through front panel and tighten the two setscrews in each knob.

(7) If only front panel is being replaced, mount front panel lamps as instructed in o below.

m. Frequency Dial Indicator Lamps.

(1) Insert two VHF NAV indicator lamps (18) into mounting holes in rear gear plate (19).

(2) Position retaining tabs (17) over base of lamps and tighten screws (16).

(3) Place cover (15) over each lamp.

(4) Insert two VHF COMM indicator lamps (13) into mounting holes in rear gear plate (14).

(5) Position retaining tabs (12) over lamp bases and tighten screws (11).

(6) Place cover (10) over each lamp.

n. Protective Covers.

(1) Mount bottom cover (9) on the bottom of the radio control with four screws (8).

(2) Mount top cover (7) on the top of the radio control with four screws (6).

o. Front Panel Lamps.

(1) Insert one panel lamp (4) into each of the three lamp receptacle caps (1).

(2) Screw lamp receptacle caps (1) into three mounting holes in front panel (5).

3-4. Cleaning

Cleaning procedures are identical with those in TM 11-6625-1635-12.

CHAPTER 4

GENERAL SUPPORT TESTING PROCEDURES

4-1. General

a. Testing procedures are prepared for use by Signal Field Maintenance Shops and Signal Service Organizations responsible for GS (general support) maintenance of electronics equipment to determine the acceptability of repaired electronics equipment. These procedures set forth specific requirements that repaired electronics equipment *must* meet before it is returned to the using organization. These procedures may also be used as a guide for testing electronics equipment repaired by direct support and organizational personnel if the proper tools and test equipments are available. A summary of the performance standards is given in paragraph 4-13.

b. Comply with the instructions preceding each chart before proceeding to the chart. Perform each step in sequence. Do not vary the sequence. For each step, perform all the action required in the *Control settings* columns; then perform each specific test procedure and verify it against its performance standard.

4-2. Test Equipment Required

All test equipment and other equipment required to perform the testing procedures given in this chapter are listed in the following charts and are authorized under TA 11-17, Signal Field Maintenance Shops, and TA 11-100 (11-17), Allowances of Signal Corps Expendable Supplies for Signal Field Maintenance Shop, Continental United States.

a. Test Equipment.

Nomenclature	Federal stock No.	Technical manual
Generator, Signal AN/USM-44.	6625-539-9685	TM 11-6625-508-10
Generator, Signal AN/URM-127.	6625-783-5964	TM 11-6625-683-15
Wattmeter, Radio Frequency AN/URM-43A.	6625-557-0389	TM 11-5133
Multimeter TS-352B-U.	6625-242-5023	TM 11-6625-366-15

b. Other Equipment.

Equipment	Federal stock No.	Technical manual	Common names
Radio Set AN/ARC-134.	5821-072-6018	TM 11-5821-277-25-1	Radio Set
Power Supply PP-3931/FLR-9 (V), or equal.	6130-733-3638		Power supply
Power source: 5 volts, ac; Stanco Type P6467, or equal. (Unmodified equipment).	None	Ac power supply
Microphone M-52A/U. (Unmodified equipment).	5965-646-4678		Microphone
Headset H-216/U with Cord CD-307 (FSN 5995-553-0056). (Unmodified equipment).	5965-892-3353		Headset
Coaxial Adapter UG-201/U.	None	Adapter
Coaxial Connector UG-88/U (two required).	None	Connector
Capacitor, 50-μf, 25-vdc, Sprague Type TL1209, or equal.	None	Capacitor, 50-μf, 25-vdc
Coaxial Cable RG-58/U (as required).	None	Cable

4-3. Modification Work Orders

The performance standards listed in the tests (para 4-4 through 4-12) are based on the assumption that the modification work orders have been performed. A listing of current modification work orders will be found in DA Pam 310-7.

4-4. Physical Tests and Inspections

a. Test Equipment and Materials. None required.


b. Test Connections and Conditions..

(1) No connections necessary.

(2) Remove front and rear covers from maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
1	None	Controls may be in any position.	<p>a. Inspect CY-6207/ARC (equipment case) and test panel for damage, missing parts, and conditions of paint.</p> <p><i>Note.</i> Touchup painting is recommended in lieu of refinishing whenever practical; screwheads, binding posts, plugs, receptacles, and other plated parts will not be painted or polished with abrasives.</p> <p>b. Inspect all cables wiring, resistors, and capacitors for breaks or bums.</p> <p>c. Inspect all controls and assemblies for loose or missing screws, bolts, and nuts.</p> <p>d. Inspect all connectors, plugs, jacks, receptacles, lamps, and indicators for looseness, damage, or missing parts.</p> <p>e. Inspect maintenance kit for missing items</p>	<p>a. No damage evident or parts missing. External surfaces intended to be painted will not show bare metal. Test panel lettering will be legible.</p> <p>b. No broken or bum damage evident.</p> <p>c. Screws, bolts, and nuts will be tight. No missing items.</p> <p>d. No loose parts or damage. No missing parts.</p> <p>e. No missing items.</p>
2	None	Controls may be in any position.	<p>a. Rotate all controls throughout their limits of travel.</p> <p>b. Inspect dial stops for proper operation.</p> <p>c. Operate all switches.</p> <p>d. Connect all plugs to their respective receptacle</p>	<p>a. Controls will rotate freely without binding or excessive looseness.</p> <p>b. stops will operate properly without evidence of damage.</p> <p>c. Switches will operate properly.</p> <p>d. All plugs will connect smoothly; no binding or forcing required.</p>



TM 11-6625-1635-35-37

Figure 4-1. Receiver circuit test setup No. 1, unmodified maintenance kit.

4-5. Receiver Circuit Test No. 1


a. Test Equipment and Materials.

- (1) Radio Set AN/ARC-134.
- (2) Generator, Signal AN/USM-44.
- (3) Power supply.
- (4) Ac power source (unmodified equipment).
- (5) Headset (unmodified equipment).
- (6) Multimeter TS-352B/U.
- (7) Adapter.

(8) Fuseholder 700061-0001 (part of MK-1004/ARC).

(9) 1/16-amp, 250-volt fuse 700061-0002 (part of MK-1004/ARC).

b. *Test Connections and Conditions.* Connect the equipment as shown in figure 4-1 or 4-1.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.



TM6625-1635-35-94


Figure 4-1.1. Receiver circuit test setup No. 1, modified maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to LINE V. AN/USM-44 Set output level to zero. TS-352B/U a. Function: AC VOLTS. b. Range scale: 50 Vac.	a. Set all test panel switches to OFF. b. Set EXT SQUELCH CONT fully counterclockwise.	Apply primary operating power to test equipment and maintenance kit, and allow a few minutes warm-up period before proceeding.	None.
2	Leave controls in positions last indicated in step 1.	Leave controls in position last indicated in step 1.	CAUTION Be sure to connect the 700061-0001 fuseholder between the AN/USM-44 output receptacle and maintenance kit antenna connector J1 as shown in figure 4-1. The fuseholder must be equipped with a 700-061-0002 fuse (1/16-amp, 250-volt, normal blow). Do <i>not</i> set the test panel PTT switch to ON when the AN/USM-44 is connected to J1. Set maintenance kit POWER switch to ON.	a. Maintenance kit POWER indicator lamps must light. b. On modified equipment intercom control panel lamps must light.
3	Leave controls in positions last indicated in step 2.	Leave controls in position last indicated in step 2.	Set maintenance kit VHF COMM OFF-PWR switch to PWR.	a. Indicator lamps behind maintenance kit VHF COMM frequency counter dials must light. b. Meter on AN/ARC-134 must indicate 27.5 volts dc (-20 + 1070). c. On unmodified equipment the ammeter must indicate 2 to 3 amps.
4	AN/ARC-134 Leave controls in positions last indicated in step 1. AN/USM-44 a. Frequency: 132.500 MHz. b. Internal modulation: 90% at 1,000 Hz.	Leave controls in positions last indicated in step 2.	Set maintenance kit VHF COMM frequency-selector switches to 132.500 MHz.	An output indication must be obtained on the TS-352B/U.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
■	c. Output level: 6 μ V. TS-352B/U Leave controls in positions last indicated in step 1.			

Figure 4-2. Receiver circuit test setup No. 2, unmodified maintenance kit.



TM 11-6625-1635-35


4-6. Receiver Circuit Test No. 2*a. Test Equipment and Material*

- (1) Radio Set AN/ARC-134.
- (2) Generator, Signal AN/USM-44.
- (3) Power supply.
- (4) Ac power source (unmodified equipment).
- (5) Headset (unmodified equipment).
- (6) Multimeter TS-352B/U.
- (7) Adapter.

(8) Fuseholder 700061-0001 (part of MK-1004/ARC).

(9) 1/16-amp, 250-volt fuse 700061-0002 (part of MK-1004/ARC).

b. Test Connections and Conditions. Connect the equipment as shown in figure 4-2 or 4-2.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.



TM 11-6625-1635-35-55

Figure 4-2.1. Receiver circuit test setup No. 2, modified maintenance kit.

c. Procedure.

[illegible]

<p>4 Leave control in position last indicated in step 1.</p>	<p>Leave controls in positions last indicated in step 1.</p>	<p>a. Set AUDIO switch to ON and EXT. SQUELCH CONT. switch to OFF.</p> <p>b. Set maintenance kit VHF COMM VOL control to its midposition, and adjust AN/USM-44 output to 3 uv.</p> <p>c. Set maintenance kit VHF COMM and AN/USM-44 frequency-selector switches to each of the following frequencies and check for proper frequency selection:</p> <p>116.00 MHz, 126.00 MHz, 136.00 MHz, 146.00 MHz, 147.00 MHz, 148.00 MHz, 149.00 MHz, 140.00 MHz, 141.00 MHz, 142.00 MHz, 143.00 MHz, 144.00 MHz, 145.00 MHz, 145.10 MHz, 145.20 MHz, 145.30 MHz, 145.40 MHz, 145.50 MHz, 145.60 MHz, 145.70 MHz, 145.80 MHz, 145.90 MHz, and 145.95 MHz.</p>	<p>Tone must be heard in headset at each respective frequency.</p>
---	--	---	--




Figure 4-3. Transmitter output and control circuit check. test setup, unmodified maintenance kit.

4-7. Transmitter Output and Control Circuit Test

a. Test Equipment and Material.

- (1) Radio Set AN/ARC-134.
- (2) Ac power source (unmodified equipment)
- (3) Ac power source.
- (4) Wattmeter, Radio Frequency AN/URM-43A.

(5) Adapter.

b. *Test Connections and Conditions.* Connect the equipment as shown in figure 4-3 or 4-3.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test,




Figure 4-3.1. Transmitter output and control circuit check, test setup, modified maintenance kit.

c. Procedure.

Step No.	Control settings		Teat procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to LINE V AN/URM-43A Set to HIGH	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter-clockwise.	<p>a. Apply primary operating power to test equipment and maintenance kit, and allow a few minutes warmup period before proceeding.</p> <p>b. Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and VHF COMM frequency-selector switches to 132.500 MHz.</p> <p>c. Set maintenance kit PTT switch to ON.</p>	<p>a. None.</p> <p>b. None.</p> <p>c. A power output indication should be obtained on the AN/URM-43A.</p> <p>d. On modified equipment, the ammeter should indicate 6 to 9 amps.</p>




Figure 4-4. Sidetone circuit check, test setup, unmodified maintenance kit.

4-8. Sidetone Circuit Check

a. Test Equipment and Material.

- (1) Radio Set AN/ARC-134.
- (2) Power supply.
- (3) Ac power source (unmodified equipment).
- (4) Wattmeter, Radio Frequency AN/URM-43A.
- (6) Microphone (unmodified equipment).

- (6) Headset (unmodified equipment).
(7) Adapter.

b. Test Connections and Conditions. Connect

the equipment as shown in figure 4-4 or 4-41. On modified equipment, place the G-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.





Figure 4-4.1. Sidetone circuit check, test setup, modified maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to LINE V. AN/URM-43A Set to HIGH	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter-clockwise.	<p>a. Apply primary operating power to test equipment and maintenance kit, and allow a few minutes warmup period before proceeding.</p> <p>b. Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and VHF COMM frequency-selector switches to 132.500 MHz.</p> <p>c. Key the AN/ARC-134 with the microphone switch and speak into microphone. Release microphone switch.</p>	<p>a. None.</p> <p>b. None.</p> <p>c. The AN/ARC-134 sidetone should be heard in headset.</p>
2	AN/ARC-134 Set meter switch to MOD 1. AN/URM-43A Leave controls in position last indicated in step 1.	Leave controls in positions last indicated in step 1.	Key AN/ARC-134 with switch and speak into microphone.	The meters on the test panel and the AN/ARC-134 should fluctuate with modulation.



4-9. Modulation Check, MIKE INPUT Circuit*a. Test Equipment and Material.*

- (1) Radio Set AN/ARC-134.
- (2) Power supply.
- (3) Ac power source (unmodified equipment).
- (4) Wattmeter, Radio Frequency AN/URM-43A.
- (5) Generator, Signal AN/URM-127.

*(6) Adapter.**(7) Capacitor, 50- μ f, 25-vdc.*

b. Test Connections and Conditions. Connect the equipment as shown in figure 4-5 or 4-5.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.




Figure 4-5.1. Modulation check, MIKE INPUT circuit, test setup, modified maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to MOD 1. AN/URM-43A Set to HIGH AN/URM-127 Set frequency to 1,000 Hz.	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter-clockwise.	<i>a.</i> Apply primary operating power to test equipment and test panel, and allow a few minutes warmup period before proceeding. <i>b.</i> Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and VHF COMM frequency-selector switches to 132.500. <i>c.</i> Set maintenance kit PTT switch to ON and increase AN/URM-127 output level.	<i>a.</i> None. <i>b.</i> None. <i>c.</i> A modulation indication should be obtained on the test panel AN/ARC-134 meter.




Figure 4-6. Modulation check, 0 DBM INPUT circuit, test setup, unmodified maintenance kit.

4-10. Modulation Check 0 DBM INPUT Circuit

a. Test Equipment and Material.

- (1) Radio Set AN/ARC-134.
- (2) Power supply.
- (3) Ac power source (unmodified equipment).
- (4) Wattmeter, Radio Frequency AN/URM-43A.

(5) Generator, Signal AN/URM-127.

(6) Adapter.

(7) Capacitor, 50 μ f, 25-vdc.

b. *Test Connection and Conditions.* Connect the equipment as shown in figure 4-6 or 4-6.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.





Figure 4-6.1. Modulation check, 0 DBM INPUT circuit, test setup, modified maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to MOD 1, AN/URM-43A Set to HIGH AN/URM-127 Set frequency to 1,000 Hz.	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter-clockwise.	<p><i>a.</i> Apply primary operating power to test equipment and maintenance kit, and allow a few minutes warmup period before proceeding.</p> <p><i>b.</i> Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and the VHF COMM frequency-selector switches to 132.500 MHz.</p> <p><i>c.</i> Set maintenance kit PTT switch to ON and increase AN/URM-127 output level.</p>	<p><i>a.</i> None.</p> <p><i>b.</i> None.</p> <p><i>c.</i> A modulation indication should be obtained on the AN/ARC-134 meter.</p>



TM6625-1635-35-43

4-11. Modulation Check DATA LINK INPUT Circuit

a. Test Equipment and Material.

- (1) Radio Set AN/ARC-134.
- (2) Power supply.
- (3) Ac power source (unmodified equipment).
- (4) Wattmeter, Radio Frequency AN/URM-43A.

- (5) Generator, Signal AN/URM-127.
(6) Adapter.
(7) Capacitor, 50- μ f, 25-vdc.

b. Test Connection and Conditions. Connect the equipment as shown in figure 4-7 or 4-7.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.




Figure 4-7.1. Modulation check, DATA LINK INPUT circuits, test setup modified maintenance kit.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to MOD 1. AN/URM-43A Set to HIGH AN/URM-127 Set frequency to 1,000 Hz.	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter- clockwise.	<i>a.</i> Apply primary operating power to test equipment and maintenance kit, and allow a few minutes warmup period before proceeding. <i>b.</i> Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and the VHF COMM frequency-selector switches to 132.500 MHz. <i>c.</i> Set maintenance kit PTT switch to ON and increase AN/URM-127 output level.	<i>a.</i> None <i>b.</i> None. <i>c.</i> A modulation indication should be obtained on the AN/ARC-134 meter.




Figure 4-8. Detector circuit check, test setup, unmodified maintenance kit.




Figure 4-8.1. Detector circuit check, test setup, modified maintenance kit.

4-12. Detector Circuit Check*a. Test Equipment and Material.*

- (1) Radio Set AN/ARC-134.
- (2) Power supply.
- (3) Ac power source (unmodified equipment).
- (4) Wattmeter, Radio Frequency AN/URM-43A.
- (5) Generator, Signal AN/URM-127.
- (6) Multimeter TS-352B/U.
- (7) Adapter.
- (8) Two (2) coaxial connectors,
- (9) One (1) length of cable.
- (10) Capacitor, 50- μ f, 25-vdc,

b. Test Connections and Conditions. Connect the equipment as shown in figure 4-8 or 4-8.1. On modified equipment, place the C-1611D/AIC PVT-INT switch in position 3, the RECEIVERS 3 switch ON, all other RECEIVERS switches off, and position the VOL control as required. These settings must be maintained during the test.

c. Procedure.

Step No.	Control settings		Test procedure	Performance standards
	Test equipment	Equipment under test		
1	AN/ARC-134 Set meter switch to MOD 1. AN/URM-43A Set to HIGH TS-352B/U a. Function: OUTPUT a. Function: OUTPUT b. Range scale: 10 vac. AN/URM-127 Set frequency to 1,000 Hz.	Set all test panel switches to OFF, and set EXT. SQUELCH CONT. fully counter-clockwise.	a. Apply primary operating power to test equipment and maintenance kit and allow a few minutes warmup period before proceeding. b. Set the maintenance kit POWER switch to ON, VHF COMM OFF-PWR switch to PWR, and the VHF COMM frequency-selector switches to 132.500 MHz. c. Set maintenance kit PTT switch to ON and increase AN/URM-127 output level.	a. None. b. None. c. Modulation should be indicated by 2 meter deflection on the TS-352B/U and by an increase on the AN/URM-43A.

4-13. Test Data Summary

Personnel may find it convenient to arrange the checklist in a manner similar to that shown below. The data in the checklist may then be used, as a check against the test results, the next time the tests are performed.

a. Receiver Circuit Test No. 1.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-5 c.

<i>Step No.</i>	<i>Test indication</i>
2	Maintenance kit POWER indicator lamps illuminated.
3 a.	Indicator lamps behind Maintenance kit VHF COMM frequency counter dials illuminated.
4	Output indication on TS-352B/U.

b. Receiver Circuit Test No. 2.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-6 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. Output indication on TS-352B/U.
2 a.	Headset signal obtained.
	b. Headset signal again obtained.
3 a.	AN/USM-44 output level not greater than 1 uv.
4 b.	AN/USM-44 output level not greater than 100 uv.
	Tone obtained in headset at each respective frequency.

c. Transmitter Output and Control Circuit Test.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-7 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. Output indication on AN/URM-43A.

d. Sidetone Circuit Check.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-8 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. AN/ARC-134 sidetone heard in headset.
2	Meters on AN/ARC-134 and test panel fluctuate with modulation.

e. Modulation Check, MIKE INPUT Circuit.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-9 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. Modulation indication is obtained on AN/ARC-134 meter.

f. Modulation Check, Ø DBM INPUT Circuit.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-10 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. Modulation indication is obtained on AN/ARC-134 meter.

g. Modulation Check, DATA LINK INPUT Circuit.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-11 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. Modulation indication is obtained on AN/ARC-134 meter.

h. Detector Circuit Check.

Note. The references in the *Step No.* column below are references to the *Step No.* column in paragraph 4-12 c.

<i>Step No.</i>	<i>Test indication</i>
1 a.	None.
	b. None.
	c. Modulation is indicated by a meter deflection on the TS-352B/U and by an increase in the indication of the AN/URM-43A.

CHAPTER 5
DEPOT OVERHAUL STANDARDS

5-1. Applicability of Depot Overhaul Standards

The maintenance kit must be tested thoroughly after repair or overhaul to insure that it meets adequate performance standards for return to stock and reissue. Use the tests described in this chapter to measure the performance of the repaired or overhauled maintenance kit. It is mandatory that equipment repaired for reissue, or return to stock for reissue, meet all of the performance standards given in this chapter.

5-2. Applicable References

a. *Repair Standards.* Applicable procedures

Nomenclature	Federal stock No.	Technical manual
Radio Set AN/ARC-134	5821-072-6018	TM 11-5821-277-35
Generator, Signal AN/USM-44	6625-539-9685	TM 11-6625-508-10
Generator, Signal AN/URM-127	6625-783-5965	TM 11-6625-683-15
Power Supply PP-3931/FLR-9 (V) or equal -----	6130-733-3638	
Power source: 5 volts ac; Stancor Type P6467, or equal (unmodified equipment).		
Microphone M-52A/U (unmodified equipment) . -----	5965-646-4678	
Headset H-216/U, with Cord CD-307 (FSN 5995-553-0066) (unmodified equipment).	5965-892-3353	
Wattmeter, Radio Frequency AN/URM-43A . . . -----	6625-557-0389	
Multimeter TS-352B/U -----		TM 11-6626-366-16
Coaxial Adapter UG-201/U.		
Coaxial Connector UG-88/U (two required).		
Capacitor, 50- μf, 25-Vdc, Sprague Type TL1209, or equal.		
Coaxial Cable RG-58/U (as required).		

5-4. General Test Requirements

Most of the tests will be performed under the conditions given below. Testing will be simplified if connections and control settings are initially made and then changed as required for the individual tests.

of the depot performing this test and its general standards for repaired electronic equipment given in TB SIG 355-1, TB SIG 356-2, and TB SIG 355-3 form a part of the requirements for testing this equipment.

b. *Modification Work Orders.* Perform all modification work orders applicable to this equipment before making the tests specified. DA Pam 310-7 lists all available MWO'S.

5-3. Test Facilities Required

The following items (or equivalent) are equipped for depot testing.

- a. Connect the equipment as shown in figures 4-1 or 4-1.1.
- b. For all tests with modified kits, set the intercom control PVT-INT switch to 3, RECEIVERS switch 3 to ON, all other RECEIVERS switches off, and position the VOL control as required.

c. Set the test panel controls as follows:

<i>Control</i>	<i>Position</i>
EXT SQUELCH CONT (switch)	OFF
SQUELCH DISABLE	OFF
AUDIO	OFF
PTT	OFF
EXT SQUELCH CONT (pot.)	Fully counter-clockwise.
POWER	ON
VHF COMM OFF-PWR	PWR
VHF COMM VOL	Fully clockwise

d. Set the AN/ARC-134 meter switch to LINE V.

e. Apply primary operating power to the maintenance kit and adjust the primary direct-current (dc) supply to 27.5 volts dc. The AN/ARC-134 meter should indicate 27.5 volts dc. The maintenance kit POWER lamps should light, and the indicator lamps behind the VHF COMM frequency counter dials should light.

5-5. Receiver Control Circuit Check at 132.50 MHz

a. Set the TS-352B/U to read ac volts and connect to the maintenance kit RECEIVER OUTPUT jacks.

CAUTION

In *b* below, be sure to connect the 700061-0001 fuse holder between the AN/USM-44 output receptacle and maintenance kit antenna connector J1. The fuse holder should be equipped with a 700061-002 fuse. Do not press the microphone PTT switch or set the maintenance kit PTT switch to ON when the AN/USM-44 is connected to J1.

b. Set the AN/USM-44 for a 132.50-MHz signal, modulated 90 percent at 1,000 Hz, and set the output attenuator for a 6-microvolt output.

c. Set the VHF COMM frequency selector switches to 132.50 MHz. An output should be indicated on the TS-352B/U.

d. Connect the TS-352B/U to the DATA LINK OUTPUT jacks. The indicated voltage should be considerably lower than that in *c* above.

5-6. Receiver Audio Output Checks

a. Connect the headset to the maintenance kit RECEIVER jack (unmodified equipment).

b. Set the AUDIO switch to ON. A signal should be audible in the headset.

c. Set the EXT SQUELCH CONT switch to ON, and adjust EXT SQUELCH CONT until the signal just disappears.

d. Press the COMM TEST switch. The signal should again be heard, indicating that the AN/ARC-134 squelch circuit is disabled. Release the COMM TEST switch.

5-7. Squelch Control Circuit Checks

a. Set the maintenance kit EXT SQUELCH CONT switch to ON.

b. Adjust the AN/USM-44 output attenuator for a 0-microvolt output.

c. Increase the AN/USM-44 level until the squelch just opens as indicated by the presence of a tone in the headset. The AN/USM-44 output level should not be greater than 1 microvolt.

d. Set the AN/USM-44 output level to 0 microvolt. Adjust the EXT SQUELCH CONT fully clockwise. Increase the AN/USM-44 output until the squelch opens. The AN/USM-44 output level should not be greater than 100 microvolt.

5-8. Channel Selection Checks

a. Set the EXT SQUELCH CONT switch to OFF. Adjust the AN/USM-44 output attenuator for a 3-microvolt output.

b. Set the AN/USM-44 and the VHF COMM frequency selector switches on the maintenance kit to each of the following frequencies and check for proper frequency selection as indicated by the presence of a tone in the headset: 116.00 MHz, 126.00 MHz, 136.00 MHz, 146.00 MHz, 147.00 MHz, 148.00 MHz, 149.00 MHz, 140.00 MHz, 141.00 MHz, 142.00 MHz, 143.00 MHz, 144.00 MHz, 145.00 MHz, 145.10 MHz, 145.20 MHz, 145.30 MHz, 145.40 MHz, 145.50

MHz, 145.60 MHz, 145.70 MHz, 146.80 MHz, 145.90 MHz, and 145.95 MHz.

c. Disconnect the AN/USM-44, H-216/U, and TS-352B/U from the maintenance kit.

5-9. Transmitter Output and Control Circuit Check

a. Connect the equipment as shown in figure 4-3.

b. Set the VHF COMM frequency selector switches to 132.50 MHz.

c. Set the PTT switch to ON. A power output should be indicated on the AN/USM-43A.

d. Set the PTT switch to OFF.

5-10. Sidetone Check

a. Connect the microphone to the MIKE jack (unmodified equipment).

b. Connect the headset to the SIDETONE jack (unmodified equipment).

c. Key the AN/ARG134; sidetone should be heard in the headset. Release the microphone switch.

5-11. Modulation Checks

a. Set the AN/ARC-134 meter switch to MOD 1.

b. Key the AN/ARC-134 with the microphone switch and talk into the microphone. The AN/ARC-134 meter indication should vary with modulation.

c. Connect the AN/URM-127 through a blocking capacitor (50 microfarads (μ f)), as shown in figure 4-5, to the MIKE INPUT jacks.

d. Adjust the AN/URM-127 frequency to 1,000 Hz.

e. Set the PTT switch to ON and increase the output level of the AN/URM-127. A modulation indication should be observed on the AN/ARC-134 meter.

f. Repeat *e* above with the AN/URM-127 connected first to the Ø DBM INPUT jacks and then to the DATA LINK INPUT jacks.

g. Set the PTT switch to OFF.

5-12. Detector Circuit Checks

a. Connect the equipment as shown in figure 4-8.

b. Connect the TS-352B/U to the DETECTOR METER jacks and set the TS-352B/U to the 10-volt range on the OUTPUT scale.


c. Disconnect antenna connector J1 from the AN/URM-43A and connect J1 to DETECTOR INPUT receptacle.

d. Connect the AN/URM-43A to the SCOPE OUTPUT receptacle.

e. Set the PTT switch to ON and increase the AN/URM-127 output level. Modulation should be indicated by a meter deflection on the TS-352B/U by an increase in the AN/URM-43A indication.

f. Set the PTT switch to OFF.


COLOR CODE MARKING FOR MILITARY STANDARD RESISTORS



COLOR CODE TABLE

BAND A		BAND B		BAND C		BAND D*	
COLOR	FIRST SIGNIFICANT FIGURE	COLOR	SECOND SIGNIFICANT FIGURE	COLOR	MULTIPLIER	COLOR	RESISTANCE TOLERANCE (PERCENT)
BLACK	0	BLACK	0	BLACK	1		
BROWN	1	BROWN	1	BROWN	10		
RED	2	RED	2	RED	100		
ORANGE	3	ORANGE	3	ORANGE	1,000		
YELLOW	4	YELLOW	4	YELLOW	10,000	SILVER	± 10
GREEN	5	GREEN	5	GREEN	100,000	GOLD	± 5
BLUE	6	BLUE	6	BLUE	1,000,000		
PURPLE (VIOLET)	7	PURPLE (VIOLET)	7				
GRAY	8	GRAY	8	SILVER	0.01		
WHITE	9	WHITE [†]	9	GOLD	0.1		

EXAMPLES OF COLOR CODING



*If Band D is omitted, the resistor tolerance is ± 20%, and the resistor is not Mil-Std.


STD-R2

STD-R2


Figure 5-1. Color code marking for MIL-STD resistors.

COLOR CODE MARKING FOR MILITARY STANDARD CAPACITORS


GROUP I Capacitors, Fixed, Various-Dielectrics, Styles CM, CN, CY, and CB



GROUP II Capacitors, Fixed Ceramic-Dielectric (General Purpose) Style CK



GROUP III Capacitors, Fixed, Ceramic-Dielectric (Temperature Compensating) Style CC



COLOR CODE TABLES

TABLE I - For use with Group I, Styles CM, CN, CY and CB

COLOR	MIL ID	1st SIG FIG	2nd SIG FIG	MULTIPLIER ¹	CAPACITANCE TOLERANCE				CHARACTERISTIC ²				DC WORKING VOLTAGE		OPERATING TEMP. RANGE		VIBRATION GRADE
					CM	CN	CY	CB	CM	CN	CY	CB	CM		CM		
BLACK	CM, CY, CB	0	0	1			± 20%	± 20%		A					-55° to +70°C		10-55 gps
BROWN		1	1	10					B	E		B			-55° to +85°C		
RED		2	2	100	± 1%		± 2%	± 2%	C		C						
ORANGE		3	3	1,000		± 30%			D			D	300				
YELLOW		4	4	10,000					F				500		-55° to +125°C		10-2,000 gps
GREEN		5	5		± 5%												
BLUE		6	6												-55° to +150°C		
PURPLE (VIOLET)		7	7														
GREY		8	8														
WHITE		9	9														
GOLD				0.1			± 5%	± 5%									
SILVER	CN				± 10%	± 10%	± 10%	± 10%									


TABLE II - For use with Group II, General Purpose, Style CK

COLOR	TEMP. RANGE AND VOLTAGE - TEMP. LIMITS ³	1st SIG FIG	2nd SIG FIG	MULTIPLIER ¹	CAPACITANCE TOLERANCE	MIL ID
BLACK		0	0	1	± 20%	
BROWN	AW	1	1	10	± 10%	
RED	AX	2	2	100		
ORANGE	BK	3	3	1,000		
YELLOW	AY	4	4	10,000		CK
GREEN	CZ	5	5			
BLUE	BY	6	6			
PURPLE (VIOLET)		7	7			
GREY		8	8			
WHITE		9	9			
GOLD						
SILVER						

TABLE III - For use with Group III, Temperature Compensating, Style CC

COLOR	TEMPERATURE COEFFICIENT ⁴	1st SIG FIG	2nd SIG FIG	MULTIPLIER ¹	CAPACITANCE TOLERANCE	MIL ID
BLACK	0	0	0	1	Capacitances over 10uuf Capacitances 10uuf or less	CC
BROWN	± 30	1	1	10	± 1%	
RED	± 80	2	2	100	± 2%	± 0.25uuf
ORANGE	± 120	3	3	1,000		
YELLOW	± 220	4	4			
GREEN	± 320	5	5		± 3%	± 0.5uuf
BLUE	± 470	6	6			
PURPLE (VIOLET)	± 750	7	7			
GREY		8	8	0.01		
WHITE		9	9	0.1	± 10%	
GOLD	± 100					± 1.0uuf
SILVER						

1. The multiplier is the number by which the two significant (SIG) figures are multiplied to obtain the capacitance in uuf.
2. Letters indicate the Characteristics designated in applicable specifications: MIL-C-5, MIL-C-91, MIL-C-11272, and MIL-C-10950 respectively.
3. Letters indicate the temperature range and voltage-temperature limits designated in MIL-C-11015.
4. Temperature coefficient in parts per million per degree centigrade.




BAND A		BAND B		BAND C	
COLOR	FIRST SIGNIFICANT FIGURE	COLOR	SECOND SIGNIFICANT FIGURE	COLOR	MULTIPLIER
BLACK	0	BLACK	0	BLACK	1
BROWN	1	BROWN	1	BROWN	10
RED	2	RED	2	RED	100
ORANGE	3	ORANGE	3	ORANGE	1,000
YELLOW	4	YELLOW	4	YELLOW	10,000
GREEN	5	GREEN	5	GREEN	100,000
BLUE	6	BLUE	6	BLUE	1,000,000
PURPLE (VIOLET)	7	PURPLE (VIOLET)	7		
GRAY	8	GRAY	8	GRAY	0.01
WHITE	9	WHITE	9	WHITE	0.1

TM6625-1635-35-45

TM 6625-1635-35-45

Figure 5-3. Color code marking for diode CR1.

1	Receptacle cap	74	Not used
2	Washer, fiber 0.875 id	75	Retaining ring
3	Rubber ring	76	Washer, 0.125 id, 0.010 thk
4	Panel lamp	77	Shaft, frequency-selector
5	Front panel	78	Screw, special 6-32 fillister-head turned down to 0.188-0.010 head diameter
6	Screw, 4-40 by 1/4	79	Same as 78
7	Top cover	80	Nut, 6-32
8	Screw, 4-40 by 1/4	81	Lockwasher, No. 6
9	Bottom cover	82	Plate
10	Rubber cover	83	Washer, 0.125 id, 0.010 thk
11	Screw, 6-32 by 5/16	84	Insulator, spacer, 0.250 id, 0.187 lg
12	Retaining tab	85	Switch section S4B
13	VHF COMM indicator lamp	86	Insulator, spacer, 0.140 id, 0.156 lg
14	Rear gear plate	87	Insulator, spacer, 0.140 id, 0.125 lg
15	Rubber cover	88	Switch section S4A
16	Screw, 6-32 by 5/16	89	Insulator, spacer, 0.140 id, 0.156 lg
17	Retaining tab	90	Insulator, spacer, 0.140 id, 0.125 lg
18	VHF NAV indicator lamp	91	Switch section S3A
19	Rear gear plate	92	Gear assembly
20	Knob	92A	Spur gear
21	Knob	92B	Spur gear
22	Knob	93	Insulator, spacer, 0.140 id, 0.250 lg
23	Mounting plate	94	Not used
24	Screw, 4-40 by 5/8	95	Retaining ring
25	Spacer, standoff	96	Washer, 0.125 id, 0.80 thk
26	Spur gear	97	Shaft, frequency-selector
27	Nut	98	Screw, special 6-32 fillister head turned down to 0.188-0.010 head diameter
28	Washer	99	Same as 98
29	Switch S6	100	Screw, 4-40 by 1/4
30	Spur gear	101	Screw, 4-40 by 1/4
31	Nut	102	Screw, 4-40 by 1/4
32	Washer	103	Screw, 4-40 by 1/4
33	VOL control R1	104	Support member, upper right
34	Front gear plate	105	Support member, lower
35	Mounting plate	106	Support member, upper left
36	Screw, 4-40 by 1/4	107	Support member, lower
37	Spacer, standoff	107A	Screw, 4-40 by 5/16
38	Spur gear	108	Washer, No. 4
39	Nut	109	Screw, 4-40 by 5/16
40	Washer	110	Washer, No. 4
41	Switch S7	111	Screw, 4-40 by 5/16
42	Nut	112	Washer, No. 4
43	Not used	113	Screw, 4-40 by 5/16
44	Switch S5	114	Washer, No. 4
45	Screw, 4-40 by 1/4	115	Lamp receptacle
46	Lockwasher, No. 4	116	Lamp receptacle
47	Rear plate	117	Lamp receptacle
48	Screw, 4-40 by 5/16	118	Nut
49	Nut, self-locking, 4-40	119	Washer
50	Screw, 4-40 by 5/16	120	Nut
51	Nut, self-locking, 4-40	121	Spur gear
52	Connector J1, PTO2A-20-39PY	122	Insulator, spacer
53	Connector J2, PTO2A-20-39PZ	123	Helical gear
54	Bracket	124	Detent wheel, 8 point
55	Nut, 6-32	125	Washer, flat, 0.187 id, 0.010 thk
56	Lockwasher, No. 6	126	Washer, flat, 0.187 id, 0.031 thk
57	Plate	127	Washer, flat, 0.187 id, 0.010 thk
58	Washer, 0.125 id	128	Gear assembly, fraction mc
59	Washer, 0.25 id	129	Gear shaft
60	Insulator, spacer, 0.125 lg	130	Spur gear
61	Switch section S2B	131	Insulator, spacer
62	Insulator, spacer, 0.187 lg	132	Helical gear
63	Switch section S2A	133	Detent wheel, 10-point
64	Gear assembly	134	Washer, 0.187 id, 0.010 thk
64A	Gear, driving	135	Washer, 0.187 id, 0.031 thk
64B	Gear, spur	136	Stop washer
65	Insulator, spacer, 0.250 lg	137	Cam
66	Insulator, spacer, 0.218 lg	138	Gear assembly
67	Washer, 0.125 id, 0.010 lg	139	Gear shaft
68	Washer, 0.125 id, 0.030 lg	140	Screw, 4-40 by 5/16
69	Switch section S1B	141	Washer, No. 4
70	Insulator, spacer, 0.140 id, 0.187 lg	142	Washer, No. 4
71	Switch section S1A	143	Spacer, sleeve
72	Gear assembly	144	Detent arm
72A	Gear, composite	145	Spring, helical extension
72B	Gear, spur		
73	Insulator, spacer, 0.140 id, 0.125 lg		



NOTES
 1. ○ INDICATES SWITCH SECTION TERMINAL NUMBERS.
 2. [] INDICATES THAT NUMBER AND THICKNESS OF WASHERS USED AT THESE POINTS VARY BETWEEN UNITS.

146	Screw, 4-40 by 5/16	212	Gear assembly
147	Washer, No. 4	213	Flanged hub
148	Washer, No. 4	214	Pinion gear
149	Spacer, sleeve	215	Flanged hub
150	Detent arm	216	Helix gear
151	Spur gear	217	Washer, 0.125 id, 0.21875 od, 0.10 thk
152	Insulator, spacer	218	Flanged hub
153	Helical gear	219	Pinion gear
154	Detent wheel, 10-point	220	Washer, 0.125 id, 0.21875 od, 0.010 thk
155	Washer, 0.186 id, 0.010 thk	221	Flanged hub
156	Washer, 0.187 id, 0.010 thk	222	Helix gear
157	Gear assembly, whole mc	223	Washer, 0.125 id, 0.21875 od, 0.010 thk
158	Gear shaft	224	Screw, 4-40 by 5/16
159	Helical gear	225	Washer, No. 4
160	Detent wheel, 8-point	226	Terminal lub
161	Washer, 0.187 id, 0.010 thk	227	Screw, 4-40, Phillips fillister-head, 0.156 ±0.003 dia hd
162	Washer, 0.187 id, 0.010 thk	228	Stop plate, navigation
163	Washer, 0.187 id, 0.031 thk	229	Screw, 4-40 by 5/16
164	Gear assembly, fraction mc	230	Washer, No. 4
165	Gear shaft	231	Gear plate
166	Screw, 4-40 by 5/16	232	Gear plate
167	Washer, No. 4	233	Screw, 4-40 by ¼
168	Washer, No. 4	234	Spacer, sleeve
169	Spacer, sleeve	234A	Screw, 2-56 by 3/16
170	Detent arm	235	Dial, segment
171	Spring, helical extension	235A	Washer, flat, stl, cres, 0.250 od, 0.111 id, 0.010 thk
172	Screw, 4-40 by 5/16	236	Detent plate
173	Washer, No. 4	237	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg
174	Washer, No. 4	238	Spring, detent
175	Spacer, sleeve	239	Ball bearing
176	Detent arm	240	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg
177	Screw, 4-40 by 5/16	241	Spring, detent
178	Washer, No. 4	242	Ball bearing
179	Screw, 4-40 fillister-hd with 0.156 ±0.003 dia head	243	Screw, 2-56 by 3/16
180	Stop plate, communication	244	Washer, flat, stl, cres, 0.250 od, 0.111 id, 0.010 thk
181	Screw, 4-40 by 5/16	245	Detent plate
182	Washer, No. 4	246	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg
183	Terminal lug	247	Spring, detent
184	Gear plate	248	Ball bearing
185	Gear plate	249	Screw, 0-80 roundhead, 0.63 ±0.010 —0.000 lg
186	Screw, 4-40 by ¼	250	Spring, detent
187	Spacer, sleeve	251	Ball bearing
188	Dial, segment	252	Retaining ring
189	Screw, 2-56 by 3/16	253	Retaining ring
190	Washer, flat, stl, cres, 0.250 od, 0.111 id, 0.010 thk	254	Shaft, dial support
191	Detent plate	255	Dial assembly
192	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg	256	Washer, 0.125 id, 0.21875 od, 0.030 thk
193	Spring, detent	257	Dial assembly
194	Ball bearing	258	Flanged hub
195	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg	259	Pinion gear
196	Spring, detent	260	Flanged hub
197	Ball bearing	261	Helix gear
198	Screw, 2-56 by 3/16	262	Washer, 0.125 id, 0.21875 od, 0.010 thk
199	Washer, flat, stl, cres, 0.250 od, 0.111 id, 0.010 thk	263	Flanged hub
200	Detent plate	264	Pinion gear
201	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg	265	Washer, 0.125 id, 0.21875 od, 0.010 thk
202	Spring, detent	266	Flanged hub
203	Ball bearing	267	Helix gear
204	Screw, 0-80 roundhead, 0.063 ±0.010 —0.000 lg	268	Washer, 0.125 id, 0.21875 od, 0.010 thk
205	Spring, detent	269	Setscrew
206	Ball bearing	270	Setscrew
207	Retaining ring	271	Setscrew
208	Retaining ring	272	Setscrew
209	Shaft, dial support	273	Setscrew
210	Gear assembly	274	DZUS fasteners

Figure 5-4. Radio control, exploded view.




Figure 5-5. Test panel (modified), schematic diagram.

APPENDIX A

REFERENCES

Following is a list of applicable references available to the direct support, general support, and depot maintenance repairmen of Maintenance Kit, Electronic Equipment MK-1004/ARC:

DA Pam 310-4	Index of Technical Manuals, Technical Bulletins, Supply Manuals (types 7, 8, and 9), Supply Bulletins, and Lubrication Orders.
DA Pam 310-7	US Army Equipment Index of Modification Work Orders.
TB SIG 355-1	Depot Inspection Standard for Repaired Signal Equipment.
TB SIG 355-2	Depot Inspection Standard for Refinishing Repaired Signal Equipment.
TB SIG 355-3	Depot Inspection Standard for Moisture and Fungus Resistant Treatment.
TB 746-10	Field Instructions for Painting and Preserving Electronics Command Equipment.
TM 11-5821-277-20	Organizational Maintenance Manual: Radio Sets AN/ARC-134, AN/ARC-134A, and AN/ARC-134B.
TM 11-5821-27735	DS, GS, and Depot Maintenance Manual (Including Repair Parts and Special Tools List): Radio Sets AN/ARC-134, AN/ARC-134A, and AN/ARC-134B.
TM 11-5831-201-20	Organizational Maintenance Manual: Control, Intercommunication Set C-1611D/AIC and Discriminator, Discrete Signal MD-736/A.
TM 11-6625-666-15	Operator's, Organizational, DS, GS, and Depot Maintenance Manual: Multimeter TS-352B/U.
TM 11-6625-508-10	Operator's Manual: Signal Generators AN/USM-44 and AN/USM-44A.
TM 11-6625-683-15	Operator, Organizational, Direct Support, General Support, and Depot Maintenance Manual: Signal Generator AN/URM-127.
TM 11-6625-1635-12	Operator's and Organizational Maintenance Manual Including Repair Parts and Special Tool Lists: Maintenance Kit, Electronic Equipment MK-1004/ARC.

APPENDIX B

DS, GS, AND DEPOT REPAIR PARTS

Section I. INTRODUCTION

B-1. Scope

This appendix contains a list of repair parts required for the performance of direct support, general support, and depot maintenance for Maintenance Kit, Electronic Equipment MK-1004/ARC.

Note. No special tools, test, and support equipment are required.

B-2. General

The repair parts list is divided into the following sections:

a. Repair Parts for Direct Support, General Support, and Depot Maintenance, Section II. Repair parts authorized for direct support, general support, and depot maintenance are included in this section.

Note. All indexes noted below are cross referenced to index numbers. The index numbers appear in ascending sequence in column 3 of the repair parts list (para B-3 c). The index number for the particular item will be the same for the item in all sections of this publication.

b. Federal Stock Number Cross-Reference to Index Number, Section III. This is a cross-reference index of Federal stock numbers and manufacturer's part numbers to index numbers.

c. Figure and Item Number Cross-Reference to Index Number, Section IV. This is a cross-reference index of figure number and item number (or reference designation) to index number. The figure numbers are listed in numerical sequence; item numbers and/or reference designations are listed for each figure.

d. Reference Designation Cross-Reference to Index Number, Section V. This is a cross-reference index of reference designations and/or item numbers to index numbers.

B-3. Explanation of Columns

An explanation of the columns is given below.

a. Source, Maintenance, and Recoverability

Codes Column. This column lists the applicable SMR codes for the part.

(1) *Source code (A).* The selection status and source for the listed item is noted here. Source codes and their explanations are as follows:

Code	Explanation
P	Applies to repair parts that are stocked in or supplied from the GSA/DSA, or Army supply system, and authorized for use at indicated maintenance categories.
X1	Applies to repair parts that are not procured or stocked, the requirement for which will be supplied by the use of next higher assembly or component.
X2	Applies to repair parts that are not staked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
MD	Applies to repair parts that are not procured or stocked, but are to be fabricated by using units at depot.

(2) *Maintenance code (B).* The lowest category of maintenance authorized to install the listed item is noted here.

Code	Explanation
O	Organizational Maintenance
F	Direct Support Maintenance
H	General Support Maintenance

(3) *Recoverability code (C).* The information in this column indicates whether un-serviceable items should be returned for recovery or salvage. Recoverability code and its explanation is as follows:

Note. When no code is indicated in the recoverability column, the part will be considered expendable.

Code	Explanation
R	Applies to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.

b. Federal Stock Number Column. The Federal stock number for the item is listed in this column.

c. Description Column. The sequence number, Federal item name, a five-digit manufacturer's code, an indenture code, and a part number are included in this column. For subsequent appearances of the same item, the manufacturer's code and part number are omitted. The words "same as" followed by the sequence number assigned to the item when it first appeared in the list will follow the item name, e.g., "RESISTOR, FIXED, COMPOSITION: SAME AS A298." The indenture codes indicate the end item, the assemblies, and the component parts. Identical codes are parts of the preceding higher code. An asterisk (*) in the indenture code column indicates attaching hardware. Model column is not used.

d. Unit of Issue Column. The unit used as a basis of issue (e.g., ea, pr, ft, yd, etc.) is indicated in this column.

e. Quantity Incorporated in Unit Pack Column. The actual quantity contained in the unit pack is indicated in this column.

f. Quantity Incorporated in Unit Column. The quantity of repair parts in an assembly is given in this column. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF." An asterisk (*) indicates that the item may be requisitioned "as required."

g. Maintenance Allowances Column.

(1) The maintenance allowance columns are divided into subcolumns. Indicated in each subcolumn opposite the first appearance of the item is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have no entry in the allowance columns, but will have a reference in the description column to the first appearance of the item. Items authorized for use as required, but not for initial stockage, are identified with an asterisk (*) in the allowance column.

(2) The quantitative allowances for DS/GS categories of maintenance will represent initial stockage for a 30-day period for the number of equipments supported.

h. One-Year Allowances Per 100 Equipments/Contingency Planning Purposes Column. Opposite the first appearance of each item, the total quantity required for distribution and contingency planning purposes is indicated. The range of items indicates total quantities of all authorized items required to provide for adequate support of 100 equipments for 1 year.

i. Depot Maintenance Allowance Per 100 Equipments Column. This column indicates the total quantity of each item authorized depot maintenance for 100 equipments. Subsequent appearances of the same item will have no entry in this column, but will have a reference in the description column to the first appearance of the item.

j. Illustrations Column.

(1) *Figure number (A).* The number of the illustration in which the item is shown is indicated in this column.

(2) *Item or symbol number (B).* The reference designation or item number used to reference the item in the illustration appears in this column.

B-4. Location of Repair Parts

a. This manual contains three cross-reference indexes (sec. III, IV, and V), to be used to locate a repair part when either the Federal stock number, reference number (manufacturer's part number), figure number, or reference designation and/or item number is known. . The first column in each cross-reference index is prepared, as applicable, in numerical or alphanumerical sequence. The last column of each cross-reference index lists the index number assigned to the part.

b. Refer to the appropriate cross-reference index (para B-2 *b, c, d*) and note the index number in the last column; then refer to the repair parts list to locate the index number which is listed in ascending order in column 1 of the repair parts list.

B-5. Federal Supply Codes

This paragraph lists the Federal supply code and the associated manufacturer's name.

<i>Code</i>	<i>Manufacturer</i>
00779	AMP, Inc.
01121	Allen-Bradley Co.
05402	Controls Co. of America
08795	Rayclad Tubes, Inc.
08800	General Electric Co., Insulating Materials Dept.
14370	Continental Rubber Works
15909	Daven Div. Thomas A. Edison Industries, McGraw-Edison Co.
28307	Bradley Industries
28480	Hewlett-Packard Co.
37942	Mallory, P. R. & Co., Inc.
41340	Montgomery Ward & Co., Inc.
58474	Superior Electric Co.
65597	Wilcox Electric Co., Inc.
71041	Boston Gear Works Div. of Murray Co. of Texas
71124	Brand-Rex Division, American Enka Corp.
71279	Cambridge Thermionic Corp.
71400	Bussman Mfg. Div. of McGraw-Edison Co.
71468	ITT Cannon Electric, Inc.
71744	Chicago Miniature Lamp Works
71785	Cinch Mfg. Co. and Howard B. Jones Div.
71984	Dow Corning Corp.
72136	Electro Motive Mfg. Co., Inc.

<i>Code</i>	<i>Manufacturer</i>
72619	Dialight Corp.
72794	Dzus Fastener Co., Inc.
72914	Grimes Mfg. Co.
72962	Elastic Stop Nut Corp. of America
72982	Erie Technological Products, Inc.
73957	Groov-Pin Corp.
74284	Skydyne, Inc.
75382	Kulka Electric Corp.
76545	Mueller Electric Co.
77820	Bendix Corp., The Electrical Components Div.
78189	Shakeproof Div. of Illinois Tool Works, Inc.
79136	Waldes Kohinoor, Inc.
79963	Zierick Mfg. Corp.
81343	Society of Automotive Engineers
81348	Federal Specifications
81349	Military Specifications
82104	Standard Grigsby Co.
82110	Gudebrad Bros. Silk Co., Inc.
83259	Parker Seal Co.
88044	Aeronautical Standards Group
93332	Sylvania Electric Products, Inc., Semiconductor Products Div.
96906	Military Standards
97539	APM-Hexseal Corp.
98291	Sealectro Corp.

B

[illegible]

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						IND CD	(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						1 YR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
															DS			GS								
				1	2	3	4	5	6						(A)	(B)	(C)	(A)	(B)	(C)						
X1	F								C	A016 GEAR, BEVEL: 65597; 072565-0001	ea		1													
X1	F		4920-627-8271						D	A017 GEAR, BEVEL: 71041; G460Y	ea		1													
X1	F								C	A018 GEAR, BEVEL: 65597; 072566-0001	ea		1													
X1	F		4920-627-8271						D	A019 GEAR, BEVEL: Same as A017	ea		1													
P	F		5305-866-2765						C	A020 SETSCREW: 96906; MS51053-102	ea		2	*	*	*	*	*	*	5	20					
P	F		5826-948-5286						C	A021 SHIM: 65597; 270214-2	ea		*	*	*	*	*	*	*	5	24					
NO	O								C	A022 TAG, CAUTION: 65597; 104826-0001	ea		1													
P	O								C	A023 TWINE, NYLON: 81349; MILT713, type P, class S2 waxed	ft		2	*	*	*	*	*	*	4	20					
E	F		5330-784-918						C	A024 WASHER, NONMETALLIC: 65597; 76029	ea		1	*	*	*	*	*	*	4	15					
P	F		5905-073-8220						B	A025 ATTENUATOR, FIXED: 65597; 700060-0002	ea		1	*	*	*	*	*	*	4	10	(-12 1-3)				
X1	F		6680-527-6045						C	A026 ATTENUATOR, FIXED: 28480; 505B	ea		1													
P	O		5115-708-0116						B	A027 BOX, PLASTIC, SMALL PARTS: 65597; 083447-0001	ea		1	*	*	*	*	*	*	5	4	(-12 1-4)				
X1	O								C	A028 BOX, PLASTIC, SMALL PARTS: 28307; 12CD	ea		1													
P	O		5115-708-011						B	A029 BOX, PLASTIC, SMALL PARTS: 65597; 083448-0001	ea		1	*	*	*	*	*	*	5	4	(-12 1-4)				
X1	O								C	A030 BOX, PLASTIC, SMALL PARTS: Same as A028	ea		1													

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW						1 YR. ALW PER 100 EQUIP. CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
SOURCE CD	MAINT. CD	REC. CODE		IND CD										DS			GS								
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	O		8115-708-0084						B	A031	ea		1	*	*	*	*	*	*	5	4	(-1- 1-3)			
X2	F		5821-933-9607						B	A032	ea		1												
P	H		3110-915-5572						C	A034	ea		8				*	*	2	16	48	(-35 5-4)	194, 197, 203 206, 239, 242 248, 251		
P	F		6250-604-0752						C	A035	ea		3	*	2	2	*	2	2	18	15	(-35 5-4)	115, 116, 117		
P	H		5821-738-2856						C	A036	ea		1				*	*	*	5	3				
P	H		5305-054-5648						*	A037	ea		2				*	2	2	40	280	(-35 5-4)	113		
P	H		5310-965-1805						*	A038	ea		2				*	2	2	35	300	(-35 5-4)	114		
X1	H								D	A039	ea		1									(-35 5-4)	185		
X1	H								D	A040	ea		1									(-35 5-4)	188		
X1	H								D	A041	ea		1									(-35 5-4)	222		
X1	H								D	A042	ea		1									(-35 5-4)	219		
X1	H								D	A043	ea		1									(-35 5-4)	191		
P	H								D	A044	ea		2				*	*	*	8	30	(-35 5-4)	186		
P	H								D	A045	ea		2				*	*	2	16	80	(-35 5-4)	192, 195		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7) 30 DAY MAINT. ALW.						(8)	(9)	(10) ILLUSTRATIONS	
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	DS			GS			1 YR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
SOURCE CD	MAINT. CD	REC. CODE		1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)	
P	H		5305-054-5636							D A046	SCREW, MACHINE: 96906; MS51957-2	ea	2				*	*	2	16	80	(-35 5-4)	189		
P	H										D A047	SETSCREW: 65597; 302720-1	ea	2				2	2	2	60	410	(-35 5-4)	269	
P	H										D A048	SPACER, SLEEVE: 65597; 270255-1	ea	2				*	*	*	10	40	(-35 5-4)	187	
P	H										D A049	SPRING, FLAT: 65597; 61237-1	ea	1				*	*	*	5	8	(-35 5-4)	196	
P	H										D A050	SPRING, FLAT: 65597; 61239-1	ea	1				*	*	*	10	16	(-35 5-4)	193	
MD	H									D A051	STUD, TRANSFER PINION MOUNTING: 65597; 302019-1	ea	2									(-35 5-4)	218, 221		
P	H		5310-543-4652							D A052	WASHER, LOCK: 96906; MS35333-69	ea	2				*	*	2	16	80	(-35 5-4)	190		
P	H										D A053	WASHER, SPRING TENSION: 65597; 276367-0001	ea	2				*	*	2	16	120	(-35 5-4)	220, 223	
P	H		5821-736-5888							C A054	BLOCK, SUBASSEMBLY: 65597; 117444-1	ea	1				*	*	*	5	4				
P	H		5305-054-5648							* A055	SCREW, MACHINE: Same as A037	ea	2									(-35 5-4)	107A		
P	H		5310-965-1805							* A056	WASHER, LOCK: Same as A038	ea	2									(-35 5-4)	108		
X1	H									D A057	BLOCK, SWITCH MOUNTING, NAVIGATION, RIGHT: 65597; 77920-1	ea	1									(-35 5-4)	231		
X1	H									D A058	GEAR, HELICAL: 65597; 72539-1	ea	1									(-35 5-4)	261		
X1	H									D A059	GEAR, SPUR: 65597; 72543-1	ea	1									(-35 5-4)	259		
X1	H									D A060	PLATE, FRACTIONAL MC DIAL DETENT: 65597; 284526-1	ea	1									(-35 5-4)	245		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	(2) MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						(8) LYR. ALW PER 100 EQUIP CNTG CY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(10) ILLUSTRATIONS				
														DS			GS					(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER			
				1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)		
P	H		5305-054-5636						D	A061	SCREW, MACHINE: Same as A045	ea		2											(-35 5-4)	246, 249
P	H									D	A062	SCREW, MACHINE: Same as A046	ea		2										(-35 5-4)	243
P	H									D	A063	SETSCREW: Same as A047	ea		2										(-35 5-4)	270
P	H									D	A064	STUD, TRANSFER PINION MOUNTING: Same as A051	ea		2										(-35 5-4)	258, 260
P	H									D	A065	SPRING, FLAT: 65597; 61238-1	ea		1			*	*	*	5	8		(-35 5-4)	247	
P	H		5310-543-4652							D	A066	SPRING, FLAT: Same as A050	ea		1										(-35 5-4)	250
P	H									D	A067	WASHER, LOCK: Same as A052	ea		2										(-35 5-4)	244
P	H									D	A068	WASHER, SPRING: Same as A053	ea		2										(-35 5-4)	262
P	H		5821-736-5899							C	A069	BLOCK, SUBASSEMBLY: 65597; 117445-1	ea		1			*	*	*	5	4				
P	H		5305-054-5648							*	A070	SCREW, MACHINE: Same as A037	ea		2										(-35 5-4)	111
P	H		5310-965-1805							*	A071	WASHER, LOCK: Same as A038	ea		2										(-35 5-4)	112
X1	H									D	A072	BLOCK, SWITCH MOUNTING, COMMUNICATION, RIGHT: 65597; 77918-1	ea		1										(-35 5-4)	184
X1	H									D	A073	GEAR, HELICAL: Same as A058	ea		1										(-35 5-4)	216
X1	H									D	A074	GEAR, SPUR: Same as A059	ea		1										(-35 5-4)	214
X1	H									D	A075	PLATE, FRACTIONAL MC DIAL DETENT: Same as A060	ea		1										(-35 5-4)	200
P	H									D	A076	SCREW, MACHINE: Same as A045	ea		2										(-35 5-4)	201, 204

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE								(4)	(5)	(6)	(7)						(8)	(9)	(10)			
SOURCE CD	MAINT. CD	REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						1 YR. ALW PER 100 EQUIP CNTGTY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	ILLUSTRATIONS			
				1	2	3	4	5	6					IND CD	DS			GS				(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
															(A)	(B)	(C)	(A)	(B)					(C)	
P	H		5305-054-5636						D	A077	SCREW, MACHINE: Same as A046	ea		2										(-35 5-4)	198
P	H								D	A078	SETSCREW: Same as A047	ea		2										(-35 5-4)	271
P	H								D	A079	SPRING, FLAT: Same as A065	ea		1										(-35 5-4)	202
P	H								D	A080	SPRING, FLAT: Same as A050	ea		1										(-35 5-4)	205
P	H								D	A081	STUD, TRANSFER PINION MOUNTING: Same as A051	ea		2										(-35 5-4)	213, 215
P	H		5310-543-4652						D	A082	WASHER, LOCK: Same as A052	ea		2										(-35 5-4)	199
P	H								D	A083	WASHER, SPRING, TENSION: Same as A053	ea		2										(-35 5-4)	217
P	H		5821-736-5913						C	A084	BLOCK SUBASSEMBLY: 65597; 117446-1	ea		1			*	*	*	5	4				
P	H		5305-054-5648						*	A085	SCREW, MACHINE: Same as A037	ea		2										(-35 5-4)	109
P	H		5310-965-1805						*	A086	WASHER, LOCK: Same as A038	ea		2										(-35 5-4)	110
	H								D	A087	BLOCK, SWITCH MOUNTING NAVIGATION, LEFT: 65597; 77919-1	ea		1										(-35 5-4)	232
XI	H								D	A088	DIAL SEGMENT, NUMERAL ONE: Same as A040	ea		1										(-35 5-4)	235
XI	H								D	A089	GEAR, HELICAL: Same as A041	ea		1										(-35 5-4)	267
XI	H								D	A090	GEAR, SPUR: Same as A042	ea		1										(-35 5-4)	264
XI	H								D	A091	PLATE, WHOLE MC DIAL DETENT: Same as A043	ea		1										(-35 5-4)	236
P	H								D	A092	SCREW, MACHINE: Same as A044	ea		1										(-35 5-4)	233
P	H		5305-151-0206						D	A093	SCREW, MACHINE: 88044; AN505-2R7	ea		1			*	*	*	4	10			(-35 5-4)	

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7) 30 DAY MAINT. ALW.						(8)	(9)	(10) ILLUSTRATIONS	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UN PK	(6) QTY INC IN UNIT	DS			GS			(8) 1 YR. ALW PER 100 EQUIP CNTGY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)	
X1	H								D A111 DIAL ASSEMBLY, 25KC COMMUNICATION FREQUENCY SELECTOR: 65597; 118044-0001	ea		1													
X1	H								E A112 DIAL CONTROL: 65597; 82328-1	ea		1													
X1	H								F A113 DIAL BLANK, 25K: 65597; 82324-1	ea		1													
X1	H								E A114 SLEEVE SUBASSEMBLY, 25KC DIAL MOUNTING: 65597; 75631-1	ea		1													
X1	H								F A115 DETENT, DIAL: 65597; 10842-1	ea		1													
X1	H								F A116 DIAL MECHANISM BODY, FRACTIONAL MC: 65597; 77936-1	ea		1													
X1	H								F A117 DISC, DIAL LOCKING: 65597; 10837-1	ea		1													
X1	H								F A118 GEAR, DIAL DRIVING: 65597; 72541-1	ea		1													
X1	H								F A119 GEAR, HELICAL: 65597; 72544-1	ea		1													
X1	H								F A120 PIN, GROOVED, HEADLESS: 73957; GP1-047X312-12	ea		1													
X1	H								D A121 GEAR, SPUR: 65597; 75632-1	ea		1													
X1	H								D A122 WASHER, FLAT: 65597; 276343-1	ea		1													
X1	H								D A123 WASHER, SPRING: 65597; 276365-0001	ea		1													
P	H		5821-736-5879						C A124 DIAL ASSEMBLY: 65597; 117405-1	ea		2				*	*		5	5	(210)	255, 210			
X1	H								D A125 DIAL, CONTROL: 65597; 82327-1	ea		1													

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.			DS			GS			1 YR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER
SOURCE CD	MAINT. CD	REC. CODE		1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)	(C)						
X1	H								E	A142	DIAL BLANK, TENTHS: Same as A110	ea	1													
X1	H								D	A143	DIAL ASSEMBLY, 50KC NAVIGATION FREQUENCY SELECTOR: 65597; 118043-0001	ea	1													
X1	H								E	A144	DIAL, CONTROL: 65597; 82329-1	ea	1													
X1	H								F	A145	DIAL BLANK, 50KC: Same as A113	ea	1													
X1	H								E	A146	SLEEVE ASSEMBLY, 50KC DIAL MOUNTING: 65597; 75634-1	ea	1													
X1	H								F	A147	DETENT, DIAL: Same as A115	ea	1													
X1	H								F	A148	DIAL MECHANISM BODY, FRACTIONAL MC: Same as A116	ea	1													
X1	H								F	A149	DISC, DIAL LOCKING: 65597; 10839-1	ea	1													
X1	H								F	A150	GEAR, DIAL DRIVING: 65597; 72542-1	ea	1													
X1	H								F	A151	GEAR, HELICAL: Same as A119	ea	1													
X1	H								F	A152	PIN, GROOVED, HEADLESS: Same as A120	ea	1													
X1	H								D	A153	GEAR, SPUR: Same as A121	ea	1													
X1	H								D	A154	WASHER, FLAT: Same as A122	ea	1													
X1	H								D	A155	WASHER, SPRING: Same as A123	ea	1													
P	F		6210-725-6170						C	A156	HOLDER, LAMP: 72914; A5069-14	ea	3	*	2	2	*	2	2	18	30			(-35 5-4)	1	

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)			
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	(3) MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						1 YR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER				
														DS			GS										
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)								
MD	H								D	A175	PANEL, FRONT: 65597; 284481-1	ea		1												(-35 5-4)	34
P	F								D	A176	STUD ASSEMBLY, TURNLOCK FASTENER: 65597; 60695-1	ea		4	*	*	*	*	*	*	10	16			(-35 5-4)	274	
P	F		5325-989-6033						E	A177	EYELET, TURNLOCK FASTENER: 72794; PC3 1-2	ea		1	*	*	*	*	*	*	10	20					
P	F		5340-989-9948						E	A178	SPRING, HELICAL, COMP- RESSION: 72794; PS3 1-2	ea		1	*	*	*	*	*	*	10	20					
P	F		5325-543-2418						E	A179	STUD, TURNLOCK FASTENER: 72794; PF3 1-2 38	ea		1	*	*	*	*	*	*	10	16					
P	H		5821-736-5791						C	A180	PANEL, FRONT, PLASTIC: 65597; 284499-1	ea		1				*	*	*	4	6			(-35 5-4)	5	
XL	H								D	A181	PANEL, FRONT: 65597; 284480-1	ea		1													
XL	H								D	A182	WINDOW DIAL: 65597; 65776-1	ea		2											(-35 5-4)	275	
MD	F								C	A183	PLATE, IDENTIFICATION: 65597; 266023-0002	ea		1													
MD	F								C	A184	PLATE, RETAINING, ELECT- RICAL CONNECTOR: 65597; 284482-1	ea		1										(-35 5-4)	47		
MD	F								C	A185	PLATE, SLOT COVER STRIP: 65597; 284528-1	ea		1										(-35 5-4)	54		
MD	F								C	A186	POST, ELECTRICAL-MECHAN- ICAL EQUIPMENT: 65597; 77932-1	ea		1										(-35 5-4)	104		
MD	F								C	A187	POST, ELECTRICAL-MECHAN- ICAL EQUIPMENT: 65597; 77933-1	ea		1										(-35 5-4)	106		
MD	F								C	A188	POST ELECTRICAL-MECHAN- ICAL EQUIPMENT: 65597; 77934-1	ea		2										(-35 5-4)	105, 107		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
SOURCE CD	MAINT. CD	REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UN PK	(6) QTY INC IN UNIT	30 DAY MAINT. ALW.						(8) 1 YR. ALW PER 100 EQUIP CNTG CY PL	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(10) ILLUSTRATIONS			
														DS			GS					(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	F		5340-816-4239						C A189 RING, RETAINING: 79136; 5133-12ND	ea		4	*	*	2	*	*	2	13	30	(-35 5-4)	207, 208, 252 253			
P	F								C A190 SCREW, MACHINE: Same as A104	ea		8									(-35 5-4)	8, 100, 101, 102, 103			
P	F		5305-054-5635						C A191 SCREW, MACHINE: 96906; MS51957-1	ea		2	*	*	*	*	*	*	10	40					
P	F		5305-054-5646						C A192 SCREW, MACHINE: 96906; MS51957-12	ea		1	*	*	*	*	*	*	4	10					
P	F		5305-054-5648						C A193 SCREW, MACHINE: Same as A037	ea		4									(-35 5-4)	45			
P	H		3040-880-0497						C A194 SHAFT, STRAIGHT: 65597; 71595-1	ea		2				*	*	*	5	4	(-35 5-4)	209, 254			
MD	H								C A195 SPACER, SLEEVE: 65597; 270247-1	ea		4									(-35 5-4)	25, 37			
MD	H								C A196 STOP PLATE, NAVIGATION WHOLE MC: 65597; 284495-1	ea		1									(-35 5-4)	228			
MD	H								C A197 STOP PLATE, VHF COMMUNICATION WHOLE MC: 65597; 284494-1	ea		1									(-35 5-4)	180			
P	F		5930-723-4562						C A198 SWITCH, PUSH: 05402; B7001	ea		1	*	*	*	*	*	*	4	15	(-35 2-1 5-4)	55 44			
P	F		5930-998-7568						C A199 SWITCH ASSEMBLY: 65597; 117448-1	ea		1	*	2	2	*	*	2	12	15					
P	F		5310-857-5548						* A200 NUT, SELF-LOCKING, HEXAGON: 96906; MS21044-D04	ea		4	*	*	2	*	*	2	16	40	(-35 5-4)	49			
P	F		5305-054-5648						* A201 SCREW, MACHINE: Same as A037	ea		7									(-35 5-4)	48, 177, 181			
P	F		5305-054-5652						* A202 SCREW, MACHINE: 96906; MS51957-18	ea		2	*	*	*	*	*	*	10	40	(-35 5-4)	24			
P	F		5305-787-2202						* A203 SCREW, MACHINE: 65597; 302718-1	ea		1	*	*	*	*	*	*	5	20	(-35 5-4)	179			

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7) 30 DAY MAINT. ALW.						(8)	(9)	(10) ILLUSTRATIONS	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	DS			GS			YR. ALW PER 100 EQUIP CNTGTY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					IND CD	(A) 1-20	(B) 21-50	(C) 51-100	(A) 1-20	(B) 21-50					(C) 51-100	
P	F		5940-156-7431						*	A204	TERMINAL; LUG: 79963; 75-120	ea	1	*	*	*	*	*	*	10	48	(-35 5-4)	183		
P	F		5310-965-1805						*	A205	WASHER, LOCK: Same as A038	ea	5									(-35 5-4)	178, 182		
P	F		5821-736-5887						D	A206	ARM ASSEMBLY, DETENT: 65597; 117443-1	ea	2	*	*	*	*	*	*	10	40	(-35 5-4)	144, 150		
P	F		5305-054-5649						*	A207	SCREW, MACHINE: 96906; MS51957-15	ea	2	*	*	*	*	*	*	16	80	(-35 5-4)	140, 146		
P	F		5310-595-6211						*	A208	WASHER, FLAT: 96906; MS15795-803	ea	2	*	2	2	*	2	2	19	150	(-35 5-4)	142, 148		
MD	F								*	A209	WASHER, FLAT: 65597; 276341-1	ea	*												
P	F								*	A210	WASHER, LOCK: 96906; MS35338-78	ea	2	*	*	*	*	*	*	10	40	(-35 5-4)	141, 147		
MD	F								E	A211	ANCHOR, SPRING: 65597; 10850-1	ea	1												
X1	F								E	A212	ARM, DETENT LEVER: 65597; 10847-1	ea	2												
MD	F								E	A213	SLEEVE, ROLLER BEARING: 65597; 10849-1	ea	1												
MD	F								E	A214	SPACER, SLEEVE: 65597; 10848-1	ea	1												
P	F		6210-918-5679						D	A215	CAP, ELECTRICAL: 97539; 1813-2LW5-20	ea	2	*	*	*	*	*	*	10	40	(-35 5-4)	10		
X1	F								D	A216	COLLAR, STOP: 65597; 60830-1	ea	1									(-35 5-4)	137		
X1	F								E	A217	COLLAR, STOP: 65597; 60830-2	ea	1												
X1	F								E	A218	PIN, STRAIGHT, HEADLESS: 65597; 60830-3	ea	1												
P	F		5935-051-4779						D	A219	CONNECTOR, RECEPTACLE, ELECTRICAL: 77820; PT02A20-39PY	ea	1	*	*	*	*	*	*	4	10	(-35 5-4)	J1 52		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	DS			GS			1 YR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)	
X1	F		5821-736-5914						E	A235 GEAR, COMPOSITE: 65597; 72524-1	ea		1											(-35 5-4)	72A
X1	F								E	A236 GEAR, SPUR: 65597; 117996-0001	ea		1												
X1	F		5821-736-5993						F	A237 GEAR, SPUR: 65597; 72546-1	ea		1											(-35 5-4)	72B
X1	F								F	A238 SHAFT, SHOULDERED: 65597; 71582-1	ea		1											(-35 5-4)	72
X1	F								E	A239 SHAFT, SHOULDERED: 65597; 71581-1	ea		1												
X1	F								D	A240 GEAR SUBASSEMBLY, VHF COMMUNICATION WHOLE MC: 65597; 117995-0001	ea		1												
X1	F		5821-736-5856						E	A241 GEAR, DRIVING: 65597; 72522-1	ea		1											(-35 5-4)	64A
X1	F								E	A242 GEAR, SPUR: 65597; 117997-0001	ea		1												
X1	F		5821-736-5858						F	A243 GEAR, SPUR: 65597; 72523-1	ea		1											(-35 5-4)	64B
X1	F								F	A244 SHAFT, SHOULDERED: Same as A238	ea		1											(-35 5-4)	64
X1	F								E	A245 SHAFT, SHOULDERED: Same as A239	ea		1												
P	F								D	A246 INSULATION SLEEVING, ELECTRICAL: 81343; AMS3651SIZE11 natural	ft		1	*	*	*	*	*	*	8	16				
P	F								D	A247 INSULATION SLEEVING, ELECTRICAL: 81343; AMS3651SIZE14 natural	ft		1	*	*	*	*	*	*	5	8				
P	F								D	A248 INSULATION SLEEVING, ELECTRICAL: 81343; AMS3651SIZE20 natural	ft		1	*	*	*	*	*	*	5	8				
P	F								D	A249 INSULATION SLEEVING, ELECTRICAL: Same as A157	ft		1												

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						YR. ALW PER 100 EQUIP CNTG CY PL	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
														DS			GS								
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	F		5970-905-9220						D A250	INSULATOR, BUSHING: 65597; 75646-1	ea		2	*	*	*	*	*	*	10	24				
P	F		5970-723-9683						D A251	INSULATOR, BUSHING: 65597; 270288-1	ea		2	*	*	2	*	*	2	13	36	(-35 5-4)	60		
P	F		5970-723-9684						D A252	INSULATOR, BUSHING: 65597; 270288-2	ea		2	*	*	*	*	*	*	10	24	(-35 5-4)	65		
P	F		5970-723-9685						D A253	INSULATOR, BUSHING: 65597; 270288-3	ea		2	*	*	2	*	*	2	13	36	(-35 5-4)	73		
F	F		5970-723-9686						D A254	INSULATOR, BUSHING: 65597; 270288-4	ea		4	*	*	2	*	*	2	13	36	(-35 5-4)	62, 70		
P	F		5970-904-6251						D A255	INSULATOR, BUSHING: 65597; 270288-5	ea		2	*	*	*	*	*	*	5	8	(-35 5-4)	66		
P	O		6240-801-5941						D A256	LAMP, INCANDESCENT: Same as A169	ea		2									(-35 2-1 5-4)	DS1 13		
P	O		6240-801-5941						D A257	LAMP, INCANDESCENT: Same as A169	ea		REF									(-35 2-1 5-4)	DS2 13		
P	F		5310-274-8321						D A258	NUT, SELF-LOCKING, CAP: 72962; ZZNQ462	ea		2	*	*	*	*	*	*	10	32	(-35 5-4)	55		
MD	F								D A259	PLATE, MOUNTING, RESISTOR-SWITCH: 65597; 284485-1	ea		1									(-35 5-4)	23		
MD	F								D A260	PLATE, REAR CROSS BAR: 81349; 284852-1	ea		1									(-35 5-4)	57		
MD	F								D A261	PLATE, SWITCH MOUNTING: 65597; 284483-1	ea		1									(-35 5-4)	14		
MD	F								D A262	POST, ELECTRICAL-MECHANICAL-EQUIPMENT: 65597; 270283-1	ea		1												
MD	F								D A263	POST, ELECTRICAL-MECHANICAL-EQUIPMENT: 65597; 270448-0001	ea		1												
P	F								D A264	RESISTOR, VARIABLE: 01121; GA2G03ZF501BA	ea		1	*	*	*	*	*	*	4	6	(-35 5-4)	33		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW						1 YR. ALW PER 100 EQUIP CNTGY PL	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
SOURCE CD	MAINT. CD	REC. CODE		1	2	3	4	5	6					IND CD	DS			GS							
															(A)	(B)	(C)	(A)	(B)					(C)	
	F		5340-816-4239							C	A265 RING, RETAINING: Same as A189	ea		1										(-35 5-4)	75
	F		5305-054-5615							D	A266 SCREW, MACHINE: Same as A191	ea		1											
	F		5305-054-5649							D	A267 SCREW, MACHINE: Same as A207	ea		2											
	F		5305-774-9876							D	A268 SCREW, MACHINE: 65597; 302710-1	ea		2	*	*	*	*	*	*	5	1		(-35 5-4)	78, 79
										D	A269 SETSCREW: Same as A047	ea		18											
	F									D	A270 SETSCREW: 65597; 302721-1	ea		2	*	*	*	*	*	*	5	15			
	F									D	A271 SHAFT, SHOULDERED: 65597; 71580-1	ea		1										(-35 5-4)	129
	F									D	A272 SHAFT, SHOULDERED: 65597; 71587-1	ea		1										(-35 5-4)	139
	F									D	A273 SHAFT, STRAIGHT: 65597; 71590-1	ea		1										(-35 5-4)	77
	F									D	A274 SPACER, SLEEVE: 65597; 270282-1	ea		2										(-35 5-4)	122, 131
	F									D	A275 SPACER, SLEEVE: 65597; 75645-1	ea		2										(-35 5-4)	143, 149
	F									D	A276 SPRING, HELICAL, EXTEN- SION: 65597; 10851-1	ea		1	*	*	*	*	*	*	5	12		(-35 5-4)	145
	F									D	A277 SWITCH, ROTARY: 15909; 10929	ea		1										(-35 5-4)	29
	F		5930-866-8532							D	A278 SWITCH SECTION, ROTARY: 82104; 28595-720LR	ea		1										(-35 5-4)	71,
	F		5930-866-8531							D	A279 SWITCH SECTION, ROTARY: 82104; 28594-720LR	ea		1										(-35 5-4)	69,
	F		5930-868-1712							D	A280 SWITCH SECTION, ROTARY: 82104; 28593-720LR	ea		1										(-35 5-4)	63,

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
SOURCE CD	MAINT. CD	REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						1 YR. ALW PER 100 EQUIP CNTG CY PL	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER			
														DS			GS									
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)							
XL	F		5930-866-8529						D	A281	SWITCH SECTION, ROTARY: 82104; 28592-720LR	ea		1											(-35 5-4)	61.
MD	F								D	A282	TAP BAR, DIAL LIGHT: 65597; 77937-1	ea		1											(-35 5-4)	11
P	F		5940-156-7431						D	A283	TERMINAL LUG: Same as A204	ea		1												
P	F		5310-595-6211						D	A284	WASHER, FLAT: Same as A208	ea		2												
P	F		5310-722-5998						D	A285	WASHER, FLAT: 96906; MS15795-805	ea	*	*	*	*	*	*	*	10	30		(-35 5-4)	56		
P	F								D	A286	WASHER, FLAT: 65597; 276325-1	ea	7	*	2	2	*	2	2	27	300		(-35 5-4)	125, 126, 127, 134		
P	F								D	A287	WASHER, FLAT: 65597; 276326-1	ea	2	*	*	*	*	*	*	10	60		(-35 5-4)	135		
P	F								D	A288	WASHER, FLAT: 65597; 276340-1	ea	*	*	*	*	*	*	*	10	30		(-35 5-4)	76		
P	F								D	A289	WASHER, FLAT: Same as A209	ea	*										(-35 5-4)	67		
P	F		5310-917-4721						D	A290	WASHER, FLAT: 65597; 276342-1	ea	*	*	*	*	*	*	*	10	30		(-35 5-4)	68		
P	F								D	A291	WASHER, FLAT: 65597; 276373-0001	ea	*	*	*	*	*	*	*	10	30		(-35 5-4)	58,59		
P	F								D	A292	WASHER, KEY: 65597; 60829-1	ea	3	*	*	*	*	*	*	5	18		(-35 5-4)	136		
P	F		5310-550-3715						D	A293	WASHER, LOCK: 96906; MS35333-70	ea	2	*	*	*	*	*	*	10	40					
P	F		5310-058-3829						D	A294	WASHER, LOCK: 96906; MS35338-77	ea	1	*	*	*	*	*	*	10	40					
P	F		5330-785-2129						D	A295	WASHER, NONMETALLIC: 65597; 76102	ea	4	*	*	2	*	*	2	16	90					
P	F		6145-754-8057						D	A296	WIRE, ELECTRICAL: 81349; MILW16878 type 22 black	ft	2	*	*	*	*	*	*	10	24					

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7) 30 DAY MAINT. ALW.						(8)	(9)	(10) ILLUSTRATIONS	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	DS			GS			(8) 1 YR. ALW PER 100 EQUIP CNTG CY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)	
P	F		6145-841-2913							D A297 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white black green	ft		1	*	*	*	*	*	*	5	12				
P	F		6145-060-9083							D A298 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white black orange	ft		1	*	*	*	*	*	*	4	6				
P	F									D A299 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white black red	ft		1	*	*	*	*	*	*	4	6				
P	F									D A300 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white black violet	ft		3	*	*	*	*	*	*	8	18				
P	F		6145-841-2912							D A301 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white black yellow	ft		2	*	*	*	*	*	*	5	12				
P	F									D A302 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white blue orange	ft		1	*	*	*	*	*	*	4	6				
P	F									D A303 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown black	ft		1	*	*	*	*	*	*	4	6				
P	F		6145-841-3247							D A304 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown green	ft		1	*	*	*	*	*	*	4	6				
P	F									D A305 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown orange	ft		1	*	*	*	*	*	*	4	6				
P	F		6145-686-4950							D A306 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown red	ft		1	*	*	*	*	*	*	5	12				
P	F									D A307 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown violet	ft		1	*	*	*	*	*	*	5	12				
P	F									D A308 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white brown yellow	ft		1	*	*	*	*	*	*	5	12				

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	(3) MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						(8) 1 YR. ALW PER 100 EQUIP CNTG CY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
														DS			GS								
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	F		6145-725-3081						D A309	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white green black	ft		1	*	*	*	*	*	*	5	12				
P	F			D A310	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white green blue	ft		1	*	*	*	*	*	*	5	12									
P	F			D A311	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white green orange	ft		1	*	*	*	*	*	*	5	12									
P	F			D A312	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white green violet	ft		1	*	*	*	*	*	*	4	6									
P	F			D A313	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white green yellow	ft		1	*	*	*	*	*	*	5	12									
P	F		6145-686-4916						D A314	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white orange black	ft		2	*	*	*	*	*	*	5	12				
P	F			D A315	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white orange blue	ft		1	*	*	*	*	*	*	5	12									
P	F		6145-686-4917						D A316	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white orange green	ft		1	*	*	*	*	*	*	4	6				
P	F		6145-686-4918						D A317	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white red blue	ft		1	*	*	*	*	*	*	5	12				
P	F		6145-686-4952						D A318	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white red orange	ft		1	*	*	*	*	*	*	5	12				
P	F								D A319	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white red red	ft		1	*	*	*	*	*	*	4	6				
P	F								D A320	WIRE, ELECTRICAL: 81349; MILW16878 type E22 white red yellow	ft		1	*	*	*	*	*	*	5	12				

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
SOURCE CD	MAINT. CD	REC. CODE	(2) FEDERAL STOCK NUMBER	MODEL						IND CD	(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						LYR. ALW PER 100 EQUIP CNTG CY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER	
															DS			GS							
				1	2	3	4	5	6						(A)	(B)	(C)	(A)	(B)	(C)					
P	F								D	A321 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white yellow black	ft		1	*	*	*	*	*	*	5	12				
P	F								D	A322 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white yellow blue	ft		1	*	*	*	*	*	*	5	12				
P	F								D	A323 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white yellow brown	ft		1	*	*	*	*	*	*	5	12				
P	F								D	A324 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white yellow orange	ft		1	*	*	*	*	*	*	5	12				
P	F								D	A325 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white yellow red	ft		1	*	*	*	*	*	*	5	12				
P	F								D	A326 WIRE, ELECTRICAL: 81348; QQW343 type S22 AWG annealed tinned	ft		1	*	*	*	*	*	*	8	18				
P	F		5930-998-7569						C	A327 SWITCH ASSEMBLY: 65597; 117449-1	ea		1	*	2	2	*	*	2	12	15				
P	F		5310-857-5548						*	A328 NUT, SELF-LOCKING, HEXAGON: Same as A200	ea		4									(-35 5-4)	51		
P	F		5305-054-5648						*	A329 SCREW, MACHINE: Same as A037	ea		7									(-35 5-4)	224, 229		
P	F		5305-054-5652						*	A330 SCREW, MACHINE: Same as A202	ea		2									(-35 5-4)	36		
P	F		5305-787-2202						*	A331 SCREW, MACHINE: Same as A203	ea		1									(-35 5-4)	227		
P	F		5940-156-7431						*	A332 TERMINAL, LUG: Same as A204	ea		1									(-35 5-4)	226		
P	F		5310-965-1805						*	A333 WASHER, LOCK: Same as A038	ea		5									(-35 5-4)	225, 230		
P	F		5821-736-5887						D	A334 ARM ASSEMBLY DETENT: Same as A206	ea		2									(-35 5-4)	170, 176		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
SOURCE CD (A)	MAINT. CD (B)	REC. CODE (C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	DS			GS			YR ALW PER 100 EQUIP CNTGY PL	DEPOT MAINT ALW PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					IND CD	(A)	(B)	(C)	(A)	(B)					(C)	
X1	F		5821-736-5967							D A351 GEAR, SPUR: Same as A229	ea		1										(-35 5-4)	151	
X1	F		5821-736-5915							D A352 GEAR, WHOLE: 65597; 72525-1	ea		1											(-35 5-4)	157
X1	F									D A353 GEAR SUBASSEMBLY, NAVI- GATION FREQUENCY SELEC- TOR: 65597; 117994-0001	ea		1												
X1	F									E A354 GEAR, SPUR: 65597; 117998-0001	ea		1												
X1	F		5821-736-5836							F A355 GEAR, SPUR: 65597; 72518-1	ea		1											(-35 5-4)	92B
MD	F									F A356 SHAFT, SHOULDER: 65597; 71586-1	ea		1											(-35 5-4)	92
X1	F		5821-736-5839							E A357 GEAR, SPUR: 65597; 72519-1	ea		1											(-35 5-4)	92A
X1	F									F A358 GEAR, SPUR: 65597; 72519	ea		1												
MD	F									F A359 PIN, STRAIGHT, HEADED: 65597; 74351-1	ea		1												
MD	F									E A360 SHAFT, SHOULDERED: 65597; 71585-1	ea		1												
P	F									D A361 INSULATOR SLEEVING, ELECTRICAL: Same as A246	ft		1												
P	F									D A362 INSULATOR SLEEVING, ELECTRICAL: Same as A247	ft		1												
P	F									D A363 INSULATOR SLEEVING, ELECTRICAL: Same as A248	ft		1												
P	F									D A364 INSULATOR SLEEVING, ELECTRICAL: Same as A157	ft		1												
P	F		5970-905-9220							D A365 INSULATOR, BUSHING: Same as A250	ea		2												
P	F		5970-723-9683							D A366 INSULATOR, BUSHING: Same as A251	ea		4											(-35 5-4)	87, 90

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)							
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.			(A) DS	(B) DS	(C) DS	(A) GS	(B) GS	(C) GS	1 YR. ALW PER 100 EQUIP CNTGY PL	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER					
SOURCE CD	MAINT. CD	REC. CODE		1	2	3	4	5	6					IND	CD	(A)											(B)	(C)	(A)	(B)	(C)
																1-20											21-50	51-100	1-20	21-50	51-100
MD	F								D	A383	SHAFT, STRAIGHT: 65597; 71596-1	ea	1											(-35 5-4)	165						
MD	F								D	A384	SPACER, SLEEVE: Same as A274	ea	1											(-35 5-4)	152						
MD	F								D	A385	SPACER, SLEEVE: Same as A275	ea	2											(-35 5-4)	169, 175						
P	F								D	A386	SPRING, HELICAL, EXTEN- SION: Same as A276	ea	1											(-35 5-4)	171						
X1	F								D	A387	SWITCH, ROTARY: Same as A277	ea	1											(-35 5-4)	57 41						
X1	F								D	A388	SWITCH, SECTION, ROTARY: 82104; 28598-720LR	ea	1											(-35 5-4)	91,						
X1	F		5930-866-8534						D	A389	SWITCH, SECTION, ROTARY: 82104; 28597-720LR	ea	1											(-35 5-4)	88,						
X1	F		5930-866-8533						D	A390	SWITCH, SECTION, ROTARY: 82104; 28596-720LR	ea	1											(-35 5-4)	85,						
MD	F								D	A391	TAP BAR, DIAL LIGHT: Same as A282	ea	1																		
F	F		5940-156-7431						D	A392	TERMINAL, LUG: Same as A204	ea	1																		
P	F		5310-595-6211						*	A393	WASHER, FLAT: Same as A208	ea	2																		
F	F								D	A394	WASHER, FLAT: Same as A286	ea	6											(-35 5-4)	155, 161, 162, 163						
F	F								D	A395	WASHER, FLAT: Same as A287	ea	2											(-35 5-4)	156						
F	F								D	A396	WASHER, FLAT: Same as A288	ea	*											(-35 5-4)	96						
F	F		5310-917-4721						D	A397	WASHER, FLAT: Same as A290	ea	*											(-35 5-4)	83						
F	F		5310-550-3715						D	A398	WASHER, LOCK: Same as A293	ea	2																		

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	(3) MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.			1 YR. ALW PER 100 EQUIP CNTGY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER						
				MODEL										DS							GS					
				1	2	3	4	5	6					IND CD	(A) 1-20	(B) 21-50					(C) 51-100	(A) 1-20	(B) 21-50	(C) 51-100		
P	F		6145-686-4952						D	A415 WIRE, ELECTRICAL: Same as A318	ft	2														
P	F								D	A416 WIRE, ELECTRICAL: Same as A320	ft	2														
P	F								D	A417 WIRE, ELECTRICAL: Same as A321	ft	2														
P	F								D	A418 WIRE, ELECTRICAL: Same as A322	ft	2														
P	F								D	A419 WIRE, ELECTRICAL: Same as A323	ft	1														
P	F								D	A420 WIRE, ELECTRICAL: Same as A324	ft	2														
P	F								D	A421 WIRE, ELECTRICAL: Same as A325	ft	1														
P	F								D	A422 WIRE, ELECTRICAL: Same as A326	ft	1														
P	F		5940-081-2939						C	A423 TERMINAL, STUD: 71279; 1947-1	ea	1	*	*	*	*	*	*	4	6	(-35 5-4)					
P	F		5340-962-5523						C	A424 WASHER, FLAT: 65597; 276286-1	ea	2	*	*	*	*	*	*	5	20	(-35 5-4)	211, 256				
P	F								C	A425 WASHER, NONMETALLIC: 65597; 276344-1	ea	1									(-35 5-4)	2				
P	F		5310-965-1805						C	A426 WASHER, LOCK: Same as A038	ea	3														
P	F		5310-058-3829						C	A427 WASHER, LOCK: Same as A294	ea	2														
P	F								C	A428 WASHER, SPRING: 65597; 276368-0001	ea	4	*	*	*	*	*	*	10	40						
P	F		6145-548-0969						C	A429 WIRE, ELECTRICAL: 81349; MILW16878 type E22 white	ft	1	*	*	*	*	*	*	4	6						
P	F								C	A430 WIRE, ELECTRICAL: Same as A326	ft	1														

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)				
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW						YR ALW PER 100 EQUIP CNTGY PL	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER					
SOURCE CD	MAINT. CD	REC. CODE		IND CD										DS			GS											
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)									
P	F		5821-933-9606							B	A431	DETECTOR: RADIO FREQUENCY: 65597; 117875-0001	ea		1	*	*		*	*	*						(-12 1-3)	
X1	F		5910-946-6784							C	A432	CAPACITOR, FIXED, MICA DIELECTRIC: 72136; DM10F251G0500WV4CR	ea		1													
X1	F		5905-683-3129							C	A433	RESISTOR, FIXED, COMPOSITION: 81349; RC07GF104J	ea		1													
X1	F		5961-556-2091							C	A434	SEMICONDUCTOR DEVICE, DIODE: 81349; 1N270	ea		1													
X1	F									C	A435	TERMINAL BOARD: 65597; 285053-0003	ea		1													
P	F		5940-865-3216							D	A436	TERMINAL, STUD: 71279; 2041-2	ea		1	*	*	*	*	*	*	*	4	6				
P	F		5940-280-0600							D	A437	TERMINAL, STUD: 71279; 2042-2	ea		2	*	*	*	*	*	*	*	5	10				
X1	F									D	A438	TERMINAL, BOARD: 65597; 285053-0002	ea		1													
P	O		5920-280-8342							B	A439	FUSE, CARTRIDGE: 81349; FO2A250V1A	ea		5	2	2	3	2	2	2	33	450			(-12 3-1)		
P	O		5920-727-1452							B	A440	FUSE, CARTRIDGE:	ea		5	2	3	5	2	2	2	46	525			(-12 3-1)		
P	O		5920-686-1107							B	A441	FUSEHOLDER: 28480; 11509A	ea		1	*	*	2	*	*	2	8	12			(-12 1-3)		
P	O		5920-804-5028							C	A442	FUSE, CARTRIDGE: 28480; 2110-0026	ea		10	2	3	6	2	2	2	107	750			(-12 3-3)		
P	O		6240-155-7836							B	A443	LAMP, INCANDESCENT: 96906; MS25237-327	ea		2	2	4	7	2	2	2	80	225			(-12 3-1)		
P	O		6240-155-7857							B	A444	LAMP, INCANDESCENT: 96906; MS25237-328	ea		2	2	4	7	2	2	2	80	225			(-12 3-1)		
P	F									B	A445	NUT, SELF LOCKING, HEXAGON: 72982; 68M40	ea		2	*	*	*	*	*	*	5	70					

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						YR. ALW PER 100 EQUIP CNTGY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
SOURCE CD	MAINT. CD	REC. CODE		1	2	3	4	5	6					IND CD	DS			GS							
															(A)	(B)	(C)	(A)	(B)					(C)	
P	F		5305-059-3659							*	A447	ea	4	*	*	*	*	*	*	10	40				
P	F		5310-619-1148							*	A448	ea	4	*	*	2	*	*	2	13	60				
P	F									C	A449	pt	*												
P	F		6150-933-9805							C	A450	ea	1	*	*	*	*	*	*	5	10	(-12 1-3)			
P	F		6145-284-0579							D	A451	ea	1	*	*	*	*	*	*	4	6				
P	F		5975-988-0649							D	A452	ea	1	*	*	*	*	*	*	4	10				
P	F									D	A453	ea	1	*	*	*	*	*	*	4	10				
P	F									E	A454	ea	1	*	*	*	*	*	*	5	15				
P	F									D	A455	ea	1	*	*	*	*	*	*	4	10				
P	F									E	A456	ea	1												
P	F		5940-788-5655							D	A457	ea	3	*	*	*	*	*	*	8	18				
P	F									D	A458	ft	1	*	*	*	*	*	*	4	6				
P	F									D	A459	ft	1	*	*	*	*	*	*	4	6				
P	F		5940-204-8966							D	A460	ea	3	*	2	2	*	2	2	46	300				

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
SOURCE CD	MAINT. CD	REC. CODE	(2) FEDERAL STOCK NUMBER	(B) MODEL						(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UN PK	(6) QTY INC IN UNIT	(7) 30 DAY MAINT. ALW.						(8) 1 YR. ALW PER 100 EQUIP CNTGCTY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(10) ILLUSTRATIONS			
														DS			GS					(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	F		5940-557-1629						D	A461	TERMINAL, LUG: 00779; 31888	ea		3	*	*	*	*	*	*	8	30			
F	F		5910-822-5682						C	A462	CAPACITOR, FIXED, CERAMIC DIELECTRIC: 81349; CK62X102M	ea		1	*	2	2	*	*	2	12	8			
P	F		5340-682-1617						C	A463	CLAMP, LOOP: 96906; MS21919DC12	ea		1	*	*	*	*	*	*	4	10			
P	F		5935-843-9008						C	A464	CONNECTOR, RECEPTACLE, ELECTRICAL: 96906; MS35179-1094	ea		2	*	*	*	*	*	*	5	12	(-35 2-1)	J2	
P	F								C	A465	CONNECTOR, RECEPTACLE, ELECTRICAL: Same as A464	ea	REF										(-35 2-1)	J3	
P	O		5920-280-8342						C	A466	FUSE, CARTRIDGE: Same as A439	ea		1									(-35 2-1)	F3	
P	O		5920-727-1452						C	A467	FUSE, CARTRIDGE: Same as A440	ea		2									(-35 2-1)	F1	
P	O		5920-727-1452						C	A468	FUSE, CARTRIDGE: Same as A440	ea	REF										(-35 2-1)	F2	
P	F		5920-505-1398						C	A469	FUSE HOLDER: 71400; HKPZ	ea		3	*	*	2	*	*	2	9	36			
P	F		5920-505-1398						C	A470	FUSEHOLDER: Same as A469	ea	REF												
P	F		5920-505-1398						C	A471	FUSEHOLDER: Same as A469	ea	REF												
P	F								D	A472	CAP, ELECTRICAL: 71400; 9435F1-2	ea		3	*	*	*	*	*	*	8	18			
P	F								C	A473	INSULATOR SLEEVEING, ELECTRICAL: 81343; AMS3651SIZE18 natural	ft		1	*	*	*	*	*	*	4	6			
P	F		5935-234-2076						C	A474	JACK, TELEPHONE: 37942; B113812	ea		2	*	*	*	*	*	*	5	10	(-35 2-1)	J4	
P	F		5935-234-2076						C	A475	JACK, TELEPHONE: Same as A474	ea	REF										(-35 2-1)	J5	
P	F		5935-192-4729						C	A476	JACK, TELEPHONE: 81349; JJ033	ea		1	*	*	*	*	*	*			(-35 2-1)	J22	

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A) SOURCE CD	(B) MAINT. CD	(C) REC. CODE	(2) FEDERAL STOCK NUMBER	(3) MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						(8) YR. ALW PER 100 EQUIP CNTG CY PL.	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
														DS			GS								
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	O		5355-914-1974						C	A477	KNOB: 65597; 60848-1	ea		1	*	*	*	*	*	*	4	7			
P	O		6240-155-7836						C	A478	LAMP, INCANDESCENT: Same as A443	ea		1										(-35 2-3)	DS2
P	O		6240-155-7857						C	A479	LAMP, INCANDESCENT: Same as A444	ea		1										(-35 2-3)	DS1
P	O		6210-080-7803						C	A480	LIGHT, INDICATOR: 72619; 101-5030-0931	ea		2	*	2	2	*	2	2	13	26		(-12 3-1)	XDS1
P	O		6210-080-7803						C	A481	LIGHT, INDICATOR: Same as A480	ea		REF										(-12 3-1)	XDS2
P	O		6210-842-1679						D	A482	LENS, INDICATOR LIGHT: 72619; 101-0931	ea		2	*	*	2	*	*	2	10	16		(-12 3-1)	
P	F		5340-619-0165						C	A483	LINK, TERMINAL CONNECT- ING: 75382; 601SP	ea		2	*	*	*	*	*	*	5	12			
P	F		5310-622-1724						C	A484	NUT, SELF-LOCKING, HEXAGON: 72962; 68-1660-26	ea		2	*	*	*	*	*	*	5	20			
P	F		5310-680-7543						C	A485	NUT, SELF-LOCKING; HEXAGON: 72962; 68NM62	ea		5	*	*	2	*	*	2	12	50			
MD	F								C	A486	PANEL, TEST: 65597; 285033-0003	ea		1											
MD	F								D	A487	PANEL, TEST: 65597; 285033-0002	ea		1											
P	F		5325-530-9034						D	A488	RECEPTACLE, TURNLOCK FASTENER: 72794; SX560	ea		4	*	*	*	*	*	*	10	24			
P	F		5320-117-6938						D	A489	RIVET, SOLID: 96906; MS20426AD3-4	ea		8	*	*	2	*	*	2	16	60			
MD	O								C	A490	PLATE, IDENTIFICATION: 65597; 266022-0002	ea		1											
P	F		5940-223-5295						C	A491	POST, BINDING: 58474; DF30BC	ea		6	*	*	2	*	*	2	13	30		(-35 2-1)	J7
P	F		5940-223-5295						C	A492	POST, BINDING: Same as A491	ea		REF										(-35 2-1)	J9

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)		
SOURCE CD (A)	MAINT. CD (B)	REC. CODE (C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW						1 YR ALW PER 100 EQUIP. CNTGTY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER			
														DS			GS									
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)							
P	F		5940-223-5295						C	A493	POST, BINDING: Same as A491	ea		REF											(-35 2-1)	J11
P	F		5940-223-5295						C	A494	POST, BINDING: Same as A491	ea		REF											(-35 2-1)	J14
P	F		5940-223-5295						C	A495	POST, BINDING: Same as A491	ea		REF											(-35 2-1)	J17
P	F		5940-223-5295						C	A496	POST, BINDING: Same as A491	ea		REF											(-35 2-1)	J20
P	F		5940-356-2493						C	A497	POST, BINDING: 58474; DF30RC	ea	10	*	2	2	*	2	2	20	40			(-35 2-1)	J6	
P	F		5940-356-2493						C	A498	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J8
P	F		5940-356-2493						C	A499	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J10
P	F		5940-356-2493						C	A500	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J12
P	F		5940-356-2493						C	A501	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J13
P	F		5940-356-2493						C	A502	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J15
P	F		5940-356-2493						C	A503	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J16
P	F		5940-356-2493						C	A504	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J18
P	F		5940-356-2493						C	A505	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J19
P	F		5940-356-2493						C	A506	POST, BINDING: Same as A497	ea		REF											(-35 2-1)	J21
P	F		5905-299-2020						C	A507	RESISTOR, FIXED, COM- POSITION: 81349; RC32GF273J	ea	1	*	2	2	*	*	2	12	7			(-35 2-1)	R3	

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)	
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						(8) YR. ALW PER 100 EQUIP CNTG CY PL	(9) DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER		
SOURCE (D)	MAINT. CD	REC. CODE		IND CD										DS			GS								
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)						
P	F		5905-279-2650						C	A508	RESISTOR, FIXED, COM- POSITION: 81349; RC32GF562J	ea		1	*	2	2	*	*	2	12	7	(-35 2-1)	R2	
P	F		5905-89-4000						C	A509	RESISTOR, VARIABLE: 01121; CANON 38103-A	ea		1	*	2	2	*	2	2	19	8	(-35 2-1)	R1	
F	F		5305-054-6654						C	A510	SCREW, MACHINE: 96906; MS51957-30	ea		1	*	*	*	*	*	*	4	10			
F	F		5305-054-6656						C	A511	SCREW, MACHINE: 96906; MS51957-32	ea		4	*	*	*	*	*	*	10	40			
F	F		5305-054-5638						C	A512	SCREW, MACHINE: 96906; MS51957-4	ea		2	*	*	*	*	*	*	5	20			
P	F		5961-170-4430						C	A513	SEMICONDUCTOR DEVICE, DIODE: 93332; 1N34A	ea		1	*	2	2	*	*	2	13	12	(-35 2-1)	CR1	
F	F		5305-717-6950						C	A514	SETSCREW: 96906; MS51963-9	ea		2	*	*	*	*	*	*	5	20			
P	F		5930-655-1514						C	A515	SWITCH, TOGGLE: 96906; MS35058-22	ea		4	*	2	2	*	2	2	29	60	(-35 2-1)	S1	
P	F		5930-655-1514						C	A516	SWITCH, TOGGLE: Same as A515	ea		REF									(-35 2-1)	S2	
P	F		5930-655-1514						C	A517	SWITCH, TOGGLE: Same as A515	ea		REF									(-35 2-1)	S3	
P	F		5930-655-1514						C	A518	SWITCH, TOGGLE: Same as A515	ea		REF									(-35 2-1)	S4	
P	F		5930-655-1575						C	A519	SWITCH, TOGGLE: 96906; MS35059-22	ea		1	*	2	2	*	*	2	12	15	(-35 2-1)	S5	
F	F		5940-329-5754						C	A520	TERMINAL, LUG: 37942; A131023-1	ea		4	*	*	*	*	*	*	10	40			
P	F		5940-834-9660						C	A521	TERMINAL BOARD: 65597; 284761-3	ea		1	*	*	2	*	*	*	8	9			
F	F		5940-834-9660						D	A522	TERMINAL, STUD: 98291; ST1000SL	ea		4	*	*	*	*	*	*	10	16			
X1	F								D	A523	TERMINAL BOARD: 65597; 284761-2	ea		1											

(1)			REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE										(4)	(5)	(6)	(7)						(8)	(9)	(10)			
(A)	(B)	(C)	(2) FEDERAL STOCK NUMBER	MODEL						(3) DESCRIPTION	UNIT OF ISSUE	QTY INC IN UN PK	QTY INC IN UNIT	30 DAY MAINT. ALW.						1 YR. ALW PER 100 EQUIP CNTGY PL.	DEPOT MAINT ALW. PER 100 EQUIP.	(A) FIGURE NUMBER	(B) ITEM OR SYMBOL NUMBER				
SOURCE CD	MAINT. CD	REC. CODE		IND CD										DS			GS										
				1	2	3	4	5	6					(A)	(B)	(C)	(A)	(B)	(C)								
MD	F								D	A538	BRACKET, ELECTRICAL CONNECTOR: 65597; 92561-1	ea		1													
MD	F								D	A539	BRACKET, ELECTRICAL CONNECTOR: 65597; 92561-2	ea		1													
MD	F								E	A540	BRACKET, ELECTRICAL CONNECTOR: Same as A538	ea		1													
P	F		6145-771-3336						D	A541	CABLE, RADIO FREQUENCY: 81349; RG58AU	ft		6	*	*	*	*	*	*	24	36					
P	F		6145-669-6701						D	A542	CABLE, SPECIAL, ELECTRI- CAL: 81349; MILW16878 type B22 JSJ black	ft		6	*	*	*	*	*	*	24	36					
P	H								D	A543	CABLE, SPECIAL, ELECTRI- CAL: 71124; T2402-2-20	ft		26	*	*	*	*	*	*	52	78					
P	H								D	A544	CABLE, SPECIAL, ELECTRI- CAL: 71124; T2402-3-22- 19STR	ft		6	*	*	*	*	*	*	24	36					
P	F		5935-937-8296						D	A545	CONNECTOR, PLUG, ELECTRI- CAL: 71468; 228550-4	ea		1	*	*	*	*	*	*	5	14					
P	H		5935-914-2384						D	A546	CONNECTOR, PLUG, ELECTRI- CAL: 96906; MS3116E20- 39SY	ea		1				*	*	*	5	14	(-35 2-1)	P1			
P	H								D	A547	CONNECTOR, PLUG, ELECT- RICAL: 96906; MS3116E20- 39S2	ea		1				*	*	*	5	14					
P	F		5935-823-0487						D	A548	CONNECTOR, PLUG, ELECT- RICAL: 96906; MS35168- 88E	ea		1	*	*	*	*	*	*	5	14	(-35 2-1)	J1			
P	F								D	A549	INSULATOR SLEEVING, ELECTRICAL: Same as A246	ft		1													
P	H								D	A550	INSULATOR SLEEVING, ELECTRICAL: 81343; AMS3651SIZE15 natural	ft		1				*	*	*	4	6					

**SECTION III. INDEX-FEDERAL STOCK NUMBER CROSS REFERENCE
TO INDEX NUMBER**

FEDERAL STOCK NUMBER	INDEX NO.	FEDERAL STOCK NUMBER	INDEX NO.	FEDERAL STOCK NUMBER	INDEX NO.
3040-880-0497	A194	5310-622-1724	A484	5821-736-5899	A069
3110-915-5572	A034	5310-680-7543	A485	5821-736-5913	A084
4920-627-8271	A017	5310-722-5998	A285	5821-736-5914	A235
5120-949-6692	A004	5310-857-5548	A200	5821-736-5915	A352
5305-054-5635	A191	5310-917-4721	A290	5821-736-5944	A348
5305-054-5636	A046	5310-965-1805	A038	5821-736-5967	A229
5305-054-5638	A512	5320-117-6938	A489	5821-736-5993	A237
5305-054-5648	A037	5320-817-0728	A015	5821-738-2856	A036
5305-054-5649	A207	5325-530-9034	A488	5821-926-7292	A001
5305-054-5652	A202	5325-543-2418	A179	5821-933-9605	A033
5305-054-6654	A510	5325-989-6033	A177	5821-933-9606	A431
5305-054-6656	A511	5330-784-9188	A024	5821-933-9607	A032
5305-059-3659	A447	5330-785-2129	A295	5821-933-9608	A446
		5330-971-7983	A173	5826-948-5286	A021
		5340-619-0165	A483	5905-073-8220	A025
5305-151-0206	A093	5340-682-1617	A463	5905-279-2650	A508
5305-282-4546	A162	5340-816-4239	A189	5905-299-2020	A507
5305-717-6950	A514	5340-962-5523	A424	5905-683-3129	A433
5305-774-9874	A379	5340-989-9948	A178	5905-852-7602	A509
5305-774-9876	A268	5355-727-4064	A166	5910-822-5682	A463
5305-787-2202	A203	5355-728-6448	A163	5920-280-8342	A439
5305-959-2727	A161	5355-913-9601	A158	5920-505-1398	A469
		5355-914-1974	A477	5920-686-1107	A441
5310-011-1041	A531	5821-736-5791	A180	5920-727-1452	A440
5310-054-1831	A532	5821-736-5792	A227	5920-804-5028	A442
5310-058-2951	A530	5821-736-5836	A355	5930-655-1514	A515
5310-058-3829	A294	5821-736-5839	A357	5930-655-1575	A519
5310-180-0277	A529	5821-736-5855	A223	5930-723-4562	A198
5310-274-8321	A258	5821-736-5856	A241	5930-866-8529	A281
5310-543-2740	A528	5821-736-5858	A243	5930-866-8531	A279
5310-543-4652	A052	5821-736-5872	A222	5930-866-8532	A278
5310-543-5933	A527	5821-736-5877	A108	5930-866-8533	A390
5310-550-3715	A293	5821-736-5879	A124	5930-866-8534	A389
5310-595-6211	A208	5821-736-5885	A140	5930-868-3732	A280
5310-595-7154	A533	5821-736-5887	A206	5930-998-7568	A199
5310-614-3500	A554	5821-736-5888	A054	5930-998-7569	A327
5310-619-1148	A448				

SECTION III. INDEX-FEDERAL STOCK NUMBER CROSS REFERENCE
TO INDEX NUMBER (CONTINUED)

FEDERAL STOCK NUMBER	INDEX NO.	FEDERAL STOCK NUMBER	INDEX NO.	REF NUMBER	INDEX NUMBER
		6145-295-2810	A560	AMS3651SIZE16 NATURAL	A592
5935-051-4779	A219	6145-295-2812	A559	AMS3651SIZE18	A473
		6145-548-0969	A429	AMS3651SIZE20	A248
5935-192-4729	A476	6145-623-7224	A535	AMS3651SIZE22	A157
		6145-669-6701	A542	GA2G032F501RA	A264
5935-234-2076	A474	6145-686-4916	A315	GP1-047X312-12	A120
		6145-686-4917	A316	GUDELACH18	A100
5935-823-0487	A548	6145-686-4918	A317	MILW16878 TYPE F	A023
5935-843-9008	A464			CLASS52	
5935-914-2384	A546	6145-686-4950	A306		
5935-937-8296	A545	6145-686-4952	A318	MILW16878	A299
				WHITE,BLACK,RED	
5940-081-2939	A423	6145-725-3081	A310		
5940-156-7431	A204	6145-754-8057	A296	MILW16878	A300
				WHITE,BLACK,VIOLET	
5940-204-8966	A460	6145-771-3336	A541	MILW16878	A302
				WHITE,BLUE,ORANGE	
5940-223-5295	A491	6145-841-2912	A301	MILW16878	A303
5940-280-0600	A437	6145-841-2913	A297	WHITE,BROWN,BLACK	
5940-329-5754	A520	6145-841-3247	A304	MILW16878	A305
				WHITE,BROWN,ORANGE	
5940-356-2493	A497	6150-933-9805	A450	MILW16878	A307
				WHITE,BROWN,VIOLET	
5940-502-8806	A555	6210-725-6170	A156		
5940-557-1629	A461	6210-918-5679	A215	MILW16878	A308
				WHITE,BROWN,YELLOW	
5940-577-3711	A558	6210-089-7803	A480	MILW16878	A309
				WHITE,GREEN,BLACK	
5940-707-6754	A521	6210-842-1679	A482		
5940-788-5655	A457	6240-155-7836	A443	MILW16878	A311
				WHITE,GREEN,ORANGE	
5940-834-9660	A522	6240-155-7857	A444	MILW16878	A312
				WHITE,GREEN,VIOLET	
5940-865-3216	A436	6240-801-5941	A169		
5961-170-4430	A513	6250-604-0752	A035	MILW16878	A313
				WHITE,GREEN,YELLOW	
5961-556-2091	A434	6680-527-6045	A026	MILW16878	A314
				WHITE,ORANGE,BLACK	
5970-723-9683	A251	8115-708-0084	A031		
5970-723-9684	A252	8115-708-0112	A029	MILW16878	A413
				WHITE,ORANGE,RED	
5970-723-9685	A253	8115-708-0116	A027		
5970-723-9686	A254			MILW16878	A319
				WHITE,RED,RED	
5970-754-9716	A553	REF NUMBER	INDEX NUMBER	MILW16878	A320
		AMS3651SIZE11	A246	WHITE,RED,YELLOW	
5970-904-6251	A255	AMS3651SIZE14	A247		
5970-905-9220	A250			MILW16878	A321
				WHITE,YELLOW,BLACK	
5975-988-0649	A452	AMS3651SIZE15 NATURAL	A550		
6145-060-9083	A298			MILW16878	A322
				WHITE,YELLOW,BLUE	
6145-284-0579	A451	AMS3651SIZE15 YELLOW	A551		
				MILW16878	A323
				WHITE,YELLOW,BROWN	

SECTION III. INDEX-FEDERAL STOCK NUMBER CROSS REFERENCE
TO INDEX NUMBER (CONTINUED)

REF NUMBER	INDEX NO.	REF NUMBER	INDEX NO.	REF NUMBER	INDEX NO.
MILW16878 WHITE, YELLOW, ORANGE	A324	10849-1	A213	276368-0001	A428
MILW16878 WHITE, YELLOW, RED	A325	10850-1	A211	276373-0001	A291
MILW16878 TYPE S18WG	A536	10851-1	A276	28225-1	A106
MS3116E20-9952	A547	10858-1	A232	284480-1	A181
MS35190-7	A044	10939	A277	284481-1	A175
MS35190-12	A104	117413-1	A174	284482-1	A184
MS35338-78	A210	117737-0001	A006	284483-1	A261
PT02A20-39P2	A343	117738-0001	A009	284485-1	A259
UG274A/U	A002	117993-0001	A234	284494-1	A197
QQW343 TYPE522	A326	117994-0001	A353	284495-1	A196
REF100 3-8	A458	117995-0001	A240	284525-1	A043
TYPE 2		117996-0001	A236	284526-1	A060
RTV732	A003	117997-0001	A242	284528-1	A185
TURBOLEX85	A459	117998-0001	A354	284761-2	A523
T2402-2-20	A543	118042-0001	A127	284852-1	A260
T2402-3-22-19STR		118043-0001	A143	285033-0002	A487
ZV903	A005	118044-0001	A111	285033-0003	A486
028255-0001	A453	120D	A028	285053-0002	A438
028255-0002	A455	26 RED	A454	285053-0003	A435
060893-0001	A010	266022-0001	A490	28598-720LR	A388
071625-0001	A008	266023-0002	A183	302019-1	A051
071626-0001	A011	267498-0002	A562	302711-1	A045
072565-0001	A016	270247-1	A195	302720-1	A047
072566-0001	A018	270255-1	A048	302721-1	A270
078094-0001	A007	270282-1	A274	4-141AFV	A524
078095-0001	A013	270283-1	A262	432956-0001	A537
078095-0002	A014	270448-0001	A263	60695-1	A176
078095-0003	A012	276325-1	A286	60825-1	A159
100558	A172	276326-1	A287	60827-1	A164
104826-0001	A022	276340-1	A288	60828-1	A160
10837-1	A117	276341-1	A209	60829-1	A292
10838-1	A134	276343-1	A122	60830-1	A216
10839-1	A149	276344-1	A425	60830-2	A217
10840-1	A225	276365-0001	A123	60830-3	A218
10841-1	A132	276366-0001	A139	60831-1	A167
10842-1	A115	276367-0001	A053	61237-1	A049
10845-1	A221				
10847-1	A212				
10848	A214				

**SECTION III. INDEX-FEDERAL STOCK NUMBER CROSS REFERENCE
TO INDEX NUMBER (CONTINUED)**

REF. NUMBER	INDEX NO.	REF. NUMBER	INDEX NO.	FEDERAL STOCK NUMBER	INDEX NO.
61238-1	A065	77919-1	A087		
61239-1	A050	77920-1	A057		
65776-1	A182	77921-1	A345		
68440	A445	77932-1	A206		
71580-1	A271	77933-1	A187		
71581-1	A239	77934-1	A188		
71582-1	A238	77935-1	A133		
71585-1	A360	77936-1	A116		
71586-1	A356	77937-1	A282		
71587-1	A272	82316-1	A040		
71589-1	A382	82319-1	A110		
71590-1	A273	82323-1	A129		
71596-1	A383	82324-1	A113		
72514-1	A228	82327-1	A126		
72516-1	A231	82328-1	A128		
72517-1	A224	82329-1	A125		
72519	A358	82328-1	A112		
72527-1	A130	82329-1	A144		
72530-1	A042	82330-1	A109		
72539-1	A041	82332-1	A220		
72539-1	A058	827	A563		
72540-1	A135	89695-1	A105		
72541-1	A116	89695-2	A103		
72542-1	A150	89695-1	A107		
72543-1	A059	92571-1	A538		
72544-1	A119	9435F1-2	A472		
74351-1	A359				
75630-1	A131				
75631-1	A114				
75632-1	A121				
75634-1	A146				
75639-1	A130				
75645-1	A275				
77917-1	A039				
77918-1	A072				
77919-1	A087				

**SECTION IV. INDEX-FIGURE AND ITEM NUMBER CROSS REFERENCE
TO INDEX NUMBER**

FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.	FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.
-35	90	A366		157	A352
54	91	A388		158	A381
	92	A356		159	A349
	92A	A357		160	A347
	92B	A355		161,	A394
	93	A367		162,	
	95	A376		163	
	96	A396		164	A348
	97	A382		165	A383
	98,	A379		166	A335
	99			167	A337
	100,	A190		168	A336
	101,			169	A385
	102,			170	A334
	103			171	A386
	104	A186		172	A335
	105	A188		173	A337
	106	A187		174	A336
	107	A188		175	A385
	107A	A055		176	A334
	108	A056		177	A201
	109	A065		178	A205
	110	A066		179	A203
	111	A070		180	A197
	112	A071		181	A201
	113	A037		182	A205
	114	A036		183	A204
	115,	A035		184	A072
	116,			185	A039
	117			186	A044
	120	A172		187	A048
	121	A229		188	A040
	122	A274		189	A046
	123	A227		190	A052
	124	A222		191	A043
	125,	A266		192	A045
	126,			193	A050
	127			194	A034
	128	A223		195	A045
	129	A271		196	A049
	130	A229		197	A034
	131	A274		198	A077
	132	A227		199	A082
	133	A221		200	A075
	134	A266		201	A076
	136	A272		202	A079
	137	A217		203	A034
	138	A230		204	A077
	139	A272		205	A060
	140	A207		206	A034
	141	A210		207,	A189
	142	A207		208	
	143	A275		209	A194
	144	A206		210	A124
	145	A277		211	A424
	146	A207		212	A108
	147	A210		213	A061
	148	A205		214	A074
	149	A277		215	A061
	150	A206		216	A073
	151	A351		217	A053
	152	A364		218	A051
	153	A349		219	A042
	154	A346		220	A053
	155	A394		221	A051
	156	A395		222	A041

SECTION IV. INDEX-FIGURE AND ITEM NUMBER CROSS REFERENCE
TO INDEX NUMBER (CONTINUED)

FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.	FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.
-12	XDS1	A480	15		A342
3-1	XDS2	A481	17		A344
			18		A370
-35	CR1	A513	19		A374
2-1	DS1	A256,	20		A163
		A479	21		A158
	DS2	A257	22		A166
	F1	A467	23		A259
	F2	A468	24		A202
	F3	A466	25		A195
	J1	A219,	26		A228
		A548	29		A277
	J2	A464	30		A228
	J3	A465	33		A264
	J4	A474	34		A175
	J5	A475	35		A373
	J6	A497	36		A330
	J7	A491	37		A195
	J8	A498	38		A350
	J9	A492	41		A387
	J10	A499	44		A198
	J11	A493	45		A193
	J12	A500	47		A184
	J13	A501	48		A201
	J14	A494	49		A200
	J15	A502	51		A328
	J16	A503	52		A219
	J17	A495	53		A343
	J18	A504	54		A185
	J19	A505	55		A258
	J20	A496	56		A285
	J21	A506	57		A260
	J22	A476	58,		A291
	P1	A546	59		
	R1	A509	60		A251
	R2	A508	61		A281
	R3	A507	62		A254
	S1	A515	63		A280
	S2	A516	64		A244
	S3	A517	64A		A241
	S4	A518	64B		A243
	S5	A519	65		A252
	TB1	A524	66		A255
			67		A289
-35	DS5	A169	68		A290
2-2	DS6	A170	69		A279
	DS7	A171	70		A254
	ST	A387	71		A278
			72		A238
-35	DS2	A478	72A		A235
2-3	DS3	A370	72B		A237
	DS4	A371	73		A253
			75		A265
-35	1	A156	76		A288
5-4	2	A425	77		A273
	4	A169	78,		A268
	5	A180	79		
	6	A104	80		A372
	7	A105	82		A345
	8	A190	83		A397
	9	A107	84		A369
	10	A215	85		A390
	11	A282	86		A368
	12	A220	87		A366
	13	A256	88		A389
	14	A261	89		A368

SECTION IV. INDEX-FIGURE AND ITEM NUMBER CROSS REFERENCE
TO INDEX NUMBER (CONTINUED)

FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.	FIG. NO.	ITEM NO. OR REFERENCE DESIGNATION	INDEX NO.
-35	224	A329			
5-4	225	A333			
	226	A332			
	227	A331			
	228	A196			
	229	A329			
	230	A333			
	231	A057			
	232	A087			
	233	A092			
	234	A097			
	234A	A095			
	235	A088			
	235A	A101			
	236	A091			
	237	A094			
	238	A099			
	239	A034			
	240	A094			
	241	A058			
	242	A034			
	243	A062			
	244	A067			
	245	A060			
	246	A061			
	247	A065			
	248	A034			
	249	A061			
	250	A066			
	251	A034			
	252	A189			
	253				
	254	A194			
	255	A124			
	256	A424			
	257	A140			
	258	A064			
	259	A059			
	260	A064			
	261	A058			
	262	A068			
	263	A100			
	264	A090			
	265	A102			
	266	A100			
	267	A089			
	268	A102			
	269	A047			
	270	A063			
	271	A078			
	272	A096			
	273	A162			
	274	A176			
	275	A182			

**SECTION V. INDEX-REFERENCE DESIGNATION CROSS REFERENCE
TO INDEX NUMBER**

REFERENCE DESIGNATION	INDEX NO.	REFERENCE DESIGNATION	INDEX NO.	REFERENCE DESIGNATION	INDEX NO.
CRL	A513	R3	A507		
DS1	A256 A479	S1	A515		
DS2	A257	S2	A516		
DS2	A478	S3	A517		
DS3	A370	S4	A518		
DS4	A371	S5	A519		
DS5	A169	S7	A387		
DS6	A170	TB1	A524		
DS7	A171	XDS1	A480		
F1	A467	XDS2	A481		
F2	A468				
F3	A466				
J1	A219 A548				
J2	A464				
J3	A465				
J4	A474				
J5	A475				
J6	A497				
J7	A491				
J8	A498				
J9	A492				
J10	A499				
J11	A493				
J12	A500				
J13	A501				
J14	A494				
J15	A502				
J16	A503				
J17	A495				
J18	A504				
J19	A505				
J20	A496				
J21	A506				
J22	A476				
P1	A546				
R1	A509				
R2	A508				

By Order of the Secretary of the Army:

Official:

KENNETH G. WICKHAM,
MajorGeneral, United States Army,
The Adjutant General.

W. C. WESTMORELAND
General, United States Army,
Chief of Staff.

Distribution:

To be distributed in accordance with DA Form 12-36 (Unclassified) requirements for Direct and General Support Avionics maintenance literature for O-1A, O-1E, OV-1A, OV-1B, OV-1C, U-1A, U-6A, U-8D, U-8F, CH-21C, CH-34A, CH-34C, CH-47A, UH-1B, UH-1D, UH-19C and UH-19D.

* U.S. GOVERNMENT PRINTING OFFICE : 1994 0 - 300-421 (82626)

This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)