DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) MULTIMETERS AN/USM-33 AND AN/USM-33A FSN 6625-648-9172

Headquarters, Department of the Army, Washington, D.C. 15 August 1973

Current as of January 1973

			Paragraph	Page
Section	I.	INTRODUCTION	.	Ū
		Scope	1-1	2
		General	1-2	2
		Explanation of columns	1-3	2
		Special information	1-4	4
		Location of repair parts		4
		Abbreviations(Not applicable)	1-6	4
		Reporting of equipment publication improvements	1-7	4
	II.	REPAIR PARTS LIST		6
	III.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not ap	plicable)	
	IV.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER	BER	
		CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		8

This publication is a courtesy quick copy from the UNITED STATES ARMY PUBLICATIONS CENTER, ST; LOUIS, MISSOURI, to meet your needs while we-are replenishing our regular stock.

^{*}This manual supersedes TM 11-6625-314-35P, 27 November 1961.

SECTION I

1-1. Scope

This manual lists repair parts and special tools required for the performance of direct support, general support, and depot maintenance of the AN/USM-33 and AN/USM-33A. The PCCN for the equipment is GTEABN for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

- a. Repair Parts List-Section II. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level. This repair parts list is arranged in alphabetical order.
- b. Special Tools, Test and Support Equipment- Section III. Not applicable.
- c. Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section IV. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

- a. Source, Maintenance. and Recoverability Codes (SMR).
- (1) Source code. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are-

Code Explanation

- PA Item procured and stocked for anticipated or known usage.
- PB Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
- PC Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
- PD Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or

outfittings. Not subject to automatic replenishment.

Code Explanation

- PE Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
- PF Support equipment which will not be stocked but which will be centrally procured on demand.
- PG Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
- KD An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
- KF An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.' KB Item included in both a depot overhaul/repair kit and a maintenance kit.
- MO Item to be manufactured or fabricated at organizational level.
- MF Item to be manufactured or fabricated at direct support maintenance level.
- MH Item to be manufactured or fabricated at general support maintenance level.
- MD Item to be manufactured or fabricated at-depot maintenance level.
- AO Item to be assembled at organizational level.
- AF Item to be assembled at direct support maintenance level.
- AH Item to be assembled at general support maintenance level.
- AD Item to be assembled at depot maintenance level.
- XA Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB Item is not procured or stocked. If not available through salvage, requisition.
- XC Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
- XD Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 70042.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows
- (a) Use (third position). The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

Code Application/Explanation

O - Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- F Support item is removed, replaced, used at the direct support maintenance level.
- H Support item is removed, replaced, used at the general support maintenance.
- D Support items that are removed, replaced, used at depot only.
- (b) Repair (fourth position). The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/ systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code-

Code Application/Explanation

- O The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F The lowest maintenance level capable of complete repair of the support item is direct support.
- H The lowest maintenance level capable of complete repair of the support item is general support.
- D The lowest maintenance level capable of complete repair of the support item is the depot level.

Code Application/Explanation

 L - Repair restricted to designated Specialized Repair Activity.

- Z Non-repairable. No repair is authorized.
- B No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.
- (3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows-

Code Explanation

- Z Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
- O Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
- F Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
- H Repairable item When uneconomically repairable, condemn and dispose at the general support level.
- D Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
- A Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).
- b. Federal Stock Number. Indicates the Federal stuck number assigned to the item and will be used for requisitioning purposes.
- c. Description. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.
- d. Unit of Measure (U/M). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This

measure is expressed by a two-character alphabetical abbreviation: e.g., ea. in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment.

f. 30-Day DS/GS Maintenance Allowances.

NOTE

Allowances in GS column are for GS maintenance only.

- (1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.
- (2) Allowance quantities are indicated in the special tool lists section. for special tools, TMDE, and other support equipment.
- g. 1-Year Allowances Per 100 Equipments/Contingency Planning Purposes. Column intentionally left blank.
- h. Depot Maintenance Allowance Per 100 Equipments. This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.
- e. Illustration. This column is divided as follows:
- (1) Figure number. Indicates the figure number of the illustration on which the item is shown in TM 11-6625-314-15.
- (2) Item number. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

Code Used on AMD AN/USM-33 AME AN/USM-33A

b. The following publications pertain to the equipment and its components:

TM 11-6625-314-15 Operator,

Operator, Organizational, Field, and Depot Maintenance Manual: MultimeterAN/USM-33.

TM 11-6625-314-20P

Organizational Maintenance Repair Parts and Special Tools Lists: Multimeters AN/USM-33 and AN/USM-33A.

1-5. Location of Repair Parts

- a. This manual contains one cross-reference index (sec IV) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.
- b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.
- (1) Refer to the index of Federal stock numbers (sec IV) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.
- (2) Refer to the repair parts list (sec II) and locate the figure number (col 10a) and item number or reference designation (col 10b) as noted in the FSN index.
- c. When the figure and item number or reference designation are known. scrutinize columns 10a and 10b of the repair parts list (sec II) until the item is located.
- d. When the FSN. reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec II), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSELMACRA, Fort Monmouth. N.J 07703.

(Next printed page is 6)

SECTION II TM11-6625-314-34P

(1)	(2)	(3)		(5)		(6) AYS DS LLOWAN			(7) AYS GS I LLOWAN		(8) 1-YEAR	(9)	(10 ILLUSTR	,
				QTY			NOL		LLOWAN	<u> </u>	ALW PER	DEPOT MAINT	ILLOSTI	CATION
SMR	FEDERAL STOCK	DESCRIPTION	UNIT OF	INC	(a)	(b)	(c)	(a)	(b)	(c)	100 EQUIP	ALW PER 100	(a)	(b)
CODE	NUMBER	REFERENCE NUMBER & MFR CODE USABLE ON CODE	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	CNTGCY	EQUIP	FIGURE NO.	ITEM NO.
PAOZZ	6145-542-6092	GROUP 0001 LEAD, TEST CX-2281/USM-33 CABLE, RADIO FPREQUENCY NO-REF-DESIG 10	EA	10	*	*	*	*	*	*		10	6	
PAOZZ	5975-281-9046	RG58CU (80044) CABLE NIPPLE, ELECTRICAL NO-REF-DESIG	EA	2	*	*	*	*	*	*		3	6	3
PAOZZ	5999-230-1212	49 (02871) CLIP, ELECTRICAL NO-REF-DESIG	EA	2	*	*	*	*	*	*		3	6	1
PAOZZ	5935-654-9722	48B 76545) CONNECTOR NO-REF-DESIG	EA	2				*	*	*		3	6	6
PAOZZ	5935-654-9705	124-1017 (95325) TIP, CABLE NO-REF-DESIG	EA	2	*	*	*	*	*	*		3	6	7
PAHHD	5950-655-0569	124-1013 (95325) GROUP 0002 MULTIMETER ME-79/USM-33 COIL L101	EA	1				*	*	*		3	3	3
PAHHD	6625-646-8777	COVER NO-REF-DESIG	EA	1				*	*	*		3	3	1
PAOZZ	6625-646-8770	124-1001 (95325) COVER, TONG, INSULATING NO-REF-DESIG 124-1048 (95325)	EA	2	*	*	*	*	*	*		4	3	11
PAOZZ	6625-646-8765	GASKET NO-REF-DESIG COVER TO CASE	EA	1	*	*	*	*	*	*		5	1	9
PAHZZ	6625-646-8768	GASKET NO-REF-DESIG GLASS TO CLAMP	EA	1				*	*	*		5	1	15
PAOZZ	5355-619-9004	KNOB NO-REF-DESIG	EA	1	*	*	*	*	*	*		3	1	11
PAHZZ	6625-646-8766	GASKET NO-REF-DESIG GLASS TO COVER	EA	1				*	*	*		5	1	14
PAHHD	6625-618-1051	MULTIMETER, REPLACEMENT M101	EA	1				*	*	*		3	7-1	
PAHZZ	5315-652-0401	124-4006 (95325) PIN 1 TRIGGER TO CASE	EA	1				*	*	*		3	2	2
PAHZZ	5940-315-3619	124-1083 (95325) PIN, SPRING NO-REF-DESIG STEEL	EA	1				*	*	*		3	3	5
PAHZZ	5935-543-8910	79-032-156-0812 (72962) RESISTOR, FIXED, WIRE WOUND R104 28.7 OHM PORMO.25%	EA	1				*	*	*		3	7-1	R104
PAHZZ	5905-543-8909	SM4-28R7C (96451) RESISTOR, FIXED WIRE WOUND R103 119.3 OHM PORMO.25%	EA	1				*	*	*		3	7-1	R103
PAHZZ	5905-543-8908	SM4-119R3C (96451) RESISTOR, FIXED, WIRE WOUND R106 180 OHM OHM PORM0.25%	EA	1				*	*	*		3	7-1	R106
PAHZZ	5905-543-8908	SM4-181C (96451) RESISTOR, FIXED, WIRE WOUND R107 180 OHM PORM0.25%	EA	1				*	*	*		3	7-1	R107
PAHZZ	5905-543-8438	SM4-181C (96451) RESISTOR, FIXED, WIRE WOUND R102 472 OHM PORM0.25% SM4-4720C (96451)	EA	1				*	*	*		3	7-1	R102
PAHZZ	5905-543-8907	RESISTOR, FIXED, WIRE WOUND R101 1380	EA	1				*	*	*		3	7-1	R101
PAHZZ	5905-543-8437	SM4-1381C (96451)AMD RESISTOR, FIXED, WIRE WOUND R110 159 840 OHM PORM 0.25% XCS-6A159, 841C	EA					*	*	*		3	7-1	R110

SECTION II TM11-6625-314-34P

(1)	(2)		(4)	(5)	30 D	(6) AYS DS	MAINT	30 D	(7) AYS GS	MAINT	(8)	(9)	(10	·
				QTY	A	LLOWA	NCE	A	LLOWAN	ICE	1-YEAR ALW PER	DEPOT MAINT	ILLUSTR	RATION
SMR	FEDERAL STOCK	DESCRIPTION		UNIT INC	(a)	(b)	(c)	(a)	(b)	(c)	100 EQUIP	ALW PER	(a)	(b)
CODE	NUMBER	REFERENCE NUMBER & MFR CODE USABLE ON CODE	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	CNTGCY	EQUIP	FIGURE NO.	NO.
PAHZZ	5905-543-8909	CONTINUED RESISTOR, FIXED, WIRE WOUND R103 119.3	EA					*	*	*		3	7-1	R103
PAHZZ	5905-543-8437	XCS6A159-841C (96451) RESISTOR, FIXED, WIRE WOUND R111 159 840 OHMS PORMO.25%	EA	1				*	*	*			7-1	R111
PAHZZ	5905-543-8437	XCS6A159-841C (96451)AMD RESISTOR, FIXED, WIRE WOUND R111 159 840 OHMS PORMO.25%	EA	1				*	*	*		3	7-2	R111
PAHZZ	5905-845-7230	XCS6A159-841C (96451)AME RESISTOR, FIXED, WIRE WOUND R110 79, 920OHM PORM0.25%	EA	1				*	*	*		3	7-2	R110
PAHZZ	5905-845-7230	EE22-79921 (96451) AME RESISTOR, FIXED, WIRE WOUND R113 79, 920	EA	1				*	*	*			7-2	R113
PAHZZ	5905-657-0321	EE22-79921 (96451)	EA	1				*	*	*		3	7-1	
PAHZZ	5935-847-0965	124-2016 (95325) RHEOSTAT 3 250 OHM TOTAL RESISTANCE	EA	2				*	*	*		3	5	1b
PAHZZ	5905-847-0965	172-2000 (95325)	EA	2				*	*	*			5	1b
PAHZZ	5905-552-1458	RESISTOR, THERMAL R109 100 OHM PORM10%	EA	1				*	*	*		3	7-1	R109
PAOZZ	5305-619-2436	SCREW, MACHINE NO-REF-DESIG (PECULIAR)	EA	1	*	*	*	*	*	*		5	3	6
PAHZZ	5305-619-5025	124-1066 (95325) SCREW, SHOULDER NO-REF-DESIG	EA	1				*	*	*		5	2	16
PAHZZ	5961-581-8366	124-1104 (95325) SEMICONDUCTOR DEVICE, DIODE CR101	EA	2				*	*	*		3	7-1	CR101
PAHZZ	5961-581-8066	IN69A (80063) SEMICONDUCTOR DEVICE, DIODE CR102	EA	1				*	*	*			7-1	CR102
PAHZZ	6625-646-8773	IN69A (80063) SUPPORT, TRIGGER, TONG NO-REF-DESIG	EA	1				*	*	*		3	4	7
PAHZZ	5933-652-9412	124-1084 (95325) SWITCH, ROTARY S101	EA	1				*	*	*		5	7-1	S101
PAHZZ	5940-617-0789	124-1082 (95325) TERMINAL LUG NO-REF-DESIG	EA	2				*	*	*		5	5	5
PAHZZ	5940-643-6369	56-1028 (95325) TERMINAL LUG NO-REF-DESIG	EA	2				*	*	*		5	2	11
PAHZZ	6625-646-8769	2914-02-00 (78189) TONG ASSEMBLED, FIXED NO-REF-DESIG	EA	1				*	*	*		3	3	12
PAHHD	6625-646-8774	124-1026 (95325) TRIGGER ASSEMBLED 6	EA	1				*	*	*		3	2	1
PAHHD	6625-646-8772	124-2003 (95325) TONG ASSEMBLED, TRIGGER NO-REF-DESIG	EA	1				*	*	*		3	2	4
PAHZZ	5310-619-7054	124-1057 (95325) WASHER, FLAT NO-REF-DESIG	EA	1				*	*	*		5	3	7

SECTION IV TM11-6625-314-34P

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER		FIG.	ITEM	STOCK NUMBER		FIG.	ITEM
5305-619-2436 5305-619-5025 5310-619-7054 5940-315-3619				5930-652-9412 5935-654-9705 5935-654-9722 5940-617-0789		7-1	S101
5315-652-0401 5355-619-9004 5905-543-8437 5905-543-8437 5905-543-8437		6-1 7-1 7-1 7-2	1 R110 R111 R111	5940-643-6369 5950-655-0569 5961-581-8066 5975-281-0046 5999-230-1212		1-2 7-1	L101
5905-543-8438 5905-543-8907 5905-543-8908 5905-543-8908		7-1 7-1 7-1 7-1	R102 R101 R106 R107	6145-542-6092 6625-618-1051 6625-646-8765 6625-646-8766		7-1	M101
5905-543-8909 5905-543-8910 5905-552-1458 5905-657-0321 5905-845-7230		7-1 7-1 7-1 6-1 7-2	R103 R104 R109 R110	6625-646-8768 6625-646-8769 6625-646-8770 6625-646-8772 6625-646-8773			
5905-845-7230 5905-847-0965 5905-847-0965		7-2 6-1 6-1	R113 2 3	6625-646-8774 6625-646-8777		1-1	6
REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM. NO
EE22-79921 EE22-79921 RG58CU SM4-119R3C SM4-1381C SM4-181C SM4-181C SM4-28R7C	96451 96451 80044 95451 96451 96451 96451	7-2 7-2 7-1 7-1 7-1 7-1 7-1	R110 R113 R103 R101 R106 R107 R104	124-1048 124-1050 124-1057 124-1066 124-1082 124-1084 124-1090 124-1096	95325 95325 95325 95325 95325 95325 95325 95325	7-1	S101
SM4-4720C XCS6A159-841C XCS6A159-841C XCS6A159-841C IN69A 124-0163	96451 96451 96451 S6451 80063 95325	7-1 7-1 7-1 7-2 7-1 1-2	R102 R110 R111 R111	124-1104 124-2003 124-2016 124-4006 172-2000 172-2000	95325 95325 95325 95325 95325 95325	1-1 6-1 7-1 6-1 6-1	6 M101 2 3
124-1000 124-1001 124-1013 124-1017 124-1026 124-1027 124-1083	95325 95325 95325 95325 95325 95325 95325	6-1	1	2914-02-00 304B101 48C 49 56-1028 79-032-156-0812	78189 10646 76545 02871 95325 72962	7-1	R109

CREIGHTON W. ABRAMS General, United States Army Chief of Staff

Official:

VERNE L. BOWERS Major General, United States Army The Adjutant General

Distribution:

Active Army USASA (2) Instl (2) except CNGB (1) Ft Gordon (10) ACSC-E(2) Ft Huachuca (10) USAARENBD (2) WSMR (2) Ft Carson (10) **USAMB** (10) AMG (1) Army Dep(2) except CONARC (5) LBAD (14) ARADCOM (2) SAAD (30) ARADCOM Rgn (2) TOAD (14) OS Mai Comd (4) LEAD (7) LOGCOMDS (5) ATAD (10) MICOM (2) Gen Dep (2) TECOM (2) Sig Sec Gen Dep (2) USASTRATCOM (4) Sig Dep (5) HISA (ECOM) (18) Sig FLDMS (1) MDW(1)USAERDAA (1) Armies (2) **USAERDAW (1)** Corps (2) MAAG (1) Svc Colleges (2) USARMIS (1) Ft Richardson (ECOM Ofc) (2) USASESS (5) USAADS (2) WRAMC (1) USAFAS (2) Units org under fol TOE: USAARMS (2) (1 cy each) USAIS (2) 11-158 USAES (2) 29-134 29-136 USAINTS (3) USACDCEC (5)

NG: State AG (3) USAR: None

For explanation of abbreviations used. see AR 310-50.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS SOMETHING WRONG WITH THIS PUBLICATION? FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) THEN. . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL! DATE SENT PUBLICATION DATE PUBLICATION TITLE PUBLICATION NUMBER BE EXACT. . . PIN-POINT WHERE IT IS IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT: FIGURE TABLE NO. TEAR ALONG PERFORATED LINE

SIGN HERE

DA 1 JUL 70 2028-2

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

PREVIOUS EDITIONS • ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 017095-000

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers