TECHNICAL MANUAL

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-288/URM (NSN 6625-00-55fa7-5716)

TECHNICAL MANUAL No. 11-6625-478-14P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 16 December 1976

OPERATORS, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR

MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-288/URM (NSN 6625-00-557-5716)

Current as of 8 October 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

			Page	Figur
S ECTION	I.	Introduction	1	
	II	Repair parts list	5	
Group	00	Maintenance Kit, Electronic Equipment MK-288/URM	5	
	III.	Special tools list (Not applicable)		
	IV.	National stock number and part number index	6	
APPENDIX	Α.	COMPONENTS OF END ITEM LIST (Not applicable)		
	В.	ADDITIONAL AUTHORIZATION LIST (Not applicable)		
	C.	MAINTENANCE ALLOCATION		
S ECTION	I.	Introduction	7	
	II.	Maintenance allocation chart	9	
APPENDIX	D .	EXPENDABLE SUPPLIES AND MATERIALS LIST (Not applicable)		

i

Illus

^{*} This manual supersedes TM 11-6625-478-14P, 29 June 1973.

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts and special tools required for performance of organizational, direct support, and general support maintenance of the MK-288/URM.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.
 - b. Section III. Special Tools List. Not applicable
- c. Section IV. National Stock Number and Part Number Index. A list, in ascending National item identification number (NIIN, last 9 digits) sequence, of all National stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

- a. Illustration. This column is divided as follows:
- (1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.
- (2) *Item number.* The number used to identify each item called out in the illustration.
- b. Source, Maintenance, and Recoverability Codes (SMR).
- (1) Source code. Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

- PA Item procured and stocked for anticipated or known usage.
- XD A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

- O Support item is removed, replaced, used at the organizational level.
- H Support item is removed, replaced, used at the general support level.
- (b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

- H The lowest maintenance level capable of complete repair of the support item is the general support level.
- Z Nonreparable. No repair is authorized.
- (3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

1

Recoverability

Codes Definition

- Z Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- H Reparable item. When uneconomically reparable, condemn and dispose at the general support level.
- c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.
- d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

- e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.
- g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, sub functional group, or an assembly.

4. Special Information

Not applicable.

5. How to locate Repair Parts

- a. When National stock number or part number is unknown.
- (1) First. Using the table of contents, determine the functional group within which the repair part belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.
- (2) *Second.* Find the illustration covering the functional group to which the repair part belongs.
- (3) *Third.* Identify the repair part on the illustration and note the illustration figure and item number of the repair part.
- (4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- *b.* When National stock number or part number is known.
- (1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in ascending NIIN sequence followed by a list of part numbers in ascending alphameric sequence, cross-referenced to the illustration figure number and item number.
- (2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.




Figure 1. Maintenance Kit, Electronic Equipment MK-288/URM.

SECTION II TM 11-6625-478-14P

		SECTION	II			TM 11-6625-478-14P		
(1)		(2)	(3)	(4)	(5)	(6))	(8)
LLUSTR.	ATION (b)		NATIONAL			DESCRIPTION		QTY INC
FIG NO.	LEW NO	SMR CODE	STOCK NUMBER	PART NUMBER	SCM		N	IN JNIT
NO.		CODE	HOWLER	NOMBER	3010	USABLE ON CODE		51411
						GROUP OO MAINTENANCE KIT, ELECTRONIC		
						EQUIPMENT MK-288/URM		
1		AHZZ	5935-00-665-5711	UG1094U	0058	CONNECTOR, RECEPT ACLE, ELECTRICAL	, k	8
1		AHZZ	5935-00-681-568!	UG88CU	0058	CONNECTOR, PLUG, ELECTRICAL	i.	1
1		AHZZ	5935-00-201-2410	UG971U	0058	ADAPTER, CONNECTOR	,	1
1		AHZZ	5935-00-557-986	UG636AU	0058	ADAPTER, CONNECTOR	¥.	1
1		AHZZ	5910-00-636-210	CM15C241J	1349	CAPACITOR, FIXED, MICADIELECTRIC	, k	1
1	4	AHZZ	5905-00-581-747;	RN70849R9F	1349	RESISTOR, FIXED, FILM	l.	3
1		'A OHH	6625-00-557-5711	DA122U	0058	DUMMY LOAD + ELECTRICAL	, L	1
1		AHZZ	5905-00-106-9344	RC20GF101J	1349	RESISTOR, FIXED, COMPOSITION	, k	1
1		AHZZ	5905-00-195-557	RC20GF680J	1349	RESISTOR FIXEO COMPOSITION	*	1
1	11	HHOA	6625-00-557-571	DA121U	0058	DUMMY LOAD, ELECTRICAL	7	1
1	1	KDHZZ		CM15C111J	1349	CAPACITOR, FIXED, MICADIELECTRIC	4	1
1	1.	нноач	6625-00-557-5719	DA123U	0058	DUMMY LOAD, ELECTRICAL	· ·	1
1	1	AHZZ	5910-00-901-8796	CM15C560J	1349	CAPACITOR, FIXED, MICADIELECTRIC	1	1
1	1	HHOA	6625-00-557-572	DA124U	0058	DUMMY LOAD, ELECTRICAL	4	1
t	1	PAHZZ	5999-00-204-520	60CS	6545	CLIP, ELECTRICAL	7	2
1	t	HHOA	5995-00-823-213:	CG1471U	0058	CABLE AS SEMBLY, RADIO FREQUENCY	4	1
1	1	AOZZ	6625-00-557-571	CY1892URM	0058	CASE, ELECTRICAL DUMMY LOAD	1	1
						5		

	STOCK NUMBER	FIG. NO.	ITEM NO.	
	5905-00-106-9344 5905-00-195-5571 5935-00-201-2410 5999-00-204-5206 6625-00-557-5715 6625-00-557-5717 6625-00-557-5719 6625-00-557-5719 6625-00-557-5720 5935-00-581-7472 5910-00-636-2105 5935-00-665-5718 5935-00-681-5685 5995-00-823-2133 5910-00-901-8796	1 1 1 1 1 1 1 1 1 1 1	8 9 3 15 17 10 7 12 14 4 6 5 1 2 16 13	
:	PART NUMBER	FSCM	FIG.	ITEM NO.
CG1471U CM15C111J CM1 5C244J CM15C56OJ CY1892URM DA122U DA122U DA122U DA122U DA124U RC2OGF101J RC2OGF66OJ RN7OB49R9F UG1094U UG636AU UG88CU UG971U 60CS		80058 81349 81349 81349 80058 80058 80058 80058 81349 81349 81349 81349 80058 80058 80058	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	16 11 5 13 17 10 7 12 14 8 9 6 1 4 2 3

6

APPENDIX C

MAINTENANCE ALLOCATION

Section I. INTRODUCTION

C-1. General

This appendix provides a summary of the maintenance operations for MK-288/URM. It authorizes categories of maintenance for specific maintenance functions on repairable items and components and the tools and equipment required to perform each function. This appendix may be used as an aid in planning maintenance operations.

C-2. Maintenance Function

Maintenance functions will be limited to and defined as follows:

- a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination.
- b. Test. To verify serviceability and to detect incipient failure by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean, preserve, drain, paint, or to replenish fuel/lubricants/hydraulic fluids or compressed air supplies.
- d. Adjust. Maintain within prescribed limits by bringing into proper or exact position, or by setting the operating characteristics to the specified parameters.
- e. Align. To adjust specified variable elements of an item to about optimum or desired performance.
- f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test measuring and diagnostic equipment used in precision measurement. Consists of the comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.
- g. Install. The act of emplacing, seating, or fixing into position an item, part, module (component or assembly) in a manner to allow the proper functioning of the equipment/system.

- *h. Replace.* The act of substituting a serviceable like-type part, subassembly, model (component or assembly) for an unserviceable counterpart.
- i. Repair. The application of maintenance services (inspect, test, service, adjust, align, calibrate, replace) or other maintenance actions (welding, grinding, riveting, straightening, facing, remachining, or resurfacing) to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module/component/assembly, end item or system. This function does not include the trial and error replacement of running spare type items as fuses, lamps, or electron tubes.
- j. Overhaul. That periodic maintenance effort (service/action) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards (e.g., DMWR) in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like-new condition.
- k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like-new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours, miles, etc.) considered in classifying Army equipment/components.

C-3. Column Entries

- a. Column 1, Group Number. Column 1 lists group numbers, the purpose of which is to identify components, assemblies, subassemblies and modules with the next higher assembly.
- b. Column 2, Component/Assembly. Column 2 contains the noun names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- c. Column 3, Maintenance Functions. Column 3 lists the functions to be performed on the item listed in column 2. When items are listed without maintenance functions, it is solely for the purpose

of having the group numbers in the MAC and RPSTL coincide.

d. Column 4, Maintenance Category. Column 4 specifies, by the listing of a "worktime" figure in the appropriate subcolumn(s), the lowest level of maintenance authorized to perform the function listed in column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate "worktime" figures will be shown for each category. The number of task-hours specified by the "worktime" figure represents the average time required to restore an item (assembly, subassembly, component, module, end item or system) to a serviceable condition under typical field operating conditions. This time includes preparation time, troubleshooting time and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the maintenance allocation chart. Subcolumns of column 4 are as follows:

- C Operator/Crew
- O Organizational
- F Direct Support
- H General Support
- D Depot

e. Column 5, Tools and Equipment. Column 5 specifies by code, those common tool sets (not individual tools) and special tools, test, and support equipment required to perform the designated function.

C-4. Tool and Test Equipment Requirements (Table 1)

- a. Tool or Test Equipment Reference Code. The numbers in this column coincide with the numbers used in the tools and equipment column of the MAC. The numbers indicate the applicable tool or test equipment for the maintenance functions.
- *b. Maintenance Category.* The codes in this column indicate the maintenance category allocated the tool or test equipment.
- c. Nomenclature. This column lists the noun name and nomenclature of the tools and test equipment required to perform the maintenance functions.
- d. National/NATO Stock Number. This column lists the National/NATO stock number of the specific tool or test equipment.
- e. Tool Number. This column lists the manufacturer's part number of the tool followed by the Federal Supply Code for Manufacturers (5-digit) in parentheses.

SECTION II MAINTENANCE ALLOCATION CHART FOR

MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-288/URM

(I) GROUP	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE	М	AINTEN	(4) ANCE C	ATEGOR	RY	(5) TOOLS AND	
NUMBER		FUNCTION	С	0	F	Н	D	EQUIPMENT	
00	MAINTENANCE KEE, ELECTROLIC FOULPMENT NE-288/GRM	Inspect 1		0.2					
		Service		0.3				3	
		fest				0.5		1	
		Repair 2				1.0		2	
		Repair 3		0.3				3	
			[
						ļ			
				1					
				ĺ		[
							,		
						;			
				-					

⁽¹⁾ Visual
(2) By replacement of connectors, capacitors, and resistors.
(3) By replacement of dummy loads and cable ascemblies.

TABLE 1. TOOL AND TEST EQUIPMENT REQUIREMENTS

MAINTENANCE KIT, ELECTRONIC EQUIPMENT MK-288/URM

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	H,D	MULTIMETER AN/USM-223	6625-00-999-7465	
2	н,D	TOOL KIT, ELECTRONIC EQUIPMENT TK-100G/U	5180-00-605-0079	
3	0	TOOLS AND TEST EQUIPMENT AVAILABLE TO THE ORGANIZATIONAL REPAIR TECHNICIAN BECAUSE OF HIS/HER ASSIGNED MISSION	5180-00-605-0079	
•				

By Order of the Secretary of the Army:

BERNARD W. ROGERS General, United States Army Chief of Staff

Official:

PAUL T. SMITH Major General, United States Army The Adjutant General

```
DISTRIBUTION:
   Active Army:
      USASA (2)
       COE (1)
       TSG (1)
       USAARENBD (1)
       DARCOM (1)
       TRADOC (2)
       OS Maj Cored (4)
       LOGCOMDS (3)
       MICOM (2)
       TECOM (2)
       USACC (4)
       MDW (1)
       Armies (2)
       Corps (2)
       HISA (Ft Monmouth) (33)
       Svc Colleges (1)
       USASIGS (5)
       USAADS (2)
       USAFAS (2)
       USAARMS (2)
       USAIS (2)
   NG: State AG (3); Units-None
   USAR: None
   For explanation of abbreviations used, see AR 310-50.
```

```
USAES (2)
USAICS (3)
MAAG (1)
USARMIS (1)
Installations (2) except
 Fort Carson (5)
 Fort Gillem (10)
 Fort Gordon (10)
 Fort Huachuca (10)
 Ft Richardson (ECOM Ofc) (2)
 LBAD (14)
 SAAD (30)
 TOAD (14)
 SHAD (3)
SigFLDMS (1)
USAERDAA (1)
USAERDAW (1)
Units org under fol TOE: (1)
 29-134
 29-136
```

☆ I U.S. GOVERNMENT PRINTING OFFICE: 1976-703-025 /78

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS

SOMETHING WRONG WITH THIS MANUAL? THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL! DATE TM 11-58/10-340-12 23 Jan 74

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

Commander

Stateside Army Depot ATTN: AMSTA-US

Stateside, N.J. 07703

DATE 10 July 1975

PUBLICATION NUMBER

TEAR ALONG DOTTED LINE

TITLE

Radar Set AN/RS-76

TM 11	5840 -3	340-12		23 Jan 74 Radar Set AN 25-76
BE EXACT	rPIN-PC	INT WHE	REITIS	IN THIS SPACE TELL WHAT IS WRONG
PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.	AND WHAT SHOULD BE DONE ABOUT IT:
2-25	2-28			Recommend that the installation antenna alignment procedure be changed throughout to specify a 2° IFF antenna lag rather than 1°.
				REASON: Experience has shown that with only a 1° lag, the antenna servo syst m is too sensitive to wind gusting in excess of \$\sigma \text{knots}\$, and has a tendency to rapidly accelerate and recelerate as it hunts, causing strain to the drive train. Hunting is minimized by adjusting the lag to 2° without degradation of operation
3-10	3 - 3		3-1	Item 5, Function column. Change "2 db" to "3db."
				REASON: The adjustment procedure for the TRANS POWER FAULT indicator calls for a 3 db (500 watts) adjustment to light the TRANS POWER FAULT indicator.
5-6	5-8			Add new step f.l to read, "Replace cover plate removed in tape."
				REASON: To replace the cover plate.
		F03	3	Zone C 3. On Jl-2, change "+24 VDC to "+5 VDC."
			S.	REASON: This is the output line of the 5 VDC power supply. + 24 VDC is the input voltage.
	me, grade		•	999-1776 SSC. M. Do Servery.

DA , FORM 2028-2 (TEST)

P.S. -- IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND."
A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

HISA 1686-75

	RECOMMENDED CHAI	IGES TO E	QUIPMENT TECHNICAL MANUALS
S S	omethi		WRONG WITH THIS MANUAL?
I MODEA	.JOT DOWN THE BOUT IT ON THIS FEAR IT OUT, FOLD DROP IT IN THE	FROM: (YO	OUR UNIT'S COMPLETE ADDRESS)
PUBLICATION NUMBER	DATE		TITLE
BE EXACT PIN-POINT WHERE IT IS	IN THIS SPACE TELL	WHAT IS WR	ONG
PAGE PARA-GRAPH NO. TABLE NO.	AND WHAT SHOULD BE	E DONE ABO	OUT IT:
TYPED NAME, GRADE OR TITLE, AND TE	LEPHONE NUMBER	SIGN HER	RE:

DA FORM 2028-2 (TEST) P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.



FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD-314



TEAR ALONG DOTTED LINE

Commander

US Army Electronics Command ATTN: DRSEL-MA-Q

Fort Monmouth, New Jersey 07703

FOLD BACK

REVERSE OF DA FORM 2028-2 (TEST)

1					RECOMMEND	ED CHAN	GES TO	EQUIPMENT TECHNICAL MANUALS	
	1,5	- J.	1	$\mathbb S$	OME		JC 1	WRONG WITH THIS MANUAL?	
			DOPE A	JOT DOWN BOUT IT ON TEAR IT OUT DROP IT IN	THIS F. FOLD	FROM: ((YOUR UNIT'S COMPLETE ADDRESS)		
	PUBLICAT	ION NUMBE	R			DATE		TITLE	
1	BE EXACT	PIN-PC	INT WHER		IN THIS SPAC	L CE TELL W			
TEAR ALONG DOTTED LINE	NO.	GRAPH	NO.	NO.					
	TVDE				LEPHONE NUM	950	SIGN HE		, 100 - 100 10

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD-314



TEAR ALONG DOTTED LINE

Commander

US Army Electronics Command ATTN: DRSEL-MA-Q Fort Monmouth, New Jersey 07703

FOLD BACK

! 2	RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS									
	7,7	-31	1	S	OME		JG V	WRONG WITH THIS MANUAL?		
				DOPE A	JOT DOWN ABOUT IT ON TEAR IT OUT DROP IT IN	THIS T. FOLD		OUR UNIT'S COMPLETE ADDRESS)		
ij		<u> </u>		MAIL.			DATE			
	PUBLICATIO	ON NUMBEI	R			DATE		TITLE		
1	BE EXACT PIN-POINT WHERE IT IS IN THIS SPA			IN THIS SPAC	SE TELL W	HAT IS WR	ONG			
TEAR ALONG DOTTED LINE	PAGE NO.	PARA-GRAPH			AND WHAT SI	HOULDBE	DOME ABO	OUT IT:		
ı	i	!	[l					
1	1	ļ	()	1	•					
	TYPEO NAN	E GRADE	OR TITLE	E AND T	ELEPHONE NUM	ARER	SIGN HER	DE.		
	l 25 MAM	-,		., 12			SIGN HER			

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD-314



Commander

US Army Electronics Command ATTN: DRSEL-MA-Q Fort Monmouth, New Jersey 07703

FOLD BACK

REVERSE OF DA FORM 2028-2 (TEST)

TEAR ALONG DOTTED LINE

THE METRIC SYSTEM AND EQUIVALENTS

'NEAR MEASURE

Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches

1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches

1 Kilometer = 1000 Meters = 0.621 Miles

YEIGHTS

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces

1 Kilogram = 1000 Grams = 2.2 lb.

1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces

1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches

1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet

1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

 $5/9(^{\circ}F - 32) = ^{\circ}C$

212° Fahrenheit is evuivalent to 100° Celsius

90° Fahrenheit is equivalent to 32.2° Celsius

32° Fahrenheit is equivalent to 0° Celsius

 $9/5C^{\circ} + 32 = {\circ}F$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	
Miles	Kilometers	
Square Inches	Square Centimeters	
Square Feet	Square Meters	
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	
Cubic Feet	Cubic Meters	
Cubic Yards	Cubic Meters	
Fluid Ounces	Milliliters	
nts	Liters	
arts	Liters	
allons	Liters	
Ounces	Grams	
Pounds	Kilograms	
Short Tons	Metric Tons	
Pound-Feet	Newton-Meters	
Pounds per Square Inch	Kilopascals	
Miles per Gallon	Kilometers per Liter	
Miles per Hour	Kilometers per Hour	
•	- · · · · · · · · · · · · · · · · · · ·	

TO CHANGE	то	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	
Meters	Yards	
Kilometers	Miles	
Square Centimeters	Square Inches	
Square Meters	Square Feet	
Square Meters	Square Yards	1 106
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	
Cubic Meters	Cubic Feet	
Cubic Meters		
Milliliters	Cubic Yards	
	Fluid Ounces	
Liters	Pints	
Liters	Quarts	
'ers	Gallons	
.ms	Ounces	
.ograms	Pounds	
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch.	0.145
ometers per Liter	Miles per Gallon	2.354
meters per Hour	Miles per Hour	



PIN: 020766-000

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers