#### TECHNICAL MANUAL

# ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

**FOR** 

RADAR SIGNAL SIMULATOR SM-756/APR-44(V) (NSN 6940-01-058-1066)

Technical Manual

No. 11-6940-214-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 25 January 1982

## ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR

### RADAR SIGNAL SIMULATOR SM-756/APR-44(V) (NSN 6940-01-058-1066)

Current as of 10 August 1981

#### REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) direct to: Commander, US Army Communications-Electronics Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. A reply will be furnished direct to you.

#### Table of Contents

|         |     |   |      | Illus  |
|---------|-----|---|------|--------|
|         |     |   | Page | Figure |
| Section | Ι.  | Introduction                                | 1    |        |
|         | II. | Repair Parts List                           | 5    |        |
| Group   | 00  | Radar Signal Simulator SM-756/APR-44(V).    | 5    | 1      |
|         | 01  | Gun (No parts authorized)                   |      |        |
|         | 02  | Transit Case (No parts authorized)          |      |        |
|         | 03  | Microwave Cable (No parts authorized)       |      |        |
|         | 04  | 50 Ohm Termination (No parts authorized)    |      |        |
| Section | III | Special Tools List (Not applicable)         |      |        |
|         | IV. | National Stock Number and Part Number Index | 6    |        |
|         |     |   |      |        |

## SECTION I

#### 1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the SM-756/APR-44(V). It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

#### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.
  - b. Section III. Special Tools List. Not applicable.
- c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

#### 3. Explanation of Columns

- a. Illustration. This column is divided as follows:
- (1) *Figure number*. Indicates the figure number of the illustration on which the item is shown.
- (2) *Item number*. The number used to identify item called out in the illustration.
- b. Source, Maintenance, and Recoverability (SMR) Codes.
- (1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

- PA- Item procured and stocked for anticipated or known usage.
- XD- A support item that is not stocked. When required, item will be procured through normal supply channels.

#### NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

- O Support item is removed, replaced, used at the organizational level.
- (b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

- D- The lowest maintenance level capable of complete repair of the support item is the depot level.
- Z- Nonreparable. No repair is authorized.
- (3) *Recoverability code*. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

codes Definition

- Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- D Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- c. *National Stock Number*. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

#### TM 11-6940-214-20P

- d. Federal Supply Code for Manufacturer (FSCM,). The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- e. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications; standards, and inspection requirements to identify an item or range of items.

#### NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.
- g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

#### 4. Special Information

a. The following publication pertains to the SM-756/APR-44(V) and its components:

TM 11-6940-214-12, Simulator, Radar Signal SM-756/APR-44(V) (To be published).

b. National stock numbers (NSN'S) that are missing

from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN'S are established and published, submit exception requisitions to: Commander, US Army Communications-Electronics Command, ATTN: DRSEL-MM, Fort Monmouth, NJ 07703 for the part required to support your equipment.

#### 5. How to Locate Repair Parts

- a. When National stock number or part number is unknown.
- (1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.
- (2) *Second*. Find the illustration covering the functional group to which the item belongs.
- (3) *Third*. Identify the item on the illustration and note the illustration figure and item number of the item.
- (4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- b. When National stock number or part number is known.
- (1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.
- (2) *Second*. After finding the figure and item number, locate the figure and item number in the repair parts list.

#### 6. Abbreviations

Not applicable.

(Next printed page is 4)




Figure 1. Radar Signal Simulator SM-756/APR-44(V).

EL7BR001

| TM11-69<br>SECTION | 940-214-2<br>I II | 0P          |                  |       |                  |                                 |                |     |            |
|--------------------|-------------------|-------------|------------------|-------|------------------|---------------------------------|----------------|-----|------------|
| (1)<br>ILLUSTE     | PATTON            | (2)         | (3)              | (4)   | (5)              | (6)<br>DESCRIPTION              |                | (7) | (8)<br>OTY |
| (A)                | (B)               | NATIONAL    |                  |       |                  | 2200111101                      |                |     | INC        |
| FIG<br>NO          | ITEM<br>NO        | SMR<br>CODE | STOCK<br>NUMBER  | FSCM  | PART<br>NUMBER   |                                 | USABLE ON CODE | U/M | IN<br>UNIT |
|                    |                   |             |                  |       |                  | GROUP 00 RADAR SIGNAL SIMULATOR |                |     |            |
|                    |                   |             |                  |       |                  | SM-756/APR-44(V)                |                |     |            |
| 1                  | 1                 | PAODD       |                  | 80058 | CY-7714/APR-44   | CASE, RADAR SIM                 |                | EA  | 1          |
| 1                  | 2                 | PAODD       | 6940-01-061-8907 | 80058 | SM-757/APR-44(V) | SIMULATOR, RADAR SIG            |                | EA  | 1          |
| 1                  | 3                 | PAOZZ       |                  | 93346 | 2252262-501      | CABLE ASSEMBLY, RP              |                | EA  | 1          |
| 1                  | 4                 | XDOZZ       |                  | 16179 | 2001-6100-00     | TERMINATION                     |                | EA  | 1          |

SECTION TV TM11-6940-214-20P

| SECTION IV        | MODE AND DADE MUNDED        | TAIDIN |              |        | TM11-6940-214-20P |        |      |
|-------------------|-----------------------------|--------|--------------|--------|-------------------|--------|------|
| NATIONAL STOCK NO | MBER AND PART NUMBER FIGURE | ITEM   |              | FIGURE | ITEM              |        |      |
| STOCK NUMBER      | NO                          | NO     | STOCK NUMBER | NO     | NO                |        |      |
| 6940-01-061-8907  | 1                           | 2      |              |        |                   |        |      |
|                   |                             | FIGURE | ITEM         |        |                   | FIGURE | ITEM |
| FSCM              | PART NUMBER                 | NO     | NO           | FSCM   | PART NUMBER       | NO     | NO   |
| 80058             | CY-7714/APR-44              | 1      | 1            | 16179  | 2001-6100-00      | 1      | 4    |
| 80058             | SM-757/APR-44(V)            | 1      | 2            | 93346  | 2252262-501       | 1      | 3    |

E. C. MEYER General, United States Army Chief of Staff

Official:

ROBERT M. JOYCE Brigadier General, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, Organizational maintenance requirements for OV-1D/RV-21 and UH-1D/H, EH-1H Aircraft.

U.S. GOVERNMENT PRINTING OFFICE: 1982-564-016/186

## DEPARTMENT OF THE ARMY US ARMY AG PUBLICATIONS CENTER 1655 WOODSON ROAD ST. LOUIS, MISSOURI 63114

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY DOD 314



PIN: 050487-000

### This fine document...

Was brought to you by me:



### <u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=http://www.liberatedmanuals.com/>Free Military and Government Manuals</A>

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers