


OPERATOR'S MANUAL



**LOADER, SCOOP TYPE, DED
4x4, ARTICULATED FRAME STEER,
2-1/2 CUBIC YARD
(J.I.CASE MODEL MW24C)
(NSN 3805-01-150-4814)**

**TABLE OF CONTENTS
PAGE i**

**EQUIPMENT DESCRIPTION
PAGE 1-4**

**TECHNICAL PRINCIPLES OF OPERATION
PAGE 1-9**

**DESCRIPTION AND USE OF OPERATOR'S
CONTROLS AND INDICATORS PAGE 2-1**

**PREVENTIVE MAINTENANCE CHECKS AND
SERVICES PAGE 2-26**

**OPERATION UNDER USUAL CONDITIONS
PAGE 2-45**

**TROUBLESHOOTING SYMPTOM INDEX
PAGE 3-3**

**TROUBLESHOOTING TABLE
PAGE 3-4**

**MAINTENANCE PROCEDURES
PAGE 3-35**

**REFERENCES
PAGE A-1**

**EXPENDABLE/DURABLE SUPPLIES AND
MATERIALS LIST PAGE D-1**

**ALPHABETICAL INDEX
PAGE INDEX 1**

Approved for public release, Distribution is unlimited.

WARNING

TOXIC/FLAMMABLE

Dry cleaning solvent P-D-680 used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and get medical aid immediately.

Starting fluid is toxic and highly flammable. Container is pressurized to act as an expellent. Don't heat container and don't discharge starting fluid in confined areas or near open flame. Don't discard used container in an open flame. To do any of the above will cause an explosion. Don't breathe ether vapor or allow ether to come in contact with your skin. To do so will cause severe injury or death.

WARNING

HIGH VELOCITY AIR

Compressed air used for cleaning purpose will not exceed 30 psi. Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc). Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

WARNING

FALLING EQUIPMENT

Be careful when inspecting blade cutting edges not to place any part of your body between clamshell and blade. To do so could cause serious injury if clamshell suddenly closes crushing you.

When using chain hoist to remove or install parts, be sure chain hoist is securely fastened to the part and that all slack in chain is taken up. Failure to do so could cause serious injury due to the part falling on you. If you are injured by falling equipment, obtain medical aid immediately.

WARNING

TOWING THE LOADER

Don't allow personnel in or near the loader when it is being towed with the engine stopped. To do so could cause serious injury or death.

WARNING

EXHAUST GASES CAN BE DEADLY

Exhaust gases can produce symptoms of headache, dizziness, loss of muscular control, or coma. Permanent brain damage or death can result from severe exposure. You can insure your safety by following these rules: DON'T operate the heater or engine in an enclosed area unless it is properly ventilated. DON'T drive with any of the loader's inspection plates, cover plates, or the hood off unless necessary for maintenance. If you notice exhaust odors or exposure symptoms, IMMEDIATELY VENTILATE the area.

If symptoms persist, remove the affected people and treat them:

- Expose them to fresh air.
 - If necessary, give artificial respiration.
 - Keep them warm.
- DON'T permit physical exercise.

Refer to FM 21-11, First Aid for Soldiers, for first aid treatment of injured personnel.

WARNING

ROTATING FAN BLADES

Before adjusting position of defogger fan, be sure it is not operating. Failure to do so could cause serious injury to fingers or hand by rotating fan blade. If you injure your fingers or hand, obtain medical aid immediately.

WARNING

SAFETY HAZARD

When upper door is opened, be sure you latch it to side of cab. Failure to do so will allow door to swing back and forth causing glass to break and injuring you.

WARNING

OIL UNDER PRESSURE

Hydraulic reservoir is pressurized. Shut off engine and operate hydraulic control valves before removing hydraulic reservoir fill cap. Failure to do so could cause serious injury or death.




NOISE HAZARD

Noise level exceeds 85 dB when operating loader with cab windows open. All personnel shall wear a hearing protective device when operating loader with windows open to prevent hearing loss.



EXPLOSIVE HAZARD

Don't use jumper cables connected to battery terminals to start engine or charge batteries. Always use slave receptacle. Failure to do so could cause serious injury due to batteries exploding caused by improper connection of jumper cables to battery terminals.




STEAM UNDER PRESSURE

Remove radiator cap slowly to relieve pressure before completely removing when engine is hot. Failure to do so could cause severe burns due to hot steam scalding you. If you are scalded by hot steam, seek medical aid immediately.



Before starting engine, check and be sure that transport/service link is in released position. Failure to do so will cause loss of steering control which may result in serious injury or death and extensive property damage.



Always use hand rails and steps when you mount or dismount loader. Don't use steering wheel or controls as a hand rail. Any other method of mounting or dismounting loader could make you slip and fall causing serious injury to yourself.



Before starting engine, fasten your seat belt securely and be sure parking brake is applied, transmission control lever is in neutral (N) position, and both cab doors are closed. Failure to do so could cause serious injury or death due to an accident.



Operating on a hillside can be dangerous. Rain, snow, loose gravel, soft grounds etc., change ground conditions. Only you, the operator, can determine if your machine can be safely operated on any hillside or ramp.

WARNING

Before you operate on any hillside or ramp, always select low range and never coast down hill with transmission in neutral (N). To do so could cause you to lose control of loader and roll over causing loss of life or serious injury and extensive property damage.

WARNING

Keep loader bucket as low as possible. This low position gives better balance and permits you to see ground condition more clearly. If bucket is full and you move loader over rough terrain or terrain that can cause loader to slide, always operate loader at slow speed. Failure to do so could cause you to lose control over loader causing serious injury or loss of life and extensive property damage.

Before moving loader up ramps, remove all ice, oil or grease from ramp to prevent loader from falling and causing death or serious injury and extensive damage to loader. Tell personnel to move away from loader.

WARNING

Don't allow personnel in or near the loader when it is being towed with the engine stopped. To do so could cause serious injury or death.

WARNING


Diesel fuel is highly combustible. Do not smoke or allow open flames or sparks into the area. Death or severe injury may result if personnel fail to observe this precaution. If you are burned, obtain medical aid immediately.

WARNING


Before performing any loader maintenance that requires servicing in area between front and rear chassis, be sure that transport/service link is engaged. Failure to do so could cause serious injury or death due to chassis pivoting and crushing you when you are working in area between front and rear chassis.

WARNING

Don't depress button in center of steering wheel while operating loader. Button is not a horn button. Depressing this button causes steering wheel to collapse for shipment purposes. If you depress this button while operating loader, steering wheel will collapse. Your fingers could be crushed between steering wheel and windshield wiper motor bracket causing painful injury to fingers.



Left Front View



Right Rear View

MW24C Loader

Change
No. 2

TECHNICAL MANUAL

**HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 19 December 2008**

**OPERATOR'S MANUAL
FOR
LOADER, SCOOP TYPE, DED,
4 x 4, ARTICULATED FRAME STEER,
2-1/2 CUBIC YARD
(J.I. CASE MODEL MW24C)
(NSN 3805-01-150-4814)**

TM 5-3805-262-10, 01 September 1987, is changed as follows:

1. Remove old pages and insert new pages.
2. New or changed material is indicated by a vertical bar in the margin of the page.

Remove Pages	Insert Pages
i/ii	A/(B blank) I/II
1-15 and 1-16	1-15 and 1-16
DA Form 2028 Sample	DA Form 2028 Sample
DA Form 2028 (3 copies)	DA Form 2028 (3 copies)

3. File this change sheet in front of the publication for reference purpose.

TM 5-3805-262-10 C02

By Order of the Secretary of the Army:

Official:

A handwritten signature in black ink, reading "Joyce E. Morrow". The signature is written in a cursive style with a large, stylized "J" and "M".

JOYCE E. MORROW
*Administrative Assistant to the
Secretary of the Army*

0833006

GEORGE W. CASEY, JR.
*General, United States Army
Chief of Staff*

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 252302, requirements for TM 5-3805-262-10.

CHANGE

No. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 02 August 1990

OPERATOR'S MANUAL

**LOADER, SCOOP TYPE, DED, 4 x 4 ,
ARTICULATED FRAME STEER,
2-1/2 CUBIC YARD
(J.I. CASE MODEL MW24C)
(NSN 3805-01-150-4814)**

TM 5-3805-262-10, 01 September 1987, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin and by a vertical bar adjacent to the TA number.

Remove Pages

*i and ii
2-33 and 2-34
2-39 and 2-40*

Insert Pages

*I and ii
2-33 and 2-34
2-39 and 2-40*

3. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

THOMAS F. SIKORA
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-25-E (Block 2302) Unit maintenance requirements for TM 5-3805-262-10.

LIST OF EFFECTIVE PAGES

Date of issue for original manual is:

Original 01 September 1987

Change 1 02 August 1990

Change 2 19 December 2008

Total number of pages for front and rear matter is 26 and total number of pages is 198, consisting of the following:

Page No.	*Change No.	Page No.	*Change No.
Cover	0		
a to d	0		
i thru iv	0		
1-1 thru 1-14	0		
1-15	2		
1-16 thru 1-26	0		
2-1 thru 2-32	0		
2-33 and 2-34	1		
2-35 thru 2-39	0		
2-40	1		
2-41 thru 2-69/(2-70 Blank)	0		
3-1 thru 3-47/(3-48 Blank)	0		
A-1 and A-2	0		
B-1 and B-2	0		
C-1/(C-2 Blank)	0		
D-1 thru D-4	0		
INDEX 1 thru INDEX15/ (INDEX 16 Blank)	0		
DA Form 2028 Sample	2		
DA Form 2028 (three copies)	2		
Back Cover	0		

* Zero in this column indicates an original page or work package.

OPERATOR'S MANUAL

LOADER, SCOOP TYPE, DED, 4 X 4, ARTICULATED FRAME STEER,
2-1/2 CUBIC YARD
(J.I.CASE MODEL MW24c)
(NSN 3805-01-150-4814)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, or the Army Electronic Product Support (AEPS) website. The Internet address is <https://aeps.ria.army.mil>. The DA Form 2028 is located under the Public Applications section in the AEPS Public Home Page. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or E-mail your letter or DA Form 2028 direct to: AMSTA-LC-LMPP / TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is ROCK-TACOM-TECH-PUBS@conus.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

	Page
HOW TO USE THIS MANUAL	iii
CHAPTER 1 INTRODUCTION	1-1
Chapter Overview	1-1
Section I General Information	1-1
Section II Equipment Description	1-4
Section III Technical Principles of Operation	1-9
CHAPTER 2 OPERATING INSTRUCTIONS	2-1
Chapter Overview	2-1
Section I Description and Use of Operator-s Controls and Indicators	2-1
Section II Preventive Maintenance Checks and Services (PMCS)	2-26
Section III Operation Under Usual Conditions	2-45
Section IV Operation Under Unusual Conditions	2-66
CHAPTER 3 MAINTENANCE INSTRUCTIONS	3-1
Chapter Overview	3-1
Section I Lubrication Instructions	3-1
Section II Troubleshooting Procedures	3-3
Troubleshooting Symptom Index	3-3
Troubleshooting Table	3-4

		Page
Section III	Maintenance Procedures	3-35
APPENDIX A.	REFERENCES	A-1
APPENDIX B.	COMPONENTS OF END ITEM (COEI) AND BASIC ISSUE ITEMS (BII) LISTS	B-1
APPENDIX C.	ADDITIONAL AUTHORIZATION LIST (AAL)	C-1
APPENDIX D.	EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	D-1
	ALPHABETICAL INDEX	Index 1

HOW TO USE THIS TECHNICAL MANUAL

This manual is designed to help you operate and maintain the MW24C loader. It's divided into chapters, sections, and appendices. The chapters contain general information, operating procedures, and maintenance procedures. Chapters are divided into sections containing equipment description, principles of operation, description of operating controls and indicators, operating procedures, and troubleshooting and maintenance procedures.

Appendices contain supplemental information which you require to operate and maintain the loader.

Procedures in this manual tell you several things:

- how to perform your PMCS and how often
- how to start the loader including locations of all controls and indicators
- how to operate the loader safely and efficiently
- how to troubleshoot the loader
- how to maintain the loader

All operating, troubleshooting, and maintenance procedures include illustrations to help you quickly locate the items on your equipment.

To quickly locate data in this manual, let's say you want to find out the function and use of the hydraulic control levers mounted to the right of your seat. There are two ways you can locate this information.

a. Use the alphabetical index:

- (1) Look on the front cover index for ALPHABETICAL INDEX.
- (2) See that there is a black box drawn to the right of ALPHABETICAL INDEX.
- (3) Flip through the pages starting at the back of this manual stopping at the page that has a black box in line with the box on the front cover index. This is the alphabetical index.
- (4) The alphabetical index contains subject matter listed in alphabetical sequence. Look up Hydraulic control levers or Loader controls. In some cases, subject matter may be listed in several different ways to help you locate the information. Across from these two entries you will find the page number 2-19.
- (5) Turn to page 2-19 where you will find a short functional description and operation of the hydraulic control levers.

(b) Use the front cover index:

- (1) Look on the front cover index for DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS.
- (2) See that there is a black box drawn to the right of this entry.

(3) Flip through the pages starting at the back of this manual stopping at the page that has a a black box in line with the box on the front cover index. This is the DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS, page 2-1.

(4) Look in the section index and locate Loader Controls. It states the loader controls are provided in paragraph 2-10.

(5) Flipping through the pages, see that paragraph numbers are always located at the top of the left page. Now, go to paragraph 2-10 (page 2-21) to locate the information you want.

This manual has been designed so that you can quickly locate data you are looking for. Either look in the ALPHABETICAL INDEX for the subject matter, refer to the front cover index, table of contents, chapter index, or section index to locate the data.

CHAPTER 1

INTRODUCTION

CHAPTER OVERVIEW

The purpose of this chapter is to acquaint you with the maintenance forms, records, and reports that you must maintain for the MW24C loader, to familiarize you with the purpose and capabilities of the vehicle, and to give you a brief description of its different systems and components.

Index

Section	Title	Page
I	General Information	1-1
II	Equipment Description	1-4
III	Technical Principles of Operation	1-9

Section I. GENERAL INFORMATION

	Para
Scope	1-1
Maintenance Forms, and Records	1-2
Hand Receipt (-HR) Manuals	1-3
Reporting Equipment Improvement Recommendations (EIR'S)	1-4
Warranty Information	1-5
Orientation	1-6
List of Abbreviations	1-7

NOTE

The equipment described herein is non-metric and does not require metric common or special tools; therefore, metric units are not supplied. Tactical instructions for sake of clarity will also remain non-metric.

a. Type of Manual. Operator's Manual, including operating, maintenance, and troubleshooting instructions.

b. Model Number and Equipment Name. MW24C Diesel Engine Driven, 4 by 4, Articulated Frame Steer, 2-1/2 Cubic Yard Scoop Type Loader.

1-1. SCOPE (CONT)

c. Purpose of Equipment. Loading trucks from stockpiles, stockpiling materiel, and excavating undisturbed and compacted soil. Unit also used as a clamshell to handle irregular shaped objects, as a dozer for general bulldozer work, and as a scraper.

1-2. MAINTENANCE FORMS,AND RECORDS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS).

1-3. HAND RECEIPT (-HR) MANUALS

This manual has a companion document with a TM number followed by "-HR" (which stands for Hand Receipt). The TM 5-3805-262-10-HR consists of preprinted hand receipts (DA Form 2062) that list end item related equipment (i.e., COEI, BII, and AAL) you must account for. As an aid to property accountability, additional -HR manuals may be requisitioned as outlined in DA PAM 310-10.

1-4. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR'S)

If your MW24C loader needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, US Army Tank-Automotive Command, ATTN: AMSTA-MV Warren, MI 48397-5000. We'll send you a reply.

1-5. WARRANTY INFORMATION

The MW24C loader is warranted by J.I. Case Company, Racine, Wisconsin for 15 months or 1500 hours of operation, whichever occurs first. Warranty starts on the date, found in block 23, DA Form 2408-9 in the logbook. Report all defects in material or workmanship to your supervisor who will take appropriate action through your organizational shop.

1-6. ORIENTATION

The loader bucket is mounted at the front of the MW24C and the engine faces the rear. Controls for operating the bucket (lift arm, bucket tilt, clam) are located to the right when you are sitting in the operator-s seat. All references to right, left, front , or rear are from the viewpoint of the operator when he is sitting in the operator's seat.

1-7. LIST OF ABBREVIATIONS

ABBREVIATION	DEFINITION
A	After
AAL	Authorized allow- ance list
AMP	Amperes
AR	Army regulations
ATTN	Attention
B	Before
BII	Basic issue items
BRT.	Bright
B.O.	Black out
C	Celsius
COEI	Components of end items
COMPT	Compartment
CONT	Continued
CONV	Converter
D	Daily
DA	Department of the Army
dB	Decibel
EIR	Equipment improve- ment recommenda- tions
etc.	Etcetera (unspeci- fied additional things)

ABBREVIATION	DEFINITION
F	Fahrenheit
H	High (forward)
HR	Hand receipt
L	Low (forward)
lb-ft	Pounds feet
M	Monthly
MI	Michigan
MO	Missouri
MPH	Miles per hour
N	Neutral
NEUT.	Neutral
Para	Paragraph
PMC S	Preventive main- tenance checks and services
PRESS	Pressure
psi	Pounds per square inch
R	Reverse
rpm	Revolutions per minute
SER.	Service
TEMP	Temperature
TM	Technical Manual
W	Weekly

Section II. EQUIPMENT DESCRIPTION

	Para
Equipment Characteristics, Capabilities, and Features	1-8
Location and Description of Major Components . .	1-9
Differences Between Models	1-10
Equipment Data	1-11

1-8. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

a. Purpose of MW24C Loader. Loading trucks and railcars from stockpiles, stockpiling materiel, and excavating undisturbed and compacted soil. Unit also used as a clamshell to handle irregular shaped objects, as a dozer for general bulldozer work, and as a scraper.

- b. Capabilities and Features.
- (1) Two and one-half yard capacity bucket.
 - (2) Operates over rough terrain.
 - (3) Four speed ranges in forward; two speed ranges in reverse.
 - (4) Declutch pedal disengages transmission during loader operation to provide maximum hydraulic power when needed.
 - (5) Diesel engine driven.
 - (6) Power steering.
 - (7) Power assisted air over hydraulic brakes.
 - (8) Enclosed operator's compartment.
 - (9) Auxiliary steering automatically cuts-in if primary steering is disabled.
 - (10) Bucket height control to automatically stop loader lift arms at a preselected dump height.
 - (11) Bucket return-to-dig control to automatically return bucket to preselected position.
 - (12) Four-in-one bucket used as a scraper, blade, clamshell, or standard bucket .
 - (13) Ford depths up to 30 inches.
 - (14) Collapsible steering wheel for air transport.

1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

ENGINE. J.I.Case Model A504BD Diesel engine having a displacement of 504 cubic inches. Accessories mounted on and considered a part of the engine include the alternator, air compressor, starting motor, fuel injection pump, and fuel filters.

FUEL SYSTEM. Consists of fuel injectors, fuel injection pump, electric fuel pump, air cleaner, fuel filters, and cold start kit.


EXHAUST SYSTEM. Consists of muffler and exhaust pipe. Muffler mounted on top of engine.

COOLING SYSTEM. Includes radiator mounted in rear of loader, thermostat and housing, engine driven water pump, and fan.

ELECTRICAL SYSTEM. 24 volt, negative ground. Includes engine driven alternator, starter motor, instrument panels, light system, and two 12 volt batteries connected in series.

BRAKES. Disk brakes, air over hydraulic. Air actuated drum type parking brake located on transmission output shaft.

STEERING SYSTEM. Consists of steering wheel, steering column and gear, and two steering cylinders. Power assist provided by hydraulic pump mounted on and driven by transmission. Also includes auxiliary steering system.



FRAME AND TOWING ATTACHMENTS. Two section frame consisting of front and rear chassis; drawbar pin located at rear of loader.

SIGNALING DEVICES. Consists of back-up alarm and turn signals. Back-up alarm located at rear of loader; sounds when transmission is shifted into reverse. Turn signals located at top of cab; turn signal switch mounted on steering column.

TRANSMISSION AND DRIVE SHAFTS. Four speeds in forward and two speeds in reverse. Has declutch feature which permits neutralizing transmission. Three drive shafts used to transmit power to front and rear axles.

AXLES AND WHEELS. Standard planetary axles; pneumatic tires.

CAB. Fully enclosed and removable for shipment purposes when necessary. With doors, windows, and front and rear windshields.

ACCESSORIES. Includes air horn and control valve, windshield washer and wiper, outside mirrors, heater, and fan defrosters.

HYDRAULIC SYSTEM. Consists of hydraulic main pump assembly/steering pump, control valve assembly, hydraulic cylinders (lift arm, bucket tilt, and clam), hydraulic reservoir, and hydraulic filter.

EARTHMOVING COMPONENTS. Includes bucket lift arms and pivot assemblies and loader bucket assembly.

1-10. DIFFERENCES BETWEEN MODELS


There are no differences between models of the MW24C loader.

1-11. EQUIPMENT DATA

Manufacturer J.I. Case
Model MW24C

Dimensions and Weight

Overall operating height (A)	16 feet, 1-1/2 inches
Dump clearance at maximum height, 45 degrees dump (B)	9 feet
Dump reach at maximum height, 45 degrees dump (C)	3 feet, 1 inch
Dump reach at 7 feet dump height, 45 degrees dump (D)	4 feet, 5 inches
Height to bucket hinge pin (E)	12 feet, 2-1/2 inches
Maximum shipping height (F)	10 feet, 10-1/2 inches
Overall length, bucket on ground (G)	22 feet, 5-1/2 inches
Overall width 1	94-1/2 inches
Wheel base (H)	10 feet, 1-1/2 inches
Tire tread	77 inches
Ground clearance (I)	16 inches
Height to top of steering wheel (J)	106-1/2 inches
Overall height without cab	106-1/2 inches
Width overtires	100 inches

1-11. EQUIPMENT DATA (CONT)

Dimensions and Weight (Continued)

Total weight	25,900 pounds
Front axle weight	12,750 pounds
Rear axle weight	13,150 pounds

Capacities

Cooling system	11.25 gallons
Cold weather protection	
To zero degree	2.5 gallons ethylene glycol
To -20 degrees F	3 gallons ethylene glycol
To -40 degrees F	3.75 gallons ethylene glycol
Fuel tank	58 gallons
Engine crankcase	18 quarts refill; 20 quarts with filter change
Transmission	7.5 gallons refill; 9 gallons total system capacity
Axles (each)	
Front differential carrier	26 quarts
Rear differential carrier	20 quarts
Planetary ends (each)	3.5 quarts
Hydraulic reservoir	17 gallons refill; 29 gallons total system capacity

1-11. EQUIPMENT DATA (CONT)

Loader bucket

Width	101 inches
Rated capacity	2-1/2 yards

Tires

Size	20.5 X 25
Air pressure	40 psi

Performance speeds (MPH)

Forward

1st low range	2.6
2nd low range	6.5
3rd high range	11.4
4th high range	22.2

Reverse



1st	3.6
2nd	8.7

Military Load Classification

Empty	13
Loaded	21

Section III. TECHNICAL PRINCIPLES OF OPERATION

	Para		Para
Fuel System	1-12	Transmission and Drive Shafts	1-15
Cooling System	1-13	Transmission Controls	1-15a
Electrical System	1-14	Drive Shafts	1-15b
Vehicle Lights	1-14a	Brakes	1-16
Switches and Circuit Breakers	1-14b	Steering System	1-17
Warning Indicators	1-14c	Frame and Towing Attachments	1-18
Gages	1-14d	Cab	1-19
Slave Receptacle and Hour-		Accessories	1-20
meter/Tachometer	1-14e	Hydraulic System	1-21
Batteries and Cables	1-14f	Signaling Devices	1-22
Wiring Harnesses	1-14g	Earthmoving Components	1-23

1-12. FUELSYSTEM

AIR PRECLEANER AND CLEANER. Removes dust and dirt from air before application to engine through intake manifold. Metal shell houses replaceable inner and outer filter elements. Squeezing ends of vacuator valve (located at bottom of metal shell) releases dust and dirt from air cleaner housing.

AIR CLEANER RESTRICTION INDICATOR. Indicates restriction of air flow through air cleaner due to dirty or clogged filter elements. Filter elements servicing is required when red signal within indicator is in full view. After servicing filter elements, indicator is reset by depressing button on top of indicator.

FUEL TANK AND FUEL FILLER. Fuel tank holds approximately 58 gallons of Diesel fuel; located at rear of loader. Fuel filler neck and removable cap located at right rear of loader. Accessible by unlocking and removing right rear side panel. Drain plug located at bottom of fuel tank.

COLD START SWITCH. When depressed, injects ether starting fluid into intake manifold. This switch is used to start engine in cold weather only. It operates when ignition key switch is in start position and starter is cranking.

1-12. FUEL SYSTEM (CONT)



ACCELERATOR PEDAL. Depressing pedal with foot increases fuel flow and engine speed. Releasing pedal decreases fuel flow and engine speed. Pedal is spring loaded to return to low speed position when released.

FUEL LEVEL GAGE. Electrically operated meter type. With ignition key switch in ON position, FUEL LEVEL gage indicates quantity of fuel remaining in fuel tank.

FUEL SHUT OFF CONTROL (ENGINE STOP). Cable connected to fuel injection pump fuel shut off lever. When pulled out, fuel is unable to enter fuel injection pump effectively stopping engine operation.

FUEL INJECTOR LINES. Fuel is routed to six fuel injectors from fuel injection pump through rigid metal tubes. Return (leak-off) fuel is routed through rigid metal tubes interconnecting each fuel injector back to fuel injection pump.

1-13. COOLING SYSTEM






RADIATOR. Located at rear of loader. Engine coolant circulated through radiator giving up its heat to air stream developed by belt driven fan. Cooled coolant drawn from bottom of radiator by water pump and discharged into lower part of cylinder block. Radiator has oil cooler built into its bottom for cooling transmission hydraulic oil. Radiator cap accessible by unlocking and raising access panel located at top rear of loader.

WATER TEMP GAGE. Indicates engine coolant temperature. Normal operating temperature is in green zone.

1-14. ELECTRICAL SYSTEM

a. Vehicle Lights.

VEHICLE LIGHTS SWITCH. Contains three separate switch sections used to control all vehicle lights. Ignition key switch must be turned to on position for this switch to operate.



1-14. ELECTRICAL SYSTEM (CONT)

a. Vehicle Lights (Cont).

FLOOD LIGHTS SWITCH. Independently turn front and rear flood lights on and off. Vehicle lights switch must be in SER. DRIVE position for this switch to operate.

BLACK OUT DRIVING LAMP. Mounted on left front fender. Provides forward black out illumination during tactical operations. Controlled by vehicle lights switch.

FRONT FLOOD LAMPS. Two sealed beam type lamps mounted on mounting brackets at front left and right sides of loader. Illuminate work area in front of loader. Turned on and off with FLOOD LIGHTS switch.


DRIVING LAMPS. Two sealed beam type lamps mounted above flood lamps at left and right sides of loader. Illuminate area in front of loader for driving at night.

REAR FLOOD LAMPS. Two sealed beam type lamps mounted on mounting brackets at rear left and right sides of loader within radiator guard and behind radiator grille. Illuminate work area in rear of loader. Turned on and off with FLOOD LIGHTS switch.

STOP AND TAIL LIGHTS. Two light assemblies mounted on brackets within radiator guard, behind radiator grille. Includes incandescent lamp and red plastic lens. Tail lights turned on by vehicle lights switch. Stop lights normally off; turned on by pressing brake treadle valve or declutch treadle valve.

BLACK OUT STOP LIGHT-TAIL LIGHT. Two light assemblies mounted in protective metal housings within radiator guard, behind radiator grille. Each assembly contains two incandescent lamps. Provide stop light and tail light illumination during tactical operations. Tail lights turned on and off by vehicle lights switch. Stop lights are normally off; turned on by pressing brake treadle valve or declutch treadle valve.

b. Switches and Circuit Breakers.




IGNITION KEY SWITCH. Four position key switch controls power to all vehicle electrical circuits.

DIMMER COMPT LIGHTS CONTROL. Rheostat. Controls brightness of left instrument panel cluster illumination lamps, voltmeter gage illumination lamp, and cab dome light.

5 AMP CIRCUIT BREAKER (A). Resettable circuit breaker. Protects auxiliary steering circuit, air brake pressure switch and buzzer, gages, warning lights, and voltmeter, cab relay solenoid, and electric fuel pump.

5 AMP CIRCUIT BREAKER (B). Resettable circuit breaker. Protects return-to-dig and bucket height control circuits.

c. Warning Indicators.



BRAKE ENGAGED INDICATOR. When lit, indicates either parking brake is engaged or brake system air pressure is too low for safe loader operation.

ENGINE OIL PRESS INDICATOR. When lit with engine operating, indicates engine oil pressure is too low and damage to engine will occur if you continue to operate engine.

CLUTCH PRESS INDICATOR. Will light if declutch treadle valve is pressed with engine operating, if transmission converter oil pressure is too low, or if parking brake is engaged. If transmission converter oil pressure is too low, continued loader operation will damage transmission.


AIR PRESSURE WARNING ALARM. Sounds when brake system air pressure is too low for safe loader operation.

HYDRAULIC FILTER INDICATOR. When lit, indicates hydraulic filters (steering and hydraulic system) require replacement.

AUXILIARY STEERING BUZZER AND INDICATOR. Buzzer sounds and indicator lights warning operator that hydraulic pump has failed and auxiliary steering system has been energized and is now operating. If this happens, you must stop loader operation and notify next higher maintenance level.

1-14. ELECTRICAL SYSTEM (CONT)

d. Gages.



CONV TEMP GAGE. Indicates operating temperature of transmission torque converter. Normal temperature is in green area of gage.

AIR PRESS GAGE. Indicates brake system air pressure. Air pressure is normal when pointer is in green area of gage.

FUEL LEVEL GAGE. Indicates amount of fuel in fuel tank.


WATER TEMP GAGE. Indicates temperature of engine coolant. Coolant temperature is normal when pointer is in green area of gage.

VOLTMETER GAGE. Indicates voltage level of batteries. Voltage is normal when pointer indicates 24 volts 22 volts with ignition key switch in on position.

e. Slave Receptacle and Hourmeter/Tachometer.

SLAVE RECEPTACLE. Permits charging of batteries or slave starting of engine from an external power source. Also provides power source for slave starting other equipment. 24 volt negative ground.


HOURLMETER/TACHOMETER. Indicates engine operating time in hours and tenths of hours and engine rpm. Connected by drive cable to engine tachometer drive.



f. Batteries and Cables.

BATTERY CABLES. Six cables used. Battery interconnecting cable connects first battery negative terminal to second battery positive terminal. Ground cables connected between second battery negative post, battery disconnect switch, and negative terminal of slave receptacle. A separate ground cable connects from output of battery disconnect switch to the starter motor terminal. Ground cables connected at battery terminal by terminal lug. Positive cable connected between first battery positive terminal, starter solenoid, and slave receptacle positive terminal. Positive cables connected at battery terminal by terminal lug.


BATTERY DISCONNECT SWITCH. Isolates ground from electrical system when turned off. Slave receptacle remains connected to negative battery terminal. Battery disconnect switch provides ground to the electrical system when energized.



468-004

1-14. ELECTRICAL SYSTEM (CONT)

g. Wiring Harnesses.



FRONT WIRING HARNESS. Interconnects front driving lamps and flood lamps, black out driving lamps, left and right instrument panels, turn signal lamps, return-to-dig circuit, bucket height control circuit, control valve solenoids, and hydraulic filter switch. Multi-pin connector mates with associated connector on rear harness.

REAR WIRING HARNESS. Interconnects engine and transmission sending units, rear flood lamps, stop and tail lights, black out stop light-tail light, back-up alarm, and starter and cab relay solenoids and associated circuit breakers. Multi-pin connector mates with associated connector on front harness.

BLACKOUT LIGHTS WIRING HARNESS. Interconnects front wiring harness to blackout driving lamp mounted on left front fender and blackout stop lights-tail lights mounted at rear of loader. Connection between wiring harnesses accomplished by block-type connectors.


CAB UPPER WIRING HARNESS. Interconnects cab console wiring harness to cab dome light, defroster fans, defogger, and turn signal lamp assemblies. Cab upper wiring harness connector is mounted on cab wall just behind cab console. Connection between wiring harnesses accomplished by block-type connectors.

CAB LOWER WIRING HARNESS. Interconnects front wiring harness to cab console wiring harness and to circuit breakers mounted on cab switch panel. Connection between wiring harnesses accomplished by block-type connectors.

CAB CONSOLE WIRING HARNESS. Interconnects cab upper wiring harness to cab lower wiring harness and switches mounted on cab switch panel. Connection to cab upper wiring harness accomplished by block-type connector; connection to cab lower wiring harness accomplished by bullet terminals.

1-15. TRANSMISSION AND DRIVE SHAFTS

a. Transmission Controls.



TRANSMISSION CONTROL LEVER. Selects one of four positions: low range forward, high range forward, neutral, and low range reverse.


DECLUTCH TREADLE VALVE. Applies service brakes, lights stop lights at rear of loader, disengages transmission, and lights CLUTCH PRESS indicator. Used to disengage transmission to provide maximum hydraulic power for loader operation.

b. Drive Shafts.


FRONT DRIVE SHAFT. Connected between center drive shaft and front axle. Connected to front axle yoke by universal joint and to center drive shaft by yoke with internal splines. Rear of front drive shaft supported by a bearing.

CENTER DRIVE SHAFT. Connected between transmission output shaft and front drive shaft. Connection accomplished by universal joints.

REAR DRIVE SHAFT. Connected between transmission output shaft and rear axle by universal joints.



1-16. BRAKES



PARKING BRAKE VALVE. Controls flow of air to actuator. Pushing knob in applies air pressure to actuator in turn releasing parking brake. Pulling knob out releases air pressure applied to actuator. Large spring in actuator then moves piston causing linkage and lever in parking brake to force brake shoes against brake drum.

ACTUATOR. Located left side of loader. Includes large spring and piston. When air pressure applied by parking brake valve, it pushes against piston and compresses spring in turn releasing parking brake. When air pressure released, large spring forces piston to move and apply parking brake.

PARKING BRAKE. Mounted on transmission output shaft. Drum type parking brake prevents axles and wheels from rotating when applied.

BRAKE TREADLE VALVE. Depressing treadle valve applies air pressure to brake actuators. This in turn applies hydraulic pressure to brake calipers mounted on each wheel end and applying brake pads to disks mounted on wheel ends to stop loader. Brake actuators consist of an air chamber and hydraulic master cylinder. Also turns on stop or black out stop lights as determined by position of vehicle lights switch. Brake system is air over hydraulic.

SERVICE BRAKES. Disk brakes mounted on each wheel end.

AIR RESERVOIR. Mounted at right side of loader. Air from air compressor routed to and stored in air reservoir until required by air system components.


1-17. STEERING SYSTEM

STEERING WHEEL. Connected to steering column and steering gear. Steering column and steering gear control flow of hydraulic oil to and from steering cylinder assemblies. Power assist provided by hydraulic pump mounted on transmission for reduced steering wheel turning effort when engine is running. Collapsible steering wheel column allows for reduction in height for transport operations by depressing button in center of steering wheel under cover.

STEERING CYLINDER ASSEMBLIES. Two hydraulic cylinders, one mounted on each side of loader. Cylinder housings attached to front chassis and cylinder rods attached to rear chassis. Cylinder rods extend or retract as steering wheel is turned, forcing front chassis to pivot about chassis spindle assemblies.

CHASSIS SPINDLE ASSEMBLIES. Heavy duty spindles mounted in thrust bearings and located at top and bottom of chassis connection points. Secure front chassis to rear chassis and allow front chassis to pivot and steer loader.

AUXILIARY STEERING MOTOR AND PUMP. Mounted on left side of loader. Provides emergency hydraulic power for steering loader if hydraulic pump fails. Consists of hydraulic pump driven by electric motor. Electric motor automatically operates if main hydraulic pump fails and auxiliary steering warning buzzer sounds when motor turns on. If you crank starter motor with SHUT OFF control pulled out then release ignition key switch, you will hear auxiliary steering motor and pump start to operate. If this happens, turn ignition key switch to off position to stop auxiliary steering motor and pump.



1-18. FRAME AND TOWING ATTACHMENTS


ENGINE SIDE PANELS. Constructed of sheet metal. Secured to rear chassis by latches: two for each panel. Provide access to engine compartment.

DRAWBAR PIN. Constructed of heavy steel. Provides means of attaching pintle hook or drawbar for towing loader or using loader as tow vehicle.

TRUNNION ASSEMBLY. Rear axle mounted on trunnion assembly providing rear axle oscillation. Allows rear chassis to pivot when operating over rough terrain.

TRANSPORT/SERVICE LINK. Constructed of heavy gage steel. Must be in operating position during loader operation. Prevents loader from pivoting therefore no steering control when in engaged position. Must be in engaged position when personnel are working in area between front and rear chassis, when loader is being airlifted or transported, or loader is jacked up.

FRONT ACCESS DOOR. Constructed of sheet metal. Provides access to hydraulic reservoir and windshield washer reservoir. Hydraulic reservoir sight gage located just below access door.




1-19. CAB

WINDSHIELDS AND SIDE WINDOWS. Front windshield, rear windshields, and two side windows provide operator with a 360 degree field of vision.

DOOR ASSEMBLIES. Two door assemblies. Each door assembly consists of an upper and a lower door assembly. Upper door assembly can be unlatched from lower door assembly and latched in full open position. Upper door assembly includes glazing.


SLINGING EYES. Two slinging eyes located at top of cab to aid in cab removal and installation.



1-20. ACCESSORIES

WINDSHIELD WASHER. Front windshield washer. Air actuated. Nozzle mounted just below front windshield. Depressing control located on left instrument panel applies air pressure to fluid reservoir in turn forcing fluid from reservoir through hose to spray out nozzle onto windshield.

OUTSIDE MIRRORS. One mounted on each side of cab. Easily adjusted by operator.



CAB INSIDE MIRROR. Mounted inside cab, right side.

WINDSHIELD WIPER AND MOTOR. Electric motor driven wiper. Wiper motor mounted directly behind wiper arm.

DEFROSTER ASSEMBLY. Mounted at cab ceiling. Directs air over front windshield to clear windshield of fog.

CAB DOME LIGHT. Located behind defogger assembly. Includes on-off switch. provides illumination for cab. Brightness controlled by DIMMER COMPT LIGHTS control mounted on right instrument panel and vehicle lights switch auxiliary switch. Vehicle lights switch main switch and auxiliary switch must be in any position other than OFF for this light to operate.


DEFOGGER FANS. Two fans. Mounted above and to sides of rear windshield. Each fan includes LOW-OFF-HIGH switch and is directionally adjustable to direct airflow over rear windshields.

CAB HEATER. Located to left of operator's seat. Utilizes heat from engine coolant to heat cab. Includes electric motor driven fan.

CONSOLE SWITCH PANEL. Contains switches and circuit breakers for defroster, heater fan, and front wiper circuits.

AIR HORN. Air horn valve located on cab deck to left of declutch treadle valve. Depressing valve routes air Pressure to air horn causing diaphragm to vibrate sounding air horn. Air horn located on left side of front chassis beneath cab.

1-21. HYDRAULIC SYSTEM




1-21 HYDRAULIC SYSTEM (CONT)

RETURN-TO-DIG CONTROL. Returns bucket to digging position after it has been dumped. Operator adjusted control.

BUCKET HEIGHT CONTROL. Automatically stops loader lift arms at an operator selected dump height.

BUCKET TILT CYLINDER ASSEMBLIES. Two used. Position bucket for digging, scraping, dumping, etc.




LIFT ARM CYLINDER ASSEMBLIES. Two used. Raise or lower bucket.


BUCKET CLAMSHELL CYLINDER ASSEMBLIES. Two used. Open or close bucket clamshell.

LIFT ARM CONTROL LEVER. Controls raising and lowering of bucket.

BUCKET CONTROL LEVER. Controls dumping of bucket and tilting bucket for carrying a load.

CLAM CONTROL LEVER. Controls opening and closing of bucket clamshell. Placing control lever in HOLD position will cause bucket clamshell to hold its position.






HYDRAULIC RESERVOIR. Located behind front access door. Oil filler cap located at top of reservoir.

SIGHT GAGE. Located at front of loader. Oil level must be seen in sight gage. If oil level is not seen, hydraulic oil must be added.

1-22. SIGNALING DEVICES




BACK-UP ALARM. Electrically operated alarm located at rear of loader behind radiator grille. Sounds distinctive warning whenever transmission control lever is placed in reverse (R) position. Ignition key switch must be turned to on position before back-up alarm will sound.

1-22. SIGNALING DEVICES (CONT)

TURN SIGNALS. Two turn signal lamps located at top left and right of cab. Turn signal lever mounted on steering column. Moving turn signal lever away from you causes left turn signal lamp to flash on and off indicating left turn. Lever must be manually returned to center position after turn is completed. Moving lever towards you causes right turn signal lamp to flash on and off indicating right turn.

1-23. EARTHMOVING COMPONENTS



BUCKET LIFT ARMS AND PIVOT ASSEMBLIES. Provides the means of raising/lowering bucket and tilting bucket.

LOADER BUCKET ASSEMBLY. Includes bucket and clam. Bucket cutting edge consists of three cutting edges bolted to bucket. Nine tooth assemblies bolted to clam cutting edge. Clam cutting edge welded to clam.

CHAPTER 2

OPERATING INSTRUCTIONS

CHAPTER OVERVIEW

The purpose of this chapter is to familiarize you with the equipment so that you can operate it safely, efficiently, and effectively.

Index

Section	Title	Page
I	Description and Use of Operator's Controls and Indicators	2-1
II	Preventive Maintenance Checks and Services (PMCS)	2-26
III	Operation Under Usual Conditions	2-45
IV	Operation Under Unusual Conditions	2-66

Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS

	Para		Para
Instrument Panels	2-1	Rear Windshield Defogger Fans	2-6
Right Instrument Panel	2-1a	Dome Light Switch	2-7
Left Instrument Panel	2-1b	Upper and Lower Door Latches	2-8
Console Switch Panel	2-2	Operator's Seat	2-9
Switches and Control	2-2a	Loader Controls	2-10
Circuit Breakers	2-2b	Externally Mounted Controls and	
Transmission Controls	2-3	Indicators	2-11
Brake and Throttle Controls	2-4	Other Operator's Controls and	
Turn Signals and Flasher	2-5	Indicators	2-12

12-1. INSTRUMENT PANELS

a. Right Instrument Panel.

(1) Circuit Breakers.

5 AMP CIRCUIT BREAKER

Resettable circuit breaker; reset by pressing button.

Button pops out when circuit breaker blows.


Protects HYDRAULIC FILTER warning indicator and switches and bucket height and return-to-dig control circuits.

5 AMP CIRCUIT BREAKER

Resettable circuit breaker; reset by pressing button.

Button pops out when circuit breaker blows.

Protects auxiliary steering control circuit, air brake pressure switch and buzzer, gages, warning indicators located on left instrument panel, cab relay solenoid, and electric fuel pump.



2-1. INSTRUMENT PANELS (CONT)

a. Right Instrument Panel (Cont).

(2) Engine Switches.

IGNITION KEY SWITCH

Four position key switch.

First unmarked position (key turned counterclockwise): Applies power to: vehicle lights switch enabling lights to be turned on; auxiliary steering control circuit; low air pressure warning circuit sounding warning buzzer; gages; and left instrument panel warning indicators turning them on; and electric fuel pump.

Off position (key straight): Electrical system off.

On position (key turned to first clockwise position): Applies power to: vehicle lights switch enabling lights to be turned on; auxiliary steering control circuit; low air pressure warning circuit sounding warning buzzer; gages; left instrument panel warning indicators turning them on; electric fuel pump; and return-to-dig and bucket height control circuits.

Start position (key turned to extreme clockwise position, spring loaded return): Applies power to return-to-dig and bucket height control circuits; cranks starter motor to start engine, momentarily turns on HYDRAULIC FILTER warning indicator, and applies power to COLD START switch.


COLD START SWITCH

Aids in starting engine when temperature is 40 degrees or less.

WARNING

Starting fluid is toxic and highly flammable. Use caution when handling.

Pushbutton switch: Operates only when ignition key switch is cranking starter. Pressing switch energizes solenoid valve installed on cold start container allowing starting fluid to enter intake manifold.



2-1. INSTRUMENT PANELS (CONT)

a. Right Instrument Panel (Cont).

(3) Flood Lights Switch and Warning Indicator.

FLOOD LIGHTS SWITCH


Two position toggle switch.

On position (right position): Turns on front and rear flood lamps.

NOTE

Main switch on vehicle lights switch must be in SER. DRIVE position for this switch to operate.

Off position (left position): Turns off front and rear flood lamps.



HYDRAULIC FILTER WARNING INDICATOR

Indicator light.

Turns on momentarily when first starting engine indicating bulb is okay.

During operation, turns on indicating hydraulic filters are clogged and require replacement.

2-1. INSTRUMENT PANELS (CONT)

a. Right Instrument Panel (Cont).

(4) Vehicle Lights Switch.

MAIN SWITCH

Five position switch section.

B.O. MARKER: Black out tail lights lit. Stoplights will light when brake treadle valve is pressed.

B.O. DRIVE: Black out tail lights and blackout drivinglamp lit. Stop lights will lightwhenbrake treadle valve is pressed.

OFF (Unmarked): All lamps off.

STOP LIGHT Stop lights will light when brake treadle valve is depressed. Turn signals can be turned on.

SER DRIVE: Tail lights and front driving lamps lit. Stop lights will light when brake treadle valve is pressed. Turn signals and flood lights can be turned on.

NOTE

Ignition key switch must be in extreme counterclockwise position or on position for vehicle lights switch to operate.

AUXILIARY SWITCH

Four position switch section.

PANEL BRT.: Gage lights brightly lit and cab dome light can be turned on.


DIM: Gage lights dimly lit and cab dome light can be turned on.

OFF (unmarked): Panel and tail lights off.

PARK: Service tail lights lit (main switch in SER DRIVE position) and gage lights dimly lit and cab dome light can be turned on. Black out tail lights lit (main switch in B.O. DRIVE or B.O. MARKER position).

NOTE

Main switch section must be in any position other than OFF for auxiliary switch section to operate.



MECHANICAL LOCK

Spring loaded switch section.

LOCK (unmarked): Main switch can only be placed in B.O. MARKER position; all other positions locked out.

UNLOCKED: Enables main switch to be placed in B.O. DRIVE, STOP LIGHT, or SER DRIVE POSITION.

To operate, hold lever in UNLOCK position and move main switch lever to desired position.

2-1. INSTRUMENT PANELS (CONT)

a. Right Instrument Panel (Cont).

(5) Other Controls and Indicator.

SHUT OFF CONTROL

Fuel shut off control; engine stop.

Cable connected to fuel injection pump fuel shut off lever.


Pull out to stop engine. After engine has stopped, push control in. Control must be pushed in all the way in order to start engine.

PARKING BRAKE CONTROL

Pull on, push off control.

Applies parking brake.

Pulling knob out applies parking brake. Pushing knob in releases parking brake. When parking brake applied, BRAKE ENGAGED and CLUTCH PRESS warning indicators on left instrument panel will be lit.



DIMMER COMPT LIGHTS CONTROL

Rheostat control.

Controls brightness of gage lights and cab dome light (auxiliary switch in any position other than OFF). Turn control to extreme counter-clockwise position for brightly lit lights. Turn control clockwise to decrease brightness. Extreme clockwise position turns lights off.

AIR PRESSURE WARNING ALARM

Audible alarm.

Sounds when engine is first started until air pressure reaches approximately 65 psi at which time it will turn off. During operation, sounds to warn operator that there is not enough air pressure to continue operating loader safely.

2-1. INSTRUMENT PANELS (CONT)b. Left Instrument Panel.

(1) Warning Indicators.

BRAKE ENGAGED

Warning indicator light.

Turns on indicating there is low or no air pressure in brake system. Will also turn on when parking brake control is pulled out indicating parking brake is applied.

OIL PRESS

Warning indicator light.

Turns on indicating there is no oil pressure or low oil pressure in the engine. Will also turn on if engine is stopped and ignition key switch is turned to on position indicating bulb is okay. If this indicator turns on when engine is running, turn engine off and check engine oil level. If engine oil level is okay, do not start engine; notify organizational level maintenance.

AUXILIARY STEERING

Audible warning indicator and light.

Buzzer sounds and lamp turns on indicating steering system is not operating and that auxiliary steering system is operating. If buzzer sounds and/or lamp turns on, stop loader immediately and notify organizational maintenance.


NOTE

The auxiliary steering system is only used for a short period of time if steering system doesn't operate. When actuated, this system will allow you to steer the loader with hydraulic power until the loader can be stopped. After stopping loader, be sure you turn ignition key switch to off position and apply parking brake as soon as possible. If you fail to do this, you will cause damage to auxiliary steering electric motor and discharge the batteries.

CLUTCH PRESS

Warning indicator light.

Turns on indicating there is no oil pressure or low oil pressure in the transmission torque converter. Will also turn on if engine is stopped and ignition key switch is turned to on position indicating bulb is okay, if engine is running and declutch treadle valve is pressed, and if parking brake is applied. If this indicator turns on with engine running and declutch treadle valve is not depressed, and stays on for more than 60 seconds, stop engine and notify organizational maintenance.



2-1. INSTRUMENT PANELS (CONT)

b. Left Instrument Panel.

(2) Gages.

CONV TEMP GAGE


Indicates transmission torque converter temperature.

Normal operating temperature indication is in green area of gage. If gage pointer goes into red area, select a lower transmission speed. If pointer remains in red area, stop operation, move transmission control lever in neutral (N) position, and run engine at full throttle. If this does not reduce temperature indication, stop engine and check transmission oil level. If oil level is okay, check radiator for obstructions.

AIR PRESS GAGE

Indicates brake system air pressure.

Normal air pressure indicated when pointer is in green area of gage. If air pressure decreases and pointer goes into red area, warning buzzer will sound alerting you of this condition. If air pressure continues to decrease, parking brake will automatically engage.



FUEL LEVEL GAGE

Indicates amount of fuel in fuel tank.

VOLTMETER GAGE

Indicates voltage level of batteries.

Voltage is normal when pointer indicates 24 volts. If pointer indicates below 22 volts, battery charge is too low for continued operation or alternator is not charging batteries. If pointer is indicating above 30 volts and you know that batteries were not weak, alternator is over charging batteries. If this condition continues, damage to batteries will result. Report these problems to organizational maintenance.

WATER TEMP GAGE


Indicates temperature of coolant in engine cooling system.

Normal coolant temperature indicated when gage pointer is in green area. If pointer goes into red area, stop engine and check radiator coolant level or for radiator obstructions.

2-1. INSTRUMENT PANELS (CONT)

b. Left Instrument Panel.

(3) Windshield Washer Control.



WINDSHIELD WASHER CONTROL

Push on control.

Controls flow of washer solvent sprayed on windshield. Push control in to spray washer solvent on windshield; release to stop spray.

2-2. CONSOLE SWITCH PANEL

a. Switches and Control.

DEFROSTER SWITCH

Two position rotary switch.

ON: Turns on defroster motor located above front windshield to de-fog front windshield.

OFF: Turns off defroster motor.


HEATER FAN SWITCH

Three position pull on - push off switch.

OUT - LOW (switch shaft pulled completely out): Heater fan operates at low speed. Heater fan draws air over heater core where it is heated then expelled out heater console.

MID - HI (switch shaft pulled out to first detent position): Heater fan operates at high speed.

IN - OFF (switch shaft pushed in): Heater fan off.



FRONT WIPER SWITCH

Three position rotary switch.

H (high): Front windshield wiper motor operates at high speed.

L (low): Front windshield wiper motor operates at low speed.

OFF: Front windshield wiper motor off.

HEAT CONTROL

Rotary control. Clockwise rotation increase; counterclockwise rotation decrease.

Controls flow of engine cooling system coolant through heater core. For maximum heat, turn control completely clockwise to WARM position. To turn off heat, turn control to OFF position.

WARM: Valve completely open allowing maximum flow of engine coolant through heater core.

OFF: Valve closed; flow of engine coolant through heater core blocked.

2-2. CONSOLE SWITCH PANEL (CONT)

b. Circuit Breakers.

6 AMP CIRCUIT BREAKER

Resettable circuit breaker; reset by pressing button.

Button pops out when circuit breaker blows.


Protects defroster and defogger fans circuits.

3 AMP CIRCUIT BREAKER

Resettable circuit breaker; reset by pressing button.

Button pops out when circuit breaker blows.

Protects front windshield wiper circuit.



3 AMP CIRCUIT BREAKER

Resettable circuit breaker; reset by pressing button.

Button pops out when circuit breaker blows.

Protects heater fan circuit.


2-3. TRANSMISSION CONTROLS

TRANSMISSION CONTROL LEVER

Selects direction and drive speeds (in forward).

Rearmost position is reverse (R), next position is neutral (N), third position is low range forward (F), and forwardmost position is high range forward (H). To go from low range forward (F) to high range forward (H), you must lift control lever up then push it forward. When control lever is in reverse (R) position, back-up alarm at rear of loader will sound.

Control lever must be in neutral (N) to start engine.



DECLUTCH TREADLE VALVE

Neutralizes transmission, applies service brakes and turns on stop lights and CLUTCH PRESS warning indicator.

Use to provide maximum engine power to increase loader hydraulic system power for raising bucket. Move loader into stockpile. When engine speed decreases, press declutch treadle valve to disengage transmission, then press accelerator pedal to increase engine rpm providing maximum engine power to loader hydraulic system to quickly raise bucket.

2-4. BRAKE AND THROTTLE CONTROLS**STEERING WHEEL**

Steers loader by moving front chassis on pivot pins.

Turn clockwise for right turn. Turn counterclockwise for left turn.


WARNING

Do not depress button in center of steering wheel; it is not a horn button. Depressing this button causes steering wheel to collapse for shipment purposes. If you depress this button while operating loader, steering wheel will collapse. Your fingers could be crushed between steering wheel and windshield wiper motor bracket.

ACCELERATOR PEDAL

Increases/decreases engine speed.

Depressing pedal increases engine rpm; releasing pedal decreases engine rpm.

**HORN VALVE**

Actuates air horn.

Press button with foot to sound air horn.

SERVICE BRAKE TREADLE VALVE

Applies service brakes.

Depress treadle valve to apply brakes. With vehicle lights switch main switch in any position other than OFF, stop lights will turn on.

2-5. TURN SIG NALS AND FLASHER


TURN SIGNAL SWITCH

Three position switch with indicator.

Lever in forward position (away from you): Lamp assembly mounted at top left of cab flashes on and off signaling left turn. Bulb located in turn signal switch will also flash on and off. You must return lever to center position after you have completed the turn to stop lamp assembly from flashing.

Lever in center position: Turn signals off.

Lever in rearward position (toward you): Lamp assembly mounted at top right of cab flashes on and off signaling right turn. Bulb located in turn signal switch will also flash on and off. You must return lever to center position after you have completed the turn to stop lamp assembly from flashing.




HAZARD CONTROL

Pull on control.

On (pull out): Pull control out to the right. Lamp assemblies mounted at top left and right of cab will flash on and off. Bulb located in turn signal switch will also flash on and off.

Off: Turn off flashing lamp assemblies by pulling turn signal switch lever down or up.

2-6. REAR WINDSHIELD DEFOGGER FANS

**ON-OFF SWITCH**

Three position rocker switch.

LOW: Fan motor operates at low speed.

OFF: Turns off power to fan motor.

HIGH: Fan motor operates at high speed.

To adjust position of defogger fans, grasp motor with your hands and firmly move into desired position.

WARNING

Before adjusting position of defogger fan, be sure it is not operating. Failure to do so could cause serious injury to fingers or hand by rotating fan blade. If you injure your fingers or hand, obtain medical aid immediately.


2-7. DOME LIGHT SWITCH]

ON-OFF SWITCH

Two position rocker switch.

ON: Turns cab dome light on. Vehicle lights switch main and auxiliary switches must be in any position other than OFF for this switch to operate dome light. Brightness of cab dome light controlled by DIMMER COMPT LIGHTS control.

OFF: Turns off cab dome light.




2-8. UPPER AND LOWER DOOR LATCHES

Releases upper door enabling it to be swung open.

WARNING

When upper door is opened, be sure you latch it to side of cab. Failure to do so will allow door to swing back and forth causing glass to break and injuring you.

Move latch handle towards rear of cab to release latch. When upper door is released and opened, you must latch it to side of cab to prevent injury to yourself and damaging it.




DOOR LATCH

Latches door in closed position.

To open latch, push latch handle down until latch clears door striker, swing door open, then release latch handle.

To latch door, push latch handle down, gently but firmly close door, and release handle. Check that latch engages door striker.



CAB LATCH

Latches upper door in open position.

To latch upper door to side of cab, release upper door latch. Swing upper door open all the way. Move cab latch handle towards front of loader and gently but firmly push upper door against side of cab and move cab latch handle to engage bracket on exterior of upper door.


Move latch handle towards front of loader to release upper door.

2-9. OPERATOR'S SEAT

FORE AND AFT ADJUSTMENT LEVER

Releases seat for fore and aft adjustment and locks seat in position.

Sit in seat, move lever to left to release seat for adjustment and then move forward or rearward until seat is at desired position.



HEIGHT ADJUSTMENT

Releases seat for height adjustment.

Loosen bolt just enough to be able to raise or lower seat. Raise seat by grasping seat bottom and raise until desired height is obtained. Lower seat by firmly pushing down on seat with your hands until desired height is obtained. Tighten bolt securely after adjusting its height.

2-10. LOADER CONTROLS

LIFT ARM CONTROL LEVER

Four position control lever. Controls flow of hydraulic oil to lift cylinder assemblies.

FLOAT: Bucket follows contour of ground. Used only when bucket is on ground and you want it to follow the shape of the ground. It causes oil to flow between ends of lift cylinder assemblies only.

LOWER: Lowers bucket as long as control lever is in this position.

NEUT.: Bucket held in position.

RAISE: Raises bucket to desired height until returned to NEUT. or until height selected by bucket height control is reached.

BUCKET CONTROL LEVER

Three position control lever. Controls bucket position for dumping or carrying a load.

DUMP: Bucket will be quickly positioned to dump a load.

NEUT.: Bucket held in position.

CROWD: Bucket rolls back until control lever returned to NEUT. position. Use to position bucket for carrying a load.


CLAM CONTROL LEVER

Three position control lever. Controls clam opening or closing.

OPEN: Opens clam until control lever placed in HOLD position or clam opened to maximum position.

HOLD: Holds clam in position.

CLOSE: Closes clam until control lever placed in HOLD position or clam completely closed.




2-10. LOADER CONTROLS (CONT)

BUCKET HEIGHT CONTROL

Automatically stops loader lift arms at a preselected dump height.

Use this control when loading trucks, rail cars, hoppers, etc.


Refer to page 2-45 for adjustment.



BUCKET LEVEL INDICATOR

Tube with rod telescoping in and out. Located on right bucket tilt cylinder assembly.

When end of rod is one inch out of tube, bottom of bucket is level with ground or bucket has returned to position selected by return-to-dig control.



RETURN-TO-DIG CONTROL

Automatically returns bucket to digging position preset by this control.

Used in conjunction with BUCKET control lever in CROWD position and LIFT ARM control lever in FLOAT position.


Refer to page 2-46 for adjustment.

2-10. LOADER CONTROLS (CONT)**SELECTOR GAGE**

Bucket can be used for scooping, scraping, dozing, or clamshell operations.


Selector Gage is used to show bucket positions.

SELECTOR ALIGNMENT MARK

**STANDARD BUCKET**


Selector Gage=0

Level Indicator - Rod is one inch out of tube.

**DOZING**


Selector Gage - Reading is off gage.

Level Indicator - Rod is four to five inches out of tube.

**SCRAPING**


Selector Gage - Between 2 and 4.

Level Indicator - Rod is one inch inside of tube.

**CLAMSHELL**

Selector Gage - Reading is off gage.

Level Indicator - Rod nipple is just out of tube approximately one inch. Start clamshell operation with the blade covering 2/3 the height of the object. The clam is then rolled forward and closed.




2-11. EXTERNALLY MOUNTED CONTROLS AND INDICATORS

HOURLY/TACHOMETER

Connected to engine tachometer drive.

HOURLY: Indicates cumulative number of engine operating hours. Connected to engine tachometer drive and operates only when engine is operating. Records up to 9999.9 hours.


TACHOMETER: Indicates engine speed in revolutions per minute (rpm). Each short mark on gage equals 50 rpm; each long mark equals 100 rpm.



AIR CLEANER RESTRICTION INDICATOR

Indicates air cleaner filter elements require servicing.

Factory set to signal when air cleaner filter elements require servicing. Red signal indicator inside indicator gradually rises as air flow decreases due to dirt particles trapped in elements. When red signal is fully exposed, it is locked in position. After servicing filter elements, indicator is reset by pressing top of indicator.




SLAVE RECEPTACLE

Permits charging of batteries or slave starting of engine from an external power source. Also provides a power source for charging/slaving other equipment.

+24 volts negative ground available at this receptacle.

2-12. OTHER OPERATOR'S CONTROLS AND INDICATORS



TRANSMISSION OIL LEVEL DIPSTICK AND FILL

Indicates transmission oil level.

Oil level shall be between FULL and ADD marks with CONV TEMP gage indicating in green zone and engine operating at idle speed.


Unlock dipstick, turn handle counterclockwise several turns, then pull up to remove. Be sure dipstick is fully seated when reinstalling it, turn handle clockwise to tighten, then lock it.

ENGINE OIL LEVEL DIPSTICK AND FILL

Indicates engine oil level.

Oil level shall be between ADD and FULL marks on dipstick.

Turn handle on dipstick counterclockwise several turns, then pull up to remove. Install dipstick and turn handle clockwise to tighten.



2-12. OTHER OPERATOR'S CONTROLS AND INDICATORS (CONT)


HYDRAULIC RESERVOIR FILL

Located behind front access door.

WARNING

Hydraulic reservoir is pressurized. Shut off engine before removing hydraulic reservoir fill cap. Failure to do so could cause serious injury or death.


With engine off, unlock and open front access door. Use clean cloth to clean area around fill cap. Remove fill cap and add hydraulic oil until oil level can be seen in sight gage window. Reinstall fill cap and tighten securely by hand.



HYDRAULIC RESERVOIR OIL LEVEL SIGHT GAGE

Indicates hydraulic system oil level.

Oil level shall be seen in sight gage with engine off, loader parked on level surface, and bucket lowered to ground.

2-12. OTHER OPERATOR'S CONTROLS AND INDICATORS (CONT)

AIR RESERVOIR DRAIN VALVE

Located at right rear side of loader. Enables draining of water from air reservoir.

With engine off, slowly open drain valve and drain water from air reservoir. Tighten drain valve securely after all water is drained.

Section II. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

	Para
General	2-13
Preventive Maintenance Checks and Services	2-14

2-13. GENERAL

Every mission begins and ends with the paperwork. There isn't much of it, but you have to keep it up. The forms and records you fill out have several uses. They are a permanent record of the services, repairs, and modifications made on your loader. They are reports to organizational maintenance and to your Commander. And they are a checklist for you when you want to know what is wrong with the loader after its last use, and whether those faults have been fixed. For the information you need on forms and records, see DA PAM 738-750.

2-14. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

- a. The item numbers of table 2-1 indicate the sequence the PMCS are to be performed. This column should be used as the source of item numbers for the TM Number column on DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS.
- b. BEFORE - Checks and services performed prior to the equipment leaving its containment area or performing its intended mission.
- c. DURING - Checks begin when the equipment is being used in its intended mission.
- d. AFTER - Checks and services begin when the equipment is taken out of its mission mode or returned to its containment area.
- e. Do your weekly (W) PREVENTIVE MAINTENANCE weekly.
- f. Do your monthly (M) PREVENTIVE MAINTENANCE once a month.
- g. If something doesn't work, troubleshoot it with the instructions in this manual or notify your supervisor.
- h. Always do your PREVENTIVE MAINTENANCE in the same order, so it gets to be a habit. Once you've had some practice, you'll spot anything wrong in a hurry.
- i. If anything looks wrong and you can't fix it, write it on your DA Form 2404. If you find something seriously wrong, report it to organizational maintenance RIGHT Now.
- j. When you do your PREVENTIVE MAINTENANCE take along the tools you need to make all the checks. You always need a rag or two.

2-14. PREVENTIVE MAINTENANCE CHECKS AND SERVICES(CONT)**WARNING**

Dry cleaning solvent P-D-680 used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and get medical aid immediately.

WARNING

Compressed air used for cleaning purpose will not exceed 30 psi. Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc). Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

(1) Keep it clean: Dirt, grease, oil, and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use dry cleaning solvent (P-D-680) to clean metal surfaces. Use soap and water when you clean rubber or plastic material.

(2) Bolts, nuts, and screws: Check that they are not loose, missing, bent or broken. You can't try them all with a tool of course, but look for chipped paint, bare metal or rust around bolt heads. If you find one you think is loose, tighten it, or report it to organizational maintenance if you can't tighten it.

(3) Welds: Look for loose or chipped paint, rust or gaps where parts are welded together. If you find a bad weld, report it to organizational maintenance.

(4) Electric wires and connectors: Look for cracked or broken insulation, bare wires and loose or broken connectors. Tighten loose connectors and make sure that the wires are in good shape.

(5) Hoses and fluid lines: Look for wear, damage and leaks. Make sure clamps and fittings are tight. Wet spots show leaks, of course, but a stain around a fitting or connector can mean a leak. If a leak comes from a loose fitting or connector, tighten it. If something is broken or worn out, report it to organizational maintenance.

k. It is necessary for you to know how fluid leaks affect the status of your equipment. The following are definitions of the types/classes of leakage you need to know to be able to determine the status of your equipment. Learn them and be familiar with them and REMEMBER - when in doubt, notify your supervisor.

2-14. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (CONT)

Leakage definitions for Crew/Operator PMCS

- Class I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.
- Class II Leakage of fluid great enough to form drops, but not enough to cause drops to drip from the item being checked/inspected.
- Class III Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

CAUTION

Equipment operation is allowable with minor leakages (class I or II). Of course, consideration must be given to the fluid capacity in the system/item being checked/inspected. When in doubt, notify your supervisor.

Class III leaks should be corrected immediately or reported to your supervisor or organizational maintenance.

Table 2-1. Preventive Maintenance Checks and Services

B - Before

D - During

A - After

W - Weekly

M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
						<p>IMPORTANT: PERFORM WEEKLY AS WELL AS BEFORE OPERATION PMCS IF:</p> <ol style="list-style-type: none"> 1. YOU ARE THE ASSIGNED OPERATOR AND HAVE NOT OPERATED THE LOADER SINCE THE LAST WEEKLY. 2. YOU ARE OPERATING THE LOADER FOR THE FIRST TIME. <p><u>NOTE-NEW LOADERS</u></p> <p>Have the following two operations performed by organizational maintenance at 20 hours to comply with warranty.</p> <ol style="list-style-type: none"> 1. Replace engine oil and filter. 2. Replace steering and hydraulic system filters. 	
1	●					Loader Pivot Pins. Lubricate 22 lube fittings (1) using GAA. Refer to LO 5-3805-262-12 as necessary.	
2	●					Rear Axle Trunnion Pivots. Lubricate two lube fittings (2) using GAA. Refer to LO 5-3805-262-12 as necessary.	




Table 2-1. Preventive Maintenance Checks and Services - Continued


B - Before

D - During

A - After

W - Weekly


M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
3	⊗					<p>Engine Oil Level. Unlock and remove engine left side front panel. Turn dipstick (3) handle counterclockwise several turns, then pull up to remove. Check level on dipstick. Level shall be between ADD and FULL marks on dipstick. Add oil as necessary to bring level up. Reinstall dipstick and turn clockwise several turns. Reinstall and lock engine left side panel.</p>  <p>STARTER</p> <p>WARNING</p> <p>When doing the following, slowly loosen radiator cap to relieve pressure before completely removing when engine is hot. Failure to do so could cause severe burns due to hot steam scalding you. If you are scalded by hot steam, seek medical aid immediately.</p>	

4

Coolant Level. Unlock radiator cap access panel

(4). Slowly loosen then remove radiator cap (5). Check that coolant is one to two inches below radiator filler neck. Add coolant as necessary. Reinstall radiator cap. Close and lock radiator cap access panel.



5

Hydraulic System Oil Level. With loader parked on level surface, bucket lowered to ground, and engine off, check hydraulic oil level (OE/HDO-10) in sight gage (6). Oil level should be seen in sight gage. If oil level is not seen in sight gage, unlock and open front access door (7). Loosen and remove fill cap (8). Add oil until level is seen in sight gage. Reinstall fill cap (8) and tighten securely. Check for loose or missing attaching hardware. Close and lock front access door (7). On cold check, oil level should not be higher than 1/4 of sight gage.





Table 2-1. Preventive Maintenance Checks and Services - Continued


B - Before

D - During

A - After

W - Weekly

M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
6	•		•			<p>Air Reservoir. At right side of loader, just above rear axle, slowly open air reservoir drain valve (9) and drain water. Close air reservoir drain valve securely after all water has drained.</p> 	
7	•					<p>Tires/Wheels. Check tires for wear, nails and foreign objects, loose or missing lug nuts, cuts, and correct pressure (40 psi).</p> <p style="text-align: center;">NOTE</p> <p>Have organizational maintenance check torque of lug nuts of a new loader after first hour, first five hours, first 10 hours, first 20 hours, and first 50 hours. After that, check every 50 hours until lug nuts remain tight. If a wheel is removed, check torque of lug nuts every 50 hours until they remain tight. Lug nuts shall be tightened to 340 to 420 lb-ft.</p>	<p>Tire with less than 1/4 inch tread or cuts that show tire cord which would result in tire failure during operation. One or more tires flat or missing.</p>

8

Loader Exterior.



- a. Check for leaks (oil, fuel, hydraulic fluid, or coolant) or appearance of leaks. Especially under the loader.
- b. Check roll over protective structure (ROPS) for damage or loose mounting.

Class III leakage.

Cracks, welds, buckled or split seams and loose or missing mounting bolts.

9

Battery Cables. Open radiator grille (10) at rear of loader. Check battery cables (11) for corrosion at connection to battery terminals (12). Check cables for cracked or chafed insulation and frayed or broken strands of wire. Check for missing or broken battery caps.






10

Wiring Harnesses. Visually check wiring harnesses and connections for frayed or broken wires.

Table 2-1. Preventive Maintenance Checks and Services - Continued


B - Before D - During A - After W - Weekly M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
11	●					<p>Loader Bucket Assembly. Visually check blade and clam assembly (13) for cracks, breaks, or broken welds. Check that hardware (14) securing bucket pins (15) are tight and not loose. Check that hardware (16) securing bucket clamshell cylinder assemblies pins (17) are tight and not loose.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;">    </div> <div style="text-align: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 2px; display: inline-block;">WARNING</div> <p>Be careful when performing following procedure not to place any part of your body between clamshell and blade. To do so could cause serious injury if clamshell suddenly closes crushing you.</p> </div>	Cracks, breaks. Hardware loose or missing.

Change 1


12

Cutting Edges. Visually check clam cutting edge (18) for breaks, and nicks. Start engine and operate at idle speed. Raise bucket four feet off ground by placing LIFT ARM control lever in RAISE position then return it to NEUT. Put CLAM control lever in OPEN position and open bucket clamshell completely. Roll bucket forward using BUCKET control lever in DUMP position. Lower bucket to ground until clamshell is on ground. Put cribbing between clamshell and blade as shown. Turn off engine and relieve hydraulic pressure by operating all control levers. Check blade cutting edges (19) for looseness indicating missing or loose mounting hardware. Check blade cutting edges (19) for cracks, breaks, and nicks. Start engine, raise bucket, remove cribbing, and return bucket to normal position. Turn off engine.



13

Clamshell Teeth Assemblies. Check that tooth points (20) are present. Check tooth points for cracks, breaks, or nicks. Check that tooth shanks (21) are securely mounted and not loose.



14

Fire Extinguisher. Check availability of fire extinguisher (if authorized locally) and proper pressure (indicator in green zone).

Table 2-1. Preventive Maintenance Checks and Services - Continued


B - Before

D - During

A - After

W - Weekly

M-Monthly



Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
15	•					<p>Warning Indicator Lights. Turn ignition key switch (22) counterclockwise to first position. Check that BRAKE ENGAGED (23), OIL PRESS (24), and CLUTCH PRESS (25) warning indicators turn on. Check that air pressure warning alarm sounds. Turn ignition key switch to off position.</p> 	
16	•					<p>Seat Belt. Check that seat belt is securely mounted, material is not frayed, and latch is operable.</p>	
17	•	•				<p>Lights. Put vehicle lights switch main switch (26) in SER DRIVE position. Check that driving, tail, turn signal, and hazard lights work. Put FLOOD LIGHTS switch (27) in on position. Check that front and rear flood lights work. Depress brake treadle valve and check that stop lights work. Put vehicle lights switch main switch (26) and FLOOD LIGHTS switch (27) in OFF position.</p> <p>Put vehicle lights switch main switch (26) in B.O. DRIVE position. Check that black out tail lights and driving lamp work. Put vehicle lights switch main switch (26) in OFF position.</p>	

18

HYDRAULIC FILTER Warning Indicator. Check that light (28) turns on momentarily when cranking engine.

NOTE

If HYDRAULIC FILTER warning indicator comes on during operation, finish shift and have filters replaced before further operation.




19

Warning Indicator Lights. Check that BRAKE ENGAGED (29), OIL PRESS (30), CLUTCH PRESS (31), and AUXILIARY STEERING (32) indicator and buzzer do not turn on.

BRAKE ENGAGED, OIL PRESS, CLUTCH PRESS, and AUXILIARY STEERING lights on during operation.

20

Gages. Check that CONV TEMP (33), AIR PRESS (34), and WATER TEMP (35) gages indicate in green area. Check that voltmeter gage (36) indicates 22 to 30 volts.



Gages do not indicate in green area.

Table 2-1. Preventive Maintenance Checks and Services - Continued


B - Before

D - During

A - After


W - Weekly

M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
							
21	●	●				Tachometer/Hourmeter. Check that tachometer and hourmeter (37) are operating.	
22	●	●				Accelerator. Check that accelerator operates smoothly.	Pedal sticks.
23	●	●				Transmission Control Lever. Check that transmission control lever operates smoothly and correct gear and range are engaged.	Transmission does not operate.
24	●					Parking Brake Control. Check that brake holds loader.	
25	●	●				Service Brakes. Check that service brakes stop loader.	Service brake doesn't stop loader.
26	●	●				Back up Alarm. Check that alarm sounds when transmission control lever placed in reverse (R).	

27

Loader Controls. Operate LIFT ARM (38), BUCKET (39), and CLAM (40) control levers and check that movement is smooth and immediate.



Any function fails to operate or is erratic.

28

Restriction Indicator. Check restriction indicator (41). Have air cleaner filter elements serviced if indicator shows red.





Table 2-1. Preventive Maintenance Checks and Services - Continued

B - Before D - During A - After W - Weekly M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
29	●					<p>Auxiliary Steering. Start engine and operate at idle speed for several minutes. Pull SHUT OFF control (42) out to stop engine but don't turn ignition key switch (43) to off position. Check that AUXILIARY STEERING buzzer sounds and warning indicator (44) turns on. Check that steering wheel (45) can be turned easily. Turn ignition key switch to off position. Don't allow auxiliary steering motor and pump to operate more than 30 seconds.</p> 	
30	●					<p>Transmission Oil Level. Turn engine off and pull up on parking brake control (46). Place transmission control lever (47) in neutral (N) position. Move transport/service link (48) to engaged position to keep loader straight and prevent it from pivoting. Start engine and operate at idle speed. Unlock and remove transmission dipstick (49) and check oil level. If oil level is not between ADD and FULL marks on dipstick with transmission at operating temperature, add</p>	

oil until oil level is at FULL mark. Reinstall and lock dipstick. Turn engine off and move transport/service link to operating position.

WARNING

Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control.











Table 2-1. Preventive Maintenance Checks and Services - Continued

B - Before		D - During		A - After		W - Weekly		M-Monthly	
Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:		
	B	D	A	W	M				
31						 <p>Fuel Injector Lines (External). Unlock and remove engine rear right side panel. Check fuel injector lines (50) connections at fuel injection pump (51) for fuel leakage. Check hose (52) and tube (53) connections at fuel injection pump and fuel filters for fuel leakage. Check fuel inlet hose (54) connection at fuel transfer pump for fuel leakage. Check for water or sediment in fuel sediment bowl. If sediment is apparent, report to organizational maintenance. Reinstall and lock engine right side panel.</p>	Fuel lines leaking.		
32						<p>Drive Belts. Unlock and remove engine rear side panels. Check drive belts (55) for frayed or damaged condition. Check fan (56) for bent or damaged blades.</p>	One or more belts are broken or missing.		



- Alcohol Evaporator. Check if alcohol level in plastic jar is at least 1/3 full. Inspect parts for deformation, cracks, or breaks. To add alcohol, loosen and remove plastic jar. Fill 2/3 full with methanol alcohol. Reinstall and lock engine rear side panels.
- Batteries. Open radiator grill (57). Inspect batteries (58) electrolyte level. If electrolyte level is low, notify organizational maintenance level.



Battery cracked or missing.

Table 2-1. Preventive Maintenance Checks and Services


B - Before

D - During

A - After

W - Weekly

M-Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE: Check For And Have Repaired, Filled or Adjusted As Needed	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
34				•		Drive Shafts. Check drive shaft universal joints for loose mounting hardware. Check drive shafts for wear or damage by grasping drive shaft with both hands and trying to rotate it. Wear or damage is indicated by excessive movement of drive shaft in any direction.	Mounting hardware loose or missing, or drive shaft damaged.
35				•		<p>Windshield Washer Reservoir. Unlock and open front access door. Check fluid level in reservoir (59). To add fluid, pull up on fill cap. Reinstall fill cap. Close and lock front access door.</p> 	

Section III. OPERATION UNDER USUAL CONDITIONS

	Para		Para
Initial Checks	2-15	Stopping the Loader	2-17c
Adjustments	2-16	Operating the Loader	2-17d
Bucket Height Control		Preparation for	
Adjustment	2-16a	Movement	2-18
Return-To-Dig Control		Driving	2-18a
Adjustment	2-16b	Towing the Loader	2-18b
Operating Procedures	2-17	Preparation for Air Transport	2-18c
Starting the Engine	2-17a	Operating Instructions on Decals	
Starting the Loader	2-17b	and Instruction Plates	2-19

2-15. INITIAL CHECKS

Refer to current lubrication order and lubricate loader. Refer to page 2-29 and perform before operation PMCS.

2-16. ADJUSTMENTS


a. Bucket Height Control Adjustment. This control automatically stops loader bucket at a dump height that you select. Use this control when you are loading trucks, hoppers, rail cars, etc. This control consists of a control lever located under the left instrument panel and a microswitch mounted on bracket next to control lever.

- (1) Lift bucket height control lever all the way up.

WARNING

Noise level exceeds 85 dB when operating loader with cab windows open. All personnel shall wear a hearing protective device when operating loader with windows open to prevent hearing loss.

- (2) Start engine.
- (3) Use LIFT ARM control lever in RAISE to raise bucket to desired height. Return control lever to NEUT. position when desired height obtained.
- (4) Turn off engine.
- (5) Push bucket height control lever down until you hear microswitch make a sound.
- (6) Start engine.
- (7) Use LIFT ARM control lever in LOWER to lower bucket to ground.




2-16. ADJUSTMENTS (CONT)


a. Bucket Height Control Adjustment (Cont).

- (8) Put LIFT ARM control lever in RAISE position. Magnetic detent in control valve will hold LIFT ARM control in RAISE position until bucket is at height set in step (3) above.
- (9) Check if bucket is at desired dump height. Small adjustments can be made by pushing bucket height control lever down to increase dump height or lifting bucket height control lever to decrease dump height.
- (10) Lower bucket to ground using LIFT ARM control lever in LOWER position. Return LIFT ARM control lever to NEUT. after bucket is on ground.
- (11) Turn off engine.

b. Return-To-Dig Control Adjustment. This control automatically returns bucket to digging position. It consists of a rod, tube, and a microswitch mounted on right bucket tilt cylinder assembly.



- (1) With engine operating and loader parked on a level surface, lower bucket to ground using LIFT ARM control lever in LOWER .
- (2) Put LIFT ARM control lever in FLOAT position.
- (3) Use BUCKET control lever in DUMP position to position bucket at desired digging angle then return BUCKET control lever to NEUT. position.
- (4) Turn off engine.
- (5) Loosen two nuts and capscrews on clamps securing tube and microswitch to right bucket tilt cylinder assembly.
- (6) Move tube off rod until microswitch roller is not touching rod.
- (7) Move tube onto rod until microswitch roller is touching rod and you hear a noise from microswitch.
- (8) Tighten two capscrews and nuts on clamps. Don't let tube and microswitch move.

2-16. ADJUSTMENTS (CONT)b. Return-To-Dig Control Adjustment (Cont.)

- (9) Use LIFT ARM control lever in RAISE position and raise bucket to full height or height set with bucket height control and dump bucket using BUCKET control lever in DUMP position.
- (10) Put BUCKET control lever in CROWD position and LIFT ARM control lever in FLOAT position. Bucket will roll back and lower to ground. Return LIFT ARM control lever to NEUT. position.
- (11) Check digging angle of bucket. If desired digging angle of bucket is not obtained, repeat steps (2) through (11) above.

2-17. OPERATING PROCEDURES**WARNING**

Don't use jumper cables connected to battery terminals to start engine or charge batteries. Always use slave receptacle. Failure to do so could cause serious injury due to batteries exploding caused by improper connection of jumper cables to battery terminals.


a. Starting the Engine.**WARNING**

Before starting engine, check and be sure that transport/service link is in released position. Failure to do so will cause loss of steering control which may result in serious injury or death and extensive property damage.

- (1) Release transport/service link by removing two clips securing pins. Pull tie bar pins from chassis. Remove transport/service link and install in released position as shown. Reinstall pins and secure with clips.

2-17. OPERATING PROCEDURES (CONT)

a. Starting the Engine (Cont).




Always use hand rails and steps when you mount or dismount loader. Don't use steering wheel or controls as a hand rail. Any other method of mounting or dismounting loader could make you slip and fall causing serious injury to yourself.

(2) Mount loader and sit in operator's seat.

(3) If necessary, adjust height of seat. If necessary to adjust fore and aft position of seat, move adjustment lever to left to release seat then move seat forward or backward as necessary.

(4) Close both cab doors.


(5) Fasten your seat belt.




2-17. OPERATING PROCEDURES (CONT)

a. Starting the Engine (Cont).

- (6) Pull up on parking brake control to apply parking brake.



- (7) Check and ensure that hydraulic control levers are in NEUT. or HOLD positions.



- (8) Check and ensure that SHUT OFF control is pushed completely in.
- (9) Place transmission control lever in neutral (N) position.


WARNING

Before starting engine, fasten your seat belt securely and be sure parking brake is applied, transmission control lever is in neutral (N) position, and both cab doors are closed. Failure to do so could cause serious injury or death due to an accident.

- (10) Insert key into ignition key switch. Turn key to first position clockwise (on position). Note that warning indicators (BRAKE ENGAGED, OIL PRESS, and CLUTCH PRESS) turn on and air pressure warning alarm sounds.
- (11) Push accelerator pedal down approximately one to two inches.

2-17. OPERATING PROCEDURES (CONT)

a. Starting the Engine (Cont).



CAUTION

Don't operate starter motor more than 30 seconds . Wait at least three minutes before cranking to allow batteries to recuperate and starter motor to cool. Failure to do so could cause damage to starter motor.

- (12) Turn ignition key switch to second clockwise position (start). Starter motor will crank engine. Note that HYDRAULIC FILTER warning indicator turns on.

Starting fluid is toxic and highly flammable. Container is pressurized to act as an expellent. Don't heat container and don't discharge starting fluid in confined areas or near open flame. Don't discard used container in an open flame. To do any of the above will cause an explosion. Don't breathe ether vapor or allow ether to come in contact with your skin. To do so will cause severe injury or death.

- (13) If temperature is below 40 degrees, use COLD START switch. With starter motor cranking engine, push and release COLD START switch two times.
- (14) When engine starts, release ignition key switch; it will return to first clockwise position. See that HYDRAULIC FILTER warning indicator turns off.


CAUTION

If OIL PRESS warning indicator does not turn off within ten to 15 seconds after starting engine, turn off engine and check cause.

- (15) Check instrument panel indicators and gages for proper indication:
 - (a) Ten to 15 seconds after engine starts, check that OIL PRESS warning indicator turns off. If it does not turn off, stop engine and investigate cause.

2-17. OPERATING PROCEDURES (CONT)**a. Starting the Engine (Cont).**

- (b) Check that AIR PRESS gage pointer indicates in green zone and air pressure warning alarm stops sounding. If AIR PRESS gage pointer does not indicate in green zone after 30 to 45 seconds, stop engine and check cause.
- (c) Check that VOLTMETER gage indicates between 22 to 30 volts. If normal VOLTMETER gage indication is not seen, turn off engine and check cause.




- (16) Operate engine at approximately 1000 rpm until WATER TEMP gage pointer indicates in green area.

CAUTION

Don't operate engine at idle speed for long periods of time. Long periods at idle speed will cause acids and deposits to form in engine from low operating temperatures.

b. Starting the Loader.


- (1) Operate LIFT ARM control lever and raise bucket no less than 12 inches from ground.
- (2) Put vehicle lights switch main switch lever in STOP LIGHT position.
- (3) Press brake treadle valve.
- (4) Release PARKING BRAKE control by pushing knob inward as far as it will go. BRAKE ENGAGED and CLUTCH PRESS warning indicators will go out.
- (5) Move transmission control lever to desired position.
- (6) Release foot pressure from brake treadle valve and press accelerator pedal as required to move loader and accelerate to desired speed.
- (7) Use following guide lines for transmission shifting:

**CAUTION**


Shifting from high range forward (H) to low range forward (L) at a ground and engine speed higher than 1/4 throttle will damage transmission. Shifting from high range forward (H) to reverse (R) when loader is moving will also damage transmission.

2-17. OPERATING PROCEDURES (CONT)

b. Starting the Loader (Cont).



- (a) High Range Forward (H) - Use this range to move loader from one location to another. Don't shift from high range (H) to low range (L) until ground and engine speed is approximately 1/4 throttle, or less. Don't shift from high range forward (H) to reverse (R) if loader is moving.
- (b) Low Range Forward (L) - You can shift from low range forward (L) to high range forward (H) at any speed. Reduce engine and ground speed to approximately 1/2 throttle before shifting from low range forward (L) to reverse (R).
- (c) Reverse (R) - You can shift from reverse (R) to low range forward (L) at any speed. Reduce engine and ground speed to approximately 1/2 throttle before shifting from reverse (R) to low range forward (L).




2-17. OPERATING PROCEDURES (CONT)

b. Starting the Loader (Cont).

- (8) The declutch treadle valve can be used during operation in any speed range. The declutch treadle valve when pressed will disengage the transmission and apply service brakes. It is used when maximum power to loader is needed. Use the declutch treadle valve to quickly raise bucket when filled by pressing treadle valve and pressing accelerator pedal to increase engine rpm.
- (9) Check CLUTCH PRESS warning indicator on left instrument panel. This indicator will turn on when declutch treadle valve is pressed. If this indicator is flashing on and off or is on steadily and declutch treadle valve is not pressed, stop engine and notify organizational maintenance.
- (10) Check CONV TEMP gage on left instrument panel. If gage pointer indicates in red area, select a lower transmission speed. If pointer remains in red area, stop operation, move transmission control lever to neutral (N) position, and operate engine at full throttle for several minutes. If this does not reduce temperature indication, stop engine and check transmission oil level.
- (11) Check WATER TEMP gage on left instrument panel. If gage pointer indicates in red area, stop engine and check radiator coolant level.
- (12) If low air pressure warning buzzer sounds, stop operation immediately. When air pressure gets below a safe level, parking brake will engage automatically.
- (13) If AUXILIARY STEERING warning buzzer sounds and warning indicator turns on, stop operation and turn off engine immediately. Be sure to turn ignition key switch to off position. Notify organizational maintenance immediately.
- (14) If HYDRAULIC FILTER warning indicator turns on during operation, continue operation and notify organizational maintenance at end of work shift.

c. Stopping the Loader.


- (1) Press brake treadle valve to stop loader.
- (2) Use LIFT ARM control lever placed in LOWER position to lower bucket to ground then return control lever to NEUT. position.
- (3) Put transmission control lever in neutral (N) position.
- (4) Pull up on PARKING BRAKE control knob to engage parking brake.
- (5) Operate engine at idle speed for approximately two minutes.



2-17. OPERATING PROCEDURES (CONT)

c. Stopping the Loader (Cont).

- (6) Turn ignition key switch to off position.
- (7) Pull out SHUT OFF control. When engine has stopped, push shut off control completely in.



d. Operating the Loader.

- (1) Excavating.

WARNING

Operating on a hillside can be dangerous. Rain, snow, loose gravel, soft ground, etc., change ground conditions. Only you, the operator, can determine if your machine can be safely operated on any hillside or ramp.

Before you operate on any hillside or ramp, always select low range and never coast down hill with transmission in neutral (N). To do so could cause you to lose control of loader and roll over causing loss of life or serious injury and extensive property damage.

- (a) Use LIFT ARM control lever to raise bucket approximately 12 inches above ground.

2-17. OPERATING PROCEDURES (CONT)d. Operating the Loader (Cont).



- (b) Use BUCKET control lever in DUMP position to adjust position of bucket so that bucket front edge is lower than rear of bucket. Bucket teeth will help you dig in this type of operation.

- (c) Move loader into area to be excavated with transmission in low range forward and engine speed at full throttle.

- (d) Use LIFT ARM control lever to lower bucket to ground. When bucket is at desired depth, move LIFT ARM control lever to NEUT. position and continue to move loader forward.

- (e) When bucket is full, use BUCKET control lever in CROWD position to roll bucket back and fill it with excavated material. You lose time when material is pushed in front of bucket.

(2) Loading Loose Material.



- (a) Use bucket level indicator to ensure that bottom of bucket is level with ground. When end of rod is one inch out of tube, bottom of loader bucket is level with ground.
- (b) Put LIFT ARM control lever in FLOAT and move loader into material.
- (c) When speed of loader starts to decrease, press declutch treadle valve and accelerator pedal, put LIFT ARM and BUCKET control levers in RAISE and CROWD positions, respectively, to raise and rollback loader bucket.


2-17. OPERATING PROCEDURES (CONT)

d. Operating the Loader (Cont)




Keep loader bucket as low as possible. This low position gives better balance and permits you to see ground condition more clearly. If bucket is full and you move loader over rough terrain or terrain that can cause loader to slide, always operate loader at slow speed. Failure to do so could cause you to lose control over loader causing serious injury or loss of life and extensive property damage.

- (3) Transporting a Load. Use LIFT ARM control lever in RAISE to raise bucket off ground and BUCKET control lever in CROWD to rollback bucket. Don't raise bucket too high. Return BUCKET control lever to NEUT. position after bucket has rolled back. After desired height is reached return LIFT ARM control lever to NEUT. position.



- (4) Dumping the Bucket.

- (a) Use LIFT ARM control lever in RAISE to raise bucket to height. Return LIFT ARM control lever to NEUT. position when dump height is reached unless you have set bucket height control to a preselected dump height.




- (b) If bucket height control has been adjusted, loader lift arm will stop at preselected dump height.
- (c) Dump bucket using BUCKET control lever in DUMP.
- (d) Use return-to-dig to automatically return bucket to position for next load. Do this by putting BUCKET control lever in CROWD and LIFT ARM control lever in FLOAT. Loader bucket will automatically roll back and lower to ground. Put LIFT ARM control lever in NEUT. after bucket is on ground.

2-17. OPERATING PROCEDURES (CONT)

d. Operating the Loader (Cont).

(5) Truck Loading.

- (a) Use LIFT ARM control lever in RAISE to raise bucket. Move loader toward side of truck.
- (b) Use brake treadle valve to slow loader and declutch treadle valve to stop loader.
- (c) As you move load toward truck, use bucket height control to automatically position bucket at desired dump height.
- (d) Dump load into truck by using BUCKET control lever in DUMP.
- (e) Use return-to-dig to position bucket for next cycle. Do this by using LIFT ARM control lever in FLOAT and BUCKET control lever in CROWD. Bucket will automatically rollback and lower to ground.
- (f) After bucket is on ground, return LIFT ARM control lever to NEUT.



2-18. PREPARATION FOR MOVEMENT


a. Driving. The loader may be moved under its own power without any special preparation or may be transported on a suitable truck and flatbed trailer. If transported on a flatbed trailer:

- (1) Place blocks at front and rear of each trailer wheel.

WARNING

Be sure ramp is securely fastened to flat bed trailer to prevent personnel injury and damage to equipment.

- (2) Place ramps between flat bed trailer and ground.



WARNING

Before moving loader up ramps, remove all ice, oil or grease from ramp to prevent loader from falling and causing death or serious injury and extensive damage to loader. Tell personnel to move away from loader.


NOTE

Ramps shall not provide a grade of more than 40 percent.

2-18. PREPARATION FOR MOVEMENT (CONT)

a. Driving (Cont).

- (3) Start engine and raise bucket one foot off ground using LIFT ARM control lever in RAISE position then return to NEUT. position.
- (4) Using BUCKET control lever in CROWD position, rollback bucket completely then return BUCKET control lever to NEUT. position.
- (5) Secure bucket assembly in rollback position using 12 foot length of chain with a hook on each end. Position one chain hook on center bucket tooth and lift arm brace as shown.




- (6) Install transport bracket, stored in tool box, on either lift cylinder assembly rod and secure using capscrew and nut.
- (7) Turn off engine.

CAUTION

When performing following step, be sure that engine is off. Failure to do so will cause damage to transport bracket and lift cylinder assembly, and may distort bucket lift arms.

- (8) Place LIFT ARM control lever in LOWER position and slowly lower bucket. Lift cylinder assembly rod will retract and bucket will lower until rod eye is resting on transport bracket.
- (9) Start engine and slowly move loader up ramps and position on flat bed trailer.
- (10) Pull up on parking brake control to apply parking brake, and turn off engine. Remove key from ignition key switch.
- (11) Place transport/service link in locked position.
- (12) Make sure transmission and hydraulic control levers are in their neutral positions.

2-18. PREPARATION FOR MOVEMENT (CONT)a. Driving (Cont).

TRANSPORT/SERVICE LINK
SHOWN IN LOCKED OR
ENGAGED POSITION

- (13) Place blocks at front and rear of each tire.
- (14) Install chain tiedowns at rear of front and rear chassis to fasten loader to trailer.
- (15) Place a cover such as heavy paper over exhaust pipe and use tape to keep it in place.
- (16) Measure from ground to highest point of loader. Clearance height of loader must be known when driving under overpasses so as not to damage loader. Tell transport driver of clearance height.

b. Towing the Loader. If loader is disabled, you must determine if it can be moved without further damage. If possible, have loader repaired at job location. If loader cannot be repaired at job location, and if a transport trailer is available, park trailer as close to loader as possible. This will shorten towing distance.


WARNING

Don't allow personnel in or near the loader when it is being towed with the engine stopped. To do so could cause serious injury or death.

NOTE

If engine cannot be started go to step (1) below; if engine can be started, go to step (2) below.

- (1) If engine cannot be started, raise loader bucket one foot above ground as follows:
 - (a) Attach a chain hoist or other suitable lifting device to loader lift arm center-support.
 - (b) Pull LIFT ARM control lever back to RAISE position.



2-18. PREPARATION FOR MOVEMENT (CONT)

b. Towing the Loader (Cont).

(c) Raise loader lift arms using chain hoist or lifting device.

(d) Install transport bracket, stored in tool box, on either lift cylinder assembly rod and secure using capscrew and nut.

(e) Place LIFT ARM control lever in LOWER position. Lift cylinder assembly rod will retract and bucket will lower until rod eye is resting on transport bracket.

(f) Attach chain hoist or other suitable lifting device to loader bucket center tooth.

(g) Place BUCKET control lever in CROWD position and use chain hoist to roll bucket back.

(h) Secure bucket assembly in rollback position using 12 foot length of chain with a hook on each end. Position one chain hook on center bucket tooth and lift arm brace as shown. Place BUCKET control lever in NEUT. position.

(i) Disconnect chain hoist or lifting device from loader bucket.

(j) Go to step (3) below.



(2) If engine can be started:


(a) Start engine and raise bucket one foot off ground using LIFT ARM control lever in RAISE position then return to NEUT. position.

(b) Using BUCKET control lever in CROWD position, rollback bucket completely then return BUCKET control lever to NEUT. position.

(c) Secure bucket assembly in rollback position using 12 foot length of chain with a hook on each end. Position one chain hook on center bucket tooth and lift arm brace as shown.

(d) Install transport bracket, stored in tool box, on either lift cylinder assembly rod and secure using capscrew and nut.



2-18. PREPARATION FOR MOVEMENT (CONT)**b. Towing the Loader (Cont).**

(e) Turn off engine.


CAUTION

When performing following step, be sure that engine is off. Failure to do so will cause damage to transport bracket and lift cylinder assembly, and may distort bucket lift arms.

(f) Place LIFT ARM control lever in LOWER position and slowly lower bucket. Lift cylinder assembly rod will retract and bucket will lower until rod eye is resting on transport bracket.

(g) Go to step (3) below.

(3) Place transport/safety link in locked position. If loader is turned to one side and engine is inoperable:



(a) Clear personnel from area.

(b) Pull SHUT OFF control all the way out.

(c) Turn ignition key switch to start position and at the same time turn steering wheel. When loader is straight, install transport/safety link. Don't operate starter motor more than 30 seconds at a time without allowing two minutes for it to cool.

(d) Place ignition key switch in off position.

2-18. PREPARATION FOR MOVEMENT (CONT)


b. Towing the Loader (Cont).

- (4) At rear of loader, remove clip from drawbar pin and remove drawbar pin.
- (5) Position rigid drawbar in location shown and secure using drawbar pin and clip.
- (6) Remove front and rear drive shafts (notify organizational maintenance).
- (7) Attach a second unit, such as a dozer, to rear of loader as close as possible.

NOTE

If front or rear axle failure is suspected, notify organizational maintenance to remove axle shafts before moving loader.

- (8) Tow disabled loader at a maximum speed of five miles per hour.




c. Preparation for Air Transport. The loader can be air transported in C-130, C-141, and C5A aircraft with cab removed to reduce loader height to 106.5 inches. All removed parts shall be palletized for air transport with the loader. Preparation is an organizational maintenance task.


2-19. OPERATING INSTRUCTIONSON DECALS AND IDENTIFICATION PLATES

Following illustrations show location of decals and identification plates containing operating or servicing instructions and warnings and their contents.













2-19. OPERATING INSTRUCTIONS ON DECALS AND IDENTIFICATION PLATES (CONT)



2-19. OPERATING INSTRUCTIONS ON DECALS AND IDENTIFICATION PLATES (CONT)



2-19. OPERATING INSTRUCTIONS ON DECALS AND IDENTIFICATION PLATES (CONT)



Section IV. OPERATION UNDER UNUSUAL CONDITIONS

	Para		Para
Operation in Unusual Weather	2-20	Lubrication	2-21d
Extreme Cold	2-20a	At Halt	2-21e
Extreme Heat	2-20b	Bucket Lift Arms and	
Rainy or Humid Conditions	2-20c	Pivot Assemblies	2-21f
Operation in Sandy or Dusty Areas	2-21	Operation in Salt Water Areas	2-22
General	2-21a	Operation at High Altitudes	2-23
Cooling System	2-21b	Operation in Snow	2-24
Air Cleaner	2-21c	Fording	2-25

2-20. OPERATION IN UNUSUAL WEATHER

a. Extreme Cold.

(1) General. Extensive preparation of the loader is required when extreme cold weather is anticipated. Extreme cold causes lubricants to thicken or congeal, presents a risk of freezing batteries and diminishes their electrical efficiency, can crack electrical insulation to cause short circuits, prevents fuel from vaporizing readily to form the combustible mixture necessary for starting, and causes various materials to become hard, brittle, and easily damaged. You must make sure the cooling system has been filled with the appropriate anti-freeze solution to protect the system against sub-freezing temperatures.

(2) Cooling System. Before the cooling system is drained and filled, inspect the system for leaks and general condition. All deteriorated or damaged hoses must be replaced. Make sure that all clamps are tight and that drain cocks are properly closed. When anti-freeze is added to the cooling system, be sure ample space is allowed for the required amount of anti-freeze. Be sure you operate the engine for 15 minutes to allow the solution to properly mix.

(3) Lubrication. Be sure that the correct grade of lubricant is applied to the lubrication points. If necessary, drain and refill if the lubricant grade is not correct for cold weather operation.

(4) Fuel System. Be sure precautions are taken to eliminate water and moisture from the fuel system by draining and flushing the fuel tank, and draining off any water from the fuel tank and filters at the end of each day's operation, replacing the fuel filter elements, and completely filling the fuel tank after each operating period to avoid water condensation. The fuel tank must not be allowed to remain partially empty over long periods of time and all ice and snow must be completely removed from around the filler opening before refilling the fuel tank.

(5) Air System. At beginning and end of daily operation, drain water and sediment from the air reservoir.

(6) Engine Operation.

- (a) Use the cold weather starting aid to start the engine.

2-20. OPERATION IN UNUSUAL WEATHER (CONT)a. Extreme Cold (Cont).

(b) Run the engine at reduced speed only long enough to circulate the oil through the engine, then increase speed and warm-up the engine. Low idling speeds during extremely cold temperature can result in incomplete combustion and heavy deposit formations on the valves.

(c) Cover the radiator if necessary to bring engine up to operating temperature.

(7) At Halt or Parking.

(a) Park loader in sheltered place if possible. Close cab doors and windows to protect accessories and controls from ice and snow.

(b) Run loader onto planks to prevent tires from freezing to ground. Block up bucket.

(c) Be sure you clean wet snow or mud from tires and cylinders before it freezes.

(d) In extremely cold weather, remove the batteries and store them in a moderately warm area. Reinstall the batteries just before starting the engine.

b. Extreme Heat.

(1) General. Check temperature gages and lights frequently for indication of overheating. Allow engine to idle slowly when it is overheated until temperature is reduced indicated by gage pointer dropping into the green zone.

(2) Cooling System.

(a) Drain, flush, and refill cooling system.

(b) Check coolant level at frequent intervals and keep radiator cap tight.

(c) Be sure that radiator is free of bugs, dust, and other foreign matter.

(d) Check drive belts tension frequently.

(3) Lubrication. Lubricate the loader with correct grade of lubricants in accordance with the lubrication chart. Change filter elements at shorter intervals than normal.

(4) Air Cleaner. Service air cleaner at shorter than normal intervals.

(5) At Halt or Parking. Park the loader in a shaded area if possible.

2-20. OPERATION IN UNUSUAL WEATHER (CONT)

c. Rainy or Humid Conditions. Keep loader protected when not in use. Dry off seat and wiring to prevent formation of mildew. Keep fuel tank full. Service filters more frequently than normal. Keep all moving parts well lubricated.

2-21. OPERATION IN DUSTY OR SANDY AREAS

a. General. Sand and dust are abrasive and can cause wear on many parts of the loader. Airborne sand and dust can clog the radiator and air cleaner.

b. Cooling System. Be sure you check the radiator frequently and keep air passages open.

c. Air Cleaner. Reduce service intervals for the air cleaner and clean the air cleaner as often as necessary.

d. Lubrication. Lubricate the loader at more frequent intervals. Clean all fittings and lubrication openings thoroughly before lubricating to prevent entry of dust or sand with the lubricant. Take care to prevent contamination of lubricants with dust or sand.

e. At Halt. When the loader is not in use, close cab windows and doors, and utilize what ever means are available to protect the engine compartment from the entry of wind blown dust or sand.

f. Bucket Lift Arms and Pivot Assemblies. Periodically check sliding mating parts for build-up of dust, dirt, or sand. Use a wire brush to remove dust, dirt, or sand build-up.

2-22. OPERATION IN SALT WATER AREAS

Keep loader as clean as possible; after use, wash with fresh water. Keep all lubrication points lubricated. Keep all wiring and connections clean and free from corrosion.

2-23. OPERATION AT HIGH ALTITUDES

Keep a constant watch on coolant level. Add coolant if necessary. Keep close watch on engine instruments during operation.

NOTE

Engine will operate at less than peak performance at high altitude.

2-24. OPERATION IN SNOW

Keep fuel tank full and snow and ice away from fuel filler when servicing the loader. Close cab windows and doors to keep snow from operating controls and indicators and from operator's seat.

2-25. FORDING

The loader may safely be subjected to depths up to 30-inches. Observe the following when fording any body of water:

a. Before Fording. Check depth of the water, allowing for the consistency of the bottom. Don't attempt to ford even the narrowest stream more than 30-inches deep. Make sure the engine is operating at full efficiency before fording.

b. During Fording. Shift the transmission in low speed range and speed up the engine to minimize the danger of stalling. Enter the water slowly to minimize surges of backwash into the engine compartment. Speed must not exceed three to four mph. If stalling or complete submersion occurs, notify higher level of maintenance.

c. After Fording. Lubricate the loader completely; as soon as possible, after fording.

CHAPTER 3

MAINTENANCE INSTRUCTIONS

CHAPTER OVERVIEW

The purpose of this chapter is to provide you with lubrication instructions, troubleshooting procedures, and maintenance procedures to help you keep your equipment in good operating condition.

Index

Section	Title	Page
I	Lubrication Instructions	3-1
II	Troubleshooting Procedures	3-3
III	Maintenance Procedures.	3-35

Section I. LUBRICATION INSTRUCTIONS

	Para
General Lubrication Information	3-1
Lubrication Information	3-2
Lubrication Requirements	3-3

3-1. GENERAL LUBRICATION INFORMATION

This section contains general lubrication instructions in addition to those contained in the lubrication order.

3-2. LUBRICATION INFORMATION

a. Care of Lubricants. Keep all lubricants in clean, closed containers and store in a dry area away from external heat. Don't allow dust, dirt, or other foreign matter to mix with lubricants during storage or use. Keep all lubrication equipment clean and ready for use.

b. Cleaning. Keep all external parts that do not require lubrication free of lubricants. Wipe all dirt and other foreign matter from lubrication points using a clean cloth. Clean caps, covers, and plugs and surrounding area before removing them from the loader. Clean lubrication points after lubrication to prevent accumulation of foreign matter.

c. Points of Lubrication. Refer to the lubrication order for lubrication points, and intervals of lubrication.

3-3. LUBRICATION REQUIREMENTS

a. For lubrication under normal conditions, refer to the lubrication order.

3-3. LUBRICATION REQUIREMENTS (CONT)

b. For instructions on lubrication in weather below zero degree F (-18 degrees C), refer to FM 9-207.

c. For lubrication before and after fording, refer to TM 9-238.

d. After operating in dusty or sandy conditions, clean and inspect all lubrication points. Lubricate loader in accordance with lubrication order.

Section II. TROUBLESHOOTING PROCEDURES

TROUBLESHOOTING SYMPTOM INDEX

	Troubleshooting Procedure Page/Malfunction
BATTERIES	
Fail to maintain charge	3-23/12
Require frequent filling	3-24/13
BRAKE SYSTEM	
Low air pressure	3-30/19
Parking brake doesn't hold	3-29/17
Service brakes uneven or erratic	3-30/18
BUCKET	
Lift arms don't operate properly	3-32/22
Return-to-dig and bucket height control circuits do not operate	3-33/23
COOLING SYSTEM	
Engine overheats	3-20/10
DRIVE SHAFTS	
Excessive noise	3-28/16
ENGINE	
Does not fire correctly (low and high rpm)	3-11/4
Excessive oil consumption	3-16/7
Low oil pressure	3-18/8
Starts but will not run	3-8/3
Stalls frequently or lacks power	3-13/5
Will not crank	3-4/1
Will not shut down	3-15/6
Hard to start or will not start	3-5/2
EXHAUST SYSTEM	
Excessive smoke	3-23/11
FUEL SYSTEM	
Excessive fuel usage	3-19/9
LOADER	
Will not move	3-34/24
STEERING SYSTEM	
Not operating properly	3-31/21
TIRES	
Wear rapidly or unevenly	3-30/20
TRANSMISSION	
Low oil pressure	3-27/15
Overheats	3-24/14

3-4. GENERAL

a. The troubleshooting table (paragraph 3-5) lists common malfunctions which you may find during operation of the loader. You should perform the tests/inspections and corrective actions in the order listed.


b. This manual cannot list all possible malfunctions that may occur or all tests, inspections, and corrective actions. If a malfunction is not listed (except when malfunctions and causes are obvious), or is not corrected by listed corrective actions, notify higher level maintenance.

3-5. TROUBLESHOOTING TABLE


MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

1. ENGINE WILL NOT CRANK

- Step 1. Check that transmission control lever is in N (neutral) position.
- a. If transmission control lever is in any position other than N (neutral), place it in N (neutral) position.
 - b. If transmission control lever is in N (neutral) position, go to step 2 below.



- Step 2. Open radiator grille at rear of loader. Check for loose, corroded, or damaged battery cables and connections.
- a. If battery cable connections are loose, notify organizational maintenance.
 - b. If battery cables or connections are corroded or damaged, notify organizational maintenance.
 - c. If battery cables are okay, go to step 3 below.



3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. ENGINE WILL NOT CRANK (CONT)

- Step 3. Unlock and remove engine front left side panel.
Check cable connections at starter motor for looseness.



- a. If cable connections at starter motor are loose, notify organizational maintenance.
- b. If cable connections are not loose, notify organizational maintenance.


2. ENGINE HARD TO START OR WILL NOT START

- Step 1. Check if there is fuel in fuel tank.

- a. If fuel tank is empty, fill with proper grade of diesel fuel.
- b. If fuel tank is not empty, go to step 2 below.

- Step 2. Check that SHUT OFF control is pushed all the way in.

- a. If SHUT OFF control is not pushed completely in, push in completely.
- b. If SHUT OFF control is pushed completely in, go to step 3 below.




3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

2. ENGINE HARD TO START OR WILL NOT START (CONT)

- Step 3. Unlock and remove engine rear right side panel.
While an assistant pushes and pulls SHUT OFF control, check at fuel injection pump that fuel shut off lever moves back and forth.
- a. If fuel shut off lever moves back and forth, go to step 4 below.
 - b. If fuel shut off lever does not move, notify organizational maintenance.



- Step 4. Tell assistant to push fuel SHUT OFF control all the way in. Check at fuel injection pump that fuel shut off lever moves behind fuel injection pump. Tell assistant to start engine while you grasp fuel shut off lever and move it towards rear of loader. Engine should start.
- a. If engine starts, notify organizational maintenance to adjust SHUT OFF control.
 - b. If engine does not start, go to step 5 below.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION


TEST OR INSPECTION

CORRECTIVE ACTION

2. ENGINE HARD TO START OR WILL NOT START (CONT)

Step 5. Check if restriction indicator red band is visible.


- a. If red band is visible, press reset button on top of indicator and check that red band disappears from view. (If red band does not disappear from view, notify organizational maintenance that restriction indicator is defective.) Crank engine and check if red band reappears; if red band is visible, service air cleaner.



- b. If red band is not visible, go to step 6 below.

Step 6. Unlock and open radiator grille at rear of loader. Check for loose, corroded, or damaged battery cables and connections.

- a. If battery cable connections are loose, notify organizational maintenance.
- b. If battery cables or connections are corroded or damaged, notify organizational maintenance.



- c. If battery cables are okay, go to step 7 below.

3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

2. ENGINE HARD TO START OR WILL NOT START (CONT)

- Step 7. Unlock and remove engine front left side panel.
Check cable connections to starter motor for looseness.



- a. If cable connections at starter motor are loose, notify organizational maintenance.
- b. If cable connections are not loose, go to step 8 below.

- Step 8. Check for incorrect or contaminated fuel in fuel tank.

Notify organizational maintenance.

3. ENGINE STARTS BUT WILL NOT RUN

- Step 1. Check fuel supply.

- a. If fuel supply is low, fill fuel tank with correct grade of fuel.
- b. If fuel supply is okay, go to step 2 below.

- Step 2. Check that SHUT OFF control is pushed all the way in.

- a. If SHUT OFF control is not pushed completely in, push in completely.

3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

3. ENGINE STARTS BUT WILL NOT RUN (CONT)


Step 2. (Continued)



b. If SHUT OFF control is pushed completely in, go to step 3 below.

Step 3. Unlock and remove engine rear right side panel.

While an assistant pushes and pulls SHUT OFF control, check at fuel injection pump that fuel shut off lever moves back and forth.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

3. ENGINE STARTS BUT WILL NOT RUN (CONT)

Step 3. (Continued]


- a. If fuel shut off lever moves back and forth, go to step 4 below.
- b. If fuel shut off lever does not move, notify organizational maintenance.

Step 4. Tell assistant to push fuel SHUT OFF control all the way in.
Check at fuel injection pump that fuel shut off lever moves behind fuel injection pump.
Tell assistant to start engine while you grasp fuel shut off lever and move it towards rear of loader.
Engine should start.

- a. If engine starts, notify organizational maintenance to adjust SHUT OFF control.
- b. If engine does not start, go to step 5 below.

Step 5. Check if restriction indicator red band is visible.

- a. If red band is visible, press reset button on top of indicator and check that red band disappears from view. (If red band does not disappear from view, notify organizational maintenance that restriction indicator is defective.) Crank engine and check if red band reappears; if red band is visible, service air cleaner.



- b. If red band is not visible, go to step 6 below.

Step 6. Check fuel injector lines for fuel leaks.

- a. If fuel injector lines are leaking, notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

3. ENGINE STARTS BUT WILL NOT RUN (CONT)

Step 6. (Continued)



b. If fuel injector lines are not leaking, go to step 7 below.

Step 7. Check for incorrect or contaminated fuel in fuel tank (notify organizational maintenance).


Notify organizational maintenance.

4. ENGINE DOES NOT FIRE CORRECTLY (LOW AND HIGH RPM)

Step 1. Check if WATER TEMP gage pointer is in green area of gage.

a. If WATER TEMP gage pointer is not in green area of gage, operate engine at approximately 1000 rpm until gage pointer indicates in green area.

If after several minutes, WATER TEMP gage pointer does not start to move into green area, notify organizational maintenance (thermostat must be tested).




b. If WATER TEMP gage pointer is in green area of gage, go to step 2 below.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

4. ENGINE DOES NOT FIRE CORRECTLY (LOW AND HIGH RPM) (CONT)

- Step 2. Unlock and remove engine rear right side panel.
Check fuel injector lines for fuel leakage.



- a. If fuel leakage is seen, notify organizational maintenance.
 - b. If fuel leakage is not seen, go to step 3 below.
- Step 3. Check for incorrect or contaminated fuel in fuel tank.
Notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION


TEST OR INSPECTION

CORRECTIVE ACTION

5. ENGINE STALLS FREQUENTLY OR LACKS POWER

Step 1. Check that SHUT OFF control is pushed all the way in.


- a. If SHUT OFF control is not pushed completely in, push in completely.
- b. If SHUT OFF control is pushed completely in, go to step 2 below.



Step 2. Unlock and remove engine rear right side panel.

Turn off engine and check and ensure that SHUT OFF lever is completely pushed in.

At fuel injection pump, try to move fuel shut off lever further to rear of loader.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION


5. ENGINE STALLS FREQUENTLY OR LACKS POWER (CONT)

Step 2. (Continued)

- a. If fuel shut off lever can be moved further to rear of loader, notify organizational maintenance to adjust SHUT OFF control cable.
- b. If fuel shut off lever can not be moved any further, go to step 3 below.

Step 3. Check if restriction indicator red band is visible.


- a. If red band is visible, press reset button on top of indicate. and check that red band disappears from view. (If red band does not disappear from view, notify organizational maintenance that restriction indicator is defective.)
Crank engine and check if red band reappears; if red band is visible, service air cleaner.



- b. If red band is not visible, go to step 4 below.

Step 4. Check WATER TEMP gage for high coolant temperature.

- a. If WATER TEMP gage indicates high coolant temperature, notify organizational maintenance (mechanical drag exists).
- b. If WATER TEMP gage indicates normal coolant temperature, go to step 5 below.
- c. If WATER TEMP gage indicates below normal coolant temperature, notify organizational maintenance (water thermostat must be tested).



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION


TEST OR INSPECTION

CORRECTIVE ACTION

5. ENGINE STALLS FREQUENTLY OR LACKS POWER (CONT)

Step 5. Remove engine front left side panel.

Check engine oil level for level exceeding full mark on dipstick.



ENGINE OIL LEVEL
DIPSTICK AND FILL

- a. If oil level is above dipstick full mark, notify organizational maintenance to drain oil.
- b. If oil level is okay, go to step 6 below.


Step 6. Check for fuel contamination and condensation in fuel tank.

Notify organizational maintenance.

6. ENGINE WILL NOT SHUT DOWN

Step 1. Check if fuel SHUT OFF control is completely pulled out

- a. If fuel SHUT OFF control is not pulled out completely, pull out completely to stop engine.
- b. If fuel SHUT OFF lever is pulled out completely and engine is still operating, go to step 2 below.



3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

6. ENGINE WILL NOT SHUT DOWN (CONT)

- Step 2. Unlock and remove engine rear right side panel.
Check if cable is connected to fuel shut off lever and if lever is in position shown.



Move fuel injection pump shut off lever to position shown.
Notify organizational maintenance to check connection of cable to fuel injection pump fuel shut off lever.

7. EXCESSIVE OIL CONSUMPTION

- Step 1. Check ground under loader for oil leaks from engine oil filter or oil pan.

- If oil leaks are observed, notify organizational maintenance.
- If oil leaks are not observed, go to step 2 below.

- Step 2. Try to determine what weight oil is used in engine crankcase (refer to LO 5-3805-262-12 for correct weight oil to be used).

- If too light of an engine oil is used, notify organizational maintenance to drain and refill engine crankcase with correct weight oil (refer to LO 5-3805-262-12).
- If weight of engine oil is okay, go to step 3 below.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION


CORRECTIVE ACTION

7. EXCESSIVE OIL CONSUMPTION (CONT)

Step 3. Unlock and open radiator cap access panel.

WARNING

Remove radiator cap slowly to relieve pressure before completely removing when engine is hot. Failure to do so could cause severe burns due to hot steam scalding you. If you are scalded by hot steam, seek medical aid immediately.



Remove radiator cap and inspect coolant for lubricating oil contaminant ion.

- a. If coolant is contaminated with oil, notify organizational maintenance (engine oil cooler must be repaired or replaced).
- b. If coolant is not contaminated with oil, notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

8. LOW ENGINE OIL PRESSURE (ENGINE OIL PRESSURE WARNING INDICATOR LIGHTS)

- Step 1. Unlock and remove engine front left side panel.
Check engine oil level.



- a. Add engine oil if oil level is not between dipstick full and add marks.
- b. If oil level is okay, go to step 2 below.

- Step 2. Check engine oil for dirty condition by removing dipstick, wiping between thumb and forefinger and noting if oil feels gritty and looks dirty.

- a. If oil feels gritty and looks dirty, notify organizational maintenance to drain oil, replace oil filter, and refill with oil.
- b. If oil is okay, go to step 3 below.

- Step 3. Try to determine what weight oil is used in engine crankcase (refer to LO 5-3805-262-12 for correct weight oil to be used).

- a. If too light of an engine oil is used, notify organizational maintenance to drain and refill engine crankcase with correct weight oil (refer to LO 5-3805-262-12).
- b. If weight of engine oil is okay, go to step 4 below.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION


8. LOW ENGINE OIL PRESSURE (ENGINE OIL PRESSURE WARNING INDICATOR LIGHTS) (CONT)

Step 4. Check ground under loader for oil leaks from engine oil filter or oil pan.

Notify organizational maintenance.

9. EXCESSIVE FUEL USAGE

Step 1. Check if restriction indicator red band is visible.



a. If red band is visible, press reset button on top of indicator and check that red band disappears from view. (If red band does not disappear from view, notify organizational maintenance that restriction indicator is defective.) Crank engine and check if red band reappears; if red band is visible, service air cleaner.

b. If red band is not visible, go to step 2 below.

Step 2. At bottom of fuel tank, check for fuel leaks.

a. If fuel tank is leaking fuel, notify organizational maintenance (fuel tank must be replaced).

b. If fuel tank is not leaking fuel, go to step 3 below.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION


TEST OR INSPECTION

CORRECTIVE ACTION

9. EXCESSIVE FUEL USAGE (CONT)

Step 3. Unlock and remove engine rear right side panel.
Inspect fuel injector lines for fuel leaks.


- a. If fuel injector lines are leaking, notify organizational maintenance.
- b. If fuel injector lines are okay, notify organizational maintenance.



10. ENGINE OVERHEATS (WATER TEMP GAGE INDICATES IN RED ZONE)

Step 1. Turn engine off.
Unlock and remove engine rear left side panel.
Check alternator drive belts for loose condition.
Press drive belts in approximate center with your hand.
Drive belts should not depress more than 1/2 inch approximately.

- a. If you are able to depress alternator drive belts more than 1/2 inch, notify organizational maintenance to adjust drive belts.
- b. If alternator drive belts are okay, go to step 2 below.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION


10. ENGINE OVERHEATS (WATER TEMP GAGE INDICATES IN RED ZONE) (CONT)

- Step 2. Unlock and remove engine rear right side panel.
Check radiator hoses at radiator top and bottom for leakage.
- If radiator hoses are leaking, notify organizational maintenance (hoses must be replaced).
 - If radiator hoses are okay, go to step 3 below.
- Step 3. Open radiator grille at rear of loader.
Inspect radiator for coolant leakage, damaged fins, or debris on fins.
- If radiator is leaking or fins are damaged, notify organizational maintenance.
 - If debris is on radiator fins, remove debris.
 - If radiator is okay, go to step 4 below.
- Step 4. Unlock and open radiator cap access panel at top of loader.

WARNING

Remove radiator cap slowly to relieve pressure before completely removing when engine is hot. Failure to do so could cause severe burns due to hot steam scalding you. If you are scalded by hot steam, seek medical aid immediately.

Slowly loosen and remove radiator cap.
Check that coolant level is between one to two inches below radiator filler neck.



3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

10. ENGINE OVERHEATS (WATER TEMP GAGE INDICATES IN RED ZONE) (CONT)

Step 4. (Continued)

- a. If coolant level is below two inches of radiator filler neck, add coolant.
- b. If coolant level is okay, go to step 5 below.

Step 5. Unlock and remove engine front left side panel. Check engine oil level.



- a. Add engine oil if oil level is not between dipstick full and add marks.
- b. If oil level is okay, go to step 6 below.

Step 6. Check for fuel contamination and condensation in fuel tank (notify organizational maintenance).


Notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION**TEST OR INSPECTION****CORRECTIVE ACTION****11. EXCESSIVE ENGINE EXHAUST SMOKE**

Step 1. Check if restriction indicator red band is visible.

- a. If red band is visible, press reset button on top of indicator and check that red band disappears from view. (If red band does not disappear from view, notify organizational maintenance that restriction indicator is defective.) Crank engine and check if red band reappears; if red band is visible, service air cleaner.



- b. If red band is not visible, go to step 2 below.


Step 2. Check if fuel tank contains proper grade of fuel (notify organizational maintenance).

Notify organizational maintenance.

12. BATTERIES FAIL TO MAINTAIN CHARGE (VOLTMETER INDICATED LOW)

Step 1. Turn engine off.
 Unlock and remove engine rear left side panel.
 Check alternator drive belts for loose condition.
 Press drive belts in approximate center with your hand.
 Drive belts should not depress more than 1/2 inch approximately.

- a. If you are able to depress alternator drive belts more than 1/2 inch, notify organizational maintenance to adjust drive belts.
- b. If alternator drive belts are okay, go to step 2 below.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

12. BATTERIES FAIL TO MAINTAIN CHARGE (VOLTMETER INDICATES LOW) (CONT)


Step 2. Check for loose wire connection at rear of alternator.

- a. If wire connection is loose at rear of alternator, notify organizational maintenance.
- b. If alternator connections are okay, go to step 3 below.

Step 3. Open radiator grille at rear of loader.

Check for loose battery cables or dirty connections at battery terminals.

- a. If battery cables are loose, dirty or corroded, notify organizational maintenance.
- b. If battery cables are not loose and connections are not dirty or corroded, notify organizational maintenance.



13. BATTERIES REQUIRE FREQUENT FILLING

If batteries require frequent filling, notify organizational maintenance.

14. TRANSMISSION OVERHEATS (CONV TEMP GAGE INDICATES IN RED ZONE)

Step 1. Place transmission control lever in lower speed range. Check if CONV TEMP gage pointer remains in red zone.

- a. If pointer remains in red zone, go to step 2 below.
- b. If pointer goes into green zone, continue operation of loader.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION



CORRECTIVE ACTION

14. TRANSMISSION OVERHEATS (CONV TEMP GAGE INDICATES IN RED ZONE) (CONT)

Step 2. Stop loader operation, move transmission control lever to N (neutral) position and operate engine at full throttle.
Check that CONV TEMP gage pointer moves into green zone of gage.

- a. If CONV TEMP gage pointer remains in red zone, go to step 3 below.
- b. If CONV TEMP gage pointer goes into green zone, continue loader operation.

Step 3. Turn off engine and pull up on parking brake control.
Place transmission control lever in N (neutral) position.
Move transport/service link to engaged position.
Start engine and operate at idle speed.
Unlock and remove transmission dipstick.
Check that oil level is between dipstick full and add marks.



- a. If oil level is below dipstick add mark, add oil to transmission (refer to LO 5-3805-262-12).
- b. If oil level is above dipstick full mark, notify organizational maintenance to drain excess oil.
- c. If oil level is okay, install and lock transmission dipstick.
Return transport/service link to operating position.

3-5. TROUBLESHOOTING TABLE (CONT)


MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

14. TRANSMISSION OVERHEATS (CON TEMP GAGE INDICATES IN RED ZONE) (CONT)

Step 3. (Continued)



WARNING

Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control.

Turn off engine.
Go to step 4 below.

- Step 4. Open radiator grille at rear of loader.
Inspect radiator for coolant leakage, damaged fins, or debris on fins.
- If radiator is leaking or fins are damaged, notify organizational maintenance.
 - If debris is on radiator fins, remove debris.
 - If radiator is okay, notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)



MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

15. LOW TRANSMISSION OIL PRESSURE (CLUTCH PRESS WARNING INDICATOR LIGHTS)

Turn off engine and pull up on parking brake control.
 Place transmission control lever in N (neutral) position.
 Move transport/service link to engaged position.
 Start engine and operate at idle speed.
 Unlock and remove transmission dipstick.
 Check that oil level is between dipstick full and add marks.



- a. If oil level is below dipstick add mark, add oil to transmission (refer to LO 5-3805-262-12).
- b. If oil level is above dipstick full mark, notify organizational maintenance to drain excess oil.
- c. If oil level is okay, install and lock transmission dipstick.
 Move transport/service link to operating position.

WARNING

Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control.

Turn off engine.
 Notify organizational maintenance.


3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

15. LOW TRANSMISSION OIL PRESSURE (CLUTCH WARNING INDICATOR LIGHTS) (CONT)



16. EXCESSIVE DRIVE SHAFTS NOISE

Turn off engine.

Inspect drive shafts for wear or damage.

Grasp drive shaft with both hands and try to rotate it. Wear or damage is indicated by movement of drive shaft in any direction.

- a. If drive shaft movement is seen indicating wear or damage, notify organizational maintenance.
- b. If drive shafts are okay, check for loose mounting hardware; notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION


TEST OR INSPECTION

CORRECTIVE ACTION

17. PARKING BRAKE DOES NOT HOLD

Step 1. Start and operate engine at 1000 rpm until AIR PRESS gage pointer indicates in green area.
 Push in and momentarily hold in knob of parking brake control.
 Release parking brake control knob.
 Check that parking brake control knob stays in and parking brake is released.

- a. If parking brake control knob does not stay in or parking brake does not release, notify organizational maintenance (parking brake control must be removed and repaired).
- b. If parking brake control knob stays in and parking brake is released, go to step 2 below.



Step 2. Turn off engine.

Depress brake treadle valve and declutch treadle valve until AIR PRESS gage pointer is approximately 1/4 inch into red zone.
 Check that parking brake control knob comes out and parking brake engages.

- a. If parking brake valve knob does not come out or parking brake does not engage, notify organizational maintenance (parking brake control must be removed and repaired).
- b. If parking brake valve knob came out and parking brake engaged, no further action is required.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------


18. SERVICE BRAKES UNEVEN OR ERRATIC

Check that tires are inflated to 40 psi.

- a. If tires are not properly inflated, notify organizational maintenance.
- b. If tires are inflated to 40 psi, notify organizational maintenance.

19. LOW AIR PRESSURE (AIR PRESS GAGE INDICATES IN RED ZONE AND BUZZER SOUNDS)

Check if air reservoir drain valve is open.



- a. If drain valve is open, close it.
- b. If drain valve is closed, notify organizational maintenance.

20. TIRES WEAR RAPIDLY OR UNEVENLY

Check that tires are inflated to 40 psi.

- a. If tires are not properly inflated, notify organizational maintenance.
- b. If tires are inflated to 40 psi, notify organizational maintenance.

3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

21. STEERING SYSTEM NOT OPERATING PROPERLY

WARNING

Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control..

Step 1. Park loader on level surface, lower bucket to ground, turn off engine, and pull up on parking brake control. Check hydraulic oil level in sight gage in front of loader. Oil level must be seen in sight gage.



- a. If oil level is not seen in sight gage, add hydraulic oil (refer to LO 5-3805-262-12).
- b. If oil level is seen in sight gage, go to step 2 below.

Step 2. Check that all tires are inflated to 40 psi.

- a. If tires are not properly inflated, notify organizational maintenance.
- b. If all tires are inflated to 40 psi, go to step 3 below.

Step 3. Start engine and turn loader completely to right. Check steering cylinder assemblies for oil leakage.

Notify organizational maintenance.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

22. LIFT ARMS DO NOT OPERATE PROPERLY

Step 1. Park loader on level surface, lower bucket to ground, turn off engine, and pull up on parking brake control. Check hydraulic oil level in sight gage in front of loader. Oil level must be seen in sight gage.


- a. If oil level is not seen in sight gage, add hydraulic oil (refer to LO 5-3805-262-12).
- b. If oil level is seen in sight gage, go to step 2 below.

Step 2. Inspect bucket lift arm pivot pins and bushings for wear or damage.

- a. If pivot pins or bushings are worn or damaged, notify organizational maintenance.
- b. If pivot pins and bushings are not worn or damaged, go to step 3 below.

Step 3. Check if bucket lift arm pivots are adequately lubricated.

- a. If pivots are not adequately lubricated, lubricate (refer to LO 5-3805-262-12) .
- b. If pivots are adequately lubricated, notify organizational maintenance.



3-5. TROUBLESHOOTING TABLE(CONT)

MALFUNCTION

TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	-------------------

23. RETURN-TO-DIG AND BUCKET HEIGHT CONTROL CIRCUITS DO NOT OPERATE

NOTE

Refer to pages 2-45 and 2-46 and adjust bucket height control and return-to-dig control.



Step 1. Press top most 5 AMP circuit breaker on right instrument pane 1. Start engine and place LIFT ARM control lever in RAISE position. Check if 5 AMP circuit breaker button pops out when bucket reaches preselected height.

- a. If circuit breaker button popped when bucket reached preselected height, lower bucket to ground. Notify organizational maintenance (short circuit exists in bucket height control circuit).

- b. If circuit breaker button did not pop, and desired dump height was not obtained, readjust bucket height control (page 2-45).

- c. If circuit breaker button did not pop, go to step 2 below.

Step 2. With bucket at preselected height, put BUCKET control lever in CROWD and LIFT ARM control lever in FLOAT. Check if 5 AMP circuit breaker button pops out when bucket reaches desired digging or rollback angle. Put LIFT ARM control lever in NEUT. position when bucket is on ground.



3-5. TROUBLESHOOTING TABLE (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

23. RETURN-TO-DIG AND BUCKET HEIGHT CONTROL CIRCUITS DO NOT OPERATE (CONT)


Step 2. (Continued)

- a. If 5 AMP circuit breaker button popped when bucket reached desired digging or rollback angle, notify organizational maintenance (short circuit exists in return-to-dig control circuit).
- b. If 5 AMP circuit breaker did not pop, and desired digging or rollback angle was not obtained, readjust return-to-dig control (page 2-46).

24. LOADER WILL NOT MOVE

Step 1. Check if parking brake control knob is pulled out.

- a. Push in parking brake control knob if pulled out.
- b. If parking brake control knob is not pulled out, go to step 2 below.



Step 2. Check if air pressure builds to normal operating pressure (AIR PRESS gage pointer indicates in green zone).

- a. If air system pressure is low, go to MALFUNCTION 19 above.
- b. If air system pressure is normal, notify organizational maintenance.

Section III. MAINTENANCE PROCEDURES

	Para		Para
Introduction	3-6	Clamshell Teeth Assemblies	3-7i
Inspection	3-7	Servicing	3-8
Fuel Injector Lines	3-7a	Air Cleaner	3-8a
Fuel Tank	3-7b	Fuel Tank	3-8b
Radiator Assembly	3-7c	Air Reservoir	3-8c
Battery Cables	3-7d	Checking Tires Air Pressure	3-8d
Wiring Harnesses	3-7e	Windshield Washer Reservoir	3-8e
Drive Shafts	3-7f	Removal and Installation	3-9
Loader Bucket Assembly	3-7g	Transport/Service	
Bucket Cutting Edge		Link	3-9a
Assemblies	3-7h	Engine Side Panels	3-9b


3-6. INTRODUCTION

This section provides maintenance procedures consisting of inspections and servicing of the various components and/or systems to be performed by the operator as authorized in the Maintenance Allocation Chart.

3-7. INSPECTION

a. Fuel Injector Lines.


- (1) Unlock and remove engine front right side panel (under fender).
- (2) Start engine and operate at idle speed for three minutes then turn off engine.
- (3) Inspect fuel injector lines at fuel injection pump and at fuel injectors for fuel leaks.
- (4) If fuel leakage is observed, notify organizational maintenance.
- (5) Install and lock engine right side panel.



3-7. INSPECTION (CONT)


b. Fuel Tank.

- (1) Unlock and remove engine rear right and left side panels.
- (2) Inspect fuel tank for cracks and broken welds. Notify organizational maintenance if any of these conditions are seen (fuel tank must be replaced).
- (3) Check beneath fuel tank for signs of fuel leakage indicating cracks or holes in fuel tank. Notify organizational maintenance if any of these conditions are seen (fuel tank must be replaced).
- (4) Install and lock engine rear side panels.



c. Radiator Assembly.

- (1) Open radiator grille at rear of loader.
- (2) Inspect radiator for coolant leakage, damaged fins, or debris on fins. Remove debris as necessary. If coolant leakage or damaged fins are seen, notify organizational maintenance (radiator must be removed and replaced).
- (3) Close radiator grille.
- (4) Unlock and open radiator cap access panel.
- (5) Check that radiator cap is tight. If necessary, tighten radiator cap.
- (6) Close and lock radiator cap access panel.
- (7) Unlock and remove engine rear right and left side panels.
- (8) At top and bottom of radiator, check radiator hoses for coolant leaks, cracks, or chafing. If any of these conditions are seen, notify organizational maintenance (hoses must be replaced).
- (9) Install and lock engine rear right and left side panels.

3-7. INSPECTION (CONT)**c. Radiator Assembly (Cont).****d. Battery Cables.**


- (1) Open radiator grille at rear of loader.
- (2) Check for loose, corroded, or damaged battery cables and connections. If any of these conditions are seen, notify organizational maintenance (battery cables must be removed).
- (3) Inspect battery terminals for looseness or corrosion buildup. If any of these conditions are seen, notify organizational maintenance (terminals must be tightened and cleaned).
- (4) Inspect batteries for electrolyte leaks or cracks. If any of these conditions are seen, notify organizational maintenance (batteries must be replaced).
- (5) Close radiator grille.

3-7. INSPECTION (CONT)

e. Wiring Harnesses. Inspect exposed wiring and connections for frayed or broken wires and cracked or broken wire insulation. If any of these conditions are seen, notify organizational maintenance (wiring must be repaired).

f. Drive Shafts.

- (1) Start engine and operate at idle speed.
- (2) Turn loader fully right or left to gain access to front drive shaft. Turn off engine.
- (3) Pull up on parking brake control knob to apply parking brake.
- (4) Grasp and try to rotate each drive shaft; check for movement indicating wear or damage. Check that universal joints mounting hardware are not loose. If any of these conditions are seen, notify organizational maintenance (drive shaft must be removed and replaced).




g. Loader Bucket Assembly.



NOTE

If any of the following conditions are seen, notify organizational maintenance (must be corrected).

- (1) Inspect blade and clam assembly for cracks, breaks, or broken welds.
- (2) Check that hardware securing bucket pins are tight and not loose.
- (3) Check that hardware securing bucket clamshell cylinder assemblies pins are tight and not loose.




3-7. INSPECTION (CONT)

g. Loader Bucket Assembly (Cont).h. Bucket Cutting Edge Assemblies.**NOTE**

If any of the following conditions are seen, notify organizational maintenance (must be corrected).

- (1) Inspect clam cutting edge for breaks, cracks, or nicks.
- (2) Start engine and operate at idle speed.
- (3) Raise bucket off ground two or three inches by operating LIFT ARM control lever in RAISE then returning it to NEUT. position.
- (4) Open clam by operating CLAM control lever in OPEN until clam is opened just enough for you to visually check blade cutting edges. Return CLAM control lever to HOLD position.
- (5) Check blade cutting edges for cracks, breaks, and nicks.
- (6) Close clam and lower bucket to ground.
- (7) Turn off engine.




3-7. INSPECTION (CONT)

i. Clamshell Teeth Assemblies.

NOTE

If any of the following conditions are seen, notify organizational maintenance (must be corrected).

- (1) At clamshell, check that tooth points are present.
Check tooth points for cracks, breaks, or nicks.
- (2) Check that tooth shanks are securely mounted and not loose.



13-8. SERVICING I


a. Air Cleaner.

NOTE

Element assemblies should be serviced whenever restriction indicator red band is in view.

(1) Precleaned Servicing.


- (a) Loosen cover wingnut, then remove cover and wingnut.
- (b) Remove precleaned bowl.
- (c) Dump any dust and dirt contained in precleaned bowl.
- (d) Wash precleaned bowl in solution of water and general purpose detergent. Dry using clean cloth.
- (e) Install precleaned bowl on air cleaner body.



- (f) Install cover and wingnut; hand tighten cover wingnut securely.

(2) Element Assemblies Servicing.

- (a) Loosen cover wingnut and remove cover assembly with wingnut attached.
- (b) Loosen and remove nut assembly.
- (c) Remove primary element assembly.
- (d) Loosen and remove nut assembly.
- (e) Remove secondary element assembly.

3-8. SERVICING (CONT)**a. Air Cleaner (Cont).**

Grasp vacuator valve and pull off air cleaner body. Dump any dust or dirt in vacuator valve.

CAUTION

Don't use compressed air to dry primary element assembly. To do so may cause damage to primary element assembly.

NOTE

Don't clean secondary element assembly. Secondary element assembly shall be replaced every third servicing of primary element assembly, when secondary element assembly is more than two years old (date of manufacture is stamped on top of secondary element assembly), when it is damaged, or when red band in restriction indicator stays in view after primary element assembly has been cleaned or replaced.

- (g) Wash primary element assembly using general purpose detergent. Allow primary element assembly to air dry.
- (h) Check for holes in primary element assembly. Check if metal covering is bent. If holes in element are apparent or if metal covering is bent, install new primary element assembly.

NOTE


Clean primary element assembly using compressed air not exceeding 30 psi.

Inspect new primary element assembly as described in step (2)(h) above; if new primary element assembly is damaged, replace it.

3-8. SERVICING (CONT)

a. Air Cleaner (Cont).

(2) Element Assemblies Servicing (Cont).



- (i) Clean vacuator valve using general purpose detergent. Dry using clean cloth.
- (j) Using a clean cloth dampened with water and general purpose detergent, wipe inside of air cleaner body. Dry using clean, dry cloth.
- (k) Reinstall vacuator valve on air cleaner body.
- (l) Install secondary element assembly; secure using nut assembly.
- (m) Install primary element assembly; secure using nut assembly.
- (n) Install cover assembly and tighten cover wingnut securely.
- (o) Press reset button on top of restriction indicator and check that red band disappears from view. Crank engine and check if restriction indicator red band comes into view. If red band is in view, repeat steps (2)(a) through (2)(e) above and replace secondary element assembly.

3-8. SERVICING (CONT)**b. Fuel Tank.****NOTE**


Add diesel fuel to fuel tank whenever FUEL LEVEL gage indicates level is low .

- (1) Unlock and remove engine rear right side pane 1.
- (2) Loosen and remove fuel filler cap.

WARNING


Diesel fuel is highly combustible. Do not smoke or allow open flames or sparks into the area. Death or severe injury may result if personnel fail to observe this precaution. If you are burned, obtain medical aid immediately.

- (3) Fill fuel tank using correct grade diesel fuel.
- (4) Install and tighten fuel filler cap.
- (5) Install and lock engine rear right side panel.

**c .Air Reservoir.****NOTE**

Drain water from air reservoir every 10 hours of operation or every day, whichever occurs first.

- (1) Find air reservoir drain valve, located above rear axle, right side.
- (2) Open air reservoir drain valve.
- (3) Allow water to drain.
- (4) Close air reservoir drain valve.




3-8. SERVICING (CONT)

d. Checking Tires Air Pressure.

- (1) Remove valve cap from tire.
- (2) Use tire pressure gage and check that tire pressure is 40 psi.
- (3) Reinstall valve cap.

e. Windshield Washer Reservoir.



- (1) At front of loader, unlock and open front access door.
- (2) Open fluid reservoir fill cap by firmly pulling up until cap snaps open.
- (3) Fill fluid reservoir with washer fluid until fluid level is 1/4 inch from top of reservoir.
- (4) Close fluid reservoir fill cap by firmly pressing downward until cap snaps into position.
- (5) Close and lock front access door.

3-9. REMOVAL AND INSTALLATION

a. Transport/Service Link.



WARNING

Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control.

Before performing any loader maintenance that requires servicing in area between front and rear chassis, be sure that transport/service link is engaged. Failure to do so could cause serious injury or death due to chassis pivoting and crushing you when you are working in area between front and rear chassis.

(1) To move transport/service link to locked or engaged position:

- (a) Remove two clips securing pins in position.
- (b) Remove two pins.
- (c) Remove transport/service link.
- (d) Position transport/service link between welded block on rear chassis and welded block on front chassis.
- (e) Install two pins.
- (f) Install two clips on pins.





3-9. REMOVAL AND INSTALLATION (CONT)

a. Transport/Service Link (Cont).

(2) To move transport/service link to operating or released position:

- (a) Remove two clips securing pins in position.
- (b) Remove two pins.
- (c) Remove transport/service link.
- (d) Position transport/service link between welded block on rear chassis and welded bracket just to side of and below hydraulic cooler on rear chassis.
- (e) Install two pins.
- (f) Install two clips on pins.




Be sure transport/service link is disengaged before driving vehicle. Failure to do so could cause serious injury or death due to loss of steering control.

Before performing any loader maintenance that requires servicing in area between front and rear chassis, be sure that transport/service link is engaged. Failure to do so could cause serious injury or death due to chassis pivoting and crushing you when you are working in area between front and rear chassis.

3-9. REMOVAL AND INSTALLATION (CONT)**b. Engine Side Panels.****(1) Removal.****NOTE**

Removal procedure for any one engine front or rear, right or left side panel is the same as described below.

- (a) Unlock and remove lock securing engine side panel.
- (b) Pull up on latch handle to disengage latch from engine side panel catch.
- (c) Grasp engine side panel handle and pull out bottom of engine side panel. Then, lift engine side panel up over spacers, washers, and capscrews at upper edge of mounting area.
- (d) Remove engine side panel from loader.

**(2) Installation.**

- (a) Grasp engine side panel handle and raise engine side panel into position.
- (b) Using two holes at engine side panel upper edge, hang engine side panel on two spacers at upper edge of mounting area, then firmly push bottom of engine side panel inward.
- (c) Pull latch handle upward then engage latch with catch on engine side panel. Push down on latch handle to secure engine side panel.
- (d) Install lock.

APPENDIX A

REFERENCES

A-1. SCOPE

This appendix lists all forms and publications pertinent to the major item material and associated equipment.

A-2. PUBLICATIONS INDEX

The following index should be consulted frequently for latest changes or revisions and for new publications relating to material covered in this manual.

DA PAM 310-1	Consolidated Index of Army Publications and Forms
--------------	---

A-3. FORMS

DA Form 2028	Recommended Changes to Publications and Blank Forms
DA Form 2028-2	Recommended Changes to Equipment Technical Publications
DA Form 2062	Hand Receipt/Annex Number
DA Form 2402	Exchange Tag
DA Form 2404	Equipment Inspection and Maintenance Work Sheet
DA Form 2406	Material Condition Status Report
DA Form 2407	Maintenance Request
DA Form 2408-9	Equipment Control Record
DA Form 2408-20	Oil Analysis Log
DD Form 314	Preventive Maintenance Schedule and Record
SF 368	Quality Deficiency Report

A-4. FIELD MANUALS

FM 9-207	Operation and Maintenance of Ordnance Material in Cold Weather (0 degrees F to -65 degrees F)
FM 20	Camouflage
FM 21-11	First Aid for Soldiers
FM 21-40	NBC (Nuclear, Biological, and Chemical) Defense
FM 21-305	Manual for Wheeled Vehicle Driver
FM 31-70	Basic Cold Weather Manual
FM 31-71	Northern Operations
FM 55-30	Driver Selection and Training (Wheeled Vehicles)
FM 90-3	Desert Operations
FM 90-5	Jungle Operations
FM 90-6	Mountain Operations
FM 90-13	River Crossing Operations

A-5. TECHNICAL MANUALS

TM 5-3805-262-20	Organizational Maintenance: Loader Scoop Type MW24C
TM 5-3805-262-24P	Organizational, Direct Support, and General Support Maintenance Repair Parts and Special Tools List: Loader, Scoop Type, MW24C

A-5. TECHNICAL MANUALS (CONT)

TM 5-3805-262-34	Direct Support and General Support Maintenance: Loader, Scoop Type MW24C
TM 9-6140-200-14	Operation and Organizational Maintenance Manual for Lead Acid Storage Batteries
TM 9-8000	Principles of Automotive Vehicles
TM 740-90-1	Administrative Storage of Equipment
TM 750-244-6	Procedures for Destruction of Tank Automotive Equipment to Prevent Enemy Use
TM 750-254	Cooling Systems: Tactical Vehicles

A-6. TECHNICAL BULLETINS

TB 9-2300-422-20	Security of Tactical Wheeled Vehicles
TB 43-0001-39	Equipment Improvement Report and Maintenance Digest
TB 750-651	Use of Antifreeze Solutions, and Cleaning Compounds in En- gine Cooling Systems
TB 43-0210	NonAeronautical Equipment Army Oil Analysis Program

A-7. OTHER PUBLICATIONS

DA PAM 738-750	The Army Maintenance Management System (TAMMS)
LO 5-3805-262-12	Lubrication Order: Loader, Scoop Type, MW24C
TM 5-3805-262-10HR	Hand Receipt: Loader, Scoop Type, MW24c

A-8. ARMY REGULATIONS

AR 310-2	Identification and Distribution of DA Publications and Issue of Agency and Command Administration Publications
AR 310-25	Dictionary of United States Army Terms
AR 385-40	Accident Reporting and Records
AR 385-55	Prevention of Motor Vehicle Accidents

APPENDIX B

COMPONENTS OF END ITEM (COEI) AND BASIC ISSUE ITEMS (BII) LISTS

Section I. INTRODUCTION

B-1. SCOPE

This appendix lists components of end item and basic issue items for the MW24C loader to help you inventory items required for safe and efficient operation.

B-2. GENERAL

The Components of End Item and Basic Issue Items Lists are divided into the following sections:

a. Section II - Components of End Item. This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

b. Section III -Basic Issue Items. These are the minimum essential items required to place the MW24C loader in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged BII must be with the loader during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorization of the end item.

B-3. EXPLANATION OF COLUMNS

The following provides an explanation of columns found in the tabular listings:

a. Column 1 - Illustration Number (Illus number). This column indicates the number of the illustration in which the item is shown.

b. Column 2 -National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

c. Column 3 - Description. Indicates the National item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

d. Column 4 - Unit of Measure (U/M). Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr).

e. Column 5 - Quantity Required (qty rqr). Indicates the quantity of the item authorized to be used with/on the equipment.

Section II. COMPONENTS OF END ITEM

(1) Illus number	(2) National stock numb e r	(3) Description FSCM and part number Usable on code	(4) U/M	(5) Qty reqd
		TRANSPORT BRACKET (10988) L114543	EA	1
		BOLT (10988) 13-680	EA	1
		NUT (96906) MS51967-8	EA	1

Section III. BASIC ISSUE ITEMS

(1) Illus numb e r	(2) National stock numb e r	(3) Description FSCM and part number Usable on code	(4) U/M	(5) Qty reqd
	7520-00-559-9618	CASE, MAINTENANCE MANUAL (81349) MIL-E-11743	EA	1
	9905-00-565-6267	KIT, VEHICLE WEIGHT CLASSIFICATION SIGN (81337) 6-1-2248	EA	1

APPENDIX C

ADDITIONAL AUTHORIZATION LIST (AAL) ITEMS

Section I. INTRODUCTION

C-1. SCOPE

This appendix lists additional items you are authorized for support of the MW24C loader.

C-2. GENERAL

This list identifies items that do not have to accompany the MW24C loader and that do not have to be turned in with it. These items are all authorized to you by CTA, MTOE, TDA, or JTA.

C-3. EXPLANATION OF LISTING

National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support the equipment.

Section II. ADDITIONAL AUTHORIZATION LIST

(1) National Stock Number	(2) Description FSCM and Part Number Usable on code	(3) U/M	(4) Qty. auth.
4210-00-889-2221	EXTINGUISHER, FIRE (58536) A-A-393	EA.	1
4910-00-204-3170	GAGE, TIRE PRESSURE (53477) 7188BH	EA	1
4930-00-253-2478	LUBRICATING GUN, HAND (36251) 1142	EA	1
5120-00-223-7397	PLIERS, SLIP JOINT (56161) 1051 0983	EA	1
5120-00-234-8913	SCREWDRIVER, CROSS TIP #2 (96906) MS15224-5	EA	1
5120-00-278-1283	SCREWDRIVER, FLAT TIP 6 INCHES (19207) 4151104	EA	1
5120-00-449-8083	WRENCH, ADJUSTABLE, 10 INCHES (11083) 1B7536	EA	1
5120-00-895-9568	WRENCH, BOX AND OPEN END 7/16 INCH (81348) GGG-W-645	EA	1
5120-00-895-9570	WRENCH, BOX AND OPEN END 9/16 INCH (81348) GGG-W-645	EA	1
5120-00-224-3153	WRENCH, BOX, 3/8 AND 7/16 INCH (47805) WBG1214	EA	1
5120-00-224-3154	WRENCH, BOX, 1/2 AND 9/16 INCH (18949) G2042	EA	1

APPENDIX D

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

D-1. SCOPE

This appendix lists expendable/durable supplies and materials you will need to operate and maintain the MW24C loader. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

D-2. EXPLANATION OF COLUMNS

- a. Column 1 - Item Number. This number is assigned to each entry in the listing.
- b. Column 2 - Level. This column identifies the lowest level of maintenance that requires the listed item. The symbol designation is as follows:
 - c Operator/Crew
- c. Column 3 - National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.
- d. Column 4 - Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.
- e. Column 5 - Unit of Measure (tJ/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by an alphabetical abbreviation (QT, GAL.). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

(1) Item number	(2) Leve 1	(3) National stock number	(4) Description	(5) U/M
1	C		ANTIFREEZE: ethylene glycol, inhibited, heavy duty, single package (81349) MIL-A-46153	
		6850-00-181-7929	1 Gallon Container	GAL .
		6850-00-181-7933	5 Gallon Container	GAL .
2	C		BRAKE FLUID: silicone, automotive, all weather, operational and preservative (81349) MIL-B-46176	
		9150-01-102-9455	1 Gallon Can	GAL .
		9150-01-123-3152	5 Gallon Can	GAL .
3	C		CLEANING COMPOUND: windshield washer (81348) O-C-1901	
		6850-00-926-2275	1 Pint	PT
4	C		DETERGENT: non sudsing, general purpose, liquid (80244) MIL-D-16791 Type 1	
		7930-00-282-9699	1 Gallon Container	GAL
5	C		DRY CLEANING SOLVENT: (81348) P-D-680, Type II	
		6850-00-110-4498	1 Pint Can	PT
		6850-00-274-5421	5 Gallon Drum	GAL .
6	C		FUEL OIL: diesel, regular, DF-2 (81348) VV-F-800	
		9140-00-286-5295	5 Gallon Can	GAL .
7	C		FUEL OIL: diesel, winter, DF-1 (81348) VV-F-800	
		9140-00-286-5287	5 Gallon Drum	GAL .

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item number	(2) Level	(3) National stock number	(4) Description	(5) U/M
8	C		FUEL OIL: diesel, arctic, DF-A (81348) VV-F-800	
		9140-00-286-5282	5 Gallon Drum	GAL.
9	C		GREASE: automotive and artillery (81349) MIL-G-10924	
		9150-00-935-1017	14 Ounce Cartridge	OZ
		9150-00-190-0904	1-3/4 Pound Can	LB
10	C		LUBRICATING OIL: gear, multipurpose, GO 85/140 (81349) MIL-L-2105	
		9150-00-035-5392	1 Quart Can	QT
		9150-01-035-5396	5 Gallon Can	GAL .
11	C		LUBRICATING OIL: general purpose, preservative, PL-S (81348) VV-L-800	
		9150-00-231-6689	1 Quart Can	QT
12	C		LUBRICATING OIL: internal combustion engine, arctic, OEA (81349) MIL-L-46167	
		9150-00-402-4478	1 Quart	QT
		9150-00-402-2372	5 Gallon Drum	GAL .
13	C		LUBRICATING OIL: internal combustion engine, tactical service, OE/HDO 10 (81349) MIL-L-2104	
		9150-00-189-6727	1 Quart Can	Qt
		9150-00-186-6618	5 Gallon Drum	GAL .

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item number	(2) Level	(3) National stock number	(4) Description	(5) U/M
14	C		LUBRICATING OIL: internal combustion engine, tactical service, OE/HDO 30 (81349) MIL-L-2104	
		9150-00-186-6681	1 Quart Can	QT
		9150-00-188-9858	5 Gallon Drum	GAL .
		9150-00-189-6729	55 Gallon Drum	GAL .
15	C		RAG: wiping, cotton and cotton-synthetic (58356) A-A-531	
		7920-00-205-1711	50 Pound Bale	LB
			ALCOHOL, METHANOL (81340) O-M-232	
16	C	6810-00-597-3608	1 Gallon Can	Gal
		6810-00-275-6010	5Gallon Can	Gal

ALPHABETICAL INDEX

Subject	Page	Subject	Page
A			
Abbreviations, List Of	1-3	A (Cont)	
Accelerator Pedal		Air Horn	
description and use	2-13	description and use	2-13
preventive maintenance	2-38	principles of operation	1-23
principles of operation	1-10	Air Precleaned	
Accessories		principles of operation	1-9
description	1-6	AIR PRESS Gage	
description and use		description and use	2-8
air horn valve	2-13	preventive maintenance	2-37
dome light, cab	2-16	principles of operation	1-14
fans, defogger	2-15	Air Pressure Warning Alarm	
windshield washer	2-9	description and use	2-6
location	1-6	preventive maintenance	2-36
operation, principles of		principles of operation	1-13
see principles of operation		Air Reservoir	
preventive maintenance		description and use	
reservoir, windshield		drain valve	2-25
washer	2-44	preventive maintenance	2-32
principles of operation	1-22	principles of operation	1-18
air horn	1-23	servicing	3-43
defroster assembly	1-23	troubleshooting	3-30
dome light, cab	1-23	Air Transport, Preparation for . .	2-62
fans, defogger	1-23	Authorization List, Additional . .	C-1
heater, cab	1-23	AUXILIARY STEERING Buzzer	
mirror, cab inside	1-23	description and use	2-7
mirrors, outside	1-22	preventive maintenance	2-37
outside mirrors	1-22	principles of operation	1-13
switch panel, cab console	1-23	AUXILIARY STEERING Indicator	
turn signals	1-26	description and use	2-7
windshield washer	1-22	preventive maintenance	2-37
windshield wiper	1-23	principles of operation	1-13
windshield wiper motor . .	1-23	Auxiliary Steering Motor	
Actuator, Parking Brake		principles of operation	1-19
principles of operation	1-18	Auxiliary Steering Pump	
Additional Authorization List . . .	C-1	principles of operation	1-19
Adjustments		Auxiliary Steering System	
bucket height control	2-45	principles of operation	1-19
return-to-dig control	2-46	preventive maintenance	2-40
seat, operator's	2-18	also see AUXILIARY STEERING Buzzer	
Air Cleaner		also see AUXILIARY STEERING Indica-	
operation, unusual weather		tor	
in dusty areas	2-68	also see Auxiliary Steering Motor'	
in extreme heat	2-67	also see Auxiliary Steering Pump	
in sandy areas	2-68	Axles	
principles of operation	1-9	capacity	1-7
servicing	3-40	description	1-6
Air Cleaner Restriction Indicator		location	1-6
see Restriction Indicator, Air			
Cleaner			

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
B		B (Cont)	
Back-up Alarm		Brake System (cont)	
preventive maintenance	2-38	principles of operation (cont)	
principles of operation	1-25	parking brake valve	1-18
Basic Issue Items	B-2	service brakes	1-18
Batteries		servcing, air reservoir	3-43
preventive maintenance	2-43	troubleshooting	3-29
principles of operation	1-15	Bucket Assembly, Loader	
troubleshooting	3-23	bucket capacity	1-8
Battery Cables		bucket width	1-8
Inspection	3-37	Inspection	3-38
preventive maintenance	2-33	preventive maintenance	2-34
principles of operation	1-15	clamshell teeth assemblies	2-35
Black Out Driving Lamp		cutting edge assemblies	2-35
preventive maintenance	2-36	principles of operation	1-26
principles of operation	1-12	Bucket Clamshell Cylinder Assemblies	
Black Out Lights Wiring Harness		principles of operation	1-24
Inspection	3-38	BUCKET Control Lever	
preventive maintenance	2-33	description and use	2-19
principles of operation	1-16	preventive maintenance	2-39
Black Out Stop Light-Tail Light		principles of operation	1-24
preventive maintenance	2-36	Bucket Cutting Edge Assemblies	
principles of operation	1-12	inspection	3-39
BRAKE ENGAGED Warning Indicator		preventive maintenance	2-35
description and use	2-7	Bucket Height Control	
preventive maintenance	2-36	adjustment	2-45
principles of operation	1-13	description and use	2-20
Brake Treadle Valve		principles of operation	1-24
description and use	2-13	troubleshooting	3-33
principles of operation	1-18	Bucket Level Indicator	
Brake System		description and use	2-20
cold weather, operation in	2-66	Bucket Lift Arm Assemblies	
description	1-5	operation in dusty areas	2-68
description and use	2-6	operation in sandy areas	2-68
air reservoir drain valve	2-25	principles of operation	1-26
brake treadle valve	2-13	troubleshooting	3-32
parking brake valve	2-6	Bucket Pivot Assemblies	
location	1-5	operation in dusty areas	2-68
operation, principles of		operation in sandy areas	2-68
see principles of operation		preventive maintenance	2-29
preventive maintenance		principles of operation	1-26
air reservoir	2-32	troubleshooting	3-32
parking brake valve	2-38	Bucket Tilt Cylinder Assemblies	
service brakes	2-38	principles of operation	1-24
principles of operation	1-18		
actuator, parking brake	1-18		
air reservoir	1-18		
brake treadle valve	1-18		
parking brake	1-18		

C

Cab

description 1-6

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
C (Cont)		C (Cont)	
Cab (cont)		Capabilities, Equipment	1-4
description and use		Capacities, Equipment	1-7
cab latch	2-17	Center Drive Shaft	
circuit breakers, 3 amp . . .	2-11	preventive maintenance	2-44
circuit breaker, 6 amp . . .	2-11	principles of operation	1-17
defroster switch	2-10	Characteristics, Equipment	1-4
door latches	2-17	Chassis Spindle Assemblies	
front wiper switch	2-10	principles of operation	1-19
heat control	2-10	Checks and Services, Preventive Main-	
heater fan switch	2-10	tenance	
location	1-6	see Preventive Maintenance Checks	
operation, principles of		and Services	
see principles of operation		Circuit Breaker, 6 Amp	
principles of operation	1-21	description and use	2-11
door assemblies	1-21	Circuit Breakers, 3 Amp	
side windows	1-21	description and use	2-11
slinging eyes	1-21	Circuit Breakers, 5 Amp	
windshields	1-21	description and use	2-2
Cab Console Switch Panel		principles of operation	1-13
description and use	2-10	CLAM Control Lever	
principles of operation	1-23	description and use	2-19
Cab Console Wiring Harness		preventive maintenance	2-39
Inspection	3-38	principles of operation	1-24
preventive maintenance	2-33	Clamshell Cylinder Assemblies, Bucket	
principles of operation	1-16	principles of operation	1-24
Cab Dome Light		Clamshell Teeth Assemblies, Bucket	
description and use	2-16	inspection	3-40
principles of operation	1-23	preventive maintenance	2-35
Cab Door Assemblies		CLUTCH PRESS Warning Indicator	
description and use, latch . . .	2-17	description and use	2-7
Cab Heater		preventive maintenance	2-36
principles of operation	1-23	principles of operation	1-13
Cab Inside Mirror		COLD START Switch	
principles of operation	1-23	description and use	2-3
Cab Lower Wiring Harness		principles of operation	1-9
inspection	3-38	Cold Weather, Operation in Ex-	
preventive maintenance	2-33	treme	2-66
principles of operation	1-16	Components of End Item	B-2
Cab Upper Wiring Harness		Control Levers	
Inspection	3-38	see BUCKET Control Lever	
preventive maintenance	2-33	see CLAM Control Lever	
principles of operation	1-16	see LIFT ARM Control Lever	
Cables, Battery		see Transmission Control Lever	
Inspection	3-37	Controls and Indicators, Description	
preventive maintenance	2-33	and Use of Operator's	
principles of operation	1-15	see Description and Use of Opera-	
		tor's Controls and Indicators	

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
C (Cont)		D (Cont)	
CONV TEMP Gage		Defroster Assembly	
description and use	2-8	principles of operation	1-23
preventive maintenance	2-37	Defroster Switch	
principles of operation	1-14	description and use	2-10
Cooling System		Description and Use of Operator's Con-	
capacity	1-7	trols and Indicators	2-1
cold weather protection	1-7	accelerator pedal	2-13
description	1-4	air horn valve	2-13
Inspection	3-36	air reservoir drain valve	2-25
location	1-4	brake treadle valve	2-13
operation		cab console switch panel	2-10
in dusty areas	2-68	circuit breakers	2-11
in extreme cold	2-66	defroster switch	2-10
in extreme heat	2-67	front wiper switch	2-10
in sandy areas	2-68	heat control	2-10
operation, principles of		heater fan switch	2-10
see principles of operation		control levers, loader	2-19
preventive maintenance	2-31	BUCKET control lever	2-19
principles of operation	1-10	CLAM control lever	2-19
radiator	1-10	LIFT ARM control lever	2-19
WATER TEMP gage	1-10	controls, loader	2-20
radiator		bucket height control	2-20
preventive maintenance	2-31	bucket level indicator	2-20
principles of operation	1-10	return-to-dig control	2-20
troubleshooting	3-20	selector gage	2-21
WATER TEMP gage		dome light switch, cab	2-16
description and use	2-8	engine oil level dipstick and	
principles of operation	1-10	fill	2-23
Cutting Edge Assemblies, Bucket		fans, defogger	2-15
Inspection	3-39	hazard control	2-14
preventive maintenance	2-35	hourmeter	2-22
Cylinder Assemblies		hydraulic reservoir fill	2-24
see Bucket Clamshell Cylinder As-		latches, cab door	2-17
semblies		left instrument panel	2-7
see Bucket Tilt Cylinder Assemblies		AIR PRESS gage	2-8
see Lift Arm Cylinder Assemblies		AUXILIARY STEERING buzzer and	
see Steering Cylinder Assemblies		indicator	2-7
D		BRAKE ENGAGED warning indica-	
Decals and Identification Plates	2-62	tor	2-7
Declutch Treadle Valve		CLUTCH PRESS warning indica-	
description and use	2-12	tor	2-7
principles of operation	1-17	CONVTEMP gage	2-8
Defogger Fans		FUEL LEVEL gage	2-8
description and use	2-15	OIL PRESS warning indica-	
principles of operation	1-23	tor	2-7
		Voltmeter gage	2-8
		WATER TEMP gage	2-8
		windshield washer control	2-9

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
D (Cont)		D (Cont)	
Description and Use of Operator's Controls and Indicators (cont)		Drawbar Pin	
restriction indicator	2-22	principles of operation	1-20
right Instrument panel	2-2	Drive Belts	
air pressure warning alarm	2-6	preventive maintenance	2-42
circuit breakers, 5 amp	2-2	Drive Shafts	
COLD START switch	2-3	description	1-6
DIMMER COMPT LIGHTS control	2-6	inspection	3-38
FLOOD LIGHTS switch	2-4	location	1-6
fuel shut off control	2-6	operation, principles of	
HYDRAULIC FILTER warning indicator	2-4	see principles of operation	
ignition key switch	2-3	preventive maintenance	2-44
parking brake valve	2-6	principles of operation	1-16
vehicle lights switch	2-5	front drive shaft	1-17
seat, operator-s	2-18	center drive shaft	1-17
fore and aft adjustment lever	2-18	rear drive shaft	1-17
height adjustment	2-18	troubleshooting	3-28
sight gage	2-24	Driving Lamps	
slave receptacle	2-22	preventive maintenance	2-36
steering wheel	2-13	principles of operation	1-12
tachometer	2-22	Dumping the Bucket	2-56
transmission controls	2-12	Dusty Areas, Operation in	2-68
declutch treadle valve	2-12		
transmission control lever	2-12	E	
transmission oil level dipstick and fill	2-23	Earthmoving Components	
turn signal lever	2-14	description	1-6
Description, Major Components	1-4	description and use, selector	
Differences Between Models	1-6	gage	2-21
DIMMER COMPT LIGHTS Control		inspection	3-38
description and use	2-6	clamshell teeth assemblies	3-40
principles of operation	1-13	cutting edge assemblies	3-39
Dipsticks		location	1-6
see Engine Oil Level Dipstick and Fill		operation, principles of	
see Transmission Oil Level Dipstick and Fill		see principles of operation	
Dome Light, Cab		preventive maintenance	
description and use	2-16	bucket assembly, loader	2-34
principles of operation	1-23	bucket pivot assemblies	2-29
Door Assemblies, Cab		clamshell teeth assemblies	2-35
description and use, latch	2-17	cutting edges	2-35
Doors		principles of operation	1-26
see Door Assemblies, Cab		bucket assembly, loader	1-26
see Front Access Door		bucket lift arm assemblies	1-26
		bucket pivot assemblies	1-26
		Electrical System	
		description	1-5
		description and use	
		AIR PRESS gage	2-8
		air pressure warning alarm	2-6
		AUXILIARY STEERING buzzer	2-7

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
E (Cont)		E (Cont)	
Electrical System (cont)		Electrical System (cont)	
description and use (cont)		principles of operation (cont)	
AUXILIARY STEERING indica-		black out stop light-tail	
tor	2-7	light	1-12
BRAKE ENGAGED warning indica-		BRAKE ENGAGED indicator . .	1-13
tor	2-7	cab console wiring	
circuit breakers, 5 amp . .	2-2	harness	1-16
CLUTCH PRESS warning indica-		cab lower wiring harness .	1-16
tor	2-7	cab upper wiring harness .	1-16
CONV TEMP gage	2-8	circuit breakers, 5 amp . .	1-13
DIMMER COMPT LIGHTS con-		CLUTCH PRESS indicator . . .	1-13
trol	2-6	CONV TEMP gage	1-14
FLOOD LIGHTS switch	2-4	DIMMER COMPT LIGHTS con-	
FUEL LEVEL gage	2-8	trol	1-13
hourmeter	2-22	driving lamps	1-12
HYDRAULIC FILTER warning indi-		flood lamps, front	1-12
cator	2-4	flood lamps, rear	1-12
ignition key switch	2-3	FLOOD LIGHTS switch	1-12
OIL PRESS warning indica-		front wiring harness	1-16
tor	2-7	FUEL LEVEL gage	1-14
slave receptacle	2-22	gages	1-14
tachometer	2-22	hourmeter	1-14
vehicle lights switch	2-5	HYDRAULIC FILTER indicator	1-13
voltmeter gage	2-8	ignition key switch	1-13
WATER TEMP gage	2-8	lights, vehicle	1-11
Inspect Ion	3-37	OIL PRESS indicator	1-13
location	1-5	rear wiring harness	1-16
operation, principles of		slave receptacle	1-14
see principles of operation		stop and tail lights	1-12
preventive maintenance		tachometer	1-14
batteries	2-42	vehicle lights switch	1-11
battery cables	2-33	voltmeter gage	1-14
gages	2-37	warning indicators	1-13
hourmeter	2-38	WATER TEMP gage	1-14
lights, vehicle	2-36	wiring harnesses	1-16
tachometer	2-38	End Item, Components of	B-2
warning indicators	2-36	Engine	
wiring harnesses	2-33	crankcase capacity	1-7
principles of operation	1-11	description	1-4
AIR PRESS gage	1-14	location	1-4
air pressure warning alarm	1-13	oil level dipstick and fill . .	2-23
AUXILIARY STEERING buzzer	1-13	description and use	2-23
AUXILIARY STEERING indica-		preventive maintenance . . .	2-30
tor	1-13	operation in extreme cold . . .	2-66
batteries	1-15	starting	2-47
battery cables	1-15	troubleshooting	3-4
black out driving lamp . . .	1-12	Engine Oil Level Dipstick and Fill	
black out lights wiring		description and use	2-23
harness	1-16		

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
E (Cont)		E (Cont)	
Engine Oil Level Dipstick and Fill (cont)		Equipment (cent)	
preventive maintenance	2-30	preventive maintenance checks and services	2-26
Engine Side Panels		principles of operation	1-9
installation	3-47	protection when not in use	
principles of operation	1-20	in extreme cold	2-67
removal	3-47	in extreme heat	2-67
Engine Stop		in dusty areas	2-68
description and use	2-6	in humid conditions	2-68
principles of operation	1-10	in rainy conditions	2-68
Equipment		in sandy areas	2-68
air transport	2-62	purpose	1-2
capabilities	1-4	removal	3-45
capacities	1-7	servicing	3-40
characteristics	1-4	speeds, performance	1-8
controls and indicators, descrip- tion and use of operator's	2-1	starting	2-47
data	1-6	stopping	2-51
dimensions	1-6	towing	2-59
features	1-4	transport	2-57
improvement recommendations, re- porting	1-2	troubleshooting	
initial checks	2-45	symptom index	3-3
inspection	3-35	table	3-4
installation	3-45	weight	1-7
lubrication	3-1	Equipment Improvement Recommendations, Reporting	1-2
major components		Excavating	2-54
location	1-4	Exhaust System	
description	1-4	description	1-4
manufacturer	1-6	location	1-4
model	1-6	troubleshooting	3-23
name	1-1	Expendable/Durable Supplies and Materials List	D-2
operating procedures	2-47	Extinguisher, Fire	2-35
operating procedures, loader	2-54	Extreme Cold, Operation in	2-66
operation in unusual weather		Extreme Heat, Operation in	2-67
in dusty areas	2-68	Eyes, Slings	
in extreme cold	2-66	principles of operation	1-21
in extreme heat	2-67		
in humid conditions	2-68	F	
in rainy conditions	2-68	Fans, Defogger	
in sandy areas	2-68	description and use	2-15
in snow	2-68	principles of operation	1-23
operation, principles of		Features, Equipment	1-4
see principles of operation		Fire Extinguisher	2-35
orientation	1-2	Flasher	
performance speeds	1-8	see Hazard Control	
preparation for movement	2-57		

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
F (Cont)		F (Cont)	
Flood Lamps		Fuel Injector Lines (cont)	
preventive maintenance	2-36	principles of operation	1-10
principles of operation	1-12	FUEL LEVEL Gage	
FLOOD LIGHTS Switch		description and use	2-8
description and use	2-4	principles of operation	1-10
principles of operation	1-12	Fuel Shut Off Control	
Fording	2-69	description and use	2-6
Forms, and Records, Maintenance .	1-2	principles of operation	1-10
Frame		Fuel System	
description	1-6	capacity	1-7
installation		cold weather, operation in . . .	2-66
engine side panels	3-47	description	1-4
transport/service link . . .	3-45	description and use	
location	1-6	accelerator pedal	2-13
operation, principles of		COLD START switch	2-3
see principles of operation		FUEL LEVEL gage	2-8
preventive maintenance		fuel shut off control	2-6
trunnion pivots, rear axle	2-29	restriction indicator	2-22
principles of operation	1-20	fuel tank capacity	1-7
engine side panels	1-20	Inspection	3-35
front access door	1-20	location	1-4
transport/service link . . .	1-20	operation, principles of	
trunnion assembly	1-20	see principles of operation	
removal		operation, air cleaner	
engine side panels	3-47	in dusty areas	2-68
transport/service link . . .	3-45	in extreme heat	2-67
transport/service link		in sandy areas	2-68
engaging or locking	3-45	preventive maintenance	
releasing	3-46	accelerator pedal	2-38
Front Access Door		fuel injector lines	2-43
principles of operation	1-20	restriction indicator	2-39
Front Drive Shaft		principles of operation	1-9
preventive maintenance	2-44	accelerator pedal	1-10
principles of operation	1-17	air cleaner	1-9
Front Flood Lamps		air precleaned	1-9
preventive maintenance	2-36	COLD START switch	1-9
principles of operation	1-12	engine stop	1-10
Front Wiper Switch		fuel filler	1-9
description and use	2-10	fuel injector lines	1-10
Front Wiring Harness		FUEL LEVEL gage	1-10
inspection	3-38	fuel shut off control	1-10
preventive maintenance	2-33	fuel tank	1-9
principles of operation	1-16	restriction indicator	1-9
Fuel Filler		servicing	
principles of operation	1-9	air cleaner	3-40
Fuel Injector Lines		fuel tank	3-43
inspection	3-35	troubleshooting	3-19
preventive maintenance	2-42		

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
F (Cont)		H (Cont)	
Fuel Tank		Hydraulic System (cont)	
inspection	3-36	description and use (cont)	
principles of operation.	1-9	bucket height control	2-20
servicing	3-43	bucket level indicator	2-20
G		CLAM control lever	2-19
Gages		fill	2-24
see AIR PRESS gage		LIFT ARM control lever	2-19
see CONV TEMP gage		return-to-dig control	2-20
see FUEL LEVEL gage		sight gage	2-24
see Voltmeter Gage		location	1-6
see WATER TEMP gage		operation, principles of	
H		see principles of operation	
Hand Receipt Manuals	1-2	preventive maintenance	
Hazard Control		control levers, loader	2-39
description and use	2-14	hydraulic reservoir	2-31
Heat Control		principles of operation	1-23
description and use	2-10	bucket clamshell cylinder as-	
Heat, Operation in Extreme	2-67	semblies	1-24
Heater Fan Switch		BUCKET control lever	1-24
description and use	2-10	bucket height control	1-24
Heater, Cab		bucket tilt cylinder assem-	
principles of operation	1-23	blies	1-24
High Altitudes, Operation at	2-68	CLAM control lever	1-24
Hourmeter		control levers	1-24
description and use	2-22	controls	1-24
preventive maintenance	2-38	cylinder assemblies	1-24
principles of operation	1-14	hydraulic reservoir	1-25
How To Use This Technical Manual iii		LIFT ARM control lever	1-24
Humid Conditions, Operation in	2-67	lift arm cylinder assem-	
Hydraulic Control Levers	2-19	blies	1-24
HYDRAULIC FILTER Warning Indicator		return-to-dig control	1-24
description and use	2-4	sight gage	1-25
preventive maintenance	2-37	I	
principles of operation	1-13	Identification Plates and Decals	2-62
Hydraulic Reservoir		Ignition Key Switch	
capacity	1-7	description and use	2-3
fill description and use	2-24	principles of operation	1-13
preventive maintenance	2-31	Initial Checks	2-45
principles of operation	1-25	Inside Mirror, Cab	
Hydraulic System		principles of operation	1-23
capacity, hydraulic reservoir	1-7	Inspection	
description	1-6	battery cables	3-37
description and use		bucket cutting edge assemblies	3-39
BUCKET control lever	2-19	clamshell teeth assemblies	3-40
		drive shafts	3-38

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
I (Cont)		L (Cont)	
Inspection (cent)		Lights, Vehicle (cont)	
fuel injector lines	3-35	principles of operation (cont)	
fuel tank	3-36	FLOOD LIGHTS switch	1-12
loader bucket assembly	3-38	front flood lamps	1-12
radiator	3-36	rear flood lamps	1-12
wiring harnesses	3-38	stop and tail lamps	1-12
Installation		tail and stop lamps	1-12
cab	2-68	vehicle lights switch	1-11
engine side panels	3-47	List Of Abbreviations	1-3
transport/service link	3-45	Load Classification, Military	1-8
Instrument Panels		Loader Bucket Assembly	
see Left Instrument Panel		see Bucket Assembly, Loader	
see Right Instrument Panel		Loader Controls	2-19
L		Loader Operation	
Left Instrument Panel		dumping the bucket	2-56
see AIR PRESS Gage		excavating	2-54
see AUXILIARY STEERING Buzzer		loading loose material	2-55
see AUXILIARY STEERING Indicator		transporting a load	2-56
see BRAKE ENGAGED Warning Indicator		truck loading	2-57
see CLUTCH PRESS Warning Indicator		Loader Orientation	1-2
see CONV TEMP Gage		Loading Loose Material	2-55
see FUEL LEVEL Gage		Location, Major Components	1-4
see OIL PRESS Warning Indicator		Lubrication	
see Voltmeter Gage		in dusty areas	2-68
see WATER TEMP Gage		in extreme cold	2-66
see Windshield Washer		in extreme heat	2-67
Level Indicator, Bucket		Information	3-1
description and use	2-20	in sandy areas	2-68
Lift Arm Assemblies, Bucket		Instruct Ions	3-1
see Bucket Lift Arm Assemblies		requirements	3-1
LIFT ARM Control Lever		M	
description and use	2-19	Maintenance Checks and Services,	
preventive maintenance	2-39	Preventive	
principles of operation	1-24	see Preventive Maintenance Checks	
Lift Arm Cylinder Assemblies		and Services	
principles of operation	1-24	Maintenance Forms, and Records	1-2
Light, Cab Dome		Manuals, Hand Receipt	1-2
description and use	2-16	Manual, Technical	
principles of operation	1-23	how to use this	iii
Lights, Vehicle		scope	1-1
preventive maintenance	2-36	type	1-1
principles of operation		Materials and Supplies List, Expend-	
black out driving lamp	1-12	able/Durable	D-2
black out stop light-tail		Military Load Classification	1-8
light	1-12	Mirror, Cab Inside	
driving lamps	1-12	principles of operation	1-23

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
M (Cont)		P	
Mirrors, Outside		Parking Brake	
principles of operation	1-22	principles of operation	1-18
Model Number	1-1	troubleshooting	3-29
Models, Differences Between	1-6	Parking Brake Actuator	
Movement, Preparation For	2-57	principles of operation	1-18
N		Parking Brake Control	
Name, Equipment	1-1	see Parking Brake Valve	
O		Parking Brake Valve	
OIL PRESS Warning Indicator		description and use	2-6
description and use	2-7	preventive maintenance	2-38
preventive maintenance	2-36	principles of operation	1-18
principles of operation	1-13	Pivot Assemblies, Bucket	
Operating Instructions on Decals and		see Bucket Pivot Assemblies	
Identification Plates	2-62	Preparation for Air Transport	2-62
Operating Procedures, Equipment	2-47	Preparation For Movement	2-57
Operation, Equipment		Preventive Maintenance Checks and	
fording	2-69	Services	2-26
in unusual weather	2-66	accelerator pedal	2-38
in dusty areas	2-68	air reservoir	2-32
in extreme cold	2-66	auxiliary steering system	2-40
in extreme heat	2-67	back-up alarm	2-38
in humid conditions	2-67	batteries	2-43
in rainy conditions	2-67	battery cables	2-33
in sandy areas	2-68	bucket assembly, loader	2-34
in snow	2-68	bucket pivot assemblies	2-29
under unusual conditions	2-66	clamshell teeth assemblies, buck-	
at high altitudes	2-68	et	2-35
in salt water areas	2-68	control levers, loader	2-39
under usual conditions	2-45	cutting edge assemblies, buck-	
Operation, Loader		et	2-35
see Loader Operation		drive shafts	2-44
Operation, Technical Principles of		engine oil level dipstick and	
see Principles of Operation, Tech-		fill	2-30
nical		fuel injector lines	2-42
Operator's Controls and Indicators,		gages	2-37
Description and Use of		hourmeter	2-38
see Description and Use of Opera-		hydraulic reservoir	2-31
tor's Controls and Indicators		lights, vehicle	2-36
Operator's Seat		parking brake valve	2-38
see Seat, Operator's		radiator	2-31
Orientation, Equipment	1-2	restriction indicator	2-39
Outside Mirrors		seat belt	2-36
principles of operation	1-22	service brakes	2-38
		tachometer	2-38
		tires/wheels	2-32
		transmission control lever	2-38
		transmission oil level dipstick and	
		fill	2-40
		trunnion assembly	2-29

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
P (Cont)		R (Cont)	
Preventive Maintenance Checks and Services (cont)		Rear Wiring Harness (cont)	
warning indicators	2-36	preventive maintenance	2-33
windshield washer reservoir . .	2-44	principles of operation	1-16
wiring harnesses	2-33	Records, and Forms, Maintenance .	1-2
Principles of Operation, Technical	1-9	References	A-1
accessories	1-22	Removal	
brake system	1-18	engine side panels	3-47
cab	1-21	transport/service link	3-45
cooling system	1-10	Reporting Equipment Improvement Recommendations	1-2
drive shafts	1-16	Restriction Indicator, Air Cleaner	
earthmoving components	1-26	description and use	2-22
electrical system	1-11	preventive maintenance	2-39
batteries	1-15	principles of operation	1-9
battery cables	1-15	Return-To-Dig Control	
circuit breakers	1-12	adjustment	2-46
gages	1-14	description and use	2-20
hourmeter	1-14	principles of operation	1-24
lights, vehicle	1-11	troubleshooting	3-33
slave receptacle	1-14	Right Instrument Panel	
switches	1-12	see Air Pressure Warning Alarm	
tachometer	1-14	see Circuit Breakers, 5 Amp	
warning indicators	1-13	see COLD START Switch	
wiring harnesses	1-16	see DIMMER COMPT LIGHTS Control	
fuel system	1-9	see FLOOD LIGHTS Switch	
frame	1-20	see Fuel Shut Off Control	
hydraulic system	1-23	see HYDRAULIC FILTER Indicator	
signaling devices	1-25	see Ignition Key Switch	
Steering system	1-19	see Parking Brake Valve	
towing attachments	1-20	see Vehicle Lights Switch	
transmission controls	1-16		
R		S	
Radiator		Salt Water Areas, Operation in . .	2-68
capacity	1-7	Sandy Areas, Operation in	2-68
Inspection	3-36	Scope of Manual	1-1
preventive maintenance	2-31	Seat, Operator's	
principles of operation	1-10	description and use	
Rainy Conditions, Operation in . .	2-67	fore and aft adjustment lever	2-18
Rear Drive Shaft		height adjustment	2-18
preventive maintenance	2-44	preventive maintenance	
principles of operation	1-17	seat belt	2-36
Rear Flood Lamps		Selector Gage	
preventive maintenance	2-36	description and use	2-21
principles of operation	1-12	Service Brakes	
Rear Wiring Harness		preventive maintenance	2-38
Inspection	3-38		

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
S (Cont)		S (Cont)	
Service Brakes (cont)		Steering System (cont)	
principles of operation	1-18	preventive maintenance	
troubleshooting	3-30	auxiliary steering	2-40
Servicing		principles of operation	1-19
air cleaner	3-40	auxiliary steering motor	1-19
air reservoir	3-43	auxiliary steering pump	1-19
fuel tank	3-43	chassis spindle assemblies	1-19
tires/wheels	3-44	steering cylinder assem-	
windshield washer reservoir	3-44	blies	1-19
Side Panels, Engine		steering wheel	1-19
see Engine Side Panels		troubleshooting	3-31
Side Windows		Steering Wheel	
principles of operation	1-21	description and use	2-13
Sight Gage		principles of operation	1-19
description and use	2-24	release button	1-19
principles of operation	1-25	Stop and Tail Lights	
Signaling Devices		preventive maintenance	2-36
description	1-6	principles of operation	1-12
description and use		stopping Loader	2-53
turn signal switch	2-14	Supplies and Materials List, Expend-	
hazard control	2-14	able	D-2
location	1-6	Switch Panel, Cab Console	
operation, principles of		description and use	2-10
see principles of operation		principles of operation	1-23
preventive maintenance		T	
back-up alarm	2-38	Tachometer	
principles of operation	1-25	description and use	2-22
back-up alarm	1-25	preventive maintenance	2-38
turn signals	1-26	principles of operation	1-14
Slave Receptacle		Tail and Stop Lights	
description and use	2-22	preventive maintenance	2-36
principles of operation	1-14	principles of operation	1-12
Slinging Eyes		Technical Manual	
principles of operation	1-21	how to use this	iii
Snow, Operation in	2-68	scope	1-1
Starting Engine	2-47	type	1-1
Starting Loader	2-51	Technical Principles of Operation	
Steering Cylinder Assemblies		see Principles of Operation, Tech-	
principles of operation	1-19	nical	
Steering System		Tilt Cylinder Assemblies, Bucket	
description	1-5	principles of operation	1-24
description and use		Tires/Wheels	
auxiliary steering	2-7	air pressure	1-8
steering wheel	2-13	preventive maintenance	2-32
location	1-5	checking air pressure	3-44
operation, principles of		size	1-8
see principles of operation		troubleshooting	3-30

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
T (Cont)		T (Cont)	
Towing Attachments		Troubleshooting	
description	1-6	air reservoir	3-30
location	1-6	batteries	3-23
principles of operation		brakes	3-29
hitch pin	1-20	bucket height control	3-33
Towing Equipment	2-62	bucket lift arm assemblies	3-32
Transmission		bucket pivot assemblies	3-29
capacity	1-7	cooling system	3-20
description	1-6	drive shafts	3-28
description and use		engine	3-4
declutch treadle valve	2-12	exhaust system	3-23
oil level dipstick and		fuel system	3-19
fill	2-23	parking brake	3-29
transmission control lever	2-12	return-to-dig control	3-33
transmission controls	2-12	service brakes	3-30
location	1-6	steering system	3-31
operation, principles of		symptom index	3-3
see principles of operation		table	3-4
preventive maintenance		tires	3-30
oil level dipstick and		transmission	3-24
fill	2-40	Truck Loading	2-57
transmission control lever	2-38	Trunnion Assembly	
principles of operation	1-16	preventive maintenance	2-29
declutch treadle valve	1-17	principles of operation	1-20
transmission control lever	1-17	Turn Signals	
transmission controls	1-16	description and use	2-14
troubleshooting	3-24	principles of operation	1-26
Transmission Control Lever		Type of Manual	1-1
description and use	2-12		
preventive maintenance	2-38		
principles of operation	1-17		
Transmission Controls			
principles of operation	1-16		
also see Declutch Treadle Valve			
also see Transmission Control Lever			
Transmission Oil Level Dipstick and			
Fill			
description and use	2-23		
preventive maintenance	2-40		
Transport/Service Link			
installation	3-45		
locking or engaging	3-45		
principles of operation	1-20		
releasing	3-46		
removal	3-45		
Transporting a Load	2-56		
Treadle Valve			
see Brake Treadle Valve			
see Declutch Treadle Valve			

ALPHABETICAL INDEX (CONT)

Subject	Page	Subject	Page
W		W (Cont)	
Warning Indicators		Weather, Unusual, Operation in (cont)	
preventive maintenance	2-36	rainy conditions.	2-67
principles of operation	1-13	sandy areas	2-68
also see Air Pressure Warning Alarm		Wheels	
also see AUXILIARY STEERING Buzzer		description	1-6
also see AUXILIARY STEERING Indica-		location	1-6
tor		Windows, Side	
also see BRAKE ENGAGED Warning In-		principles of operation	1-21
dicator		Windshields	
also see CLUTCH PRESS Warning Indi-		principles of operation	1-21
cater		Windshield Washer	
also see HYDRAULIC FILTER Warning		description and use	2-9
Indicator		preventive maintenance	
also see OIL PRESS Warning Indica-		reservoir, windshield	
tor		washer	2-44
Warranty	1-2	principles of operation	1-22
WATER TEMP Gage		Windshield Wiper	
description and use	2-8	principles of operation	1-23
preventive maintenance	2-37	Windshield Wiper Motor	
principles of operation	1-10	principles of operation	1-23
Weather, Unusual, Operation in		Wiring Harnesses	
dusty areas	2-68	Inspection.....	3-38
extreme cold	2-66	preventive maintenance	2-33
extreme heat	2-67	principles of operation	1-16
humid conditions	2-67		

By Order of the Secretary of the Army

Official:

CARL E. VUONO
General, United States Army
Chief of Staff

R.L. DILWORTH
Brigadier General United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-25A, Operator's Maintenance requirements for Scoop Loader, Diesel, 4 X 4, 2-1/2 CY, Model MW24C.

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE 10 October 1987
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 5-3805-262-10						DATE 01 Sep 87	TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
	0017 00-2					Part number supplied for item 2 is incorrect.	
TYPED NAME, GRADE OR TITLE						TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				FROM: <i>(Activity and location) (Include ZIP Code)</i>			DATE	
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 5-3805-262-10				DATE 01 Sep 87		TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 1/2 Cubic Yard, J.I. Case Model MW24C		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
<div style="font-size: 100px; opacity: 0.5; transform: rotate(-10deg); pointer-events: none;">SAMPLE</div>								
PART III - REMARKS <i>(Enter remarks, references, or suggestions for improvement of publications and work forms. Additional sheets may be used where space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE		

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 5-3805-262-10						DATE 01 Sep 87	TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
TYPED NAME, GRADE OR TITLE					TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				FROM: <i>(Activity and location) (Include ZIP Code)</i>			DATE	
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 5-3805-262-10				DATE 01 Sep 87		TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 5-3805-262-10						DATE 01 Sep 87	TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
TYPED NAME, GRADE OR TITLE					TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				FROM: <i>(Activity and location) (Include ZIP Code)</i>			DATE	
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 5-3805-262-10				DATE 01 Sep 87		TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 5-3805-262-10						DATE 01 Sep 87	TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
TYPED NAME, GRADE OR TITLE					TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMPP/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				FROM: <i>(Activity and location) (Include ZIP Code)</i>			DATE	
PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS								
PUBLICATION NUMBER TM 5-3805-262-10				DATE 01 Sep 87		TITLE Operator Manual for Loader, Scoop Type, DED, 4 X 4, Articulated Frame Steer, 2 ½ Cubic Yard, J.I. Case Model MW24C		
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
PART III - REMARKS <i>(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)</i>								
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION			SIGNATURE	

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet


TEMPERATURE

$\frac{5}{9}(^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $\frac{5}{9}(^{\circ}\text{C} + 32) = ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621



This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)