

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D. C., 10 October 1990

Operator's, Organizational, Direct Support and General Support Maintenance Manual

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED, 400,000 BTU/HR FIESTA MODEL FC--400-1 (4520-01-071-7191)

Approved for public release; distribution is unlimited

TM 5-4520-244-14, 11 July 1980, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

2–7 and 2–8 4–61 and 4–62 Insert pages

2-7 and 2-8 4-61 and 4-62

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

THOMAS F. SIKORA Brigadier General, United States Army The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 0981)

CHANGE

NO. 6

C 5

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D. C., 30 April 1990

Operator's, Organizational, Direct Support and General Support Maintenance Manual

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED 400,000 BTU/HR FIESTA MODEL FC-400-1 NSN 4520-01-071-7191

Approved for public release; distribution is unlimited

TM 5-4520-244-14, **11** July 1980, is changed as Follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pagesInsert pagesa and ba and b2-1 through 2-102-1 through 2-10

2. Retain this sheet in front of manual for reference purposes.

By order of the Secretary of the Army:

CARL E. VUONO General, UnitedStates Army Chief of Staff

Official:

WILLIAM J. MEEHAN, II Brigadier General, United States Army The Adjutant General

DI STRI BUTI ON:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, Direct Support and General Support Maintenance Requirements for Heater, Duct Type, Portable, Trailer Mounted MTD, 400,000 BTU/HR (FC-400-I); Gas 250,000 BTU (VBM-250, VBM-250A).

CHANGE

NO. 5

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 20 January 1988

Operator's, Organizational, Direct Support and General Support Maintenance Manual

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED, 400,000 BTU/HR FIESTA MODEL FC-400-1 (4520-01-071-7191)

TM 5-4520-244-14, 11 July 1980, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
i and ii	i and ii
4-61 and 4-62	4-61 and 4-62

2. Retain this sheet in front of manual for reference purposes.

By order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

official:

R. I,. DILWORTH Brigadier General, United States Army The Adjutant General

DI STRI BUTI ON:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, Direct Support and General Support Maintenance requirements for Heater, Duct Type, Portable, Trailer MTD, 400,000 BTU (FC-400-I); Gas 250,000 BTU (VBM-250, VBM-250A).

CHANGE

No. 4)

URGENT

TM 5-4520-244-14

С3

CHANGE)

No. 3

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 4 March 1987

Operator's, Organizational, Direct Support and General Support Maintenance Manual

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED, 400,000 BTU/HR FIESTA MODEL FC-400-1 (4520-01-071-7191)

TM 5-4520-244-14, 11 July 1980, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
a and b	a and b
2-1 and 2-2	2-1 and 2-2

2. Retain this sheet in front of manual for reference purposes.

By order of the Secretary of the Army:

JOHN A.WICKHAM, JR. General, United States Army Chief of Staff

Official:

R.L.DILWORTH

Brigadier General, United States Army The Adjutant General

DI STRI BUTI ON:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, **Direct** Support and General Support Maintenance requirements for Heater, Duct Type, Portable, Trailer MTD, 400,000 BTU (FC-400-I); Gas 250,000 BTU (VBM-250, VBM-250A).

TM 5-4520-244-14

C 2

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 30 December 1986

Operator's, Organizational, Direct Support and General Support Maintenance Manual

> HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED, 400,000 BTU/HR FIESTA MODEL FC-400-1 (4520-01-071-7191)

TM 5-4520-244-14, **11** July 1980, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pagesInsert pagesi and iii and ii1-1 and 1-21-1 and 1-22-3 and 2-42-3 and 2-4A-1/A-2A-1/A-2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

JOHN A.WICKHAM, JR. General, United States Army Chief of Staff

Official:

R.L. DILWORTH Brigadier General, United States Army The Adjudant General

distribution;

To be distributed in accordance with DA Form 12-25A, Operator's, Organizational, Direct Support and General Support Maintenance requirements for Heater, Duct Type, Portable, Trailer Mounted, 400,000 BTU (FC-400-1).

CHANGE No. 2

vo. 2

TM 5-4520-244-14 C1

CHANGE NO. 1 HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 27 June **1983**

OPERATOR' S, ORGANI ZATI ONAL, DI RECT SUPPORT AND GENERAL SUPPORT MAI NTENANCE MANUAL

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED 400,000 BTU/HR, FIESTA MODEL FC-400-1 (4520-01-071-7191)

TM 5-4520-244-14, 11 July 1980, is changed as follows:

1. Remove and insert pages as indicated below:

	Remove pages	Insert pages
Table of Contents	Warni ng	a and b i and ii
Chapter 2	2-1 and 2-2	2-1 and 2-2

2. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand,

3. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

E.C.MEYER General, United States Army Chief of Staff

official:

ROBERT M. JOYCE Major General, United States Army The Adjutant General

DI STRI BUTI ON:

To be distributed in accordance with DA Form 12-25C, Operator Maintenance requirements for Heaters, Space: 400,000 BTU.

WARNING

DO NOT OPERATE HEATER IN EXPLOSIVE VAPOR AREA

WARNING

EXHAUST FUMES

Do not operate heater in enclosed space Adequate ventilation is required to prevent buildup of exhaust fumes which can be toxic in concentrated amounts

WARNING

GASOLINE

Gasoline used in operating this heater is explosive Do not refuel during operation Avoid open flame near gas tank filler neck Keep cap on gas tank except during refueling Make sure a wheeled Class 20-B:C fire extinguisher is in easy reach

WARNING

HIGH TEMPERATURE

Heat exchanger casing may become dangerously hot during operation DO NOT TOUCH: Perform maintenance only after heater has cooled off



SOLVENT

Dry cleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property Avoid repeated and prolonged skin contact Do not use near open flame or excessive heat Flash point of solvent is 100° - 138°F (380 - 59°C)

WARNING

CARBON MONOXIDE

DO NOT use gasoline engine driven heaters to heat personnel areas, such as hospital wards and other living and sleeping quarters. Exposure to fumes usually exceeds eight hours and ventilation is frequently inadequate. Therefore, DEATH OR SERIOUS INJURY COULD RESULT FROM CARBON MONOXIDE SUFFOCATION.

Gasoline heaters are designed for use in warehouses and maintenance shops where personnel exposure is usually limited to eight hours and ventilation is adequate. DO NOT SLEEP IN ANY AREA WHILE HEATER IS IN OPERATION.

WARNING

Heaters were not designed to be towed over highways at high speeds, and to do so is considered unsafe. Movement of short distances should be made by hand. For movements of longer distances, the heater should be loaded into a truck, 2 1/2-5 tons.

TECHNICAL MANUAL

No. 5-4520-244-14

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 11 July 1980

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL

HEATER, DUCT TYPE, PORTABLE, TRAILER MOUNTED 400,000 BTU/HR, FIESTA MODEL FC-400-1(4520-01-071-7191)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms, or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

TABLE OF CONTENTS

CHAPTER 1	INTRODUCTION Page
Section I Section II Section III	Chapter Overview1-1General Information1-1Equipment Description and Data1-3Technical Principles of operation1-6
CHAPTER 2	OPERATING INSTRUCTIONS
Section I Section II Section III Section IV	Chapter Overview
CHAPTER 3	OPERATOR'S MAINTENANCE INSTRUCTIONS
Section I Section II Section III	Chapter Overview 3-1 Lubrication Instructions 3-1 Troubleshooting 3-1 Maintenance Procedures 3-2
CHAPTER 4	ORGANIZATIONAL MAINTENANCE INSTRUCTIONS
Section I Section II Section III Section IV Section V	Chapter Overview 4-1 Repair Parts and Special Tools 4-1 Service Upon Receipt 4-2 Preventive Maintenance Checks and Services 4-8 Troubleshooting 4-8 Maintenance Procedures 4-9

TM 5-4520-244-14

CHAPTER 5	DIRECT SUPPORT MAINTENANCE	Page
Section I Section II Section III Section IV Section V	Chapter Overview	5-1 . 5-1 5-2 . 5-2 5-3 5-3
CHAPTER 6	GENERAL SUPPORT MAINTENANCE	
Section I Section 11 Section III Section IV Section V Section VI	Chapter Overview	6-1 6-1 6-2 6-2 6-2 . 6-2 . 6-2 . 6-3
APPENDIX A		A-1
APPENDIX B		B-1
APPENDIX C		C-1
APPENDIX D		D-1
APPENDIX E		E-1
INDEX		Index-1

Chapter I

INTRODUCTION

Page
Overview
Scope
Maintenance Forms,
Records and Reports

	Page
Equipment Description and Data	1-3
Location and Description c Major Components	of 1-4
Technical Principles of Operation	1-5

1-1 OVERVIEW

Chapter 1 of this TM is intended to give you a general idea of the type of equipment, its" `use and the main characteristics of the heater covered by this manual .

SECTION I

GENERAL INFORMATION

1-2 SCOPE

This TM Chapter applies to Fiesta Model FC-400-1 Portable Duct Type Heater which delivers 400,000 BTU per hour of heated air. Included in this manual are :

- a. Information on operating the heater.
- b. The theory of operation of the heater.
- c. Troubleshooting and servicing information,
 - (1) For the operator
 - (2) For organizational maintenance
 - (3) For direct support maintenance
 - (4) For general support maintenance

The information in this manual is primarily intended for use by Army personnel having the responsibility of operating and maintaining the Model FC-400-1 heater.

1-3 MAINTENANCE FORMS, RECORDS AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pam 738-750, The Army Maintenance Management System.

1-4 REPORTING EQUIPMENT IMPROVEMENTS, RECOMMENDATIONS

If your heater needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, Headquarters, U. S. Army Troop Support Command, ATTN: AMSTR-QX, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. We'll send you a reply.

1-5 HAND RECEIPT

Hand receipts for Components of End Item (COEI), Basis Issue Items (BII), and additional Authorization List (AAL) items are published in a Hand Receipt Manual, TM5-4520-224-14-HR. This manual is published to aid in property accountability and is available through: Commander, U.S. Army Adjutant General Publication Center, ATTN: AGDL-OD, 2800 Eastern Boulevard, Baltimore, MD 21220.

SECTION II EQUIPMENT DESCRIPTION AND DATA

1-6 DESCRIPTION

Model FC-400-1 burns gasoline to generate fresh, uncontaminated heated air. heater is shown in figure 1-1.



Figure 1-1. Model FC 400-1 Heater

Figure 1-4 describes the operation of the fuel system. The gasoline is pumped from a fuel tank, forced through a spray nozzle, ignited, and burned in the combustion chamber of a heat exchanger. A fan blows air through the heat exchanger where it is heated and delivered through ducts to the area to be heated.

1-7 PURPOSE

Model FC-400-1 is used in the following applications.

- a. To preheat aircraft engines and fuselage.
- b. To heat up ground vehicles.
- c. To heat maintenance building, field shelter, and temporary structures.

Also for forced fresh air ventilation without heating.

1-8 CAPABILITIES AND FEATURES

- . Fully-enclosed, self-contained unit
- Trailer mounted ground portable
- . Gasoline fuel gasoline engine driven
- Variable temperature range
- With exhaust properly vented, heater delivers uncontaminated air through the flexible duct

1-9 LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

Refer to figure 1-.? f-or the location and description of the major components of the Model FC-400-1 heater.

1-10 EQUIPMENT DATA

See Table 1-1.

MAJOR COMPONENTS

- 1 CABINET TOP, open for access to prime mover.
- 2 FAN . Provides combustion air and ventilating air.
- 3 PRIME MOVER. Gasoline engine to drive fan, fuel pump and magneto.
- 4 FUEL PUMP. Pumps gasoline from fuel tank to combustor.
- 5 FUEL FILTER. Insures that only clean fuel is fed to combustor.



- 6 SKID . Provides mounting for heater assembly and a means of transporting heater to location of use.
- 7 MAGNETO . Provides high-voltage spark for igniting fuel.
- 8 FUEL TANK. Holds supply of gasoline for combustor flame and for operation of prime mover.
- 9 HEAT EXCHANGER. Fuel burns inside heat exchanger. Fan blows air over exterior of heat exchanger. Heated air is blown out of heat exchanger.
- 10 EXHAUST STACK. Expels burned gasoline fumes to exterior of heater.

Figure 1-2. Location and Description of Major Components

Manufacturer
Model
Heated Air Output: Maximum
Heated Air Temperature Range: Maximum
Air Delivery Rate: Maximum
Fuel
Fuel Tank Capacity
Overall Dimensions: Length
Shipping Cubit
Weight, Empty
Prime Mover (Gasoline Engine)
Engine Speed, factory set

Table 1-1. Equipment Data, Model FC-400-1

SECTION III TECHNICAL PRINCIPLES OF OPERATION

1-11 HEATER OPERATING PRINCIPLES

Basic heater operating principles are given in Figures 1-3 and 1-4.

١.

HEATER OPERATION

- A Gasoline engine (1) is set into operation by means of a starter rope. The engine speed is 3450 to 3750 rpm.
- B The engine is direct-coupled to fan (2). A portion of the fan air is used for the burning fuel, the remainder is heated and forced out as hot air,
- C A belt from the engine drives fuel pump (3) and magneto (4). Fuel pump (3) pumps gasoline from tank (5) into the combustor section of the heat exchanger (6). Engine (1) has its own fuel pump which pulls gasoline from tank (5) for engine operation.
- D In the combustor section of the heat exchanger, fuel is sprayed through a nozzle. Alongside the nozzle is an igniter, which is similar to a spark plug. Magneto (4) delivers high voltage to the igniter to produce an electric arc. The arc keeps the gasoline burning at the nozzle.
- E A combustion plate in the heat exchanger separates the heated air from the air used for burning fuel. Burning fuel fumes and the gasoline engine exhaust are expelled through exhaust stack (7). Clean, heated air blows out of heat exchanger (6). Ducts carry heated air to the location to be heated,



F Controls (8) allow adjustment of the combustion flame for various outlet air temperatures. Gages indicate air-temperature and fuel level in the gasoline tank,

Figure 1-3. Heater Operating Principles

HOW THE HEATER FUEL SYSTEM OPERATES



CHAPTER 2

OPERATING INSTRUCTIONS

WARNING

CARBON MONOXIDE

DO NOT use gasoline engine driven heaters to heat personnel areas, such as hospital wards and other living and sleeping quarters. Exposure to fumes usually exceeds eight hours and ventilation is frequently inadequate. Therefore, DEATH OR SERIOUS INJURY COULD RESULT FROM CARBON MONOXIDIE SUFFOCATION. These heaters may be used to heat warehouses and for maintenance shop applications, if the personnel exposure is limited to not more than eight hours and ventilation is adequate. DO NOT SLEEP IN ANY AREA WHILE HEATER IS IN OPERATION.

WARNING

Heaters were not designed to be towed over highways at high speeds and to do so is considered unsafe. Movement of short distances should be made by hand. For movements of longer distances, the heater should be loaded into a truck, 21/2-5 tons.

•	Overview	Operation Under Usual
•	Operators Controls and	Conditions
	Indicators	Operations Under Unusual
•	Preventive Maintenance	Conditions
	Checks and Services	

2-1. OVERVIEW

This chapter presents the instructions needed by the operator to effectively use the heater.

Section I. CONTROLS AND INDICATORS

2-2. CONTROLS, DESCRIPTION AND USE

(See Figure 2-1 for illustration and description of operator controls and indicators)

- 1. FUEL GAGE, Needle indicates E (Empty) 1/4, 1/2, 3/4 and F (Full).
- 2. FUEL CONTROL VALVE. An off-on valve. When open (ON) fuel goes to tank, when closed (OFF) fuel goes to nozzle.
- 3. TEMPERATURE SELECTOR. Pointer on knob indicates selected temperature in 25-degree steps from low of 150-degrees to high of 280-degrees F.
- 4. TEMPERATURE SELECTOR VALVE. Turn knob clockwise for hotter air, counterclockwise for cooler air.
- 5. TEMPERATURE GAGE. Needle points to actual temperature of discharge air in degrees Fahrenheit.
- 6. DAMPER CONTROL. When facing hot air outlet, turn LEFT to close, RIGHT to open.
- 7. ENGINE STOP. Switch that stops engine by grounding spark plug voltage.
- 8. CHOKE. Control on carburetor allows operator to adjust fuel mix for cold starting.



Figure 2-1. Heater Controls and Indicators.

Section II. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

2-3. PREVENT MAINTENANCE CHECKS AND SERVICES

Before you operate. Always keep in mind the WARNINGS and CAUTIONS. Perform your before (B) PMCS.

b. While you operate. Always keep in mind the WARNINGS and CAUTIONS. Perform your during (D) PMCS.

c. After you operate. Be sure to perform your after (A) PMCS.

d. If your equipment fails to operate. Troubleshoot with proper equipment. Report any deficiencies using the proper forms. See DA Pam 738-750.

e. Perform Operator's Preventive Maintenance Checks and Services in accordance with Table 2-1.

Table 2-1, Operator/Crew Preventive Maintenance Check sand Service

LEGEND

B- D					B-Before D-During		A-After W-Weekly	M-Monthly
Item No.	B	Ir D	terv	val W	M	Item to be Inspected	Procedures Check for and have repaired or adjusted as necessary	For readiness reporting equipment is not ready/ available
1	•	Ð				Ducts	Check for torn areas or faulty connectors	Fabric torn or connectors defective
2	•					Adapter	Bent or Worn	Bent or worn beyond satisfactory use
3					•	Basket	Inspect for distortion or broken welds	Basket damaged beyond use
4					•	Handles	Bent, broken or missing	Replacement not made
5				•		Cabinet TOP	Dented or distorted	Damage interferes with opening and closing
6	•					Access Door	Inspect latch, hinge, metal surface	Door will not open and close properly
7	•					Air Inlet Door	Inspect latch, hinge, metal surface	Door will not open and close properly
8	•					Air Inlet Screen	Inspect for attachment, torn screening	Damage prevents proper heater operation
9	•	•				Gasoline Engine	Inspect for operable condition	Preservative oil must be replaced with engine oil
10	•	•				Fuel Hose and Lines	Inspect for damage or fuel leakage	Obviously defective, or if fuel leaks
11	•	•				Fuel Line Fittings	Inspect for damage or fuel leakage	Obviously defective, or if fuel leaks
12	•	•				Fuel Filter	Inspect for damage or fuel leakage	Obviously defective, or if fuel leaks
13	•	•				Burner Fuel Control Valve	Inspect for damage or fuel leakage	Obviously defective, or if fuel leaks

Table 2-1. Operator/Crew Preventive Maintenance Checks and Service (Cont)

Item No.	B	D	nter A	val W	М	Item to be Inspected	Procedures Check for and have repaired or adjusted as necessary	For readiness reporting equipment is not ready/ available
14	•					Ignition Cable	Insulation damage, severed cable	Cable is damaged or defective
15	•					Magneto	Proper mounting — obvious damage	Damaged or defective
16	•					Drive V-Belt	Torn or frayed. Inspect for proper tension Deflection is 3/4 to 1 -inch midway between pulleys.	Damaged, defective, slipping
17	•	•				Indicators	Inspect fuel and temperature for proper operation	Damaged or defective
18	•					Damper Control	Smooth operation, bent or damaged parts	Damaged or if does not adjust properly
19	•					Exhaust Stack	Bent, corroded or leaky pipes	Pipes are damaged or cannot he installed
20				•		Side Panels	Inspect for dents, corrosion	Condition of panels interferes with proper heater operation
21					•	Information Plates	Inspect for defaced, illegible or loose condition	
22					•	wheels and Drums, Tires and Tubes	Inspect for damage, wear, proper inflation	Condition prevents proper utilization of heater
23				•		Wheel Hubs and Bearings	Inspect for damage Listen for bearing noise	Condition prevents proper proper utilization of heater

Section III. OPERATING UNDER USUAL CONDITIONS

2-4. OPERATING UNDER USUAL CONDITIONS

WARNING

DO NOT use gasoline engine driven heaters to heat personnel areas, such as hospital wards and other living and sleeping quarters. Exposure to fumes usually exceeds eight hours and ventilation is frequently inadequate. Therefore, DEATH OR SERIOUS INJURY COULD RESULT FROM CARBON MONOXIDE SUFFOCATION.

Gasoline heaters are designed for use in warehouses and maintenance shops where personnel exposure is usually limited to eight hours and ventilation is adequate. DO NOT SLEEP IN ANY AREA WHILE HEATER IS IN OPERATION.

- See figure 2-2 for duct attachment
- See figure 2-3 for start up and operating procedures
- . See figure 24 for shutdown procedures

Section IV

OPERATING UNDER UNUSUAL CONDITIONS

2-5. EXTREME COLD

a. Precautions

- (1) Carefully clean ice and snow from filler cap before adding fuel.
- (2) Keep fuel tank full to prevent condensation.
- (3) Use low-temperature lubricant in engine.
- (4) Empty engine and heater fuel filters daily.
- (5) Immediately after use, clean all snow, ice and mud from heater.
- (6) In extreme cold, remove engine and store in a heated location.
- (7) Cover heater when not in use.

b, Cold Weather Starting

- (1) Using a winterization torch, apply heat to engine block, head and flywheel. If after 3-minutes heating engine will not start, continue to preheat.
- (2) Fully open choke, give long steady pull on starter rope, close choke to 1/2 open, pull on starter rope rapidly to start engine.

NOTE

If another working heater is available, use hot air discharge to warm up heater to be started.

2-6. DUSTY OR SANDY CONDITIONS

- a. Precautions
 - (1) When operating in high velocity winds, protect heater components with tarpaulins, being careful not to close off air intake. Keep dust and sand wiped from the heater. Take advantage of natural barriers as much as possible.
 - (2) Protect fuel supply from dust and dirt contamination. Wipe dust and sand from around the fuel filler cap.
 - (3) When not in operation, close and cover the heater as tightly as possible, Clean filter frequently.
 - (4) Wipe excess fuel and oil from metal parts of the heater.
- b. Starting and Operation
 - (1) Start up and ruining See figure 2-3.
 - (2) Shut down See figure 24.

2-7. MOVEMENT TO A NEW WORK SITE

WARNING

Heaters were not designed to be towed over highways at high speeds, and to do so is considered unsafe. Movement of short distances should be made by hand. For movements of longer distances, the heater should be loaded into a truck, 2 1/2-5 tons.

- a. Follow normal shut-down procedures.
- *b.* Prepare heater for movement (See Fig 1–1).
- c. Move heater according to warning notice.
- d. Follow normal start-up and operating instructions at new work site according to Fig 2–3



С

TM 5-4520-244-14



Figure 2-3. How to Start Up and Run Heater



Figure 2-4. How to Shut Down Heater.

Chapter 3

OPERATOR'S MAINTENANCE INSTRUCTIONS

Page		Page
Overview	. Troubleshooting	. 3-1
Lubrication Instructions	Maintenance Procedures, .	. 3-2

3-1 OVERVIEW

This chapter contains instructions for troubleshooting and maintenance that are the responsibility of the heater operator.

SECTION I LUBRICATION INSTRUCTIONS

3-2 LUBRICATION

The operator is not responsible for heater lubrication. See Chapter 4 for Lubrication Instructions.

SECTION II TROUBLESHOOTING

3-3 OPERATOR'S TROUBLESHOOTING PROCEDURES

See table 3-1

SECTION III MAINTENANCE PROCEDURES

3-4 OPERATOR MAINTENANCE PROCEDURES

a. Engine Removal and Installation. See figure 3-1.

Table 3-1. Chart Operator's *Troublteshooting* MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION ENGINE WILL NOT START 1. Step 1. Check on-off switch Position to ON Step 2. Check fuel supply Add fuel If engine still will not start: Step 3. Report condition to organizational maintenance 2. HEATER WILL NOT IGNITE Check position of fuel valve control knob Step 1. Ensure that knob is down Step 2. Check condition of fuel lines Report defective condition to organizational maintenance Step 3. Check drive belt: Is belt broken or missing?" Is belt too loose? Report condition to organizational maintenance Heater still will not ignite Step 4. Report condition to organizational maintenance 3. EXCESSIVE SMOKE IN HEATER EXHAUST Step 1. Refer to NOTE on figure 4-1. No corrective action required Inspect for closed air inlet door or clogged screen Step 2. Open air inlet door, clean screen Check exhaust stack for obstruction Step 3. Remove obstruction

MALFUNCTION TEST OR INSPECTION CORRECTIVE ACTION 4. COMBUSTOR FLAME CUTS OUT ON OVERHEAT Step 1. Inspect for unobstructed air inlet Open inlet door or remove obstruction Step 2. Check for discharge air restriction Straighten air duct for free air flow 5. INCORRECT DISCHARGE AIR TEMPERATURE Step 1. Inspect setting of Temperature Selector Valve Adjust to proper setting Step 2. Condition Continues Report to Organizational Maintenance 6. MAXIMUM HEAT OUTPUT NOT OBTAINABLE Step 1. Report condition to Organizational Maintenance

Table 3-1. Operator's Troubleshooting Chart...Cont



Figure 3-1. Engine Removal and Installation

- b. *Engine Oil Level*. If oil is below full mark on dipstick, report condition to Organizational Maintenance
- c. *Tires and Tubes.* Ensure that tire air pressure is in accordance with Air Pressure stenciled on heater.

3-5 ADMINISTRATIVE STORAGE

Refer to TM750-244-3

4-2 . 4-8 4-11

Chapter 4

ORGANIZATIONAL **MAINTENANCE INSTRUCTIONS**

Page Page
-1 . Preventive Maintenance
Checks and Services. , $4-2$
-1 . Troubleshooting
2 Maintenance Procedures 4-1
[

4-1 OVERVIEW

This chapter contains maintenance and servicing procedures that are the responsibility of Organizational Maintenance. Operator maintenance tasks given in Chapter 3are not repeated in this chapter.

SECTION I REPAIR PARTS AND SPECIAL TOOLS

4-2 REPAIR PARTS

See TM5-4520-244-25P for a listing of spare parts required for maintaining the heater.

4-3 SPECIAL TOOLS

See procedure 4-20 for the special tool required for maintenance of the temperature selector valve.

SECTION II SERVICE UPON RECEIPT

4-4 SERVICE UPON RECEIPT

4-5. Service Upon Receipt Check List

See Table 4-1.

4-6 SPECIAL SERVICES

4-7. Removing Preservative from Fuel Tank

See figure 4-1.

SECTION III PREVENTIVE MAINTENANCE CHECKS AND SERVICES

(PMCS)

4-8 ORGANIZATIONAL PMCS

See Table 4-2.
LOC.	ATION	ITEM	ACTION	REMARKS
(1)	In crate with assembled heater	Contents of crate	Check crate for following contents:	Notify Supply Officer of any missing or damaged parts
			Trailer assembly and wheels Two 12-inch ducts Three 6-inch ducts One duct adapter One duct basket One exhaust stack Engine technical manual This technical manual	
(2)	Heater Package and Contents	Packing Materials	Remove all blocks and packing	Save if heater is to be shipped to different site
		Heater Parts	Check parts received against packing list	Report deficiencies to Supply Officer
			Check all parts for damage	Report damage to Supply Officer
(3)	Assembled Heater	(a) To assemble heater	(a) Assemble components per instruction sheets attached to inside of carton	
		(b) To prepare heater for use	(b) Prepare unit for use as follows:	

Table 4-1. Heater Service-Upon-Receipt Checklist

LOCATION	ITEM	ACTION	REMARKS
		. Drain preser - vative oil from fuel tank and	Ref. paragraph 4-6.
		engine . Fill tank with fuel. Fill engine with engine oil.	
		Place heater into operation	Ref. Figure 2-2.

Table 4-1. Heater Service-Upon-Receipt Checklist ... Cont

TO REMOVE PRESERVATIVE OIL

A. Procure a suitable container to catch oil drained from fuel tank D. Procure a suitable container to catch oil drained from engine



NOTE: When heater is started up, heavy white smoke will be expelled from exhaust stack until remaining preservative oil has been "burned up". This condition will not interfere with heater operation.



Table 4-2 Organizational Preventive Maintenance Checks and Service

Legend

W-Weekly	Q-Quarterly	A-Annually
M-Monthly	S-Semiannually	B-Biennially

Item No.	W	I M	nt Q	er S	val	В	Item to be Inspected	Procedures	Equipment will be reportcd NOT ready,/ available if:	
1		c				-	Ducts	Ducts Inspect for wear or damage . Repair or replace if defective		
2				•			Duct Adapter, Basket , Handles	Inspect for corrosion or damage. Repair or replace as necessary	RNA	
3				•			Cabinet ^{Top} , Access Door, Air Inlet Door, Air Inlet Screen	Inspect for damage, Repair or replace as necessary.	RNA	
4	•						Gasoline Engine	Inspect and Service: Oil supply - replenis or change Fuel Filter Spark Plug and wiring	RNA sh	
5		•					Fuel System	Inspect, Service and Replace: Hose Lines and Fittings Fuel Filter Fuel Pump To test fuel pump, see Figure 4-8	RNA	
6			•				Controls and Instruments	Test and Replace as necessary: Burner Fuel Control Valve Temperature Selector Valve	RNA	
7		•					Ignition System	Test, Repair or Replace as necessary: Magneto Ignition Cable	RNA	

Item No.	Interval WMQSAB	Item to be Inspected	Procedures	Equipment will be reported NOT ready/ available if:
8		Air System	Inspect, Service and Replace as necessary: Drive Coupling Fan Ring Vaneaxial Fan Air Vane	RNA
9		Drive Belt	Adjust to l/2-inch deflection with 10 lb. pressure at midpoint	
10		Combustion System	Inspect, Service and Replace as necessary: Tubing Fittings	RNA
11		Ignition Plug	Adjust for 5/32-inch gap. Replace if irreparable.	
12		Heat Exchanger and Damper Control	Inspect and Replace if irreparable: Damper Control Air Control Exhaust Stack	RNA
13		Side Panels	Inspect and Replace if irreparable Side Panels Information Plates	RNA
14		Trailer Assembly	Inspect and Replace if necessary: . Wheels . Wheel Drums Tires and Tubes . Wheel Hubs and Bearings	RNA

Table 4-2. Organizational Preventive Maintenance Checks and Service... Cont

*RNA - Usable replacement for irreparable part is not available.

SECTION IV TROUBLESHOOTING

4-9 ORGANIZATION MAINTENANCE TROUBLESHOOTING CHART

See Table 4-3. This table does not repeat operator's maintenance procedures given in Table 3-1. Perform tests, inspections and corrective actions in the order listed.

Table 4-3 Organizational Maintenance Troubleshooting Chart MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. ENGINE FAILS TO START

Step 1. Check for correct operating mode (See Table 3-1)

Step 2. If engine still will not start Refer to TM5-2805-256-14 for troubleshooting procedures on Model 1A08-111 engine.

2. ENGINE STARTS, BUT WILL NOT CONTINUE TO RUN

Step 1.	Inspect	for a	dequate	fuel	supply		
		Reple	enish fu	lel s	upply		
Step 2.		Refei	r troubl	e to	Direct	Support	Maintenance

3. HEATER WILL NOT IGNITE

Step 1. Check for faulty magneto (See para. 4-15). Repair or replace magneto (See para. 4-14) Step 2. Inspect igniter plug for dirt or damage Clean thoroughly. Replace if irreparable.

Step 3. Measure igniter plug gap Set gap at 5/32-inch (See para. 4-22) Step 4. Inspect for defective magneto cable Replace if defective

4. BURNER WILL NOT IGNITE (MAGNETO satisfactory)

Step 1. Ensure that fuel pump is delivering fuel to burner Check for gasoline wetness at combustor nozzle Step 2. Inspect filter, lines, nozzle for clogged condition Clean to remove obstruction. Replace filter element Step 3. Test for faulty fuel pump. (See Figure 4-8) Repair or replace fuel pump Step 4. Test for faulty fuel control valve. (See Para. 4-20) or temperature selector valve. Repair or replace defective component

5. CONTAMINATED FUEL - DIRT, ICE, WATER

Step 1. Inspect fuel filter for signs of fuel contamination Drain and flush tank. Refill. Replace fuel filter element. Table 4-3 Organizational Maintenance Troubleshooting Chart. .. Cont

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

6. EXCESSIVE SMOKE IN HEATER EXHAUST

Step 1. Possible cause: incorrect nozzle spray pattern Clean nozzle, or replace if defective Step 2. Engine operating below specified speed Refer to TM5-2805-14 and adjust engine to speed range between 3450-3750 rpm Step 3. Check for correct air/fuel mixture (high altitude) Refer to TM5-2805-14 for high altitude carburetor adjustment Step 4. Check fuel pump discharge pressure (Ref. fig. 4-8)

7. COMBUSTOR FLAME-QUT ON OVERHEAT

Step 1. Inspect for damaged capillary on heat sensor Replace heat sensor
Step 2. Fuel control valve sensor improperly positioned in air stream Adjust sensor to correct position
Step 3. Inspect for icing in burner nozzle bypass Remove nozzle, clean, reinstall

8. INCORRECT OR FLUCTUATING DISCHARGE AIR TEMPERATURE

9. MAXIMUM HEAT OUTPUT NOT OBTAINABLE

Step 1. Check for fuel system leak Tighten all fittings Step 2. Test for defective fuel pump (See fig. 4-8) Repair or replace fuel pump Step 3. Check fuel filter for clogged condition Replace filter element

SECTION V MAINTENANCE PROCEDURES

4-10 SUMMARY AND DETAILED PROCEDURES

SUMMARY PROCEDURES

PARAGRAPH	PROCEDURE	RELATED ILLUSTRATIONS
4-11	Ducts, Adapter, Basket and Support Handles	4-2
4-12	Hood Assembly	4 - 3
4-13	Power Unit	3-1
4-14	Magneto and Ignition Cable	4 - 4
4-15	Magneto Repairs	4-5
4-16	How to Adjust Magneto Points	4 - 6
4-17	Fuel Lines and Fittings and Fuel Pump Test	4 - 7,4 - 8
4-18	Servicing Heater Fuel Filter	4 - 9
4-19	Controls and Instruments	4-10
4-20	Fuel Control Valve and Temperature Selector Valve	4-11,4-12, 4-13
4-21	Drive Belt, Drive Coupling and Fan	4-14
4-22	Combustion System	4-15
4-23	Damper control, Air Control and Exhaust Stack	4-16
4 - 24	Bulkheads, Side Panels and Casing	4-17
4-25	Trailer Assembly	4 - 18
4-26	Lubrication	4-19

4-11

4-11	DUCI	S,	ADAPTER,	BASKET	AND	SUPPOR	T HANDLE
This	task	CO	vers:				
	a. b.	Rem Ins	oval spection			с.	Installation
INIT	IAL S	ETU:	₽				
	Test	Eq Nor	uipment le				References Figure 4-2
	Mate	rial Ser	ls/Parts viceable	replace	ment	parts	Equipment Condition Completely assembled
	Pers	onn 1	el Requir	ed			

LOCAI	TION	ITEM	ACTION	REMARKS					
REMOV	REMOVAL								
1.	Ducts and adapter.	a. Ducts (1), (2)	Lift from holders (11) and basket (7)						
		b. Adapter (3)	Remove from basket (7)						
2.	Duct holders	Holders (11)	Remove nut (8) Washer (9) and Screw (10) from holders (11). Remove holders (11)						
3.	Basket	Basket (7)	Remove nuts (12), washers (5) and J-bolts (6). Remove basket (7)						
4.	Handle assembly	Handle (15)	Remove nuts (12), washers (13) and screws (14). Lift handle (15) from socket in frame (16)						

INSPECTION

- . Unlock duct clamps, extend ducts to full length and examine for holes and damaged adapter ends.
- . Examine all parts for serviceable condition. Replace all broken, damaged or worn out parts with a serviceable like item.



Figure 4-2.Ducts, Adapter, Basket and Support Handles

4-13

4-12 HOOD ASSEMBLY		
This task covers: ^{a.} Removal ^{b.} Repair	c. Installation	
INITIAL SETUP Test <i>Equipment</i> None	<i>References</i> Figure	4-3
<i>Materials/Parts</i> None	<i>Equipment</i> Fully a	condition ssembled
Personnel Requin 1	red	

LOCATION	ITEM	ACTION	REMARKS
REMOVAL			

1.	Hood assembly	Hood assembly (3)	Remove screws (1) and washers (2) . Lift hood from heater
2.	Access door	Access door (9)	Remove screws (7), and washers (8) . Lift access door from hood
3.		Catch (14)	Remove screws (13) and washers (12) . Remove catch from access door.
4.		Air inlet door (17)	Remove screws (15), and washers (16) . Remove inlet door from hood assembly
5.		Catch (22)	Remove screws (21), washers (20), nuts (19). Remove catch from inlet door
б.		Screen (27)	Remove screws (25), and washers (26). Remove screen from hood assembly

REPAIR Replace any of preceding parts that are rusted or damaged such as to be beyond repair by straightening or hammering out minor dents.



- 1. SCREW
 - WASHER
- 3. HOOD ASSEMBLY
- 4. HINGE

2.

- 5. SCREW
- 6. CATCH
- 7. SCREW
- 8. WASHER
- 9. ACCESS DOOR
- 10. HINGE
- 11. NUT
- 12. WASHER
- 13. SCREW

15. SCREW

CATCH

- 16. WASHER 17. AIR IN
- 17. AIR INLET DOOR
- 18. HINGE

14.

- 19. NUT
- 20. WASHER
- 21. SCREW
- 22. CATCH
- 23. SCREW
- 24. LATCH
- 25. SCREW
- 26. WASHER
 - 27. SCREEN
 - Figure 4-3. Hood Assembly

TM 5-4520-244-14

LOCATION	ITEM	ACTION	REMARKS
7.	Catch (14)	Use screws (13), washers (12), nuts (11). Install catch on access door.	
8.	Access door (9)	Use screws (7), and washers (8). Install access door (9) on hood assembly	2
9.	Screen (27)	Use screws (25), and washers (26). Install screen on hood assembly	
10.	Air Inlet door catch (22)	Use screws (21), washers (20), nuts (19). Install catch on air inlet door.	
11.	Air inlet door (17)	Use screws (15), and washers (16). Install air inlet door on hood assembly	
12.	Hood assembly (3)	Use screws (l), and washers (2). Install hood assembly on heater	

4-1	4-13 POWER UNIT (Gasoline Engine)						
This	task covers a. Servici	: .ng					
INIT	INITIAL SETUP Test Equipment None Materials / Parts Lubricant Personnel& Required 1 References L05-2805-256-12 Equipment Condition Fully assembled						
LOCA	TION		ITEM		ACTION	REMARKS	
SERV	ICING						
1.	0il supply	a.	Check oil level on dipstick.	a.	Add lubricant as required	Use lubricant specified in L05-2805-256-12	
		b.	Change oil	b.	Remove drain plug, empty oil, install plug, add new oil.		
2.	Air cleaner	Ser 50 ł	vice every nours	Dis reoi	assemble, clean, l , reassemble	Use procedure in L05-2805-256-12	
3.	Spark plug	Rem rep 100	ove and lace every hours	Dis Ins rep	card. tall equivalent lacement plug.		

4-14	4 MAGNETO AN	D IGNITION CABLE			
This	task covers a. Removal b. Install	: ation			
INIT	IAL SETUP Test Equipn None	ment	Referenc Figur	ces ce 4-4	
	Materials / None	Parts	Equipment Condition Hood assembly removed		
Personnel Rquired			Engir (Figu	ne removed ure 3-1)	
LOCA	TION	ITEM	ACTION	REMARKS	
REMO	OVAL (Figure	4-4)			
1.	V-Belt	V-Belt (9)	Rotate Pulley (5) and disengage V-belt (9)	Or loosen fuel pump. Refer to 4-17	
2.		Ignition cable (1)	Disconnect from magneto (8) and Igniter	Discard if defective	
3.		Magneto (8)	Remove screw (6) washers (7). Remove magneto for mounting		
INS	TALLATION (F	igure 4-4)			
4.	Magneto (8)		use screws (6), washers (7). Install magneto	See 4-15 for magneto servicing	
5.		Ignition cable (1)	Connect to magneto and igniter		
6.		V-belt (9)	Engage over magneto, fan and fuel pump pulleys.		



Figure 4-4. Magneto and Ignition Cable

4-19

4-15 MAGNETO REPAIR

This task covers: a. Disassembly b. Inspection	c. Parts replacement d. Reassembly
INITIAL SETUP	
Test Equipment	References
None	Figure 4-5
Materials/ Parts	Equipment Condition
Magneto Repair Parts	Magneto removed from heater using procedure
Personnel Required 1	given in 4-13

LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY			
1.	Cover (3)	Remove screws (1) and washers (2). Remove cover (3) and gasket (4). Remove cable outlet (5) from cover (3).	
2.	Spring (11)	Remove screw (9). Remove capacitor wire, field coil wire and contact spring.	
3.	Movable contact (11)	Remove clip (10). Remove movable contact assembly (11)	Discard burned contact
4.	Capacitor (8)	Remove screw (6). Remove capacitor (18).	Discard faulty capacitor
5.	Camwick and Holder (15)	Remove screw (12) and washer (13). Remove camwick and holder (15)	

TM 5-4520-244-14

LOCATION			ITEM	ACTION	REMARKS	REMARKS		
6.		Adju cont	stable act (17)	Remove screw (9), washers (7) and (16). Remove adjustable contact assembly (17).	Discard burned contac			
7.		Fiel	.d coil (29)	Loosen set screws (28). Remove coil (29)				
8.	Bearing (19)	Remo	ve screws (12)	Remove plate (18) Remove bearing (19)				
9.	9. Housing a. Packing (21) Ren (25) pac was cli		Remove washer (12), packing (21) washer (22), clip (23).					
		b.	Use arbor press	press out rotor (24)				
		c.	Clip (26)	Remove clip (26). Press out bearing (27)				
		d.	Screw (6)	Remove screw (6). Remove vent hood (31) and screen (32).				
INSP AND REPL	ECTION PARTS ACEMENT							
	Inspect all a serviceab Test capaci	parts le lik tor as	s for serviceabl e item. described in T	e condition. Replace	all faulty ulty.	parts	with	
10.	Vent	Use	screw (6)	Install vent screen (32) and hood (31).				
11.	Housing (25)	a.	Bearing (27)	Install bearing (27), install clip (26).				
		b.	Rotor (24)	Install rotor (24) into bearing (27).				
		C.	Packing	Install clip (23), washer (22), packing (21), washer (20).	Crimp ed to retai and wash	ge of n pacl er	housing king	

4-21



6 SCREW 7 WASHER 8 CAPACITOR

16 WASHER

WASHER

CAMWICK & HOLDER

14

15

Figure 4-5. Magneto Assembly

22

23

WASHER

CLIP

24 ROTOR

29 FIELD COIL

31 VENT HOOD 32 VENTSCREEN

CONTACT

30 ELECTRICAL

1

2

3

4

5

LOCAT	FION	ITEM		ACTION	REMARKS
12.	Bearing (19)	Use	screws (12)	Install bearing (19) in plate (18). Install plate (18)	
13.	Field Coil (29)	Set	screws (28)	Install field coil and secure with setscrews	
14.	Contact (17)	Use was and	e screw (9) , ners (7) (16)	Install contact assembly (17)	
15.	Camwick	Use and (13	screw (12) washer , 14)	Install camwick and holder (15)	
16.	Capacitor	use and	screw (6) washer (7)	Install capacitor (8)	
17.	Contact	Use	clip (10)	Install contact assembly (11)	
18.	Spring	Use	screw (9)	Connect capacitor wire, field coil and spring. Contact assembly (11) and screw (9)	
19.	End Cover	a.	Cable outlet	Install cable outlet in cover	
		b.	Use screws (1) and washers (2)	Attach cover (3) and gasket (4) to housing (25)	

ADJUSTMENT

Adjust points as described in 4-16.

4-16	HOW TO ADJUST	MAGNETO POI	NTS	
This	task covers: a. Adjustment b. Test			
INIT	IAL SETUP Test Equipment None		Re	ferences Figure 4-6
	Materials/Parts None		Eq	uipment Condition Magneto removed from heater
	Personnel Requ 1	ired		using procedure given in 4-14 Magneto cover and gasket removed using procedure given in 4-15.
LOCA	TION	ITEM	ACTION	REMARKS
ADJU	ISTMENT			
1.	Magneto Cover		Remove four screws. Remove magneto cover and gasket.	
2,	Measure gap	V-belt	Rotate until arm (6) is on high point of cam (9). Insert feeler gage	Correct gap is between 0.015 and 0.018
3.	Adjust gap		Loosen screws (3). Move bracket (8) to correct gap spacing	
4.	Secure gap		Tighten screws (3). Recheck gap	
5.	Magneto Cover	Use four screws	Install cover and gasket	
INS	TALLATION			
6.	Magneto	Substitute magneto cable	Disconnect cable at magneto. In its place connect an insulated test cable. Remove	

```
LOCATION
```

ITEM

REMARKS

insulation from last l/4-inch of unconnected end of cable. Tape cable in a position to hold bare end 5/8-inch from frame of heater (ground). Start up engine. If the magneto is operating properly, an arc will jump from wire to frame.



- 1. COIL ADAPTER
- 2. CAPACITOR
- 3. ADJUSTING SCREW
- 4. CAMWICK
- 5. CONTACT POINTS
- 6. RETAINING ARM
- 7. TERMINAL SCREW
- 8. STATIONARY CONTACT ASSEMBLY
- 9. CAM

Figure 4-6. Magnato Point Adjustment

4-17 FUEL LINES AND FITTINGS

This task covers: a. Removal c. Installation b. Inspection INITIAL SETUP Test Equipment References None Figures 4-7 and 4-8 Materials/Parts Equipment Condition Replacement fuel lines and fittings Personnel Required 1

LOCATION		ITEM		ACTION	REMARKS			
REMC	REMOVAL							
1.	Fuel lines and fittings	a,	Fuel line (l), elbows (2)	Remove fuel lines from fittings	Remove fittings only if necessary			
		b.	Fuel filter (21)	Remove filter (21), nipple (12) and elbow (22)	See procedure 4-18 for fuel filter servicing			
		C.	Fuel line (11), and adapter (lo)	Remove fuel line (11) from fittings	Remove fittings only if necessary			
		d.	V-belt	Remove	Loosen fuel pump mount- ing screw (16) and slip belt off pulley (19).			
2.	Fuel pump removal	Fue	el pump (20)	Remove screw (16), and washer (17). Remove fuel pump (20)	See figure 4-8 for fuel pump test			



1	FLEXIBLE HOSE	12	NTPPLE
2	ELBOW	13	FILET. L.TNE
3	TEE	14	COUPLING
4	REDUCER	15	NUT
5	COUPLING	16	SCREW
6	GASKET	17	WASHER
7	FUEL LINE	18	SETSCREW
8	ADAPTER	19	PULLEY
9	ELBOW	20	FUEL PUMP
10	ADAPTER	21	FUEL FILTER
11	FUEL LINE	22	ELBOW

Figure 4-7. Fuel Lines and Fittings

LOCA	ATION		1	TEM	ACTION	REMARKS
3.	Fuel	lines	a.	Fuel line (1) and adapter (8)	Remove fuel line from fittings	Remove fittings only if necessary
			b.	Engine fuel Supply line (13)	Remove fuel line (13) from tee (3)	Remove fittings only if necessary
INS	PECTION	i and pa	RTS	REPLACEMENT		
Ins ser	pect al viceabl	ll parts e like i	for item.	serviceable cond	ition. Replace any :	faulty part with a
4	. Fuel	lines	a.	Engine fuel line (13)	Install in tee (3)	
			b.	Fuel line (7)	Install in fitting (8)	
5.	Fuel	pump	a.	Fuel pump (20)	Install, using screws (16) and washers (17)	Leave fuel pump mountin loose to put on V-belt
			b.	V-belt	Install V-belt. Position fuel pump for correct belt tension, then tighten fuel pump mounting screw (16)	
6.	. Fuel	lines	a.	Fuel line (11)	Install fuel line (11) and adapter (10) in fittings	
			b.	Fuel filter	Install elbow (22) nipple (12) and fuel filter (21)	
			c.	Fuel line (1)	Install elbows (2) and fuel line (1)	

LOCATION	ITEM	ACTION	REMARKS

TEST

With fuel lines, fuel filter, and fuel pump in place, install engine. Test fuel pump as shown in HOW TO TEST THE HEATER FUEL PUMP, Figure 4-8. If fuel pump cannot be adjusted, replace with a serviceable like item.

HOW TO TEST THE HEATER FUEL PUMP

- PRESSURE TEST -



 Install pump nut. Stop heater. Remove gage and tee (B). Reconnect elbow and line (A).



HOW TO TEST THE HEATER FUEL PUMP

- FLOW TEST -

- 1. Remove the engine (see figure 3-1) .
- 2, Disconnect fuel tank end of bypass tube from fuel pump to tank,
- 3. Disconnect the tube which is right by the fuel tank cap,
- 4. Connect a flexible tube or hose to each of the tubes disconnected in steps 2 and 3.
- 5. Obtain two containers, each able to hold at least one gallon, one of them having a mark at the one-gallon line, Place ends of both flexible lines into unmarked container,
- 6. Install the engine, Close heater outlet-air damper by loosening knob and turning completely to the left,
- 7* Set the temperature selector indicator knob to 150-degrees F. Start the heater, Readjust if necessary to get 150-degrees Fon temperature gage,
- When temperature is stable, transfer flexible hoses to the container having a gallon mark, Measure the time for one gallon of fuel flow, Stop the heater,
- 9. If it takes more than five minutes for the pump to deliver one gallon, replace the pump,
- 10. Remove the engine. Reconnect the fuel lines. Install the engine,



TM 5-4520-244-14

4-18 SERVICING HEATER FUEL FILTER							
This	task covers a. Disasse b. Inspect	s: mbly ion	c. Cleaning d. Reassembly				
тыттт	AL SETUP						
	Test Equip None	ment	References Figure 4-9				
	Materials/H Fuel fi	Parts ilter element	Equipment Condition Fuel filter removed from heater as described in				
Personnel Required 1			procedure 4-18 and shown in Figure 4-9				
LOCAT	ION	ITEM	ACTION	REMARKS			
DISA	SSEMBLY						
1.	Fuel filter	a. Filter	Unscrew bowl (6) from top casting (3)				
		b. Filter element	Remove element (5) and gasket (4)				
INSI	PECTION						
2.	Filter element	Inspect for accumulated debris	Clean element using an approved solvent, or replace element	See WARNING inside front cover			
3.	Gasket	Inspect for serviceability	If faulty, replace with a serviceable like item				
REASSEMBLY Element and FILTER gasket		Element and gasket	Install element and gasket. Screw bowl into top casting				



Figure 4-9. Fuel Filter Assembly

4-19 CONTROLS AND INSTRUMENTS

This task co a. Remo b. Tes	vers: val ting	с	. Installation		
INITIAL SETUP Test Equ: Non	ipment e		Re	eferences Figure 4-10	
Materials/Parts None Personnel Required 1		Equipment Condition Hood Assembly Removed (para. 4-12) Engine Removed (Figure 3-1)			
LOCATION	ITEM		ACTION	REMARKS	
REMOVAL					
1.	Control box (10)	a.	Remove screws (8), lockwashe (9), screws (2 nuts (1), lock washers (3), washer (4). Remove control box (10),	rs), -	
		b.	Remove screws (2), nuts (1), lock washers (3), washer (4 Remove door (5 from control b),) px(10),	
2.	Lines and Tubes	a.	Disconnect lines (29). Remove line fr heater.	Remove fitting only if' necessary om	
		b.	Remove elbows (27) and (28). Remove tube assembly from bulkhead		

LOCATION	ITEM		ACTION	REMARKS	
		c.	Disconnect tube assembly (23) from elbow (25)		
3.	Controls (26)	a.	Remove screws (2), lock washers (3), nuts (1), washers (4). Remove mounting plate (17) from bulkhead.		
		b.	Remove set screws (11) from knobs (12), (13) and (14). Remove knobs.		
		c.	Remove screws (2), washers (3), nuts (1) and nut (19). Remove control bracket (22) from plate (17).	See 4-19 for controls	servicing

INSPECTION

WARNING: Cleaning solvent, Federal Specification P-D-680, Type II, is flammable and gives off poisonous vapors. Use only in a well ventilated area. Avoid prolonged breathing of vapors. Keep solvent and vapors away from open flame. DO NOT use in excessive amounts.

Clean all lines and fittings as necessary to examine and to remove foreign matter that would interfere with proper operation of heater. Inspect for serviceable condition. Replace all damaged, defective or worn out parts with a serviceable like item.

INSTALLATION

4.	Controls	a.	Use nut (19)	Attach controls (26) to bracket (22)
		b.	Use screws (2),washers (4),lock washers (3). nuts (1).	Attach plate (17) to bracket (22)
		c.	Use set screws (11)	Attach knobs (12), (13), (14)



Figure 4-10. Controls and Instruments

TM 5-4520-244-14

LOCATION		ITEM	ACTION	REMARKS	
	d.	Use screws (2), washers (4), lock washers (3), nuts (1)	Attach mounting plate (17) to bulkhead		
5.	Lines a. and Tub es	Tube assembly (29)	Install adapter (33) . Install tube assembly (29)		
	b.	Tube assembly (23)	Install grommet (24). Install tube assembly (23) in elbow (25).		
6.	Control Box		Use screws (2), lockwashers (3), washer (4), nut (1). Install door (5) on control box (10)		
			Use screws (8), lockwashers (9), screws (2), nuts (1), lockwashers (3), washers (4). Mount control box (10) on heater.		

4-20 FUEL CONTROL VALVE AND TEMPERATURE SELECTOR VALVE

This task covers: a. Test

b. Disassembly c. Reassembly INITIAL SETUP Test Equipment References 0-200 psi pressure gage Figure 4-11 Materials / Parts Equipment Condition None Hood assembly removed (para 4-12) Personnel Required Engine removed 1 (Figure 3-1) ACTION LOCATION ITEM REMARKS

TEST

Test and adjust fuel controls as described in HOW TO TEST AND ADJUST TEMPERATURE SELECTOR VALVE.

REMOVAL

Disassemble heater as described in procedure 4-19. Then disassemble fuel control valve and temperature selector valve as follows:

DISASSEMBLE (Figure 4-11)

1. Air

Outlet	a.	Sensing elements	Remove sensing elements (11), (12), (13) from clips (14)
	b.	Duct adapter (15)	Remove screws (16), washers (17), nuts (18). Remove duct adapter (15)

с.	Capillary	Remove screws	(19),
	tube	washers (20),	nuts (21).
	shield (22)	Remove shield	(22)

d.	Capillary	Carefully pull capillary	CAUTION
	tubes	tubes and sensing	DO NOT kink or
		elements (11), (12), (13) through casing	damage capillary tubes while
			removing
LOCATION	ITEM	ACTION	REMARKS
----------	--------------------------------------	---	---
2.	Fuel Control. Valve (4)	Remove screw (l), and packing (2). Remove fuel control valve (4) from block (9)	DO NOT attempt to repair fuel control valve (4). If faulty, replace with a service- able like item
3.	Temperature Selector Valve (8)	Remove screw (1), and packing (2). Remove temperature selector valve (8) from block (9)	

INSPECTION

Inspect valves for indications of defect or leakage. Repair temperature selector valve stem leak as described in HOW TO REPAIR TEMPERATURE SELECTOR VALVE PACKING LEAK.

REPLACE

Replace defective valve with a serviceable like item.

INSTALLATION

4,	Temperature Selector Valve (8)	Use :	screw (1)	Install packings (2), (3) and valve (8)	
5.	Fuel Control Valve (4)	Use	screw (1)	Install packings (2), (3) and valve (4)	
б,	Air Outlet	a,	Capillary tubes	Carefully feed sensing elements (11), (12), (13) through casing into location shown in Figure 4-10.	CAUTION: DO NOT kink or damage capillary tubes while installing



Figure 4-11. Control Valve and Temperature Selector Valve

LOCATION		ITEM	ACTION	REMARKS
	b.	Capillary tube shield (22)	Install shield using screws (19), washers (20), nuts (21)	Ensure that capillary tubes are correctly inside shield
	C.	Duct adapter (15)	Install adapter using screws (16), washers (17), nuts (18)	
	d.	Sensing elements	Snap sensing elements (11), (12), (13) into clips (14)	

HOW TO TEST AND ADJUST THE



TEMPERATURE SELECTOR VALVE



- Figure 4-12. Temperature Selector Valve Adjustment -



-Figure 4-13. Temperture Selector Valve Leak Repair

SELECTOR VALVE PACKING LEAK -





- 5. Use tool to install packing nut .
- Put valve stem in place and drive in rollpin.
- Reassemble into heater as described in procedures 4-18 and 4-19.

F	Serviceable repl Personnel Required 1	acement part	ts	Hood assembly removed (procedure 4-12) Engine removed (Figure.3-1)
Ē	Serviceable repl Personnel Required 1	acement part	ts	Hood assembly removed (procedure 4-12) Engine removed (Figure.3-1)
F	Serviceable repl Personnel Required	acement part	ts	Hood assembly removed (procedure 4-12) Engine removed (Figure.3-1
	Serviceable repl	acement part	ts	Hood assembly removed
				- 1
М	Materials / Parts			Equipment Condition
	None			Figure 4-14
Г	Test Equipment			References
INITIA	AL SETUP			
b	b. Inspection		d.	Belt adjustment
This t a	tasl covers: a. Removal		c.	Installation
4-21 1	DRIVE BELI, DRIVE CC	JUPLING AND	FAN	

1.	V-Belt (1)	Remove. Loosen fuel pump mounting screws and slip belt off pulleys	See also instructions given in 4-14
2.	Exhaust Pipe (36)	Remove screws (12), washers (8), (9). Remove exhaust pipe (36), pipe support (11) and bracket (13)	Disassemble exhaust pipe supports only if necessary for repair or replacement
3.	Fan Mounting Ring (17),	Remove screws (16) and washers. Remove fan assembly	
4.	a. Fan Assembly	Remove screws (16) and lockwashers (22). Remove blade (23) from hub (28)	
	b. Fan hub (28)	Remove hub (28) from bearing (29) using a suitable puller	



1	V-BELT	13	ANGLE BRACKET	25	WASHER
2	SCREW	14	SCREW	26	COUPLING HALF
3	WASHER	15	RESILIENT MOUNT	27	FAN BEARING SUPPORT
4	RETAINER	16	SCREW	28	FAN HUB
5	SLEEVE BUSHING	17	FAN MOUNTING RING	29	FAN SHAFT BEARING
6	SLEEVE COUPLING	18	SCREW	30	SCREW
7	SCREW	19	NUT	31	SCREW
8	WASHER	20	WASHER	32	WASHER
9	WASHER	21	AIR STRAIGHTENING VANE	33	FAN GUARD
10	NUT	22	WASHER	34	NUT
11	EXHAUST PIPE SUPPORT	23	FAN BLADE	35	THIME SCREW
12	SCREW	24	SCREW	36	EXHAUST PIPE

Figure 4-14. Drive Belt, Drive Coupling and Fan

LOCATION		ITEM	ACTION	REMARKS
	C.	Fan guards	Remove screws (30), (31), washers (32), nuts (34) and washers (22). Remove fan guards (33) from mounting ring (17)	If necessary, remove screws (35)
	d.	Air straight- ening valve	Remove screws (18), nuts (19) and washers (20). Remove air straight- ening vane (21) from ring (17)	
	e.	Coupling half	Remove screws (2), and washers (3). Remove retainers (4). Remove sleeve (6) and bushing (5) from coupling half (26)	
	f.	Coupling and bearing	Using a suitable puller, remove coupling (26) from bearing (29)	
	g.	Support	Remove screws (14). Remove mount (15) from support (27)	
	h.	Bearing	Remove bearing (29) from support (27)	
INSPECTION				
5. Fan assembly	a.	Fan shaft bearing	Install bearing (29) in support (27). Press coupling half (26) on end of bearing (29)	
	b.	Bearing support (27)	position support (27) on fan mounting ring (17) and secure with screws (24) and washers (25)	

LO	CATION		ITEM	ACTION	REMARKS	
		c.	Air straight- ening vane (21)	Install vane (21) in mounting ring (17) and secure with screws (18), washers (20) and nuts (19).		
		d.	Fan hub and bearing	Press fan hub (28) on bearing (29)		
		e.	Fan blade (23)	Install blade (23) on hub (28) using screws (16) and washers (22)		
		f.	Resilient mount	Install mount (15) on fan bearing support (27) using screws (14)		
		g.	Fan guards (33)	Install guards (33) on fan mounting ring (17) and secure with screws (30) and washers (32)		
6.	Coupling	a.	Coupling sleeve (6)	Install coupling sle (6) in bushing (5). Place bushing (5) in coupling half (26)	eve	
		b.	Retainers (4)	Install retainers (4 in coupling half (26 using screws (2) and washers (22))	
7.	Fan assembly	Far	n ring (17)	Install fan ring (17 and attached parts i casing using screws and washers (3)) n (16)	
8.	Exhaust pipe (36)	Bra	acket (13)	Install bracket (13) using screws (12) and washers (8), (9)	â	
9.	V-belt	V-b	pelt	Install V-belt over pulleys and tighten : pump screws	g fuel f	See also Instructions jiven in 4 -14

	01 3131					
This task cove	ers:					
a. Remov	ve 🛛			с.	Service	or adjust
b. Inspe	ect and	test		d.	Install	
INITIAL SETUP						
Test Equi	pment					References
None						Figure 4-15 except as other- wise indicated
Materials	/Parts					Equipment Condition
Servi	lceable	replacement	parts			Hood assembly removed (para 4-12)
Personel	Requir	ed				Engine removed (Figure 3-1)
1	1					Air system removed (para 4-21
LOCATION		ITEM		ACTI	ION	REMARKS

1.		Ignition Cable		Disconnect. Unscrew cable (1), Figure 4-4) from igniter plug (12, Figure 4-15)
2,		Fuel line	- 25	Disconnect. Unscrew fuel lines (1) and (2) from nozzle holder (7). Remove check valve 17) from fuel line (1)
3.	Combustion plate assembly	a.	Plate (11)	Rotate combustor clamp (6) to the left and unhook from combustor (15)
		b.	Screws (5)	Remove screws (5). Remove clamp (6) from holder (17) and plate (11)
		c.	Nozzle (8)	Unscrew nozzle (8), strainer (9) and seal (10) from nozzle holder (7)
		d.	Igniter Plug (12)	Unscrew plug (12) from plate (11)

-



FUEL LINE 1 2 FUEL LINE 3 GROMMET 4 ELBOW SCREW 5 6 COMBUSTOR CLAMP 7 NOZZLE HOLDER 8 NOZZLE 9 STRAINER 10 SEAL

11 COMBUSTION PLATE
12 IGNITER PLUG
13 NUT
14 WASHER
15 COMBUSTOR ASSEMBLY
16 GASKET
17 CHECK VALVE
18 ADAPTER
19 IGNITION PLUG
20 GROUNDED ELECTRODE
21 , IGNITER CABLE

Figure 4-15. Combustion System

LOCATION	ITEM	ACTION	REMARKS

INSPECTION

Inspect all parts for serviceable condition. Replace any broken, damaged or worn out parts with a serviceable like item. Inspect ignition plug for indication of excessive heat damage.

INSTALL

4.	Combustor	Use nuts (13)	Install gasket (16)
	assembly	and washers (14)	and combustor (15)
		Ignition plug	Screw plug (12) into plate (11)

ADJUST

Using the shank of a 5/32-inch drill bit, measure the spacing (gap) between the ignition plug electrode (19) and the grounded electrode (20). Bend the grounded electrode to the correct gap as indicated by the 5/32-inch drill bit shank.

INSTALL

5.	Nozzle components	a.	Strainer and seal	Screw seal (10), strainer (9) and nozzle (8) into holder (7)
		b.	Clamp (6)	Install nozzle holder (7) into plate (11) and clamp (6) on plate (11) using screws (5)
		С*	Combustor plate assembly	Install plate assembly into combustor (15) by engaging tabs
6.			Check valve (17)	Install check valve (17) into adapter (18) on line (1)
7.			Fuel lines	Screw fuel lines (1) and (2) into nozzle holder (7)
8.			Ignition cable	Screw cable (21) to to igniter plug (12)

4-23 I	DAMPER C	ONTROL, AIR CONTROL AN	ND EXHAUST STACK
This	task cov a. Rem b. Ins	vers: oval c. p ect	Install
INIT	IAL SETUI Test Eq Non	p uipment e	References Figure 4-16
	Materia Ser	ls/Parts viceable replacement pa	Equipment Condition As described in procedure 4-19
	Persone 1	el Required	
LOCA	TION	ITEM	ACTION REMARKS
REMO	DVAL		
1.		a. Stack cap (1)	Remove exhaust stack cap
		b. Exhaust stack	Remove nuts (2) and washers (3). Remove exhaust stack (4) and gasket (5)
2.	Duct adapter assembly (6)	Remove three sensors (Figure 4-11)	Remove duct adapter assembly as described in procedure 4-20
3.		Damper	Remove cotter pin (7). Remove knob (8), washer (9),rubber washer (10) and damper control (11)
4.		Air control baffles	Remove nuts (12) and washers (13). Remove four air control baffles (14)
5.		Air control	Remove screws (15), washers (16), nuts (17). Remove air control (18)

DOSILIOU



1	CAP
2	NUT
3	WASHER
4	EXHAUST STACK
5	GASKET
6	DUCT ADAPTER ASSEMBLY
7	COTTER PIN
8	KNOB
9	WASHER
10	RUBBER WASHER
11	DAMPER CONTROL
12	NUT

13 WASHER

- 14 AIR CONTROL BAFFLE
- 15 SCREW
- 16 WASHER
- 17 NUT
- 18 AIR CONTROL
- 19 CASING
- 20 HEAT EXCHANGER
- 21 GASKET
- 22 DRAIN TUBE
- 23 NUT
- 24 WASHER
- 25 BULB SUPPORT

Figure 4-16. Damper Control, Air Control and Exhaust stack

LOCA	TION	ITEM		ACTION		REMARK	٢S	
INSI	PECTION							
Ţ	Inspect all p worn out part	parts for ts with a	serviceable serviceable	condition. like item.	Replace	any brok	en, damaged	or
INS	TALLATION							
6.		Air control		Use screws washers (16 nuts (17). Install air (18) into c	(15),), control asing (19)		
7.		Air control baffles		Use nuts (1 washers (13 four baffle air control	2) and). Insta s (14) on (18)	11		
8.	Damper assembly			Use cotter Install dam (11), washe Install kno damper cont and secure pin (7)	pin (7). per contr rs (10), b (8) on rol shaft with cott	ol (9). er		
9.	Duct adapter assembly (6) and sensors			Refer to pr and install adapter and	ocedure 4 duct sensors	-20		
10.		Exhaust stack		Use nuts (2 (3). Insta and stack () and was ll gasket 4)	hers (5)	If necessary cap (1) on (4)	y, place stack

4-24 BULKHEAD, SIDE PANELS AND CASING							
This task covers:							
Removal	c.	Installation					
a. Inspection							
INITIAL SETUP							
Test Equipment		References					
None		Figure 4-17					
		5					
Materials/Parts		Equipment Condition					
Serviceable replacement parts		Hood assembly removed					
		(procedure 4-12)					
Personel Required		Engine removed					
		(Figure 3-1)					
2		(Figure 5-1)					

REMOVE			
	Side panels	Remove screws (2) and washers (3). Remove side panel (1) Remove side panel (11)	
	Information plate	Drill out rivet (4). Remove information plate (5)	Remove only if damaged or illegible

ACTION

REMARKS

INSPECTION

LOCATION

ITEM

- . Inspect bulkheads (6) (7), information plates (9) (10) and casing (8) for serviceable condition. Report damage, defect or worn out condition to General Support Maintenance.
- Inspect side panels (1), (11) and plate (5) for serviceable condition. If damaged, defective or worn out, replace with a serviceable like item.

INSTALLATION

Information plate	Use l/2-inch pop rivets. Install plates (5) on panels (1), (11)
Side panels	Use screws (2) and washers (3). Install side panels on heater.



Figure 4-17. Bulkheads, side Panels and Casings

4-57

This task co	vers:		с.	Repair		
a. Remo	ove		d.	Install		
b. Insp	pect		e.	Adjust		
INITIAL SETU	D					
Test Eq	uipment			References		
None	2		Figure 4-18			
Material	s/Parts			Fauinment Conditi		
Comp	pressor a	ir supply		Fully assembled		
Devee	1 Demi	¹				
Personne 1	er kednış	eu				
-						
LOCATION		ITEM	ACTION	I REMARKS		
REMOVE						
Wheel	a. G	rease Cap (1)	Remov	re cap		
assentery	b. C	Cotter pin (2)	Remove pin			
	c. 1	Jut (3)	Remov	e nut		
	d. W	lasher (4)	Remov	e washer		
	e. (Outer bearing (5)	Remov	e bearing		
	f. W	heel	Remov	e nuts (7),		
			washe bolts	rs (8) and (9)		
			Remov	e wheel (14),		
			(15) f	from hub (10).		
			Remov	re tire (19). The hub (10)		
			1/611101	(10).		
. Tire	a. 1	lire	Remov	re cap (16)		
assembly			and tube	core (17) trom		
			Allow	air to escape.		
			P	-		
	พี . ฉ	neel	Remov	e doits (II),		

washers (13) and

Separate outer rim (14) from inner rim (15). Remove tire (19) and tube (18).

nuts (12).



1	GREASE CAP	12	NUT	23	COTTER PIN
2	COTTER PIN	13	WASHER	24	SHACKLE BOLT
3	NUT	14	OUTER RIM	25	NUT
4	WASHER	15	INNER RIM	26	SHACKLE
5	BEARING	16	VALVE CAP	27	NUT
6	OUTER BEARING CONE	17	VALVE CORE	28	WASHER
7	NUT	18	TUBE	29	PLATE
Е	WASHER	19	TIRE	30	U-BOLT
9	HUB BOLT	20	INNER BEARING CONE	31	SPRING
10	HUB ASSEMBLY	21	BEARING	32	AXLE
11	RIM BOLT	22	SEAL	33	LUBRICANT FITTING

Figure 4-18. Trailer Assembly

LOCATION	ITEM	ACTION	REMARKS
Remove ar	nd disassemble other whee	el assembly in the sam	e manner.
INSPECT			
Inspect all worn out par	parts for serviceable control of the serviceable of the serviceable literation of the serviceable literation of the serviceable literation of the serviceable literation of the service of	ondition. Replace all ike item.	defective, broken or
INSTALL			
3. Wheel assembly	a. Tire and tube	Install core (17) in valve stem. Install tube (18) in tire (19), and partly inflate tire	· .
	b. Wheel	Use bolts (9), washers (8) and nuts (7). Position inner rim (15) and outer rim (14) on tire and tube with valve stem thru hol in rim (14). Position hub (10) a rims and secure with bolts (9), washers (8) and nuts (7).	le in th
4. Bearings	Lubricate	Lubricate bearings (5) and (21) in accordance with lubrication chart.	
	Install, in	a. Seal (22)	
	the order given	b. Bearing (21)	Take caution to keep
		c. Cone (20)	clean
		d. Hub and wheel (10) and (19)	
		e. Cone (6)	
		f. Bearing (5)	
		g. Washer (4)	
		h. Nut (3)	

LOCATION	ITEM	ACTION	REMARKS

ADJUST

Rotate wheel while tightening nut (3). When wheel binds, back off nut (3) one-half turn and install cotter pin (2). Attach cap (1).

INSPECT

Inspect spring (31) and axle (32) for serviceable condition. Report condition of any damaged, broken, or worn parts to Direct Support Maintenance.

4-26 LUBRICATION

ENGINE. Lubricate in accordance with LO 5-2805-25612.

NOTE

In addition to fording requirements, normal lubrication interval is semiannual, for unusual operations, lubricate quarterly.

CHASSIS. Lubricate manually as directed in Figure 4-19 or as soon as practical after fording bodies of water or operating in extreme conditions.



Figure 4–19. Chassis Lubrication Points

LUBRICATION ORDER

то 38G2-102-2LС-1

 $\begin{array}{c} L & 0 & 5 = 2 & 8 & 0 & 5 & - 2 & 5 & 6 & - 1 & 2 \\ 27 & JULY & 1978 & (Supersedes LO 5-2805-256-12, 21 & February 1977) \end{array}$

ENGINE, GASOLINE, 1-1/2 HP, MILITARY STANDARD MODELS (MODEL 1A08-1) (MODEL 1A08-2) (MODEL 1A08-3)

Reference: TM 5-2805-256-14 and C9100-IL

Intervals and related task-hour times are based on normal hours of operation. The task-hour time specified is the time ywu need to do all the services prescribed for a particular interval. Change the interval if your lubricants are contaminated or if you \bullet re operating the equipment under adverse operating conditions, including longer-than-usual operating hours. You may extend the interval during periods of low activity, but you must take adequate preservation precautions.

"The time specified is the time required to perform all services at the particular interval.

Clean fittings before lubricating. Clean parts with SOLVE NT

dry cleaning, or with 01L, fuel, diesel Dry before lubrieating. Drain crankcase when HOT Fill and check level, The lowest level of maintenance authorized to lubricate a point is indicated by one of the following (C) Operator/ crew; or (0) Organizational Maintenance

You can help improve this publication. If you find any mistake or if you know of a way to improve the procedures, please let us know. Your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) should be mailed directly to: Commander, U S Army Troop Sup. port & Aviation Materiel Readiness Command, ATTN DRSTS-MTPS, 4300 Goodfellow Blvd St Louis, MO 63120. A reply will be furnished to you





LO5-2805-256-12

Chapter 5 DIRECT SUPPORT MAINTENANCE

Page		Page
Overview	T	roubleshooting, 5-3
Repair Parts and Special Tools 5-1	М	aintenance Procedures 5-3
Preventive Maintenance		
Checks and Service 5-2		

5-1 OVERVIEW

This chapter describes the heater repairs and parts replacement that are the responsibility of Direct Support Maintenance. Operator maintenance tasks given in Chapter 2 and Organizational Maintenance tasks given in Chapter 4 are not repeated in this chapter.

SECTION 1

REPAIR PARTS AND SPECIAL TOOLS

5-2 REPAIR PARTS

See TM-4520-244-24P for a listing of repair parts required for maintaining the heater .

5-3 SPECIAL TOOLS

See TM5-4520-244-24P Section III for the special tools required for maintenance of the heater.

SECTION II SERVICE UPON RECEIPT

5-4 SERVICE UPON RECEIPT CHECK LIST

See Table 4-1

5-5 SPECIAL SERVICES

Not applicable

SECTION III OPERATIONAL CHECKS

5-6 OPERATIONAL CHECKS

Refer to Table 4-2

SECTION IV PREVENTIVE MAINTENANCE CHECKS AND SERVICES

5-7 DIRECT SUPPORT PMCS

See Table 5--1

SECTION V TROUBLESHOOTING

5-8 DIRECT SUPPORT MAINTENANCE TROUBLESHOOTING CHART

See Table 5-2. This table does not repeat the maintenance procedures given in Tables 3-1 and 4-3. Perform tests, inspections and corrective actions in the order listed.

SECTION VI

MAINTENANCE PROCEDURES

5-9 SUMMARY AND DETAILED PROCEDURES

SUMMARY PROCEDURES

PARAGRAPH	PROCEDURE	RELATED ILLUSTRATIONS
5-10	Fuel Pump Repairs	5-1
5-11	Combustion and Nozzle	5-2, 53
512	Heat Exchanger Inspection	4-16
5-13	Bulkhead, Side Panels and Casing	5-4
5-14	Spring and Axles	4-18

Table 5-1. Direct Support Preventive Maintenance Checks and Services

Legend

M-Monthly

A-Annually Q-Quarterly W-Weekly Q-Quarterly S-Semiannually B-Biennelly

		Item		Equipment will be
Item	Interval	to be	Drogedure	available if:
1 1	₩ M Q S A B	Gasoline Engine	Start and operate engine; observe for proper starting and smooth running. Replace if operation is unsatisfactory.	
2		Fuel Pump	Test for pressure and flow as described in Figure 4-8. Replace if operation is un- satisfactory.	RNA
3		Check Valve	observe for unburned fuel in combustor. Replace check valve if defective.	RNA
4	•	Drive Belt	Inspect for service- able condition. Re- place if necessary.	RNA
5	•	Combustion Nozzle	Inspect for service- able condition. Re- place if necessary.	RNA
6		Heat Exchanger	Inspect visible parts for signs of damage or wear. If in unsatis- factory condition, report to General Support Main tenance.	Heat exchanger is damaged or - "burned". rt -
7		Bulk heads and Casings	Inspect for wear, defect or damage. Replace if unsatisfactory.	t RNA

*RNA - Usable replacement for irreparable part is not available.

Item No.	W	In M	te Q	rv s	val	В	Item to be Inspected	Procedure	Equipment will be reported NOT ready/ available if:
8					•		Fuel Tank	Inspect for wear, holes, damage. Replace if un- satisfactory.	RNA
9			+		•		Skid and Skid Cover	Inspect for damage. Repair or replace un- serviceable item.	RNA
10					•		Springs and Axles	Inspect for damage or breakage. Replace if unserviceable.	RNA

Table 5-1. Direct Support Preventive Maintenance Checks and Services ... Cont

Table 5-2. Direct Maintenance Troubleshooting Chart

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. ENGINE FAILS TO START

2. ENGINE STARTS BUT WILL NOT CONTINUE TO RUN

Step 1. Inspect fan, magneto and fuel pump for frozen shaft condition Repair or replace defective component

Step 2. Refer to TM5-2805-256-14 for troubleshooting procedures on the Model 1A08-III engine

5-10 FUEL PUMP REPAIR

This task covers:

a. Disassembly

b. Inspection

INITIAL SETUP Test Equipment None

> Materials/Parts Fuel pump repair parts

Personnel Required

c. Reassembly

References Figure 5-1

Equipment Condition Fuel pump removed from heater as described in procedure 4-17

LOCATION	ITEM	ACTION	REMARKS	
DISASSEMBLE				
1. Fuel pump	Fuel pump cover	Remove screws (20) Remove cover (19), gasket (18) and strainer (16).		
	Rotor	Remove screws (17) Remove rotor assembly (24). Remove key (15), roller and rotor from rotor housing Remove port housir (25) and gasket (2	1g 6).	
	Bearing shaft-and- seal	Remove screws (9) and washers (10).		
	assembly	a. Evenly pry shaft-and-seal assemtbly (8) from pump body (27)		
		b. Coat sleeve wi MIL-L-2104A oi	ith 11	
		c. Insert sleeve in pump body (until sleeve of adjusting scree end plug (1),	(11) (27) contacts ew in	



1	END PLUG
2	WASHER
3	SPRING SEAT
4	SPRING
5	PISTON SLEEVE
6	PIPE PLUG
7	WASHER
8	BEARING SHAFT-AND-SEAL
	ASSEMBLY
9	SCREW
10	WASHER
11	PISTON
12	SLEEVE RETAINER
13	NOZZLE AND PLUG
14	PACKING

DRIVE KEY 15 16 STRAINER SCREW 17 GASKET 18 COVER 19 20 SCREW 21 END CAP NUT 22 GASKET 23 ADJUSTING SCREW 24 ROTOR ASSEMBLY 25 PORT HOUSING 26 GASKET 27 PUMP BODY 28 PACKING

Figure 5-1. Fuel Pump

LOCATION		ITEM	ACTION REMARKS				
		Spring	a.	Remove adjust- ing screw (23) and plug (1). Install piston (5), spring (4) seat (3), gasket (2). Install plug (1) to secure parts.			
			b.	Position re- tainer (12) and washer (14) on piston (11) and washer (2) on plug (13). Install plug in pump body.			
			c.	Install adjust- ing screw (23) ir plug (1) all the way, then turn out six full turns	1		
2.	Spring	End plug (1)	Rem was sea (4)	nove plug (1), wher (2), spring at (3) and spring			
3.	Piston	Nozzle end plug (13)	a.	Remove plug (13), washer (2), and retainer (12) .			
			b.	Press piston (5) and sleeve out through nozzle port end of pump body (27)			
			c.	Remove and dis- card packing (14)			

LOCA	TION	ITEM	ACTION	REMARKS
INSP	PECTION			
Insp or w	ect all orn out	pump parts for serviceal parts with a serviceable	ble condition. R e like item.	eplace all defective, broken
REAS	SEMBLY			
4. Piston		a. End plug	Install washer (2) and end plug (1) in pump body	
		b. Piston sleeve	a. Install ne packing (1 on piston	w 4) [11)
5.	Rotor	Port housing	Install gasket (26) on port housing (25) an position housi on pump body (Locate port ho ing to align h in housing wit holes in pump	nd ng 27). us- oles h body
		Rotor	a. Reassemble assembly and instal (15)	rotor (24) 1 key
			b. Install ro assembly (and port h (25) on pur body (27) one screw then insta maining fo screws (17 leaving al screws only tight	tor 24) ousing mp using (17), ll re- ur) l five y hand

LOCATION			ITEM		ACTION	REMARKS	
6.	Bearing and shaft- and-seal	Bea	aring	a.	Install washer (7) in pump body (27)		
	assen			b.	Coat packing (28) with MIL-G-10924 lubricant. Install shaft- and-seal assembly (8) in pump body (27)		
					Rotate shaft to ensure that key (15) engages slot in shaft		
					Ensure that bearing shaft- and-seal assembly enters pump body evenly to avoid damage to packing as it passes by bearing recess shoulders on pump body		
		a.	Use screws (9) and washers (10)	Sec and Tor to-	ure bearing shaft- -seal assembly. que screws to 40- 50 inch pounds		
		b.	Connect electric drill to pump shaft using flex- ible coup- ling to rotate shaft	Whi tig sta at are 50	le rotating shaft hten screw (17) in r pattern, a little a time, until all torqued to 40-to- inch pounds	Ensure that shaft rotates freely while screws are tightened	
Cove	er	Cov	rer (19)	Use tio gasl (19 ins	screws (20) . Posi- n strainer (16) ket (18) and cover) on pump body and tall using screws (20)	Torque screws (20) to 84-to-96 inch pounds)	
5-11 COMBUSTOR AND NOZZLE							
---	--------------------------------------	--	--	---	----------------------------------		
This	task c a. R b. I	overs: emoval <u>n</u> spection	c. d.	Inspectic Install	on/Test		
INITIAL SETUP Test Equipment None Materials/Parts Maintenance Repair Parts Personnel Required 1		References Figure 5-2 Figure 5-3 Equipment Condition Hood assembly removed (para 4-12) Engine removed (Fig. 3 Air system removed (para 4-21)					
LOCA	FION	ITEM	ACT	ION	REMARKS		
REMO	VAL (Fi	gure 5-2)					
Com	bustor	Nozzle holder	Disenga from no combust Remove Remove holder combust	ge clamp otches in or (8). clamp (1). nozzle (2) from cor plate	(1)		
		Nozzle	Unscrey from h Separat strain seal (3 (2)	w nozzle (older (2). e: nozzle er (4), and 3) from hol	(5) e (5) d Lder		
		Combustor	Remove washers combus ket (11 changer	nuts (9) (10). R tor (8) and) from he	and emove 1 gas- at ex-		
INSE	ECTION						
		Clamp (1)	Inspect	for damag	ge.		
		Nozzle holder (2)	Inspect damaged	for crac threads	ks,		
		Seal (3)	Replace service	e if not i eable cond	n ition		

NOTE : Compressed air used for blowing dirt off parts must NOT exceed 15 psi. Wear suitable eye protectors.

LOCATION	ITEM	ACTION	REMARKS
	Strainer (4)	Blow clean with compressed air. Replace if not in service- able condition.	
	Combustor plate (7)	Clean with approved solvent. Inspect for signs of burn- ing or for damage. Replace if not in serviceable condi- tion.	See WARNING inside front cover about flammable cleaning fluids
	Combustor assembly (8)	Clean with an approved solvent. Inspect for signs of burning or for damage. Replace if not in service- able condition.	See WARNING inside front cover about flammable cleaning fluids
	Nozzle (5)	Clean with an approved solvent, Assemble and test as follows:	See WARNING inside front cover about using flammable cleaning fluids.
ASSEMBLE			
Nozzle holder	Seal , strainer, nozzle	Install seal (3), strainer (4) and nozzle (5) into nozzle holder (2)	

TEST

. Examine Figure 5-3 for fuel flow direction. Using low pressure air applied at fuel inlet, determine that all passages in nozzle assembly offer unobstructed flow in accordance with direction shown by arrows.

SERVICE

. Replace parts in nozzle assembly that **prevent unobstructed flow** in accordance with the preceding test.







TM 5-4520-244-14

LOCATION	ITEM	ACTION	REMARKS
ASSEMBLE (Fig	ure 5-2)		
Combustor	Combustor	Use nuts (9) and washers (10). Install gasket (11) and combustor (8) .	
	Nozzle	Use clamp (1). Install nozzle holder (2) in plate (7). Install plate (7) in combustor (8) with clamp (1). Hook clamp into notches on combuster.	3

5-12 HEAT EXCHANGER INSPECTION

This task covers:

a. Inspection only

INITIAL SETUP

Test Equipment None

Materials/Parts None

Personnel Required

1

References Figure 4-16

Equipment Condition a. As in procedure 5-11 b. Following shut down

LOCATION		ITEM	ACTION	REMARKS	
INSI	PECTION				
1.	During combustor servicing	Visible faults	With combustor removed as described in procedure 5-11 inspect all visible parts of heat exchange (20, Figure 4-16) for visible defects, burn- ing or damaged studs. Report damage to General Support Main- tenance	r	
2.	After shutdown	With ducts re- moved operate heater for 5 minutes, then shut down	Inspect interior of heat exchanger through open damper. Cracks are indicated by brigh areas inside still-hot heat exchanger. Report damaged condi- tion to General Suppor Maintenance.	t	

5-13 BULKHEAD, SIDE PANELS AND CASING

This task covers:

a. Servicing

INITIAL SETUP

Test Equipment None

Materials/Parts Serviceable replacement parts

Personnel Required

2

References Figure 5-4

Equipment Condition Disassembled as described in procedure 4-24

LOCATION		ITEM	ACTION	REMARKS
SERVICING				
Panels , bulkhead and casing	a.	Side panels and (13)	<pre>(12) Clean items (12), (13) (61), (62) and fr (63) in accordance with T.O. 35-1-12. Spot paint in</pre>	See WARNING inside ont cover about using flammable cleaning fluids
	b.	Bulkheads (61) and (63)	accordance with T.O. 35-1-3. Replace any damaged	
	С.	Casing (62)	defective or worn out parts with a serviceable like item.	



Figure 5-4. Bulkheads, Side Panels and Casing

INDEX, Figure 5-4.

1 SCREW 2 IDENTIFICATION PLATE 3 LATCH 4 SCREW 5 NUT 6 WASHER 7 WASHER 8 PUBLICATIONS CASE 9 GROMMET 10 SCREW 11 WASHER 12 LEFT SIDE PANEL 13 RIGHT SIDE PANEL 14 SCREW 15 NUT 16 WASHER 17 SCREW 18 NUT 19 WASHER 20 SUPPORT STOP, R.H. 21 SCREW 22 NUT 23 SUPPORT BRACKET 24 REMOVABLE BAR, R.H. 25 SUPPORT STOP 26 WASHER 27 BAR ASSEMBLY, R.H. 28 TOP DOOR SUPPORT, R.H. 29 SCREW 30 NUT 31 SUPPORT BRACKET 32 REMOVABLE BAR, L.H.

33 SUPPORT STOP, L.H. 34 WASHER 35 BAR ASSEMBLY, L.H. 36 HINGE SUPPORT BRACKET 37 SCREW 38 NUT 39 RESILIENT MOUNT 40 THUMBSCREW 41 SCREW 42 WASHER 43 ENGINE SUPPORT 44 CLAMP 45 EXHAUST PIPE 46 FLEX DUCT 47 CLAMP 48 EXHAUST EXTENSION 49 CHAIN" 50 ADAPTER OUTLET COVER 51 INSTRUCTION PLATE 52 FUEL SYSTEM DIAGRAM 53 CHAIN 54 WASHER 55 EXHAUST STACK CAP 56 SCREW 57 WASHER 58 EXHAUST STACK 59 GASKET 60 SQUARE WASHER 61 BOTTOM BULKHEAD 62 CASING 63 TOP BULKHEAD

5-14 SPRINGS AND AXLES This task covers: c. Replace/install a. Removal b. Inspection INITIAL SETUP References Test/ Equipment Figure 4-18) None Equipment Condition Materials/Parts Disassembled as described Maintenance Repair Parts in procedure 4-25 Personnel Required 2 ITEM ACTION REMARKS LOCATION REMOVE Remove wheels and Wheels bearings as described in procedure 4-25

Axle	Remove nuts (27), washers (28) and U-bolts (30). Remove plate (29) Separate axle (32) from springs (31)
Springs	Remove cotter pins (23),

shackle bolts (24) and nuts (25). Remove spring (31) from shackles (26). Remove shackles (26) from frame. Remove lubrication fittings (33) from shackle bolts (24)

INSPECTION

Inspect axle and springs as described in procedure 4-25.

REPLACE/INSTALL

Springs	Lubricant	Install	lubricant	fittings
	fittings	(33) in	shackle bo	olts (24)

LOCATION	ITEM	ACTION	REMARKS	
	Axle	Use U-bolts (30), washers (28) and nuts (27). Install plate (29) and axle (32) on springs (31).		
	Wheels	Install wheels as described in procedure 4-25	1	

Chapter 6

GENERAL SUPPORT MAINTENANCE

Page Maintenance Procedures. . 6-3

6-1 OVERVIEW

This chapter describes the heater repairs and parts replacement that are the responsibility of General Support Maintenance. Maintenance tasks given in Chapters 3, 4 and 5 are not repeated in this chapter.

SECTION 1

REPAIR PARTS AND SPECIAL TOOLS

6-2 REPAIR PARTS

See TM5-4520-244-24P for a listing of repair parts required for maintaining the heater.

6-3 SPECIAL TOOLS

See TM5-4520-244-24P Section III for the special tools required for maintenance of the heater.

SECTION II SERVICE UPON RECEIPT

Not applicable.

SECTION III OPERATIONAL CHECKS

6-4 OPERATIONAL CHECKS

Not applicable

SECTION IV PREVENTIVE MAINTENANCE CHECKS AND SERVICES

Not applicable

SECTION V TROUBLESHOOTING

Not applicable

SECTION VI MAINTENANCE PROCEDURES

6-5 SUMMARY AND DETAILED PROCEDURES

SUMMARY PROCEDURES

PARAGRAPH	PROCEDURE	RELATED ILLUSTRATIONS
6-6	Heat Exchanger Repair	4-16
6-7	Skid Base, Buel Tank and Skid Cover	6-1
6-8	Bulkheads, Side Panels and Casing	5-4

6-6	HEAT EXCHANGER REPAIR		
This	task covers: a. Removal b. Repair	c. Installation	
INIT:	IAL SETUP Test Equipment None	Refere Fic	e nces gure 4-16
	Materials/Parts Stainless Steel	Equi pri Ful	<i>ment Condition</i> ly assembled
	Personnel Required		
LOCAT	CION ITEM	ACTION	REMARKS
REMOV	/AL		
	Remove gasoline engine	Refer to Figure 3-1	
	Remove combustion system	Refer to procedure 4-22	
	Remove dampers, air control and stack	Refer to procedure 4-23	
	Remove heat exchanger	Slide heat exchanger (20, Figure 4-16) from casing (19)	
REPAI	R		
	Cracks in heat exchanger	Repair by welding	 DO NOT REPAIR: if crack is longer than l-inch if cracks are convergent
			 if heat exchanger has more than six cracks

TM 5-4520-244-14

LOCATION	ITEM	ACTION	REMARKS
	Sheared or stripped nuts around opening	Fabricate stainless steel patch, 6"x6" curved to fit, with exhaust hole and weld nuts. Remove damaged part of heat exchanger to accept patch. Weld in patch.	
INSTALLATION			
New or repaired heat exchanger		Slide heat exchanger (20, Figure 4-16) into casing (19)	
	Install damper, air control and stack	Refer to procedure 4-23	
	Install combustor system	Refer to procedure 4-22	
	Install gasoline engine	Refer to Figure 3-1	

This task cove a. Fuel b. <u>Disa</u>	ers: drain ssembly	с. d. е.	Service Repair Reassemble		
INITIAL SETUP <i>Test</i> Equi None	pment		<i>Refer</i> Fi	ences gure 6-1	
Materials Servio Personne 2	s/Parts ceable repair parts I Required	Equipment Condition Heater disassembled as described in procedure 5-		on mbled as rocedure 5-11	
LOCATION	ITEM		ACTION	REMARKS	
FUEL DRAIN					
(Procure suitable container) DISASSEMBLY			Remove pipe plug (7) and gasket (8). Drain residual fuel into a suit- able container.	See CAUTION cover about	inside front fuel spillag
Hose assemblies	Engine fuel		Disconnect engine fuel metal hose assembly from pipe-to-tube tee		
	Fuel hose		Disconnect fuel hose assembly from pipe elbow. Remove tee, el- bow, reducer bushing and pipe coupling from		

2. Tank	Gasket	Remove gaskets
attachments		(2), (6), (16)
		from fuel tank
		(15).



6-7

LOCATION	ITEM	ACTION	REMARKS
	Gage	Remove fuel gage (1) from tank (15)	
	Heater	Remove screws (14), nuts (9) and washers (11), also screws (7) and washers (8). Lift heater from skid base. Set on supports to suspend fuel tank.	
	Fuel Tank	Remove screws (12) nnd washers (13). Remove fuel tank (15). Remove nuts (17) from tank supports. Remove pre- formed packings from tank.	
	Fuel Gage	Remove fuel gage (1) from tank	
SERVICE			
3. Skid cover and skid base	a. Skid cover (1.4)	Clean items (14) and (29 in accordance with T.O. 351-12. Spot paint in accordance with T.O. 35 1-3. Replace unservice able item.	5) See WARNING inside front cover about - using flammable - cleaning fluids
. Fuel Tank	Inspect for leaks	Replace drain plug. Fill tank half full wth approved solvent. Agita allow to settle and in- spect tank for leaks. Drain solvent. Flush tank with fresh solvent until solvent comes out clean and clear.	ll ate,

LOCATION	ITEM	ACTION	REMARKS	
REPAIR				
5. Fuel tank		Use epoxy patch N.S.N.8040-00-77 0631. Remove paint around lea Clean area with sandpaper. Mix apply epoxy as a structed in patch kit. Allow epox to cure for 30 m utes or as spect in manufacturer instructions.	7- and in- ch ×y min- ified 's	
		Paint surface in accordance with T.O.35-1-3.	1	
REASSEMBLE				
6. Fuel tank	Fuel gage	Install fuel gag and gasket (2) : tank 15).	ge (1) in	
	Pipe plug	Install packing and plug (7) in (15)。	(8) tank	
	Barrel nuts	Position barrel (17) in tank suy straps .	nuts pport	
	Tank	Position fuel to below heater and attach by insta screws (12) and ers (13) in bar: nuts (17).	ank d lling wash- rel	
7. Skid base		Lift heater with attached fuel to and position on base . Install (10), washers (nuts (9).	n ank steel screws 11) and	

	LOCATION	ITEM	ACTION	REMARKS
8.	Hose assemblies	Fuel lines.	Install fuel lines as described in procedure 4-17	

6-8 BULKHEAD, SIDE PANELS AND CASING This task covers: c. Reassemble a. Removal d. Test **b.** Inspection INITIAL SETUP Test Equipment References Figure 5-4 None Materials/Parts Equipment Condition Heater fully assembled None Personnel Required LOCATION ACTION REMARKS ITEM REMOVAL Remove hood Refer to assembly procedure 4-12 Refer to Figure Remove gasoline 3-1 engine Refer to Remove engine fuel hose procedure 4-17 Refer to Remove heater fuel filter procedure 4-18 Remove engine Refer to procedure 4-21 exhaust pipe Remove fuel Refer to and heater procedure 4-19 controls Remove magneto Refer to procedure 4-14 and ignition cable Refer to Remove air control procedure 4-21 Remove heat Refer to procedure 6-6 exchanger

TM 5-4520-244-14

LOCATION	ITEM	ACTION	REMARKS
	Side panels	Remove screws (10), washers (11). Remove panels (12) and (13), Figure 5-4.	
	Top bulkhead	Remove screw (14), washers (16) and nuts (15). Remove top bulkhead (63)	
	Casing and bottom bulkhead	Remove screws (41) and washers (42) . Remove casing (62) from skid top. Re- move bottom bulk- head (61).	
	Engine support	a. Remove screws (37) and nuts (38). Remove thumb screws (40) and mounts (39)	
		<pre>b. Remove screws (41) and washers (42). Remove engine support (43).</pre>	
INSPECTION			
Inspect all r broken or wor	removed parts for n out parts with a	serviceable condition. Repl a serviceable like item.	ace damaged,
Inspect infor defaced or wo	mation plates for rn beyond ease of	adequate legibility. Replace readability.	e aged,
INSTALLATION	(Figure 5-4)		
	Engine support	Use screws (41) and washers (42). Install engine support (43)	
		Use screws (37) and nuts (38). Install mounts (39) and thumb	

screws (40).

LOCATION	ITEM	ACTION	REMARKS
	Casing and bottom bulkhead	Use screws (41) and washers (42). Install bottom bulkhead (61) and casing (62) on skid top.	
	Top bulkhead	Use screws (14), washers (16) and nuts (15). Install top bulkhead (63).	
	Side panels	Use screws (10) and washers (11). Install panels (12) and (13)	
	Install heat exchanger	Refer to procedure 6-6	
	Install air control	Refer to procedure 4-21	
	Install magneto and ignition cable	Refer to procedure 4-14	
	Install fuel and heater controls	Refer to procedure 4-19	
	Install engine exhaust pipe	Refer to procedure 4-21	
	Install heater fuel filter	Refer to procedure 4-17	
	Install gasoline engine	Refer to Figure 3-1	
TEST	Install hood assembly	Refer to procedure 4-12	

 $Start\ \mbox{up}$ engine and operate heater as described in Figure 2-3.

APPENDIX A

REFERENCES

A-1 SCOPE

This appendix lists all forms, field manuals, and technical manuals referenced in this manual.

A-2 FORMS

Equipment Inspection and Maintenance Work Sheet
Quality Deficiency Report SF 368
Recommended Changes to DA Publications
A-3 TECHNICAL MANUALS
Operator, Organizational, DS and GS Maintenance Manual, Engine, Gasoline, 1-1/2 HP Military Standard
Organizational, DS and GS and Depot Maintenance Repair Parts and Special Tools Lists, Engine, Gasoline, 1-1/2 HP Military Standard
Organizational, DS and GS Maintenance Repair Parts and Special Tools Lists, Heater, Duct Type, Portable, Trailer Mounted, 400,000 BTU/HR
Corrosion Prevention, Painting and Marking of USAF Support Equipment
Compounds and Procedures for Cleaning Support Equipment
The Army Maintenance Management System (TAMES)
A-4 MISCELLANEOUS PUBLICATIONS
Lubrication Order, Engine, Gasoline

Change 2 A-1/(A-2blank)

APPENDIX B

COMPONENTS OF END ITEM LIST

Section I INTRODUCTION

B-1. Scope.

This appendix lists Integral Components of and Basic Issue Items (BID) for the Heater to help you inventory items required for safe and efficient operation.

B-2. General.

The components of end item list are divided into the following sections:

a.Section II. Integral Components of the End Item. These items, when assembled, comprise the heater and must accompany it whenever it is transferred or turned in. These illustrations will help you identify these items.

b. Section III. Basic Issue Items. These are minimum essential item's required to place the heater in operation, to operate it and to perform emergency repairs. Although shipped separately packed, they must accompany the heater during operation and whenever it is transferred between accountable officers. The illustrations will assist you with hardto-identify items. This manual is your authority to requisition replacement BII based on Table(s) of Organization and Equipment (TOE)/ Modification Table of Organization and Equipment (MTOE) authorization of the end item.

B-3. Explanation of Columns.

a. Illustration. This column is divided as follows:

(1) *Figure Number*. Indicates the figure number Of the illustration on which the item is shown (if applicable).

(2) *Item Number*. The number used to identify item called out in the illustration.

b. National Stock Number (NSN). Indicates the national stock number assigned to the end item which will be used for requisitioning.

c. Part Number (P/N). Indicates the primary number used by the manufacturer which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards and inspection requirements to identify an item or range of items.

d. *Description*. Indicates the federal item name and, if required, a minimum description to identify the item.

e.. Location. The physical location of each item listed is given in this column, The lists are designed to inventory all items in one area of the major item before moving on to an adjacent area.

f. Usable on Code. "Usable On" codes are included to help you identify which component items are used on the different models. Identification of the cldes used in this list are:

Code Used On

Model FC-400-1

g. Quanity Required (Qty Reqd). This column lists the quantity of each item required for a complete major item.

h. *Quantity*. This column is left blank for use during inventory. Under the received column, list the quantity you actually receive on your major item. The date columns are for use when you inventory the major item at a later date, such as for shipment to another site.

	(1)	(2)	(3)	(4)	(5)
Ill	us Number	National Stock Number	Description FSCM and Part Number	U/M	Qty Rqr
Fi	g. 2-2 Item 8		Hose Adapter; 6 inch (57386) 10003	Ea	1
Fi	g. 2-2 Item 7		Hose, Duct; 6 inch (57386) 10001	Ea	3
Fi	g. 2-2 Item 6		Hose, Duct; 12 inch (57386) 10002	Ea	1
Fi	g. 1-3. Item 7		Pipe, Exhaust, with screen (57386) 40016	Ea	1

Section II. INTEGRAL COMPONENTS OF END ITEM

Section III. BASIC ISSUE ITEMS

(1)	(2)	(3)	(4)	(5)
Illus Number	National Stock Number	Description FSCM and Part Number	U/M	Qt Rq
	7220 -00-559- 9618	Case, Manual Department of Army Technical Manual; Operator, Organizational, Direct and General Support Maintenance Manual TM 5-4520-244-14		
		Department of Army Technical Manual; Operator, Organizational, Intermediate (Field) (Direct Sup- port and General Support) and Depot Maintenance Manual TM 5-2805-256-14		
		Lubrication Order I 0-2805-256-12		

APPENDIX C

MAINTENANCE ALLOCATION CHART

Section 1 INTRODUCTION

C-1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance functions on the identified end item or component and the work measurement time required to perform the functions by the designated maintenance level. The implementation of the maintenance functions upon the end item or components will be consistent with the assigned maintenance functions.

c. Section III lists the tools and test equipment required for each maintenance function as referenced from Section II (Not Applicable).

C-2. Explanation of Columns in Section II

a. Column (1), Group Number. Column 1 lists group numbers to identified related components, assemblies, subassemblies, and modules with their next higher assembly. The applicable groups are listed in the MAC in disassembly sequence beginning with the first group removed.

b. Column (2), Component/;Assembly. This column contains the noun mames of components, assemblies, subassemblies and modules for which maintenance is authorized.

c. Column(3), Maintenance Functions. This column lists the functions to be performed on the item listed in Column 2. The maintenance functions are defined as follows: (1)Inspect. To determine serviceability of an item by comparing its physical, mechanical, or electrical charateristics with established standards through examination.

(2) Tut. To verify serviceability of an item by comparing its physical, mechanical, or electrical characteristics of an item, and comparing those characteristics with prescribed standards.

(3) Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean (decontaminate), to preserve, to drain, to paint, or to replenish fuel, lubricants, hydraulic fluids, or compressed air supplies.

(4) Adjust. To maintain within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.

(5) Align. To ad-just specified variable elements of an item to bring about optimum or desired performance.

(6) Calibrate. To determine and cause corrections to be adjusted on instruments or test measuring and diagnostic equipments used in precision measurement. Consist of comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

(7) Install. The act of emplacing, seating, or fixing into position an

item, part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

(8) Replace The act of substituting a serviceable like type part, subassembly, or module (component or assembly) for an unservice able counterpart.

(9) Repair. The application of maintenance services (inspect, test, service, adjust, align, calibrate, or replace) or other maintenance actions (welding, grinding, riveting, straightening, facing remachining, or resurfacing) to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, sub-assembly, module (component or assembly), end item, or system.

(10) Overhaul. That maintenance effort (service/action) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards in appropriate technical manuals. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to a like new condition. (11) Rebuild. Consists of those services/ actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipments/ components.

d. Column (4), Maintenance Category. This column is made up of sub-columns for each category of maintenance. Work time figures are listed in these sub-columns for the lowest level of maintenance authorized to perform the function listed in column 3. These figures indicate the average active time required to perform the maintenance function at the indicated category of maintenance under typical field operating conditions.

e. Column (5), Tools and Equipment. This column is provided for referencing by code, the common tool sets (not individual tools) special tools, test and support equipment required to perform the designated functions (Not Applicable).

-7

Section II MAINTENCE ALLOCATION CHART

O-Organizational Maintenance F-Direct Support Maintenance H-General Support Maintenance D-Depot Maintenance C-Operator Crew

Group No.	Component/Assembly	Maintenance Function		Maint Cat	enanc egory	e		Tools and Equipment	Remarks
			с	0	F	Н	D		
01	Hose, Adapter, Basket and Support Handles								
	Hose	Inspect Install Replace	0.1 0.1	0.1					
	Adapter	Inspect Install Replace	0.1 0.1	0.1					
	Basket	Inspect Replace	0. 1	0.1					
:	Handles	Inspect Replace	0.1	0.1					
02	Hood Assembly								
	Cabinet Top	Inspect Replace	0.1	0.2					
	Access Door	Inspect Replace	0.1	0.1					
	Door, Air Inlet	Inspect Adjust Replace	0.1 0.1	0.1					
	Screen, Air Inlet	Inspect Service Replace	0.1 0.1	0.1					
03	Power Unit								
	Gasoline Engine	Inspect Service Install	0.1 0.1	0.2		_			

Group No.	Component/Assembly	Maintenance Function		Maint Cat	enanc egory	e 7		Tools and Equipment	Remarks
			С	0	F	Н	D		
04	Fuel System								
	Hose	Inspect Replace	0.1	0.1					
	Lines and Fittings	Inspect Replace	0.1	0.1					
	Fuel Filter	Inspect Service Replace	0.1	0.1 0.1					
	Fuel Pump	Inspect Test Repair Replace		0.1 0.5 0.2	1.0				
05	Control and Instruments								
	Burner Fuel Control Valve	Inspect Adjust Test Replace	0.1 0.1	0.8 0.5					
	Temperature Selector Valve	Inspect Adjust Test Replace	0.1 0.1	0.5					
	Check Valve	Inspect Test Replace	0.1 0.2	0.5					
	Tubings and Fittings	Inspect Replace		0.2 0.2					
06	Ignition System Ignition Cable	Inspect Replace	0.1	0.5					

C-4

Group No.	Component/Assembly Function	Maintenance Function		Maint Cat	enanc egory	e 7	Tools and Equipment	Remarks	
			С	0	F	Н	D		
06 cont.	Magneto	Inspect Test Repair Replace	0.2	0.3 0.5 0.5					
07	Air System								
	Drive Belt	Inspect Adjust Replace	0.1	0.1 0.3					
	Drive Coupling	Inspect Replace		0.2 0.8					
	Fan Ring	Inspect Replace		0.1 0.5					
	Fan, Vaneaxial	Inspect Service Replace		0.2 0.3 0.5					
	Air Vane	Inspect Replace		0.2 0.6					
08	Combustion System								
	Tubing and Fittings	Inspect Replace	0.2	0.5					
	Igniter Plug	Inspect Test Service Adjust Replace	0.2	0 .2 0.2 0.2 0.5					
	Combustor	Inspect Service Replace		0.2 0.5 0.8					

Group No.	Component/Assembly	Maintenance Function	Maintenance Category				Tools and Equipment	Remarks	
			С	0	F	Н	D		
08 cont.	Nozzle	Inspect Test Service Replace		0.3 0.2 0.3 0.5					
09	Heat Exchanger and Damper Control								
	Damper Control	Inspect Adjust Replace	0.1 0.1	0.5					
	Air Control	Inspect Replace		0.2 0.5					
	Exhaust Stack	Inspect Replace	0.1	0.2					
	Heat Exchanger	Inspect Replace			0.3	0.8			
10	Bulkhead, Side Panels, and Casing								
	Side Panels	Inspect Service Replace	0.1	0.3 0.5					
	Informa- tion Plates	Inspect Service Replace		0.1	0.2	0.3			
11	Skid, Cover and Fuel Bank								
	Skid Cover	Inspect Service Replace		0.3	0.5	0.8			

Group No.	Component/Assembly	Maintenance Function	Maintenance Category				Tools and Equipment	Remarks	
			С	0	F	Η	D		
11 cent.	Fuel Tank	Inspect Service Repair Replace		0.5	0.5	0.8			
	Skid	Service Replace			0.5	0.6			
12	Trailer Assembly								
	Wheels	Inspect Replace	0.2	0.5					
	Wheel Drums	Inspect Repair Replace	0.3	0.5 0.5					
	Tires and Tubes	Inspect Repair Replace	0.2	0.5 0.6					
	Wheel Hubs and Bearings	Inspect Adjust Replace	0.2	0.3 0.5					
	Axle	Inspect Replace		0.2	0.3				
	Springs	Inspect Replace		0.2	0.3				

C-7/(C-8 b1ank)

APPENDIX D

ADDITIONAL AUTHORIZATION LIST

Section 1 INTRODUCTION

D-1. Scope.

This appendix lists additional items you are authorized for the support of the Heater.

D-2. General

This list identifies items that do not have to accompany the Heater and that do not have to be turned in with it. These items are authorized to you by CTA, MTOE, TDA or JTA. D-3. Explanation of Listing

National stock number, descriptions, and quantities are provided to help you identify and request the additional items you reqire to support this equipment. "USABLE ON" codes are identified as follows:

CODE USED ON

Model FC-400-1

(1)	(2) Parts number		(3) USABLE	(4)	
STOCK NUMBER	FSCM	DESCRIPTION	ON CODE	U/M	QTY AUTH

NONE

APPENDIX E

EXPENDABLE MATERIALS LIST

Section I INTRODUCTION

E-1. Scope

This appendix lists expendable supplies and materials you will need to operate and maintain the Heater.

These items are authorized to you by CTA50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

E-2. Explanation of Columns.

a. Column 1 -- Item number_o This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "use cleaning compound, item 5, App.D").

b. Column 2 -- level. This column identifies the lowest level of maintenance that requires the listed item.

(enter as applicable)

C -- Operator/Crew

0 -- Organizational Maintenance

F -- Direct Support Maintenance

H -- General Support Maintenance

c.column 3 -- National Stock Number. This is the National stock number assigned to the item: use it to request or requisition the item.

d. Column 4 -- Description.

Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.

Column 5 -- Unit of Measure

(U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II EXPENDABLE SUPPLIES AND MATERIALS LIST

(1)	(2)	(3)	(4)	(5)
ITEM NUMBER	LEVEL	NATIONAL STOCK NUMBER	DESCRIPTION	U/M
1	0	6850-00-264-9037	Dry Clean Solvent, PD-680 (81348), 1 Gal. Can	EA
2	С	9130-00-160-1818	Gasoline, Combat, MIL-G-3056, Type I (Gallons re- quired for 8 hour operation)	BULK
3	0	9150-00-961-8995	Lubricant Grease, MIL-G-27617 (81349), 8 Ounce Tube	EA
ALPHABETICAL INDEX

Subject, Para

А

Page

Adapter, Air Duct, 4-11 Administrative Storage, 3-5 Air Control Baffles: Removal and Installation, 4-22 Air Ducts, 4-11 Air Duct Attachment, 2-4 Air Inlet, 4-12 Axle: Removal and Installation, 5-14

В

Basket, 4-11 Bulkheads: Removal and Installation, 4-24 Servicing, 5-13

С

Casing: Removal and Installation, 6-8 Servicing 5-13 Chassis Lubrication, 4-26 Combustion System: . Removal and Installation, 4-22 Combustor Nozzle: Inspection, 5-11 Removal and Installation, 4-22 Test, 5-11 Combustion Plate: Removal and Installation, 4-22 Controls and Instruments: Description and Use, 2-22 Removal and Installation, 4-19 Coupling Drive: Removal and Installation, 4-21

D

Damper: Removal and Installation, 4-23 Jamper Control: Removal and Installation, 4-23 Duct Adapter Assembly: Removal and Installation, 4-23 Ducts, Installation, 4-11 Е

Page

Engine, Gasoline: Removal and Installation, 3-4 Servicing, 4-13 Equipment Data, 1-10 Exhaust Pipe, Engine: Removal and Installation, 4-21 Exhaust Stack: Removal and Installation, 4-23

F

Fan Assembly: Removal and Installation, 4-21 Fuel Control Valve: Removal and Installation, 4-20 Test, 4-20 Fuel Filter: Servicing, 4-18 Fuel Lines and Fittings: Removal and Installation, Fuel Pump: Removal and Installation, Fepairing, 5-10 Testing, 4-17 Fuel System Operation, 1-11 Fuel Tank: Removal and Installation, Repair, 5-7

Η

Hand Receipt, 1-5
Heater, Model FC-400-1:
Capabilities and Features, 1-8
Description, 1-6
Operating Principles, 1-11
Operation:
Cold Weather Starting, 2-6
Dusty or Sandy Conditions, 2-7
Operating under Unusual Conditions, 2-5
Operating under Usual Conditions, 2-4
Shutdown, 2-6
Startup, 2-4
Purpose, 1-7

ALPHABETICAL INDEX Cent

Page

Subject, Para

H Cent

Heat Exchanger: Inspection, 5-12 Removal and Installation, Repair Hood Assembly, 4-12

Т

Ignition Plug: Adjustment, 4-22 Removal and Installation, 4-22

L

Location and Description of Major Components, 1-9 Lubrication, 3-2

М

Magneto and Ignition Cable: Point Adjustment, Removal and Installation, 4-14 Repair, 4-15 Testing, Maintenance: Operators, 3-4 Organizational, 4-9 Maintenance Forms, Records and Reports, 1-3

N

Nozzle, Combustion: Removal and Installation, 4-22 Test, 5-11

0

Operating Heater: Operation under Unusual Conditions, 2-6 Operation under Usual Conditions, 2-4 Operational check, 4-7 Ρ

Page

Power Unit, Preservative Oil, Removal, 4-6 Preventive Maintenance Checks and Servicing: Direct Support, 5-7 Operators, 2-3 organizational, 4-8

R

Removal and Installation: Air Control Baffles, 4-23 Axle, 5-14 Bulkheads, 4-24, 6-8 Casing, 6-8 Combustion System, 4-22 Combustor Nozzle, 4-22 Combustor Plate, 4-22 Controls and Instruments, 4-19 Coupling, Drive, 4-21 Damper, 4-20 Damper Control, 4-23 Duct Adapter Assembly, 4-23 Engine, 3-4 Exhaust Pipe, Engine, 4-21 Exhaust Stack, 4-23 Fan Assembly, 4-21 Fuel Control Valve, 4-20 Fuel Filter, Fuel Lines and Fittings, Fuel Pump, Fuel Tank, Heat Exchanger, Hood Assembly, 4-12 Igniter Plug, 4-22 Magneto and Ignition Cable, 4-12 Nozzle, Combustion, 4-22 Side Panels, 4-24, 6-8 Skid Base, 5-7 Springs, 5-14 Temperature Selector Valve, 4-20 Tire Assembly, 4-25 V-Belt, 4-21 Wheel Assembly, 4-25 Repair Parts and Special Tools, 4-2, 4-3 Reporting Equipment Improvements, Recommendations, 1-4

ALPHABETICAL INDEX Cent

Subject, Para

S

```
Service upon Receipt, 4-4
Side Panels:
Removal and Installation, 4-24, 6-8
Servicing, 5-13
Skid Base:
Removal and Installation, 5-7
Servicing, 5-7
Special Services, 4-5
Special Tools, 4-3
Springs:
Removal. and Installation, 5-14
Starting up Heater, 2-4
Support Handles, 4-11
```

Τ

Technical Principles of Operation, 1-4 Temperature Selector Valve: Removal and Installation, 4-20 Test and Adjust, 4-20 Tire Assembly: Removal and Installation, 4-25 Trailer Assembly: Removal and Installation, 4-25 Troubleshooting: Direct Support, 5-8 Operators, 3-3 Organizational, 4-9

۷

V-Belt: Removal and Installation, 4-21

W Wheel Assembly: Removal and Installation, 4-25 Wheel Bearings: Lubrication, 4-25

By Order of the Secretary of the Army:

E. C. MEYER General, United states Army Chief of Staff

Official:

J. C. PENNINGTON Major General, United States Army The Adjutant General

DI STRI BUTI ON:

To be distributed in accordance with DA Form 12-25C, Operator Requirements for Heaters, Space, 400,000 BTU.

* U. S. GOVERNMENT PRINTING OFFICE: 1988 - 554169 / 87153

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS SOMETHING WRONG WITH THIS MANUAL? FROM: (YOUR UNIT'S COMPLETE ADDRESS) PFC JOHN DOE THEN. . . JOT DOWN THE DOPE ABOUT IT ON THIS COA, 3ª ENGINEER BN FORM, TEAR IT OUT, FOLD FT. LEONARD WOOD MO 63108 IT AND DROP IT IN THE MAIL! DATE DATE PUBLICATION NUMBER TITLE Heater, Duct Type, Portable, 11 July 1980 TM 5-4520-244-14 Trailer Mounted, 400,000 BTU/HR IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DOME ABOUT IT: BE EXACT. . . PIN-POINT WHERE IT IS PAGE FIGURE TABLE NO. GRAPH NO. NO. In line 6 of paragraph 2-1a the 2-1 6 manual states the engine has 6 cifinders The engine on my set only has 4 cylinders. Change a the manual to show 4 cylinders. ALONG DOTTED LINE Callout 16 on figure 4-3 is pointing at a bolt. In the key to fig. 4-3, item 16 is called a 4-3 81 TEAR Please correct one on the shim. other Sørdered a gasket, stem 19 on figure B-16 by NSN 2910-00-762-3001. I got a gasket but it doesn't fit. 125 line 20 upply says got what Il dered so the NSN is wrong. glease geve me a good NSN. TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER SIGN HERE: Dre. JOHN DOE, PFC (268) 317-7111 ohn DA , FORM 2028-2 P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS. DRSTS-M OVERPRINE 1, 1 NOV 78 MAKE

יין		1	some	THU	NG (WRONG WITH THIS MANUAL
S		THEN DOP E FORM IT AN	JOT DOW ABOUT IT O , TEAR IT O D DROP IT II	N THE N THIS UT, FOLD N THE	FROM: ()	OUR UNIT'S COMPLETE ADDRESS)
DUDI ICATI		MAIL			DATE	
TM 5-45	520-244-1	4		11 July	/ 1980	Heater, Duct Type, Portable, Trailer Mounted, 400,000 BTU/H
BE EXACT.	PIN-POIN	TWHEREITI	IN THIS SP	ACE TELL W	HAT IS WE	RONG DUT IT:
TYPED NAME	, GRADE OR	TITLE, AND	I	MBER	SIGN HE	RE :

 Fold BACK

 DEPARTMENT OF THE ARMY

 Department of the ARMY

 Dot-314

 OFFICIAL BUSINESS

 PENALTY FOR PRIVATE USE, \$300

 Commander US Army Troop Support and Aviation Materiel Readiness Command ATTN: DRSTS-MTPS 4300 Goodfellow Boulevard St. Louis, MO 63120

I

TEAN ... UNG DOTTED LINE

ł

FOLD BACK

REVERSE OF DA FORM 2028-2

The Metric System and Equivalents

Linear Meanure

1 centimeter = 10 millimeters = .39 inch 1 decimenter = 10 centimeters = 3.94 inches 1 meter = 10 decimeters = 39.37 inches 1 dekameter = 10 meters = 32.8 feet 1 hectometer = 10 dekameters = 328.08 feet 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

- 1 centigram = 10 milligrams = .15 grain 1 decigram = 10 centigrams = 1.54 grains 1 gram = 10 decigrams = .035 ounce 1 dekagram = 10 grams = .35 ounce
- 1 hectogram = 10 dekagrams = 3.52 ounces
- 1 kilogram = 10 hectograms = 2.2 pounds
- 1 quintal = 100 kilograms = 220.46 pounds
- 1 metric ton = 10 quintals = 1.1 short tons

Liquid Meanure

- 1 centiliter = 10 milliters = .34 fl. ounce
- 1 deciliter = 10 centiliters = 3.38 fl. ounces
- 1 liter = 10 deciliters = 38.82 fl. ounces
- 1 dekaliter = 10 liters = 2.64 gallons
- 1 hectoliter = 10 dekaliters = 26.42 gallons
- 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

- 1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
- 1 sq. decimenter = 100 sq. centimeters = 15.5 sq. inches
- 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
- 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
- 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
- 1 sq. kilometer = 100 sq. hectometers = . 386 sq. mile

Cuhic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches 1 cu meter = 1000 cu. decimeters = 35.31 cu. feet

°C

To shange	Ť.	Multi-lu bu	To change	T.	Multinly hu
та снанде		mattepty ov	10 Change	10	marcipi, ay
inchee	centimeters	2.540	ounce-inches	newton meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	squ are inches	155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29,573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.365	metric tons	short tons	1 102
pound inches	newton meters	.11375			

Approximate Conversion Factors

Temperature (Exact)

°F	Fahrenheit	5/9 (after	Celsius
	temperature	subtracting 32)	temperature

PIN: 045667-006

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<u>http://www.liberatedmanuals.com/</u>>Free Military and Government Manuals

Sincerely
 Igor Chudov
 <u>http://igor.chudov.com/</u>
 Chicago Machinery Movers