

## TECHNICAL MANUAL OPERATOR'S MANUAL

### HEMTT TANKER AVIATION REFUELING SYSTEM (HTARS)

NSN 4930-01-269-2273

MODEL NUMBER  
50-0051

INTRODUCTION

OPERATING INSTRUCTIONS

OPERATOR MAINTENANCE  
INSTRUCTIONS


REFERENCES

COMPONENTS OF END  
ITEM/BASIC ISSUE ITEMS

ADDITIONAL  
AUTHORIZATION LIST

EXPENDABLE/DURABLE  
SUPPLIES AND MATERIALS LIST

INDEX



Approved for public release. Distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

10 MARCH 1989



CHANGE

NO. 5

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C. 30 SEPTEMBER 1998

## OPERATOR'S MANUAL

FOR

**HEMTT TANKER AVIATION REFUELING SYSTEM  
(HTARS)****NSN: 4930-01-269-2273****MODEL NUMBER 50-0051**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 5-4930-237-10, 10 March 1989 is changed as follows:

1. Retain this sheet in front of manual for reference purposes.
2. New or changed text material is indicated by a vertical bar in the margin.
3. An illustration change is indicated by a miniature pointing hand.
4. Remove and insert pages as indicated below.

## Remove Pages


i and ii  
1-1 through 1-4  
2-1 through 2-6  
2-9 and 2-10  
2-13 through 2-18  
3-7 and 3-8  
DA Form 2028's

## Insert Pages

i and ii  
1-1 through 1-4  
2-1 through 2-6  
2-9 and 2-10  
2-13 through 2-18  
3-7 and 3-8  
DA Form 2028's

**By Order of the Secretary of the Army:**

Official:



JOEL B. HUDSON

*Administrative Assistant to the  
Secretary of the Army*

05339

DENNIS J. REIMER  
*General, United States Army  
Chief of Staff*

**DISTRIBUTION:** To be distributed in accordance with the Initial Distribution Number (IDN) 254854, requirements for TM 5-4930-237-10.

**URGENT**

**TM 5-4930-237-10**

**C4**

CHANGE

NO. 4

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 16 July 1997

OPERATOR'S MANUAL

FOR

**HEMTT TANKER AVIATION REFUELING SYSTEM  
( HTARS)**

**NSN: 4930-01-269-2273  
MODEL NUMBER 50-0051**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 10-4930-237-10, 10 March 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

2-13 and 2-14

2-17 and 2-18

Insert pages


2-13 and 2-14

2-17 and 2-18

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

Official:

  
JOEL B. HUDSON

*Administrative Assistant to the  
Secretary of the Army*  
03649

DENNIS J. REIMER  
*General, United States Army  
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no.4854 requirements for TM 10-4930-237-10.

**URGENT**

CHANGE

No. 3

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 7 August 1995

Operator's Manual

**HEMTT TANKER AVIATION  
REFUELING SYSTEM (HTARS)  
NSN 4930-01-269-2273  
MODEL NUMBER  
50-0051**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 5-4930-237-10, 10 March 1989 is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

a/(b blank)

2-9 and 2-10

2-13 and 2-14

3-5 and 3-6

B-1 through B-4

Insert pages

a/(b blank)

2-9 and 2-10

2-13 and 2-14

3-5/(3-6 Blank)

B-1 through B-4

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

  
JOEL B. HUDSON

*Acting Administrative Assistant to the  
Secretary of the Army*

00761

**DENNIS J. REIMER**  
*General, United States Army  
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 4854, requirements for TM 5-4930-237-10.



CHANGE

NO. 2

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 27 FEBRUARY 1991

Operator's Manual

**HEMTT TANKER AVIATION  
REFUELING SYSTEM (HTARS)  
NSN 4930-01-269-2273  
MODEL NUMBER  
50-0051**

Approved for public release; distribution is unlimited

TM 5-4930-237-10, 10 March 1989 is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

B-1 through B-5/(B-6 blank)

B-1 through B-5/(B-6 blank)

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E. VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official:**

**THOMAS F. SIKORA**  
*Brigadier General, United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 4854).





CHANGE }  
No. 1 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 16 June 1989

Operator's Manual

HEMTT TANKER AVIATION  
REFUELING SYSTEM (HTARS)  
NSN 4930-01-269-2273  
MODEL NUMBER  
50-0051

Approved for public release; distribution is unlimited.

TM 5-4930-237-10, 10 March 1989, is changed as follows:

1. Illustration on the cover of this TM should be changed to reflect what is in Figure 1-1, change 1.

2. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

| Remove pages        | Insert pages        |
|---------------------|---------------------|
| 1-1 through 1-3/1-4 | 1-1 through 1-3/1-4 |
| 2-1 and 2-2         | 2-1 and 2-2         |
| 2-5 through 2-16    | 2-5 through 2-16    |
| -----               | 2-16.1/2-16.2       |
| A-1/A-2             | A-1/A-2             |
| B-1 through B-5/B-6 | B-1 through B-5/B-6 |
| Index-1 and Index-2 | Index-1 and Index-2 |

3. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E.VUONO**  
*General United States Army*  
*Chief of Staff*

**Official:**

**WILLIAM J. MEEHAN, II**  
*Brigadier General United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-38-R, Operator Maintenance requirements for Truck, Cargo, 10-ton, 8x8, Heavy Expanded Mobility Tactical Truck, HEMTT, M977, M978, M983, M984, M985.



## WARNING PAGE

**WARNING**

Aviation fuel is highly flammable. No smoking or open flames are permitted during fueling operations or near refueling areas. Failure to comply can result in injury or death to personnel.

**WARNING**

Proper eye protection must be worn. Failure to comply can result in loss of eyesight.

**WARNING**

Ground clips and plugs must be connected before attaching nozzle to aircraft. Failure to comply can result in injury or death to personnel from static discharge.

**WARNING**

Do not force flow handle of Dry-Lot connectors to the open position. Damage to the interlocking mechanism can result in an inadvertent disconnect and subsequent fuel discharge during operation. Failure to comply can result in injury or death to personnel or damage to equipment.



TECHNICAL MANUAL

No. 5-4930-237-10

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington, D.C., 10 March 1989

## Operator's Manual

HEMTT TANKER AVIATION REFUELING SYSTEM (HTARS)

NSN 4930-01-269-2273 MODEL NUMBER 50-0051

Approved for public release. Distribution is unlimited.

## REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can improve this manual. If you find any mistakes, or if you know of a way to improve the procedures, please let us know. Mail your letter, DA form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. A reply will be furnished to you. You may also provide DA Form 2028-2 information to TACOM via datafax or e-mail: TACOM's fax number is DSN 786-6323. TACOM's e-mail address is [tacom-tech-pubs@cc.tacom.army.mil](mailto:tacom-tech-pubs@cc.tacom.army.mil)

## Table of Contents

|  | Page    |
|--|---------|
| <b>CHAPTER 1</b>   |         |
| <b>INTRODUCTION</b> .....  | 1-1     |
| Section I. General Information .....                                       | 1-1     |
| Section II. Equipment Description and Data .....                           | 1-2     |
| Section III. Principles of Operation .....                                 | 1-3     |
| <b>CHAPTER 2</b>   |         |
| <b>OPERATING INSTRUCTIONS</b> .....  | 2-1     |
| Section I. Description and Use of Operator's Controls and Indicators ..... | 2-1     |
| Section II. Preventive Maintenance Checks and Services .....               | 2-8     |
| Section III. Operation Under Usual Conditions .....                        | 2-12    |
| Section IV. Operation Under Unusual Conditions .....                       | 2-20    |
| <b>CHAPTER 3</b>   |         |
| <b>OPERATOR MAINTENANCE INSTRUCTIONS</b> .....                             | 3-1     |
| Section I. Lubrication Instructions .....                                  | 3-1     |
| Section II. Troubleshooting Procedures .....                               | 3-1     |
| Section III. Maintenance Procedures .....                                  | 3-12    |
| APPENDIX A. <b>REFERENCES</b> .....  | A-1     |
| APPENDIX B. <b>COMPONENTS OF END ITEM/BASIC ISSUE ITEMS</b> .....          | B-1     |
| APPENDIX C. <b>ADDITIONAL AUTHORIZATION LIST</b> .....                     | C-1     |
| APPENDIX D. <b>EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST</b> .....    | D-1     |
| <b>INDEX</b> .....   | Index-1 |

LIST OF ILLUSTRATIONS

| Figure | Title  | Page |
|--------|--|------|
| 1-1    | HEMTT Tanker Aviation Refueling System (HTARS) ..... | 1-1  |
| 2-1    | Operator's Controls and Indicators .....             | 2-2  |
| 3-1    | Dust Seal Replacement .....                          | 3-13 |
| 3-2    | D1 Nozzle Strainer Inspection .....                  | 3-13 |

LIST OF TABLES

| Table | Title   | Page |
|-------|---|------|
| 1-1   | Equipment Data .....                                    | 1-3  |
| 2-1   | Preventive Maintenance Checks and Services (PMCS) ..... | 2-9  |
| 3-1   | Troubleshooting .....                                   | 3-1  |

## CHAPTER 1

## INTRODUCTION

## Section 1. GENERAL INFORMATION

**1-1. Scope.** This is an Operator's Manual and supports the Heavy Expanded Mobility Tactical Truck (HEMTT) Tanker Aviation Refueling System, model number 50-0051. The system is used to dispense aviation fuel to from one to four aircraft. Throughout this manual the HEMTT Tanker Aviation Refueling System (HTARS) shall be referred to as the equipment. (See Figure 1-1).




Figure 1-1. HEMTT Tanker Aviation Refueling System (HTARS)



**1-2. Maintenance Forms, Records, and Reports.** Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS).

**1-3. Reporting Equipment Improvement Recommendations (EIR's).** If your equipment needs improvement, let us know. Send an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at: Commander, U.S. Army TACOM, ATTN: AMSTA-TR-E/MPA, Warren, MI 48395-5000. A reply will be furnished to you.

**1-4. Warranty Information.** Refer to TB5-4930-237-23, Technical Warranty Bulletin, for all warranty information.

**1-5. Destruction of Army Material to Prevent Enemy Use.** The equipment shall be destroyed in accordance with TM 750-244-3, Procedures for Destruction of Equipment to Prevent Enemy Use.

**1-6. Preparation for Storage or Shipment-** Refer to Chapter 2, Section III, Operation Under Usual Conditions,

**1-7. Quality Assurance/Quality Control (QA/QC).** Refer to FM 55-0411, Aviation Maintenance Quality Assurance/Quality Control, for appropriate QA/QC information.

**1-8. Safety, Care, and Handling.**

### **WARNING**

Aviation fuel is highly flammable. No smoking or open flames are permitted during fueling operations or near refueling areas. Failure to comply can result in injury or death to personnel.

Ground clips and plugs must be connected before attaching nozzles to aircraft. Failure to comply can result in injury or death to personnel from static discharge.

- a. Do not use any nozzle, part, or hose that is damaged and/or leaking fuel.
- b. Keep equipment clean. Remove dirt, fuel, moisture, snow, or mud with a clean cloth (item 1, Appendix D).
- c. Keep flow handles in closed (off) position when not in use.
- d. Keep dust caps in place when not in use. Dust, dirt, moisture, or contaminants can cause damage to internal parts.
- e. Hand-carry all equipment. Do not drag or throw on ground.

## **Section II. EQUIPMENT DESCRIPTION AND DATA**

**1-9. Equipment Characteristics, Capabilities, and Features.**

- a. Equipment is light-weight and can be carried to and from the aircraft.
- b. All controls are manually operated.
- c. Nozzles will not dispense fuel unless connected to aircraft receptacle (except overwing nozzle).
- d. One nozzle or combination of nozzles will connect to aircraft receptacle without an adapter.

e. Valved and swivel adapters allow connection between camlock and sexless type fittings.

**1-10. Location and Description of Major Components.** Refer to Chapter 2, Section I, Description and Use of Operator's Controls and Indicators.

**1-11. Equipment Data.** (See Table 1-1.)

*Table 1-1. Equipment Data*

---

|   |                       |
|---|-----------------------|
| Weight (Dry) :                                |                       |
| 3 Inch Discharge Hose (50 feet) .....         | 69.0 pounds (31.3 kg) |
| Carrying Strap .....                          | 0.5 pounds (0.2 kg)   |
| Tee Connector .....                           | 6.5 pounds (2.9 kg)   |
| 2 Inch Discharge Hose (60 feet) .....         | 38.5 pounds (17.4 kg) |
| Elbow Connector .....                         | 3.5 pounds (1.6 kg)   |
| DELETED                                       |                       |
| Adapter -Valved .....                         | 2.5 pounds (1.1 kg)   |
| Adapter-Valved .....                          | 3.0 pounds (1.4kg)    |
| Adapter Valved .....                          | 2.5 pounds (1.1 kg)   |
| Swivel Adapter .....                          | 1.5 pounds (0.7 kg)   |
| Closed Circuit Refueling (CCR) Nozzle .....   | 8.0 pounds (3.6 kg)   |
| Overwing Nozzle .....                         | 2.5 pounds (1.1 kg)   |
| Recirculation Nozzle .....                    | 5.0 pounds (2.3 kg)   |
| D1 Nozzle .....                               | 9.5 pounds (4.3kg)    |
| Grounding Rod .....                           | 5.0 pounds (2.3kg)    |
| Operating Temperature Range .....             |                       |
| -30 to + 180 degrees F (-34 to +82 degrees C) |                       |

---

### Section III. PRINCIPLES OF OPERATION

Refer to Chapter 2, Section I, Description and Use of Operator's Controls and Indicators.



# CHAPTER 2

## OPERATING INSTRUCTIONS

### Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS

#### 2-1. Operator's Controls and Indicators. (See Figure 2-1.)




Figure 2-1. Operators Controls and Indicators (Sheet 1 of 8)









Figure 2-1. Operation Controls and Indicators (Sheet 2 of 8)



**VIEW E**

**DELETED**



14786A

Figure 2-1. Operator's Controls and Indicators (Sheet 3 of 8)




Figure 2-1. Operator's Controls and Indicators (Sheet 4 of 8)




Figure 2-1. Operator's Controls and Indicators (Sheet 5 of 8)



| Key | Control or Indicator  | Function  |
|-----|-----------------------|---|
| 1   | 3 Inch Discharge Hose | Connects HTARS to HEMTT tanker.                           |
| 2   | FLOW Handle           | Opens and closes valve.                                   |
| 3   | Detent Button         | Locks FLOW Handle in flow or no flow position.            |
| 4   | Cam Arm(s)            | Secures hose to connector on HEMTT tanker.                |
| 5   | Dust Cap              | Keeps dirt and contaminants out of hose.                  |
| 6   | FLOW Handle           | Opens and closes valve.                                   |
| 7   | Carrying strap        | Keeps hoses coiled for carrying or storage.               |
| 8   | Tee Connector         | Splits flow of fuel.                                      |
| 9   | Dust Cap              | Keeps dirt and contaminants out of tee connector.         |
| 10  | FLOW Handle           | Opens and closes valve.                                   |
| 11  | 2 Inch Discharge Hose | Transfers fuel from HEMTT tanker to aircraft.             |
| 12  | Dust Cap              | Keeps dirt and contaminants out of 2 Inch Discharge Hose. |
| 13  | FLOW Handle           | Opens and closes valve.                                   |
| 14  | Elbow Connector       | Directs flow of fuel.                                     |
| 15  | Dust Cap              | Keeps dirt and contaminants out of elbow connector.       |
| 16  | Interlock Pi          | Locks elbow connector to hose.                            |
| 17  | DELETED               |   |
| 18  | DELETED               |   |
| 19  | DELETED               |   |
| 20  | Adapter - Valved      | Allows connection of camlock and sexless parts.           |
| 21  | Dust Cap              | Keeps dirt and contaminants out of adapter.               |
| 22  | FLOW Handle           | Opens and closes valve.                                   |

Figure 2-1. Operator's Controls and Indicators (Sheet 6 of 8)

| Key | Control or Indicator | Function  |
|-----|----------------------|---|
| 23  | Adapter - Valved     | Allows connection of threaded and sexless parts.  |
| 24  | Dust Cap             | Keeps dirt and contaminants out of adapter.   |
| 25  | FLOW Handle          | Opens and closes valve.   |
| 26  | Adapter - Valved     | Allows connection of camlock and sexless parts.   |
| 27  | Dust Cap             | Keeps dirt and contaminants out of adapter.   |
| 28  | FLOW Handle          | Opens and closes valve.   |
| 29  | Cam Arm(s)           | Secures adapter to connector.   |
| 30  | Swivel Adapter       | Allows connection of camlock and sexless parts.   |
| 31  | Dust Cap             | Keeps dirt and contaminants out of swivel adapter.  |
| 32  | Interlock Pin        | Locks swivel adapter to hose.   |
| 33  | CCR Nozzle           | Dispenses fuel to aircraft. See TM5-4930-235-13&P, Operators, Unit, and Intermediate Direct Support Maintenance Manual and Repair Parts and Special Tools List, for details on controls and indicators. |
| 34  | Overwing Nozzle      | Dispenses fuel to aircraft.   |
| 35  | Dust Cap             | Keeps dirt and contaminants out of nozzle.  |
| 36  | Dust cap             | Keeps dirt and contaminants out of nozzle.  |
| 37  | Flow Handle          | Opens and closes valve.   |
| 38  | Recirculation Nozzle | Dispenses fuel to aircraft.   |
| 39  | Dust Cap             | Keeps dirt and contaminants out of nozzle   |
| 40  | Dust Cap             | Keeps dirt and contaminants out of nozzle   |
| 41  | FLOW Handle          | Opens and closes valve.   |
| 42  | Ground Plug          | Connects to aircraft before connecting nozzle. Prevents static electric shock and fire hazard.  |
| 43  | Fuel Sample Port     | Port to connect fuel sampling hose.   |

**Figure 2-1. Operator's Controls and Indicators (Sheet 7 of 8)**

| Key | Control or Indicator | Function   |
|-----|----------------------|--|
| 44  | Fuel Sampling Hose   | Used to obtain sample of fuel.                                 |
| 45  | Plug                 | Closes fuel sample port when fuel sampling hose not connected. |
| 46  | Release Pin          | Allows FLOW handle to open to inspect strainer housing.        |
| 47  | Strainer Housing     | Opens flow valve in aircraft.                                  |
| 48  | D1 Nozzle            | Dispenses fuel to aircraft.                                    |
| 49  | Dust Cap             | Keeps dirt and contaminants out of nozzle.                     |
| 50  | Dust Cap             | Keeps ,dirt and contaminants out of nozzle.                    |
| 51  | Interlock Pin        | Locks nozzle to hose.  |
| 52  | Retainer             | Holds strainer in nozzle.                                      |
| 53  | Strainer             | Prevents damage to nozzle and /or aircraft by removing dirt.   |
| 54  | Flow Handle          | Opens and closes valve.  |
| 55  | Rod, Grounding       | Grounds and bonds aircraft to HTARS System.                    |
| 56  | Striker              | Part of the grounding rod.                                     |
| 57  | Hanger Assembly      | Part of the grounding rod.                                     |

**Figure 2-1. Operator's Controls and Indicators (Sheet 8 of 8)**

## **Section II. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)**

### **2-2. General.**

*a.* Before you operate the equipment, perform your before (B) PMCS. Always keep in mind the WARNINGS and CAUTIONS.

*b.* While you operate the equipment, perform your during (D) PMCS. Always keep in mind the WARNINGS and CAUTIONS.

*c.* After you operate the equipment, perform your after (A) PMCS.

*d.* If your equipment fails to operate, troubleshoot with the proper equipment. Report any deficiencies using the proper forms. Refer to DA PAM 738-750, The Army Maintenance Management System.

### **2-3. PMCS Procedures. (See Table 2-1.)**

*a.* The purpose of the PMCS table is to identify each component which requires inspection to insure operational readiness.

*b.* The service intervals have been selected to ensure all components are inspected regularly.

c. Item Number Column. Item numbers in this column shall be listed in the TM Item Number column on DA Form 2404 in recording results of PMCS. Items are listed regardless of interval.

d. Interval Column. These columns are headed "B" (before), "D" (during), "A" (after), "W" (weekly), and "M" (monthly). A dot (•) in the interval column indicates when the PMCS shall occur.

e. Item to be Inspected Column. This column lists the item to be inspected.

f. Procedures Column. This column describes what must be done to the item.

g. For Readiness Reporting, Equipment is Not Ready/Available if: Column. This column contains conditions which would prevent the equipment from performing its primary function.

### NOTE

- If equipment must be kept in continuous operation, check and service only those items that can be checked and serviced without disturbing operation. Make the complete checks and services when the equipment can be shut down.
- Within designated interval, these checks are to be performed in the sequential order listed.

**Table 2-1. Preventive Maintenance Checks and Services (PMCS)**

B-Before D-During A-After W-Weekly M-Monthly

| Item No. | Interval |   |   |   |   | Item to be Inspected        | Procedures<br>Check for and have<br>Repaired or adjusted   | For Readiness Reporting, Equip<br>ment is Not<br>Ready/Available If:  |
|----------|----------|---|---|---|---|-----------------------------|--|---|
|          | B        | D | A | W | M |                             |  |   |
| 1        | •        | • | • | • |   | 3 inch<br>Discharge<br>Hose | Check for damaged valve bodies on hose and signs of leaks or cracks.<br>Check camlock body for gasket damage or loss.<br>Check cam arms for cracks or damage.<br>Check sexless body for seals/boot damage or loss.<br>Check dust cap for damage or loss.<br>Open flow handle and check for interlocking pin extension on connector face. | Outward signs of damage or leakage.<br>Gasket damaged or missing.<br>Outward signs of damage.<br>Seals/boot damaged or missing.<br>Dust cap damaged or missing.<br>Row handle does not operate smoothly; pin does not extend. |
| 2        | •        |   | • | • |   | <b>Carrying Strap</b>       | Check strap for damage. Check buckle for signs of distortion or cracks.  | Outward signs of damage.  |
| 3        | •        | • | • | • |   | Tee Connector               | Check for damaged body, and signs of leaks or cracks.<br>Check body for seals/boot damage or loss.<br>Check dust caps for damage or loss.  | Outward signs of damage or leakage.<br>Seals/boot damaged or missing.<br>Dust cap damaged or missing.   |

**Table 2-1. Preventive Maintenance Checks and Services (PMCS) (Cont.)**

B-Before D-During A-After W-Weekly M-Monthly

| Item No. | Interval |   |   |   |   | Item to be Inspected         | Procedures<br>Check for and have<br>Repair or adjusted  | or Readiness Reporting, Equipment is Not Ready/Available If:  |
|----------|----------|---|---|---|---|------------------------------|---|---|
|          | B        | D | A | W | M |                              |   |   |
| 4        | •        | • | • | • |   | <b>2 Inch Discharge Hose</b> | <p>Check for damaged valve bodies on hose and signs of leaks or cracks.</p> <p>Check camlock body for gasket damage or loss.</p> <p>Check cam arms for cracks or damage.</p> <p>Check sexless body for seals/boot damage or loss.</p> <p>Check dust cap for damage or loss.</p> <p>Open flow handle and check for interlocking pin extension on connector face.</p> | <p>Outward signs of damage or leakage.</p> <p>Gasket damaged or missing.</p> <p>Outward signs of damage.</p> <p>Seals/boot damaged or missing.</p> <p>Dust cap damaged or missing.</p> <p>Flow handle does not operate smoothly; pin does not extend.</p> |
| 5        | •        | • | • | • |   | Elbow connector              | <p>Check for damaged body, and signs of leaks or cracks.</p> <p>Check body for seals/boot damage or loss.</p> <p>Check dust caps for damage or loss.</p> <p>Check interlock pin for damage or loss.</p>   | <p>Outward signs of damage or leakage.</p> <p>Seals/boot damaged or missing.</p> <p>Dust cap damaged or missing.</p> <p>Interlock pin damaged or missing.</p>   |
| 6        |          |   |   |   |   | DELETED                      |   |   |
| 7        | •        | • | • | • |   | Adapters-Valved              | <p>Check for damaged body, and signs of leaks or cracks.</p> <p>Check body for seals/boot damage or loss.</p> <p>Check dust caps for damage or loss.</p> <p>Check camlock body for gasket damage or loss.</p> <p>Check cam arms for cracks or damage.</p>   | <p>Outward signs of damage or leakage.</p> <p>Seals/boot damaged or missing.</p> <p>Dust cap damaged or missing.</p> <p>Gasket damaged or missing.</p> <p>Outward signs of damage.</p>  |

**Table 2-1. Preventive Maintenance Checks and Services (PMCS) – Continued**

**NOTE:** Within designated interval, these checks are to be performed in the sequential order listed.

B - Before    D - During    A - After    W - Weekly    M - Monthly

| Item No. | Interval |   |   |   |   | Item to be Inspected | Procedures Check For and Have Repaired or Adjusted   | For Readiness Reporting, Equipment is Not Ready/Available if:  |
|----------|----------|---|---|---|---|----------------------|--|--|
|          | B        | D | A | W | M |                      |  |  |
| 8        | •        | • | • | • |   | Swivel Adapter       | Check for damaged body, and signs of leaks or cracks.<br><br>Check body for seals/boot damage or loss.<br><br>Check dust caps for damage or loss.<br><br>Check interlock pin for damage or loss.                               | Outward signs of damage or leakage.<br><br>Seals/boot damaged or missing.<br><br>Dust cap damaged or missing.<br><br>Interlock pin damaged or missing.         |
| 9        | Ž        | • | • |   |   | CCR Nozzle           | Refer to TM 5-4930-235-13&P.   |  |
| 10       | •        | • | • | • |   | Overwing Nozzle      | Check for damaged body, and signs of leaks or cracks.<br><br>Check dust caps for damage or loss.   | Outward signs of damage or leakage.<br><br>Dust cap damage or missing.   |
| 11       | •        | • | • | • |   | Recirculation Nozzle | Check for damaged body, and signs of leaks or cracks,<br><br>Check body for seals/boot damage or loss.<br><br>Check dust caps for damage or loss.<br><br>Check ground plug for loose/frayed cable and damage to plug or cable. | Outward signs of damage or leakage.<br><br>Seals/boot damaged or missing.<br><br>Dust cap damaged or missing.<br><br>Outward signs of damage or missing parts. |
| 12       | •        | • | Ž | • |   | D1 Nozzle            | Check plug and hose for damage or loss.<br><br>Check for damaged body, and signs of leaks or cracks.<br><br>Check body for seals/boot damage or loss.<br><br>Check dust caps for damage or loss.                               | Damaged or missing parts<br><br>Outward signs of damage or leakage.<br><br>Seals/boot damaged or missing.<br><br>Dust cap damaged or missing.                  |
| 13       | •        | • | • | • | • | Grounding Rod        | Check strainer for damaged or dirty screen.<br><br>Examine grounding rod for cracks in the striker and hanger assembly.  | Cracks in striker or hanger assembly.  |

Section III. OPERATION UNDER USUAL CONDITIONS

WARNING

Aviation fuel is highly flammable. No smoking or open flames are permitted during fueling operations or near refueling areas. Failure to comply can result in injury or death to personnel.

Proper eye protection must be worn. Failure to comply can result in loss of eyesight.

Ensure tanker grounding rod is installed and tanker is grounded prior to assembling HTARS system. Failure to comply can result in injury or death to personnel.

NOTE

The following procedures are for operation of four refueling hoses. If fewer lines are required, the quantity of parts must be adjusted.

2-4. Connection of System Components. (See Figure 2-1.)

(1) To install the grounding rod (55) use the striker assembly (56) to drive the grounding rod (55) into the ground approximately 10 feet back from the refueling nozzle.

Table 2-2. Required Depths for Ground Rods.

NOTE

In cases where the conductivity of the soil is questionable, chemicals can be used to condition the soil and raise the conductivity. Refer to FM 10-68, Chapter 7, Section III, for specific procedures and chemicals required.

| <u>Type of soil</u>  | <u>Depth of Ground Rod</u> |
|--|----------------------------|
| Course ground, cohesionless sands, and gravels.  | 6 feet                     |
| Inorganic clay, claying gravels, gravel-sand-clay, claying sands, sandy clay, gravelly clay, and silty clay, | 4 feet                     |
| Silty gravel, gravel-sand-silt, silty sand, sand, silt, peat, muck, and swamp soil.                          | 3 feet                     |

(2) Ensure that the grounding rod (55) is driven into the ground at least 3 feet, as shown in Table 2-2.

(3) Move the refueling nozzle and hose assembly back to the point where the refueling nozzle can be hung on the grounding rod (55).

(4) Hang the refueling nozzle on the hanger assembly (57).

(5) Loop the last 10 feet of hose back over itself. No portion of the hose should extend past the hanger assembly (57).

**WARNING**

Do not force handle of Dry-Loc connectors to the open position. Damage to the interlocking mechanism can result in an inadvertent disconnect and subsequent fuel discharge during operation. Failure to comply can result in injury or death to personnel or damage to equipment. If flow handle fails to operate smoothly or hose connectors fail to lock with flow handle in the open position, refer to table 3-1, Troubleshooting.

**CAUTION**

Do not throw or drag hose on ground. Do not walk on hose. All flow handles must be facing up. Failure to comply can result in damage to hose and end connectors. Ground tanker prior to assembling HTARS system.

Refer to TM 9-2320-279-10-1. operator's Manual for HEMTT tanker refueling procedures.

- b. Connect 3 inch discharge hose (1) to suction hose on HEMTT tanker as follows:
  - (1) Remove carrying strap (7) from 3 inch discharge hose (1).
  - (2) Roll 3 inch discharge hose (1) out flat and straight on ground behind truck.
  - (3) Pull cam arms (4) away from body.
  - (4) Slide end over camlock coupling.
  - (6) Push cam arms (4) against body.
- c. Connect tee connectors (8), 2 inch discharge hose (11), and elbow connectors (14) as follows:
  - (1) Remove dust caps (9) from center of one tee connector (8).
  - (2) Connect tee connector (8) to 3 inch discharge hose (1).
  - (3) Remove carrying straps (7) from two 2 inch discharge hoses (11).
  - (4) Roll both 2 inch discharge hoses (11) out flat and straight on ground on each side of tee connector (8).
  - (5) Remove dust caps (9) from both 2 inch discharge hoses (11).
  - (6) Connect both 2 inch discharge hoses (11) to tee connector (8).
  - (7) Remove dust caps (9) from two tee connectors (8).
  - (8) Connect one tee connector (8) to each 2 inch discharge hose (11).
  - (9) Remove carrying straps (7) from four 2 inch discharge hoses (11).
  - (10) Roll 2 inch discharge hoses (11) out flat and straight near tee connectors (8).
  - (11) Remove dust caps (9) from tee connectors (8) and 2 inch discharge hoses (11).
  - (12) Connect both 2 inch discharge hoses (11) to tee connectors (8).
  - (13) Connect 2 inch discharge hoses (11) together.
  - (14) Remove one dust cap (15) from each elbow connector (14).



- (16) Connect one elbow connector (14) to each 2 inch discharge hose (11).
- (16) Remove carrying straps (7) from four 2 inch discharge hoses (11).
- (17) Roll a 2 inch discharge hose (11) out on ground near tee and elbow connectors (8 and 14).
- (18) Remove dust caps (9 and 15) from tee and elbow connectors (8 and 14).
- (19) Remove dust caps (12) from 2 inch discharge hoses (11).
- (20) Connect a 2 inch discharge hose (11) to each tee or elbow connector (8 and 14).
- (21) Connect all dust caps.

d. DELETED

e. If required, attach adapters (20, 23, 26 or 30) as follows:

- (1) Remove dust cap (15) from 2 inch discharge hose (11).
- (2) Remove dust cap (21, 24, 27, or 31) from adapter (20, 23, 26, or 30).
- (3) Connect from 2 inch discharge hose (11) to adapter (20, 23, 26, or 30).
- (4) Install grounding rod (66) at each refueling point in the system.

f. Put FLOW handles (2, 6, 10, and 13) in flow position.

**2-5. Connection of CCR Nozzle.**

**CAUTION**

Immediately drain a substantial portion of the fuel from the nozzle whenever the valve on the hose attached to it is turned to off or the nozzle is removed from the system. The trapped fuel can create large internal pressure that can damage the nozzle when the temperature rises.

- a. Remove dust cap (15) from 2 inch discharge hose (11).
- b. Connect CCR nozzle (33) to 2 inch discharge hose (11). Refer to TM 5-4930-235-13&P for details.
- c. Haag CCR Nozzle (33) on grounding rod hanger assembly (57).
- d. As required, repeat steps a. and b. for each CCR nozzle (33).
- e. Connect all dust caps.

**2-6. Connection of Overwing Nozzle.**

- a. Remove dust cap (36) from overwing nozzle (34).
- b. Remove outlet cap from CCR nozzle (33). Refer to TM 5-4930-235-13&P for details.

- c. Insert inlet end of overwing nozzle (34) in outlet end of CCR nozzle (33).
- d. As required, repeat steps a., b., and c. for each overwing nozzle (34).

**2-7. Connection of Recirculation Nozzle.**

- a. Remove dust cap (40) from recirculation nozzle (38).
- b. Remove outlet cap from CCR nozzle (33). Refer to TM 5-4930-235-13&P for details
- c. Insert inlet end of recirculation nozzle (38) in outlet end of CCR nozzle (33).

**2-8. Connection of D1 Nozzle.**

- a. Remove dust cap (15) from 2 inch discharge hose (11).
- b. Remove dust cap (50) from D1 nozzle (48).
- c. Connect D1 nozzle (48) to 2 inch discharge hose (11).
- d. As required, repeat steps a., b., and c. for each D1 nozzle (48).
- e. Connect all dust caps.

**2-9. Operation of CCR Nozzle. Refer to TM 5-4930-235-13&P for details.**

**2-10. Operation of Overwing Nozzle.**

- a. Wipe around fuel receptacle with a clean cloth (Item 1, Appendix D) to remove dirt or dust.
- b. Remove fuel cap from fuel receptacle.
- c. Remove dust cap (35) and insert end of overwing nozzle (34) in fuel receptacle.

**NOTE**

Handle on CCR nozzle must be in FLOW position. Refer to TM 5-4930-235-13&P for details.

- d. Pull handle (37) and hold open to dispense fuel to aircraft.
- e. When fuel tank is full, release handle (37) and shut off fuel pump.
- f. Remove overwing nozzle (34) from fuel receptacle and install dust cap (35).
- g. Install fuel cap on fuel receptacle.
- h. Wipe exterior of overwing nozzle (34) and fuel receptacle with a clean cloth (Item 1, Appendix D) to remove dust or fuel.

**CAUTION**

Do not leave nozzle laying on ground. Failure to comply can result in damage.

- i. Place overwing nozzle (34) in storage container away from aircraft.

## 2-11. Operation of Recirculation Nozzle.

### **WARNING**

Ground and bonding plugs must be connected before attaching nozzle to aircraft. Failure to comply can result in injury or death to personnel from static discharge.

- a. Connect ground and bonding plugs (42) to aircraft.
- b. Wipe around fuel receptacle with a clean cloth (Item 1, Appendix D) to remove dirt or dust.
- c. Remove fuel cap from fuel receptacle.

### **CAUTION**

Be sure plug (45) is installed in nozzle and hand-tight. Failure to comply can result in fuel leakage.

- d. Remove dust cap (39).
- e. Connect recirculation nozzle (38) to fuel receptacle as follows:
  - (1) Grasp handle grips and align inlet with fuel receptacle.
  - (2) Press recirculation nozzle (38) against fuel receptacle and turn to align pins.
  - (3) Push recirculation nozzle (38) against fuel receptacle and turn clockwise until nozzle stops.

### **NOTE**

Handle on CCR nozzle must be in FLOW position. Refer to TM 6-4930-236-13&P for details.

- f. Put FLOW handle (41) in flow position.
- g. When fuel tank is full put FLOW handle (41) in closed position.
- h. Turn counterclockwise and remove recirculation nozzle (38) from fuel receptacle and install dust cap (39).

**2-12. Operation of D1 Nozzle.**

- a. Wipe around fuel receptacle with a clean cloth (Item 1, Appendix D) to remove dirt or dust.
- b. Remove fuel cap from fuel receptacle.
- c. Remove dust cap (49).
- d. Connect D1 nozzle (48) to fuel receptacle as follows
  - (1) Grasp handle grips and align inlet with fuel receptacle.
  - (2) Press D1 nozzle (48) against fuel receptacle and turn to align pins.
  - (3) Push D1 nozzle (48) against fuel receptacle and turn clockwise until nozzle stops.
- e. Turn flow handle (54) to full OPEN position.
- f. When fuel tank is full turn flow handle (54) to CLOSED position.
- g. Turn D1 nozzle (48) counterclockwise and remove from fuel receptacle.
- h. Install dust cap (49).
- i. Install fuel cap on fuel receptacle.
- j. Wipe exterior of D1 nozzle (48) and fuel receptacle with a clean cloth (Item 1, Appendix D) to remove dust or fuel.

**CAUTION**

Do not leave nozzle laying on ground. Failure to comply can result in damage.

- k. Place D1 nozzle (48) in storage container away from aircraft.



**2-13. Disconnection of D1 Nozzle.****CAUTION**

Immediately drain a substantial portion of the fuel from the nozzle whenever the valve on the hose attached to it is turned to off or the nozzle is removed from the system. The trapped fuel can create large internal pressure that can damage the nozzle when the temperature rises.

**NOTE**

A suitable container should be available to catch fuel spillage.

- a. Close FLOW handle (13) on 2 inch discharge hose (11).
- b. Pull interlock pin (51) and remove D1 nozzle (48) 2 inch discharge hose (11).
- c. Install dust cap (50) on D1 nozzle (48).
- d. Install dust cap (12).

**2-14. Disconnection of Recirculation Nozzle.****NOTE**

A suitable container should be available to catch fuel spillage.

- a. Remove recirculation nozzle (38) from CCR nozzle (33). Refer to TM5-4930-235-13&P for details.
- b. Install dust cap (40).

**2-15. Disconnection of Overwing Nozzle.****NOTE**

A suitable container should be available to catch fuel spillage.

- a. Remove overwing nozzle (34) from CCR nozzle (33). Refer to TM5-4930-235-13&P for details.
- b. Install dust cap (36).

**2-16. Disconnection of CCR Nozzle.**

- a. Refer to TM5-4930-235-13&P for details.
- b. Install dust cap (12).

**2-17. Disconnection of System Components.****CAUTION**

Do not throw or drag hose on ground. Do not walk on hose. Failure to comply can result in damage to hose and end connectors.

With FLOW handle in flow position, interlock pins hold components together. FLOW handles must be closed to disconnect components. Failure to comply can result in severe damage to parts.

**NOTE**

A suitable container should be available to catch fuel spillage.

a. If installed, disconnect adapters (20, 23, 26, or 30) as follows:

(1) **DELETED**

(2) Disconnect adapter (20, 23, 26, or 30) from 2 inch discharge hose (11).

(3) Install dust cap (21, 24, 27, or 31) on adapter (20, 23, 26, or 30).

(4) Install dust cap (12).

b. **DELETED**

c. Operate HEMTT tanker to evacuate fuel. Refer to TM9-2320-279-10-1 for details.

d. Disconnect 2 inch discharge hose (11) and elbow connector (14) as follows:

(1) Close FLOW handles (13).

(2) Pull interlock pin (16).

(3) Disconnect 2 inch discharge hose (11) from elbow connector (14).

(4) Install dust cap (12) on 2 inch discharge hose (11).

(5) Install dust cap (15) on elbow connector (14).

(6) Pull interlock pin (16) and disconnect elbow connector (14) from 2 inch discharge host (11).

(7) Install dust cap (15) on elbow connector (14).

(8) Repeat steps (1) through (7) for other 2 inch discharge hose (11) and elbow connector (14).

e. Disconnect 2 inch discharge hoses (11) and tee connectors (8) as follows:

(1) Close FLOW handles (10 and 1.3).

(2) Disconnect 2 inch discharge hose (11) from tee connector (8).

(3) Install dust cap (12) on 2 inch discharge hose (11).

(4) Install dustcap (9) on tee connector (8).

(5) Repeat steps (1) through (4) for other 2 inch discharge hoses (11) and tee connectors.

*f.* Disconnect tee connector (8) and 3 inch discharge hose (1) as follows:

- (1) Close FLOW handles (2 and 6).
- (2) Disconnect tee connector (8) from 3 inch discharge hose (1).
- (3) Install dust cap (5) on 3 inch discharge hose (1).
- (4) Install dust cap (9) on tee connector (8).

*g.* Disconnect 3 inch discharge hose (1) from suction hose on HEMTT tanker as follows:

- (1) Pull cam arms (4) away from body.
- (2) Slide end off camlock coupling on tanker.
- (3) Push cam arms (4) against body.

#### **CAUTION**

Do not walk on hose to flatten or remove fuel residue. Failure to comply can result in damage to hose and end connectors.

#### **NOTE**

It maybe necessary to remove a dust cap and open a FLOW handle at one end to drain fuel residue.

*h.* Roll discharge hoses (1 or 11) into a tight coil and secure with carrying strap (7).

*i.* Wipe equipment with a clean cloth (Item 1, Appendix D) to remove dirt, dust, moisture, and fuel.

*j.* Store equipment in storage box on tanker. Refer to TM9-2320-279-10-1 for details.

### **2-18. Preparation For Storage or Shipment.**

#### **NOTE**

The following procedures are for government storage and shipment between units. For shipping instructions on warranty repairs refer to TB5-4930-237-23.

- a.* Wipe equipment with a clean cloth (Item 1, Appendix D).
- b.* Inspect equipment for damaged or missing parts. Report any problems to your supervisor.
- c.* Place equipment in a water-vaporproof bag. Tape or seal bag.
- d.* Place cushioning material and equipment in fiberboard container.
- e.* Add cushioning material to fiberboard container to prevent movement of equipment.
- f.* Seal lid of fiberboard container with masking tape (item 2, Appendix D).



*g.* Mark the following information on outside of fiberboard container.

- (1) Description.
- (2) Part Number.
- (3) National Stock Number.
- (4) Serial Number.
- (5) Date Packaged.
- (6) Date repaired (if applicable).

*h.* Store fiberboard container in an area protected from extreme weather conditions such as; heat, rain, snow, humidity, sand, and direct sunlight.

#### **2-19. Administrative Storage.**

*a.* Placement of equipment in administrative storage should be for short periods of time when a shortage of maintenance effort exists. Items should be in mission readiness within 24 hours or within the time factors as determined by the directing authority. During the storage period appropriate maintenance records will be kept.

*b.* Before placing equipment in administrative storage, complete current maintenance services and equipment serviceable criteria (ESC) evaluation, correct shortcomings and deficiencies, and apply all modification work orders (MWO's).

*c.* Storage site selection. Inside storage is preferred for equipment selected for administrative storage. If inside storage is not available, use trucks, vans, conex containers, and other containers.

### **Section IV. OPERATION UNDER UNUSUAL CONDITIONS**

**2-20. Operation Under Unusual Conditions.** Operating instructions under usual conditions are acceptable; however, the following shall be observed.

*a.* Operation in Unusual Weather, After use, equipment shall be wiped with a clean cloth (Item 1, Appendix D) to remove dust, dirt, fuel, moisture, snow, or mud. Store equipment in tanker storage box.

*b.* Dust Caps. Dust caps shall be installed when equipment is not in use. Equipment shall not be installed dirty or wet.

## CHAPTER 3

### OPERATOR MAINTENANCE INSTRUCTIONS

---

#### Section I. LUBRICATION INSTRUCTIONS

No lubrication is required for operation of this equipment.

#### Section II. TROUBLESHOOTING PROCEDURES

**3-1. General.** This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

**3-2. Troubleshooting.** Table 3-1 lists the common malfunctions which may occur during operation or maintenance of HTARS or it's components. Perform test/inspections and corrective actions in the order listed.

#### NOTE

Before using the table, be sure all applicable operating checks have been performed.

*Table 3-1. Troubleshooting*

---

| Malfunction | Test or Inspection | Corrective Action |
|-------------|--------------------|-------------------|
|-------------|--------------------|-------------------|

---

#### 3 INCH DISCHARGE HOSE

##### 1. FLOW HANDLE FAILS TO OPERATE SMOOTHLY.

Step 1. Inspect FLOW handle area for signs of dirt or other foreign matter.

Clean area around FLOW handle.

Step 2. Remove dust cap and inspect interior for dirt or other foreign matter.

Rinse in clean fuel while operating FLOW handle. If parts are missing or damaged, replace 3 inch discharge hose.

---

*Table 3-1. Troubleshooting - Continued*

Malfunction

Test or Inspection

Corrective Action

**3 INCH DISCHARGE HOSE - Continued****2. LEAKAGE FROM CAMLOCK END.**

Step 1. Disconnect hose from tee connector. Inspect inside for gasket. Inspect gasket for cuts, tears, or distortion.

If gasket is missing or damaged, replace 3 inch discharge hose.

Step 2. Inspect cam arms for damage or distortion.

If cam arms are damaged, replace 3 inch discharge hose.

**3. LEAKAGE FROM SEXLESS END.**

Step 1. Disconnect hose from tee connector. Inspect inside for dust seals. Inspect dust seals for cuts, tears, or distortion.

If dust seals are missing or damaged, install new dust seals.

Step 2. Inspect boot for cuts, tears, or distortion.

If boot is missing or damaged, replace 3 inch discharge hose.

**4. LEAKAGE FROM HOSE.**

Inspect hose for cracks, abrasions, or damage.

If damage extends through hose, replace 3 inch discharge hose.

**5. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER (FLOW HANDLES IN OPEN POSITION).**

Close FLOW handles and disconnect parts. Open FLOW handle (on hose) and see if interlock pin extends.

If interlock pin does not extend or is damaged, replace 3 inch discharge hose.

**6. DUST CAP DAMAGED OR MISSING.**

Inspect dust cap for cracks or distortion.

If dust cap is missing or damaged, replace 3 inch discharge hose.

**Table 3-1. Troubleshooting - Continued**

---

**Malfunction****Test or Inspection****Corrective Action**

---

**TEE CONNECTOR****1. FLOW HANDLE(S) FAILS TO OPERATE SMOOTHLY.**

Step 1. Inspect FLOW handle area for signs of dirt or other foreign matter.

Clean area around FLOW handle.

Step 2. Remove dust cap and inspect interior for dirt or other foreign matter.

Rinse in clean fuel while operating FLOW handle. If parts are missing or damaged, replace tee connector.

**2. LEAKAGE FROM END(S).**

Step 1. Disconnect hose(s) from tee connector. Inspect inside for dust seals. Inspect dust seals for cuts, tears, or distortion.

If dust seals are missing or damaged, install new dust seals.

Step 2. Inspect boots for cuts, tears, or distortion.

If boots are missing or damaged, replace tee connector.

**3. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER (FLOW HANDLES IN OPEN POSITION).**

Close FLOW handles and disconnect parts. Open FLOW handle (on hose) and see if interlock pin extends.

If interlock pin does not extend or is damaged, replace tee connector.

**4. DUST CAP(S) DAMAGED OR MISSING.**

Inspect dust cap(s) for cracks or distortion.

If dust cap(s) is missing or damaged, replace tee connector.

---

**Table 3-1. Troubleshooting - Continued**


---

Malfunction

Test or Inspection

Corrective Action

---

### 2 INCH DISCHARGE HOSE

**1. FLOW HANDLE(S) FAILS TO OPERATE SMOOTHLY.**

Step 1. Inspect FLOW handle area for signs of dirt or other foreign matter.

Clean area around FLOW handle.

Step 2. Remove dust cap and inspect interior for dirt or other foreign matter.

Rinse in clean fuel while operating FLOW handle. If parts are missing or damaged, replace 2 inch discharge hose.

**2. LEAKAGE FROM END(S).**

Step 1. Disconnect hose from tee or elbow connector. Inspect inside for dust seals. Inspect dust seals for cuts, tears, or distortion.

If dust seals are missing or damaged, install new dust seals.

Step 2. Inspect boots for cuts, tears, or distortion.

If boots are missing or damaged, replace 2 inch discharge hose.

**3. LEAKAGE FROM HOSE.**

Inspect hose for cracks, abrasions, or damage.

If damage extends through hose, replace 2 inch discharge hose.

**4. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER (FLOW HANDLES IN OPEN POSITION)**

Close FLOW handles and disconnect parts. Open FLOW handle (on hose) and see if interlock pin extends.

If interlock pin does not extend or is damaged, replace 2 inch discharge hose.

**5. DUST CAP(S) DAMAGED OR MISSING.**

Inspect dust cap(s) for cracks or distortion.

If dust cap(s) is missing or damaged, replace 2 inch discharge hose.

Table 3-1. Troubleshooting - Continued

| Malfunction   | Test or Inspection   | Corrective Action   |
|---|--|---|
| <b>ELBOW CONNECTOR</b>  |  |   |
|   |  |   |
| 1. LEAKAGE FROM END(S).   |  |   |
|   | Step 1. Disconnect hose(s) from elbow connector. Inspect inside for dust seals. Inspect dust seals for cuts, tears, or distortion. | If dust seals are missing or damaged, install new dust seals.             |
|   | Step 2. Inspect boots for cuts, tears, or distortion.  | If boots are missing or damaged, replace elbow connector.                 |
| 2. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER (FLOW HANDLES IN OPEN POSITION). |  |   |
|   | Close FLOW handles and disconnect parts. Check interlock pin(s) for damage, distortion, or missing parts.                          | If interlock pin(s) is damaged or missing parts, replace elbow connector. |
| 3. DUST CAP(S) DAMAGED OR MISSING.  |  |   |
|   | Inspect dust cap(s) for cracks or distortion.  | If dust cap(s) is missing or damaged, replace elbow connector.            |

Information on page 3-6 has been deleted.



Table 3-1. Troubleshooting - Continued

| Malfunction  | Test or Inspection  | Corrective Action  |
|--|---|--|
| <b>ADAPTERS -VALVED</b>  |   |  |
| 1. FLOW HANDLE FAILS TO OPERATE SMOOTHLY.                                    |   |  |
|  | Step 1. Inspect FLOW handle area for signs of dirt or other foreign matter.               | Clean area around FLOW handle.   |
|  | Step 2. Remove dust cap and inspect interior for dirt or other foreign matter.            | Rinse in clean fuel while operating FLOW handle. If parts are missing or damaged, replace adapter. |
| 2. LEAKAGE FROM END.   |   |  |
|  | Step 1. Disconnect adapter from 2 inch discharge hose (11). Inspect inside for dust seal. | Inspect dust seal for cuts, tears, or distortion.  |
|  |   | If dust seal is missing or damaged, install new dust seal.   |
|  | Step 2. Inspect boot for cuts, tears, or distortion.                                      | If hoot is missing or damaged, replace adapter.  |
| 3. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER (FLOW HANDLE IN OPEN POSITION). |   |  |
|  | Disconnect parts. Check interlock pin(s) for damage, distortion, or missing parts.        | If interlock pin is damaged or missing parts, replace adapter.                                     |
| 4. DUST CAP DAMAGED OR MISSING.  |   |  |
|  | Inspect dust cap for cracks or distortion.  | If dust cap is missing or damaged, replace adapter.  |



Table 3-1. Troubleshooting - Continued

| Malfunction   | Test or Inspection  | Corrective Action   |
|---|---|---|
| <b>SWIVELADAPTER</b>  |   |   |
| 1. LEAKAGE FROM END.  |   |   |
|   | Step 1. Disconnect adapter from 2 inch discharge hose (11). Inspect inside for dust seal. Inspect dust seal for cuts, tears, or distortion. | If dust seal is damaged or distorted install new dust seal.           |
|   | Step 2. Inspect boot for cuts, tears, or distortion.  | If boot is missing or damaged, replace swivel adapter.                |
| 2. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER.               |   |   |
|   | Disconnect parts. Check interlock pin(s) for damage, distortion, or missing parts.  | If interlock pin is damaged or missing parts, replace swivel adapter. |
| 3. DUST CAP DAMAGED OR MISSING.                             |   |   |
|   | Inspect dust cap for cracks or distortion.  | If dust cap is missing or damaged, replace swivel adapter.            |
| <b>CCR NOZZLE</b> - Refer to TM5-4930-235-13&P for details. |   |   |

**Table 3-1. Troubleshooting - Continued**

| Malfunction   | Test or Inspection   | Corrective Action |
|---|--|-------------------|
| <hr/>   |  |                   |
| <b>OVERWING NOZZLE</b>  |  |                   |
| <b>1. FLOW HANDLE FAILS TO OPERATE SMOOTHLY.</b>  |  |                   |
|   | Inspect flow handle area for signs of dirt or other foreign matter.  |                   |
|   | Clean area around flow handle.   |                   |
| <b>2. LEAKAGE FROM OUTLET END.</b>  |  |                   |
|   | Step 1. Check flow handle and pivot area for sticking or binding (this can hold valve open).                                 |                   |
|   | Clean flow handle and pivot area. If still leaking, replace overwing nozzle.   |                   |
|   | Step 2. Operate flow handle to see if valve is operating smoothly.   |                   |
|   | If valve is sticking or binding replace overwing nozzle.   |                   |
| <b>3. INADEQUATE FUEL FLOW.</b>   |  |                   |
| <b>NOTE</b>   |  |                   |
| Before performing the following steps be sure CCR Nozzle is operating properly and strainer is clean. Refer to TM5-4930-235-13&P for details. |  |                   |
|   | Step 1. Operate flow handle to see if valve is operating smoothly.   |                   |
|   | If valve is sticking or binding replace overwing nozzle.   |                   |
|   | Step 2. Disconnect overwing nozzle from CCR nozzle. Press on inlet valve to be sure it operates without sticking or binding. |                   |
|   | If inlet valve is sticking or binding replace overwing nozzle.   |                   |

**Table 3-1. Troubleshooting - Continued**

Malfunction

Test or Inspection

Corrective Action

---

**RECIRCULATION NOZZLE**

**1. FLOW HANDLE FAILS TO OPERATE SMOOTHLY.**

Step 1. Inspect FLOW handle area for signs of dirt or other foreign matter.

Clean area around FLOW handle.

Step 2. Connect nozzle to aircraft receptacle. Operate FLOW handle several times to check for sticking or binding.

If FLOW handle is sticking or binding, replace recirculation nozzle.

**2. LEAKAGE FROM OUTLET END.**

Step 1. Remove dust cap and inspect inside for dust seal. Inspect dust seal for cuts, tears, or distortion.

If dust seal is missing or damaged, replace recirculation nozzle.

Step 2. Inspect boot for cuts, tears, or distortion.

If boot is missing or damaged, replace recirculation nozzle.

**3. INADEQUATE FUEL FLOW.**

**NOTE**

Before performing the following step be sure CCR Nozzle is operating properly and strainer is clean. Refer to TM5-4930-235-13&P for details.

Operate FLOW handle to see if valve is operating smoothly (use ground plug to release flow handle).

If valve is sticking or binding, replace recirculation nozzle.

**4. RECIRCULATION NOZZLE WILL NOT DISPENSE FUEL.**

Step 1. Put FLOW handle in flow position. Inspect for strainer housing. Remove strainer housing and inspect for damage or distortion.

If strainer housing is missing or damaged, replace recirculation nozzle.

---

**Table 3-1. Troubleshooting - Continued**

| Malfunction  | Test or Inspection  | Corrective Action |
|--|---|-------------------|
| <hr/>  |   |                   |
| <b>D1 NOZZLE</b>                                     |   |                   |
| <b>1. FLOW HANDLE FAILS TO OPERATE SMOOTHLY.</b>     |   |                   |
|  | Step 1. Inspect flow handle area for signs of dirt or other foreign matter.   |                   |
|  | Clean area around flow handle.  |                   |
|  | Step 2. Connect nozzle to aircraft receptacle. Operate flow handle several times to check for sticking or binding,    |                   |
|  | If flow handle is sticking or binding, replace D1 nozzle.   |                   |
| <b>2. LEAKAGE FROM OUTLET END.</b>                   |   |                   |
|  | Step 1. Remove dust cap and inspect inside for seal. Inspect seal for cuts, tears, or distortion.                     |                   |
|  | If seal is missing or damaged, replace D1 nozzle.   |                   |
|  | Step 2. Inspect three interlock pins for damage or distortion. Press on end of each to check for sticking or binding. |                   |
|  | If interlock pins are missing or damaged, replace D1 nozzle.  |                   |
| <b>3. INADEQUATE FUEL FLOW.</b>                      |   |                   |
|  | Step 1. Remove dust cap, retainer, and strainer. Check strainer for dirt or other foreign matter.                     |                   |
|  | Clean strainer by removing all dirt and foreign matter.   |                   |
|  | Step 2. With nozzle installed on receptacle, check flow handle is fully opened.                                       |                   |
|  | If flow handle will not move or stay at full open position, replace D1 nozzle.  |                   |
| <b>4. SEXLESS COMPONENTS WILL NOT LOCK TOGETHER.</b> |   |                   |
|  | Disconnect parts. Check interlock pin(s) for damage, distortion, or missing parts.                                    |                   |
|  | If interlock pin is damaged or missing parts, replace D1 nozzle.  |                   |

**Table 3-1. Troubleshooting - Continued**


---

Malfunction

Test or Inspection

Corrective Action

---

**D1 NOZZLE - Continued**
**5. DUST CAP DAMAGED OR MISSING.**

Inspect dust cap for cracks or distortion.

If dust cap is missing or damaged, replace D1 nozzle.

---

**Section III. MAINTENANCE PROCEDURES**
**3-3. General.** This section contains maintenance procedures which are the responsibility of the operator.**3-4. Dust Seal.** (See Figure 3-1.)**INITIAL SETUP**

This task covers: Removal, Cleaning, Inspection, and Installation

Tools

None Required.

**Materials/Parts**

Lint-Free Cloth, MIL-C-85043 (Item 1, Appendix D)

---

*a. Removal.*
**NOTE**

A suitable container should be available to catch fuel spillage.

(1) Remove dust cap (1) from body (2).

(2) Remove a dust seal (3) from body (2) and dust cap (1).

**b. Cleaning.** Wipe dust cap (1), body (2), and dust seal (3) with a clean cloth to remove dust, dirt, or fuel.

c. Inspection.

(1) Inspect dust seal (3) for cuts, tears, or distortion.


(2) Dust seal (3) Shall be replaced if damaged.

d. Installation.

(1) Insert a dust seal (3) in groove of body (2) and dust cap (1).

(2) Using a fingertip, push around outside edge to seat dust seal (3) in groove.

(3) Install dust cap (1) on body (2).



14791A

Figure 3-1. Dust Seal Replacement

**3-5. D1 Nozzle Strainer.** (See Figure 3-2.)

**INITIAL SETUP**

This task covers: Removal, Cleaning, Inspection, and Installation

**Tools**

None Required.

**Material/Parts**

Lint-Free Cloth, MIL-C-85043 (Item 1, Appendix D)

a. Removal.

**NOTE**

A suitable container should be available to catch fuel spillage.

(1) Remove dust cap (1) from D1 nozzle (2),

(2) Remove retainer (3) and strainer (4) from D1 nozzle (2).

b. Cleaning. Wipe retainer (3) and strainer (4) with a clean cloth to remove dust, dirt, or fuel residue.

c. Inspection.

(1) Inspect retainer (3) and strainer (4) for cracks or distortion.


(2) If retainer (3) or strainer (4) are damaged D1 nozzle shall be replaced.

d. Installation.

(1) Install strainer (4) and retainer (3) in D1 nozzle (2).

(2) Using fingertips, push against end of retainer to seat parts in D1 nozzle (2).

(3) Install dust cap (1) on body (2).



**Figure 3-2. D1 Nozzle Strainer Inspection**

**APPENDIX A****REFERENCES**

**A-1. Scope.** This appendix lists all forms, field manuals, technical publications, and miscellaneous publications referenced in this manual.

**A-2. Forms.**

Equipment Daily or Monthly Log . . . . . DA Form 2408-1  
 Equipment inspection and Maintenance Work Sheet . . . . . DA Form 2404  
 Maintenance Request . . . . . DA Form 2407  
 Material Inspection and Receiving Report . . . . . DD Form 250  
 Quality Deficiency Report . . . . . SF 368  
 Recommended Changes to DA Publications and Blank Forms . . . . . DA Form 2028-2  
 Uncorrected Fault Record . . . . . DA Form 2408-14  
 Component Removal and Repair/Overhaul Record . . . . . DA Form 2408-16

**A-3. Technical Manuals.**

Procedures For Destruction of Army Equipment to Prevent Enemy Use . . . . . TM 750-244-3  
 The Army Maintenance Management System (TAMMS) . . . . . DA PAM 738-750  
 Operators, Unit, and Intermediate Direct Support Maintenance . . . . . TM 5-4930-235-13&P  
 Manual and Repair Parts and Special Tools List (CCR Nozzle Assembly)  
 Operator's Manual (Volume No. 1 for M978 Series, 8 x 8 Heavy . . . . . TM 9-2320-279-10-1  
 Expanded Mobility Tactical Trucks (HEMTT))

**A-4. Field Manuals.**

Aircraft Refueling . . . . . FM 10-68  
 Aviation Maintenance Quality Assurance/Quality Control . . . . . FM 55-411

**A-5. Technical Bulletins.**

Warranty Technical Bulletin . . . . . TB 5-4930-237-23

**A-6. Miscellaneous Publications.**

Expendable/Durable Items . . . . . CTA 50-970  
 Report of Discrepancy (ROD) . . . . . SF-364





## APPENDIX B

### COMPONENTS OF END ITEM/BASIC ISSUE ITEMS

---

#### Section I. INTRODUCTION

**B-1. Scope.** This appendix lists components of end item and basic issue items for HTARS to help you inventory items required for safe and efficient operation.

**B-2. General.** The Components of End Item/Basic Issue Items List is divided into the following sections:

*a. Section II. - Components of End Item.* This listing is for informal purposes only and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

*b. Section III - Basic Issue Items.* These are the minimum essential items required to place the equipment in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged, BII must be with the equipment during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request or requisition replacement BII, based on TOE/MTOE authorization of the end item.

**B-3. Explanation of Columns.** The following provides an explanation of columns found in the tabular listings.

*a. Column (1) - Illustration Number (Illus Number).* This column indicates the number of the illustration in which the item is shown.

*b. Column (2) - National Stock Number.* Indicates the National Stock Number assigned to the item and will be used for requisitioning purposes.

*c. Column (3) - Description.* Indicates the Federal item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the FSCM (in parentheses) followed by the part number.

*d. Column (4) - Unit of Measure (U/M).* Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g. ea, in, pr).

*e. Column (5) - Quantity Required (Qty rqr).* Indicates the quantity of the item authorized to be used with/on the equipment.

#### Section II. COMPONENTS OF END ITEM


Not Applicable

**Section III. BASIC ISSUE ITEMS**








| (1)<br>ILLUS/<br>ITEM NO. | (2)<br>NATIONAL STOCK<br>NUMBER | (3)<br>DESCRIPTION<br>CAGE AND PART NUMBER          | Usable<br>On<br>Code | (4)<br>U/M | (5)<br>QTY<br>RQR |
|---------------------------|---------------------------------|---|----------------------|------------|-------------------|
| 1                         | 4720-01-299-5983                | 3 Inch Discharge Hose<br>65154 50-0050              | N/A                  | EA         | 1                 |
| 2                         | 5340-01-298-9787                | Carrying Strap<br>00624 AE27389-004                 | N/A                  | EA         | 11                |
| 3                         | 4730-01-297-6812                | Tee Conbnecter<br>00624 AE88033R                    | N/A                  | EA         | 3                 |
| 4                         | 4720-01-298-0732                | 2 Inch Discharge Hose<br>65154 50-0049              | N/A                  | EA         | 10                |
| 5                         | 4730-01-297-3766                | Elbow Connector<br>00624 AE88036R                   | N/A                  | EA         | 2                 |
| 6                         |                                 | <b>DELETED</b>                                      |                      |            |                   |
| 7                         | 4730-01-298-0151                | Adapter - Valved<br>00624 AE88050R                  | N/A                  | EA         | 1                 |
| 8                         | 4730-01-297-3765                | Adapter - Valved<br>00624 AE88011P                  | N/A                  | EA         | 1                 |
| 9                         | 4730-01-298-0150                | Adapter - Valved<br>00624 AE88038R                  | N/A                  | EA         | 1                 |
| 10                        | 4730-001-296-9462               | Swivel Adapter<br>00624 AE86667R                    | N/A                  | EA         | 1                 |
| 11                        | 4930-01-289-2606                | CCR Nozzle (with sexless adapter)<br>19099 125-0505 | N/A                  | EA         | 4                 |
| 12                        | 4930-00-516-0839                | Overwing Nozzle<br>00624 AE86100Z                   | N/A                  | EA         | 4                 |
| 13                        | 4930-01-297-3776                | Recirculation Nozzle<br>00624 AE88013R              | N/A                  | EA         | 1                 |
| 14                        | 4930-01-297-3777                | D1 Nozzle (with sexless adapter)<br>65154 50-0052   | N/A                  | EA         | 4                 |

Section III. BASIC ISSUE ITEMS - Continued

| (1)<br>ILLUS/<br>ITEM NO. | (2)<br>NATIONAL STOCK<br>NUMBER | (3)<br>DESCRIPTION<br>CAGE AND PART NUMBER                                  | USABLE<br>ON CODE | (4)<br>U/M | (5)<br>QTY<br>RQR |
|---------------------------|---------------------------------|---|-------------------|------------|-------------------|
| N/A                       | 4720-01-278-8973                | HTARS Overpack Spares<br>19099 PD-HTARS-KIT                                 | N/A               | EA         | 1                 |
|                           |                                 | <b>NOTE</b><br><b>The following parts are in the HTARS Overpack Spares.</b> |                   |            |                   |
| 3                         | 4720-01-297-6812                | Tee Connector<br>00624 AE88033R   | N/A               | EA         | 1                 |
| 4                         | 4730-01-298-0732                | 2 Inch Discharge Hose<br>65154 50-0049                                      | N/A               | EA         | 1                 |
| 15                        |                                 | <b>DELETED</b>  |                   |            |                   |
| 2                         | 4730-01-298-9787                | Carrying Strap<br>00624 AE27389-004   | N/A               | EA         | 1                 |
| 16                        | 4930-01-237-3655                | DUSL Seal<br>00624 AE 18900-076   | N/A               | EA         | 10                |
| 17                        | 5340-01-285-5385                | Dust Cap<br>00624 AE82155R  | N/A               | EA         | 2                 |
| 18                        | 5975-01-050-5707                | Rod, Grounding  |                   | EA         | 4                 |
| N/A                       | N/A                             | Technical Manual<br>TM 5-4930-237-10  |                   | EA         | 1                 |
| N/A                       | N/A                             | Technical Warranty Manual<br>TB 5-4930-237-23                               |                   | EA         | 1                 |



15129A





**APPENDIX C**  
**ADDITIONAL AUTHORIZATION LIST**

---

**Section I. INTRODUCTION**

**C-1. Scope.** This appendix lists additional items you are authorized for support of the equipment.

**C-2. General.** The list identifies items that do not have to accompany the equipment and do not have to be turned in with it. These items are all authorized to you by CAT, MTOE, TDA, or JTA.

**C-3. Explanation of Listing.**

*a.* National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment. The items are listed in alphabetical sequence by item name under the type document (i.e. CTA, MTOE, TDA, or JTA) which authorizes the item to you.

*b.* If the item you require differs between serial numbers of the model, effective serial numbers are shown in the last line of the description. If item required differs for different models of this equipment, the model is shown under the "Usable On Code" heading in the description column.

**Section II. ADDITIONAL AUTHORIZATION LIST**

Not Applicable





## APPENDIX D

## EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

## Section I. INTRODUCTION

**D-1. Scope.** This appendix lists expendable/durable supplies and materials needed to operate and maintain the equipment. These items are authorized by CTA 50-970, Expendable Items (except Medical, Class V, Repair Parts in Heraldic Items).

**D-2. Explanation of Columns.**

*a. Column (1) - Item Number.* The number is assigned to the entry in the listing and is referenced in the listed item. These are as follows:

*b. Column (2) - Level.* This column identifies the lowest level of maintenance that requires the listed item. These are as follows:

- C - Operator/Crew
- O - Organizational Maintenance
- F - Direct Support Maintenance
- H - General Support Maintenance
- D - Depot Maintenance

*c. Column (3) - National Stock Number.* This is the national stock number assigned to the item, use it to request or requisition the item.

*d. Column (4) - Description.* Indicates the Federal item name and, if required, a description to identify the item. the last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

*e. Column (5) - Unit of Measure (U/M).* Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit that will satisfy the requirements.

## Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

| (1)<br>Item<br>Number | (2)<br>National Stock<br>Level | (3)<br>Number    | (4)<br>Description              | (5)<br>U/M |
|-----------------------|--------------------------------|------------------|---------------------------------|------------|
| 1                     | O                              | 7920-00-044-9281 | Cloth, Lint-free<br>MIL-C-85043 | 1 PK       |
| 2                     | O                              |                  | Tape, Masking                   | 1 RL       |



## INDEX

---

|   | Page |
|---|------|
| <b>A</b>  |      |
| Additional Authorization List .....                             | C-1  |
| Administrative Storage .....                                    | 2-20 |
| <b>B</b>  |      |
| Basic Issue Items (Table) .....                                 | B-2  |
| <b>C</b>  |      |
| Components of End Item/Basic Issue Items .....                  | B-1  |
| Connect ion of CCR Nozzle .....                                 | 2-14 |
| Connection of D1 Nozzle .....                                   | 2-14 |
| Connection of Overwing Nozzle .....                             | 2-14 |
| Connection of Recirculation Nozzle .....                        | 2-14 |
| Connection of System Components .....                           | 2-12 |
| <b>D</b>  |      |
| Description and Use of Operator's Controls and Indicators ..... | 2-1  |
| Destruction of Army Material to Prevent Enemy Use .....         | 1-2  |
| Disconnection of CCR Nozzle .....                               | 2-17 |
| Disconnection of D1 Nozzle .....                                | 2-17 |
| Disconnection of Overwing Nozzle .....                          | 2-17 |
| Disconnection of Recirculation Nozzle .....                     | 2-17 |
| Disconnection of System Components .....                        | 2-17 |
| II Nozzle Strainer:   |      |
| Cleaning .....  | 3-14 |
| Inspection .....  | 3-14 |
| Installation .....  | 3-14 |
| Removal .....   | 3-14 |
| Dust Seal:  |      |
| Cleaning .....  | 3-12 |
| Inspection .....  | 3-13 |
| Installation .....  | 3-13 |
| Removal .....   | 3-12 |
| <b>E</b>  |      |
| Equipment Characteristics, Capabilities, and Features .....     | 1-2  |
| Equipment Data .....  | 1-3  |
| Equipment Description and Data .....                            | 1-2  |
| Expendable/Durable Supplies and Materials List .....            | D-1  |
| Expendable/IDurable Supplies and Materials List (Table) .....   | D-1  |

**F**

|                 |     |
|-----------------|-----|
| Forms . . . . . | A-1 |
|-----------------|-----|

**I**

|  |      |
|--|------|
| Installation of Grounding Rod. . . . . | 2-12 |
|--|------|

**L**

|  |     |
|--|-----|
| Location and Description of Major Components . . . . . | 1-3 |
| Lubrication Instructions . . . . .                     | 3-1 |

**M**

|   |     |
|---|-----|
| Maintenance Forms, Records, and Reports . . . . . | 1-2 |
| Maintenance Procedures . . . . .                  | 3-  |
| Miscellaneous Publications.. . . .                | A-1 |

**O**

|   |      |
|---|------|
| Operator Preventive Maintenance Checks and Services . . . . . | 2-1  |
| Operator PMCS Procedures.. . . .                              | 2-8  |
| Operator's Controls and Indicators . . . . .                  | 2-1  |
| Operation of CCR Nozzle . . . . .                             | 2-14 |
| Operation of DI Nozzle . . . . .                              | 2-16 |
| Operation of Overwing Nozzle. . . . .                         | 2-14 |
| Operation of Recirculation Nozzle . . . . .                   | 2-15 |
| Operation Under Usual Conditions . . . . .                    | 2-12 |
| Operation Under Unusual Conditions . . . . .                  | 2-10 |

**P**

|   |     |
|---|-----|
| Preparation for Storage or Shipment . . . . . | 1-2 |
| Principles of Operation . . . . .             | 1-3 |

**Q**

|   |     |
|---|-----|
| Quality Assurance/Quality Control (QA/QC) . . . . . | 1-2 |
|---|-----|

**R**

|   |     |
|---|-----|
| Reporting Equipment improvement Recommendations (EIR's) . . . . . | 1-2 |
| References . . . . .  | A-1 |

**S**

|                                      |     |
|--------------------------------------|-----|
| Safety, Care, and Handling . . . . . | 1-2 |
| Scope . . . . .                      | 1-1 |

**T**

|                               |     |
|-------------------------------|-----|
| Technical Manuals . . . . .   | A-1 |
| Technical Bulletins . . . . . | A-1 |
| Troubleshooting . . . . .     | 3-1 |

**W**

|                                |     |
|--------------------------------|-----|
| Warranty Information . . . . . | 1-2 |
|--------------------------------|-----|

**By Order of the Secretary of the Army:**

**CARL E. VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official:**


**WILLIAM J. MEEHAN, II**  
*Brigadier General, United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-38-R, Operator Maintenance requirements for Truck, Cargo, 10-ton, 8x8, Heavy Expanded Mobility Tactical Truck, HEMTT, M977, M978, M983, M984, M985.

\* US GOVERNMENT PRINTING OFFICE 1989-654-030/00254



|  |                |   |              |  |  |
|--|----------------|---|--------------|--|--|
|  <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="font-size: small; margin: 0;">THEN . . . JOT DOWN THE<br/>DOPE ABOUT IT ON THIS<br/>FORM. CAREFULLY TEAR IT<br/>OUT. FOLD IT AND DROP IT<br/>IN THE MAIL!</p> </div> |                | SOMETHING WRONG   |              | WITH THIS PUBLICATION?   |  |
|  |                | FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)<br><div style="border: 1px solid black; height: 20px; margin-top: 5px;"></div> |              |  |  |
|  |                | DATE SENT<br><div style="border: 1px solid black; height: 20px; margin-top: 5px;"></div>                                  |              |  |  |
| PUBLICATION NUMBER<br><div style="border: 1px solid black; padding: 2px; margin-top: 2px;">TM 5-4930-237-10</div>  |                | PUBLICATION DATE<br><div style="border: 1px solid black; padding: 2px; margin-top: 2px;">Date of TM</div>                 |              | PUBLICATION TITLE<br>HEMTT Tanker Aviation Refueling<br>System (HTARS)   |  |
| BE EXACT. . . PIN-POINT WHERE IT IS  |                |   |              | IN THIS SPACE TELL WHAT IS WRONG<br>AND WHAT SHOULD BE DONE ABOUT IT:  |  |
| PAGE<br>NO.  | PARA-<br>GRAPH | FIGURE<br>NO.   | TABLE<br>NO. |  |  |
| B-1  |                | 4-3   |              | <p>Callout 16 on Figure 4-3 is pointing at a bolt. In key to Figure 4-3, Item 16 is called a shim. Please correct one or the other.</p> <p>Procedure for disconnecting hose, does not mention pulling interlock pin. Please add the step prior to removal of discharge hose.</p> |  |
| 2-18   | d.             |   |              |  |  |
| PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBERS<br><div style="display: flex; justify-content: space-between; margin-top: 5px;"> <span>Doe, John, CPL</span> <span>810- 755-1313</span> </div>   |                |   |              | SIGN HERE:<br><div style="border: 1px solid black; padding: 2px; margin-top: 5px;">CPL John Doe</div>  |  |

SAMPLE



FILL IN YOUR  
UNITS ADDRESS



DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

BUSINESS REPLY MAIL



FIRST CLASS

PERMIT NO. 82


ROCK ISLAND IL

POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL

Director  
Armament and Chemical Acquisition  
and Logistics Activity  
ATTN: AMSTA-AC-NML  
Rock Island, IL 61201-9948



TEAR ALONG PERFORATED LINE

|   |                   |  |   |   |
|---|-------------------|--|---|---|
|  |                   | SOMETHING WRONG  |   | WITH THIS PUBLICATION?  |
|   |                   | <p>THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!</p> |   | <p>FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)</p>                         |
| <p>PUBLICATION NUMBER<br/><b>TM 5-4930-237-10</b></p>                             |                   | <p>PUBLICATION DATE<br/><b>10 MAR 1989</b></p>   | <p>PUBLICATION TITLE<br/>HEMTT Tanker Aviation Refueling System (HTARS)</p> |   |
| <p>BE EXACT. . . PIN-POINT WHERE IT IS</p>  |                   |  |   | <p>IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:</p> |
| <p>PAGE NO.</p>   | <p>PARA-GRAPH</p> | <p>FIGURE NO.</p>  | <p>TABLE NO.</p>  |   |
|   |                   |  |   |   |
| <p>PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBERS</p>                        |                   |  |   | <p>SIGN HERE:</p>   |

**DA** FORM 1 JUL 79 **2028-2**

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNITS ADDRESS



DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

BUSINESS REPLY MAIL


FIRST CLASS

PERMIT NO. 82

ROCK ISLAND IL


POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL

Director  
Armament and Chemical Acquisition  
and Logistics Activity  
ATTN: AMSTA-AC-NML  
Rock Island, IL 61201-9948



TEAR ALONG PERFORATED LINE



|  |            |  |   |  |   |
|--|------------|--|---|--|---|
|  <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 150px;"> <p><i>THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!</i></p> </div> |            | SOMETHING WRONG                            |   | WITH THIS PUBLICATION?   |   |
|  |            | FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) |   | DATE SENT  |   |
| PUBLICATION NUMBER<br><div style="text-align: center; font-weight: bold;">TM 5-4930-237-10</div>   |            |  | PUBLICATION DATE<br><div style="text-align: center; font-weight: bold;">10 MAR 1989</div> |  | PUBLICATION TITLE<br>HEMTT Tanker Aviation Refueling System (HTARS) |
| BE EXACT. . . PIN-POINT WHERE IT IS  |            |  |   | IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT: |   |
| PAGE NO.   | PARA-GRAPH | FIGURE NO.                                 | TABLE NO.   |  |   |
|  |            |  |   |  |   |
| PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBERS  |            |  |   | SIGN HERE:   |   |

**DA** FORM 1 JUL 79 **2028-2**

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

**SAMPLE**

FILL IN YOUR  
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY


CPL John Doe

APO NY

PLACE  
POSTAGE  
HERE

TEAR ALONG PERFORATED LINE

Commander  
U.S. Army Tank-automotive and Armaments Command  
ATTN: AMSTA-AC-NML  
Rock Island, IL 61299-7630

|  |                |   |  |   |  |  |
|--|----------------|---|--|---|--|--|
|  <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p><i>THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!</i></p> </div> |                | SOMETHING WRONG                                   |  | WITH THIS PUBLICATION?  |  |  |
|  |                | <b>FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)</b> |  | <b>DATE SENT</b>  |  |  |
| <b>PUBLICATION NUMBER</b><br><div style="text-align: center; font-weight: bold;">TM 5-4930-237-10</div>  |                |   | <b>PUBLICATION DATE</b><br><div style="text-align: center; font-weight: bold;">10 MAR 1989</div> |   | <b>PUBLICATION TITLE</b><br>HEMTT Tanker Aviation Refueling System (HTARS) |  |
| <b>BE EXACT. . . PIN-POINT WHERE IT IS</b>   |                |   |  | <b>IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:</b> |  |  |
| PAGE<br>NO.  | PARA-<br>GRAPH | FIGURE<br>NO.                                     | TABLE<br>NO.   |   |  |  |
|  |                |   |  |   |  |  |
| <b>PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBERS</b>   |                |   |  | <b>SIGN HERE:</b>   |  |  |

**DA** FORM 1 JUL 79 **2028-2**

 PREVIOUS EDITIONS  
ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNITS ADDRESS



DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

BUSINESS REPLY MAIL


FIRST CLASS

PERMIT NO. 82

ROCK ISLAND IL

POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL

Director  
Armament and Chemical Acquisition  
and Logistics Activity  
ATTN: AMSTA-AC-NML  
Rock Island, IL 61201-9948



TEAR ALONG PERFORATED LINE



# The Metric System and Equivalents

## Linear Measure

1 centimeter = 10 millimeters = .39 inch  
 1 decimeter = 10 centimeters = 3.94 inches  
 1 meter = 10 decimeters = 39.37 inches  
 1 dekameter = 10 meters = 32.8 feet  
 1 hectometer = 10 dekameters = 328.08 feet  
 1 kilometer = 10 hectometers = 3,280.8 feet

## Weights

1 centigram = 10 milligrams = .15 grain  
 1 decigram = 10 centigrams = 1.54 grains  
 1 gram = 10 decigrams = .035 ounce  
 1 dekagram = 10 grams = .35 ounce  
 1 hectogram = 10 dekagrams = 3.52 ounces  
 1 kilogram = 10 hectograms = 2.2 pounds  
 1 quintal = 100 kilograms = 220.46 pounds  
 1 metric ton = 10 quintals = 1.1 short tons

## Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce  
 1 deciliter = 10 centiliters = 3.38 fl. ounces  
 1 liter = 10 deciliters = 33.81 fl. ounces  
 1 dekaliter = 10 liters = 2.64 gallons  
 1 hectoliter = 10 dekaliters = 26.42 gallons  
 1 kiloliter = 10 hectoliters = 264.18 gallons

## Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch  
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches  
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet  
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet  
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres  
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

## Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch  
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches  
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

# Approximate Conversion Factors

| To change     | To                 | Multiply by | To change          | To            | Multiply by |
|---------------|--------------------|-------------|--------------------|---------------|-------------|
| inches        | centimeters        | 2.540       | ounce-inches       | newton-meters | .007062     |
| feet          | meters             | .305        | centimeters        | inches        | .394        |
| yards         | meters             | .914        | meters             | feet          | 3.280       |
| miles         | kilometers         | 1.609       | meters             | yards         | 1.094       |
| square inches | square centimeters | 6.451       | kilometers         | miles         | .621        |
| square feet   | square meters      | .093        | square centimeters | square inches | .155        |
| square yards  | square meters      | .836        | square meters      | square feet   | 10.764      |
| square miles  | square kilometers  | 2.590       | square meters      | square yards  | 1.196       |
| acres         | square hectometers | .405        | square kilometers  | square miles  | .386        |
| cubic feet    | cubic meters       | .028        | square hectometers | acres         | 2.471       |
| cubic yards   | cubic meters       | .765        | cubic meters       | cubic feet    | 35.315      |
| fluid ounces  | milliliters        | 29.573      | cubic meters       | cubic yards   | 1.308       |
| pints         | liters             | .473        | milliliters        | fluid ounces  | .034        |
| quarts        | liters             | .946        | liters             | pints         | 2.113       |
| gallons       | liters             | 3.785       | liters             | quarts        | 1.057       |
| ounces        | grams              | 28.349      | liters             | gallons       | .264        |
| pounds        | kilograms          | .454        | grams              | ounces        | .035        |
| short tons    | metric tons        | .907        | kilograms          | pounds        | 2.205       |
| pound-feet    | newton-meters      | 1.356       | metric tons        | short tons    | 1.102       |
| pound-inches  | newton-meters      | .11296      |                    |               |             |

# Temperature (Exact)

|    |                        |                            |                     |    |
|----|------------------------|----------------------------|---------------------|----|
| °F | Fahrenheit temperature | 5/9 (after subtracting 32) | Celsius temperature | °C |
|----|------------------------|----------------------------|---------------------|----|





This fine document...

Was brought to you by me:



### [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)