

TECHNICAL MANUAL


---

**Operator, Field and Sustainment Maintenance Manual Including Repair  
Parts and Special Tools List**

**for**

**TRAILER, AMMUNITION,  
HEAVY EXPANDED MOBILITY,  
11 TON, M989**

**(2330-01-109-4258)**



**DISTRIBUTION STATEMENT A** - Approved for public release; distribution is unlimited.

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**December 1985**



**WARNING SUMMARY****WARNING**

Protective eye covering should be worn at all times to prevent personal injury.

**WARNING**

Vent air tanks of air pressure before removal of air system components to prevent possible injury.

**WARNING**

Keep away from drain cocks when draining air tanks to prevent injury to eyes by compressed air.

**WARNING**

Do not attempt to dismount tire until tire has been completely deflated. When released, air under pressure can cause serious injury.

**WARNING**

DO NOT use a dry brush or compressed air to clean brake shoes. There may be asbestos dust on brake shoes which can be dangerous to your health if you breathe it. (Dampen surface of lining with water and use a soft bristle brush.)

**WARNING**

Do not attempt to pull landing leg plunger unless trailer is connected to towing vehicle pintle if trailer is loaded. The load may cause trailer to tip forward and cause injury.

**WARNING**

Asbestos dust is dangerous to your health. Wear respirator to avoid inhaling dust.

**WARNING**

Chemical Agent Resistant Coating (CARC) paint contains Hexamethylene Diisocyanate (HDI), which is highly irritating to the skin and respiratory system. High concentrations of HDI can produce symptoms of itching and reddening of the skin, a burning sensation in the throat and nose, and watering of the eyes. In extreme concentrations, HDI can cause cough, shortness of breath, pain during respiration, increased sputum production, and chest tightness. The following precautions must be taken whenever using CARC paint:

- NEVER cut CARC-coated materials without high-efficiency, air-purifying respirators in use.
- DO NOT grind or sand painted equipment without high-efficiency, air-purifying respirators in use.
- BE AWARE of CARC paint exposure symptoms; symptoms can occur a few days after initial exposure. Seek medical help immediately if symptoms are detected.
- ALWAYS wear protective equipment (gloves, ventilation mask, safety goggles, etc.).

## **WARNING SUMMARY (continued)**

### **WARNING**

Coatings can cause internal injury during prolonged breathing of vapors. Wear respirator to prevent inhaling vapors. Use adequate ventilation.

### **WARNING**

Do not attempt to disassemble brake air chambers. The springs inside the chamber are under heavy tension and may cause severe injury if released during disassembly.

### **WARNING**

Spare tire will drop to the ground as soon as ratchet is released. Stand clear to prevent possible injury.

### **WARNING**

Solvent cleaning compound is an environmentally compliant product and is low in toxicity. However, it may be irritating to the eyes and skin due to its base stock. The use of protective gloves and goggles is required. Use the cleaning compound in well-ventilated areas and keep away from open flames and other sources of ignition.

### **WARNING**

Do not actuate the trailer parking brake control unless the HEMAT is on level terrain. Without brakes the HEMAT may roll and move out of control causing possible injury or damage.

### **WARNING**

Do not stand between towing vehicle and HEMAT when backing towing vehicle. Serious injury can result if personnel are caught between the vehicles.

CHANGE  
No. 2

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington, D.C., 15 March 2007

**Operator, Field and Sustainment Maintenance Manual Including Repair Parts and Special Tools List**  
**for**

**TRAILER, AMMUNITION, HEAVY EXPANDED MOBILITY, 11 TON,  
M989 (2330-01-109-4258)**

**MODEL**

**NSN**

TRAILER, AMMUNITION, HEAVY EXPANDED MOBILITY, M989

2330-01-109-4258

**TM 9-2330-368-14&P, 15 December 1985, is changed as follows:**

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. Minor changes to illustrations are indicated by a miniature point hand.
4. Illustrations that are new or that have major revisions are indicated by a vertical bar adjacent to the illustration.

Remove Pages  
Warning Summary  
A and B  
i through iii/iv blank  
1-1 and 1-2  
4-1 through 4-7/4-8 blank  
4-13 through 4-16  
4-21 through 4-26  
5-1 through 5-4  
5-7 through 5-10  
6-1 and 6-2  
7-1 and 7-2  
8-1/8-2/blank  
A-1 and A-2  
B-1 through B-6  
E-1 and E-2  
2-1 through Figure 3  
4-1 through Figure 6  
7-1 through Figure 8  
12-1 through Figure 15  
I-1 through I-12  
Index 1 through Index 4  
Front Cover

Insert Pages  
a and b  
A and B  
i through iv  
1-1 and 1-2  
4-1 through 4-7/4-8 blank  
4-13 through 4-16  
4-21 through 4-26  
5-1 through 5-4  
5-7 through 5-10  
6-1 and 6-2  
7-1 and 7-2  
8-1/8-2/blank  
A-1 and A-2  
B-1 through B-8  
E-1 and E-2  
2-1 through Figure 3  
4-1 through Figure 6  
7-1 through Figure 8  
12-1 through Figure 15  
I-1 through I-12  
Index 1 through Index 4  
Front Cover

File this change sheet in front of the publication for reference purposes.

**Approved for public release; distribution is unlimited.**

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER  
*General, United States Army*  
*Chief of Staff*

Official:

A handwritten signature in black ink, reading "Joyce E. Morrow". The signature is fluid and cursive, with the first name "Joyce" written in a larger, more prominent script than the last name "Morrow".

JOYCE E. MORROW  
Administrative Assistant to the  
Secretary of the Army  
0701704

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 3 90031, requirements for TM 9-2330-368-14&P.

CHANGE

NO. 1

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington D.C., 15 December 1991

**Operator's, Organizational, Direct Support,  
and General Support Maintenance Manual  
with  
Repair Parts and Special Tools Lists**

**TRAILER, AMMUNITION,  
HEAVY EXPANDED MOBILITY,  
11 TON, M989  
(2330-01 -1 09-4258)**

Current as of 8 May 1991

TM 9-2330-368-14&P, 15 December 1985, is changed as follows:

1. Remove old pages and insert new pages.
2. New or changed material is indicated by a vertical bar in the margin of the page and by a vertical bar adjacent to the TA number.

**Remove Pages**

*i and ii  
2-7 and 2-8  
2-11 through 2-14  
4-1 and 4-2  
4-5 and 4-6  
4-41 through 4-46  
4-51 and 4-52  
A-1 and A-2  
B-5 and B-6  
C-1 and C-2  
F-1 through "8-2"  
9-1 through Figure 13  
17-1 and Figure 18  
Bulk- 1 and "Bulk-2"  
I-1 through "I-8"  
index 1 through index 4*

**Insert Pages**

*i through iii/(iv Blank)  
2-7 and 2-8  
2-11 through 2-14  
4-1 and 4-2  
4-5 and 4-6  
4-41 through 4-46  
4-51 and 4-52  
A-1 and A-2  
B-5 and B-6  
C-1 and C-2  
F-1 through "8-2"  
9-1 through Figure 13  
17-1 and Figure 18  
Bulk- 1 and "Bulk-2"  
i-1 through i-12  
/ndex 1 through Index 4*


3. File this change sheet in front of the publication for reference purposes.

**Approved for public release distribution is unlimited.**

By Order of the Secretary of the Army:

**GORDON R. SULLIVAN**  
*General, United States Army*  
*Chief of Staff*

Official:



MILTON H. HAMILTON  
*Administrative Assistant to the*  
*Secretary of the Army*  
00371

**Distribution**

To be distributed in accordance with DA Form 12-39-E ( Block 0031) Unit, Direct Support and General Support maintenance requirements for TM9-2330-368-14&P.



INSERT LATEST UPDATED PAGES/WORK PACKAGES, DESTROY SUPERSEDED DATE

**LIST OF EFFECTIVE PAGES/WORK PACKAGES**

**NOTE:** The portion of text affected by the updates is indicated by a vertical line in the outer margins of the page. Updates to illustrations are indicated by miniature pointing hands. Updates to wiring diagrams are indicated by shaded areas.

Dates of issue for original and updated pages/work packages are:

Original.....15 December 1985

Change 1 .....15 December 1991

Change 2 .....15 March 2007

**TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 230  
CONSISTING OF THE FOLLOWING:**

<b>Page/WP No.</b>	<b>*Change No.</b>	<b>Page/WP No.</b>	<b>*Change No.</b>	<b>Page/WP No.</b>	<b>*Change No.</b>
Cover	2	2-16	0	4-5	0
Blank	2	2-17	0	4-6	2
a	2	2-18	0	4-7	2
b	2	2-19	0	4-8 Blank	0
i	2	2-20	0	4-9	0
ii	2	2-21	0	4-10	0
iii	2	2-22	0	4-11	0
iv	2	2-23	0	4-12	0
1-1	2	2-24	0	4-13	0
1-2	2	2-25	0	4-14	2
1-3	0	2-26	0	4-15	2
1-4	0	2-27	0	4-16	0
1-5	0	2-28	0	4-17	0
1-6	0	2-29	0	4-18	0
1-7	0	2-30 Blank	0	4-19	0
1-8 Blank	0	3-1	0	4-20	0
2-1	0	3-2	0	4-21	0
2-2	0	3-3	0	4-22	2
2-3	0	3-4	0	4-23	2
2-4	0	3-5	0	4-24	2
2-5	0	3-6	0	4-25	2
2-6	0	3-7	0	4-26	0
2-7	1	3-8	0	4-27	0
2-8	0	3-9	0	4-28	0
2-9	0	3-10	0	4-29	0
2-10	0	3-11	0	4-30	0
2-11	1	3-12 Blank	0	4-31	0
2-12	0	4-1	2	4-32	0
2-13	1	4-2	2	4-33	0
2-14	0	4-3	2	4-34	0
2-15	0	4-4	0	4-35	0

\* Zero in this column indicates an original page.

**LIST OF EFFECTIVE PAGES/WORK PACKAGES (continued)**

<b>Page/WP No.</b>	<b>*Change No.</b>	<b>Page/WP No.</b>	<b>*Change No.</b>	<b>Page/WP No.</b>	<b>*Change No.</b>
4-36	0	B-3	2	12-1	2
4-37	0	B-4	2	Figure 13	0
4-38	0	B-5	2	13-1	2
4-39	0	B-6	2	Figure 14	0
4-40	0	B-7	2	14-1	2
4-41	0	B-8	2	Figure 15	0
4-42	1	C-1	0	15-1	0
4-43	1	C-2	1	Figure 16	0
4-44	0	C-3	0	16-1	0
4-45	0	C-4 Blank	0	Figure 17	0
4-46	1	D-1	0	17-1	0
4-47	0	D-2 Blank	0	Figure 18	1
4-48	0	E-1	0	18-1	0
4-49	0	E-2	2	Blank	0
4-50	0	F-1	1	Bulk-1	1
4-51	1	F-2	2	Blank	0
4-52	0	F-3	2	I-1	2
4-53	0	F-4	2	I-2	2
4-54	0	F-5	2	I-3	2
4-55	0	Figure 1	1	I-4	2
4-56 Blank	0	1-1	1	I-5	2
5-1	2	Figure 2	1	I-6	2
5-2	2	2-1	2	I-7	2
5-3	0	Figure 3	1	I-8	2
5-4	2	3-1	1	I-9	2
5-5	0	Figure 4	1	I-10	2
5-6	0	4-1	2	I-11	2
5-7	0	Figure 5	0	I-12	2
5-8	2	5-1	2	G-1	0
5-9	2	Figure 6	1	G-2	0
5-10	0	6-1	1	G-3	0
5-11	0	Figure 7	1	G-4	0
5-12	0	7-1	2	G-5	0
5-13	0	Figure 8	0	G-6	0
5-14	0	8-1	1	H-1	0
6-1	2	Figure 9	0	H-2	0
6-2	2	sh1/2		Index-1	1
7-1	2	Figure 9	0	Index-2	2
7-2	2	sh2/2		Index-3	2
8-1	2	9-1	1	Index-4	1
8-2 Blank	2	Figure 10	1	Authentication	0
A-1	2	10-1	1	Blank	0
A-2	2	Figure 11	1	Metric Page	0
B-1	2	11-1	1	Rear Cover	0
B-2	2	Figure 12	0		

\* Zero in this column indicates an original page.

TECHNICAL MANUAL

No. 9-2330-368-14&amp;P

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON D.C., 15 DECEMBER 1985

**Operator, Field and Sustainment  
Maintenance Manual Including  
Repair Parts and Special Tools List**

**for**

**TRAILER, AMMUNITION, HEAVY EXPANDED MOBILITY, 11 TON, M989**

**(2330-01-109-4258)**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications) through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. The DA Form 2028 is located in under the Public Applications section on the AEPS public home page. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond more quickly to your comments and better manage the DA Form 2028 program. You may also mail, fax, or e-mail your letter or DA Form 2028 directly to AMSTA-LC-LMIT/TECH PUBS, TACOM-R1, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The e-mail address is [ROCK-TACOM-TECH-PUBS@conus.army.mil](mailto:ROCK-TACOM-TECH-PUBS@conus.army.mil). The fax number is DSN 793-0726 or Commercial (309) 782-0726.

Current as of 15 March 2007

**Page**

**CHAPTER 1. INTRODUCTION**

Section I.	General Information.....	1-1
Section II.	Equipment Description and Data.....	1-3

**CHAPTER 2. OPERATING INSTRUCTIONS**

Section I.	Description and Use of Operators Controls and Indicators .....	2-1
Section II.	Operator Preventive Maintenance Checks and Service .....	2-7
Section III.	Operation Under Usual Conditions.....	2-14
Section IV.	Operation Under Unusual Conditions.....	2-27

**CHAPTER 3. OPERATOR MAINTENANCE INSTRUCTIONS**

Section I.	Lubrication Instructions .....	3-1
Section II.	Troubleshooting Procedures .....	3-4
Section III.	Operator Maintenance.....	3-9

## **CHAPTER 4. FIELD MAINTENANCE INSTRUCTIONS (ORGANIZATIONAL MAINTENANCE)**

Section	I.	Repair Parts, Special Tools, TMDE, and Support Equipment.....	4-1
Section	II.	Service Upon Receipt of Material.....	4-2
Section	III.	Preventive Maintenance Checks and Services.....	4-3
Section	IV.	Troubleshooting Procedures .....	4-9
Section	V.	Maintenance of Electrical System .....	4-16
Section	VI.	Maintenance of Air Brake System.....	4-22
Section	VII.	Maintenance of Wheels and Tires.....	4-38
Section	VIII.	Maintenance of Frame and Towing Components .....	4-46
Section	IX.	Maintenance of Body Components.....	4-52

## **CHAPTER 5. FIELD MAINTENANCE INSTRUCTIONS (DIRECT SUPPORT MAINTENANCE)**

Section	I.	Repair Parts, Special Tools, TMDE, and Support Equipment.....	5-1
Section	II.	Maintenance of Service Brakes .....	5-2
Section	III.	Maintenance of Suspension .....	5-4
Section	IV.	Maintenance of Body Components.....	5-9

## **CHAPTER 6. SUSTAINMENT MAINTENANCE INSTRUCTIONS (GENERAL SUPPORT/DEPOT MAINTENANCE)**

Section	I.	Repair Parts, Special Tools, TMDE, and Support Equipment.....	6-1
Section	II.	Maintenance of Frame .....	6-2

## **CHAPTER 7. PAINTING INSTRUCTIONS**

## **CHAPTER 8. PREPARATION FOR STORAGE OR SHIPMENT**

## **APPENDIX A REFERENCES..... A-1**

## **APPENDIX B MAINTENANCE ALLOCATION CHART .....B-1**

## **APPENDIX C COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS.....C-1**

## **APPENDIX D ADDITIONAL AUTHORIZATION LIST..... D-1**

## **APPENDIX E EXPENDABLE SUPPLIES AND MATERIALS LISTS .....E-1**

**APPENDIX F REPAIR PARTS AND SPECIAL TOOLS LIST ..... F-1**

Section	I.	Introduction.....	F-1
Section	II.	Repair Parts List.....	F-1

		<b>Illus Fig</b>	<b>Page</b>
GROUP 06	ELECTRICAL SYSTEM		
	0609 - LIGHTS		1-1
	LIGHTS	1	1-1
	WIRING HARNESS AND CABLE	2	2-1
GROUP 11	REAR AXLE		
	11 00 - REAR AXLE ASSEMBLY		3-1
	AXLE	3	3-1
GROUP 12	BRAKES		
	1202 - SERVICE BRAKES		4-1
	SERVICE BRAKES	4	4-1
	1208 - AIR BRAKE SYSTEM		5-1
	AIR BRAKE SYSTEM	5	5-1
	AIR BRAKE CHAMBER	6	6-1
GROUP 13	WHEELS AND TRACKS		
	1311 - WHEEL ASSEMBLY		7-1
	HEELS AND HUBS	7	7-1
	1313 - TIRES, TUBES, TIRE CHAINS		8-1
	TIRES	8	8-1
GROUP 15	FRAME, TOWING ATTACHMENTS, DRAWBARS, AND ARTICULATION SYSTEMS		
	1501 - FRAME ASSEMBLY		9-1
	FRAME COMPONENTS	9	9-1
	1503 - PINTLES AND TOWING ATTACHMENTS		10-1
	SAFETY CHAINS AND COUPLER	10	10-1
	1504 - SPARE WHEELCARRIER AND TIRE LOCK		11-1
	SPARE TIRE CARRIER	11	11-1
	1507 - LANDING GEAR, LEVELING JACKS		12-1
	LANDING GEAR	12	12-1
GROUP 16	SPRINGS AND SHOCK ABSORBERS		
	1601 - SPRINGS		13-1
	SUSPENSION AND SPRINGS	13	13-1
	1604 - TORQUE, RADIUS, AND STABILIZER RODS		14-1
	TORQUE RODS	14	14-1

			<b>Illus Fig</b>	<b>Page</b>
GROUP 18	BODY, CAB, HOOD AND HULL			
	1801 - BODY, CAB, HOOD, AND HULL ASSEMBLIES			15-1
	GATES	15		15-1
	1805 - FLOORS, SUBFLOORS, AND RELATED COMPONENTS			16-1
	FLOORBOARDS	16		16-1
GROUP 22	BODY, CHASSIS, AND HULL ACCESSORY ITEMS			
	2202 - ACCESSORY ITEMS			17-1
	REFLECTORS	17		17-1
	2210 - DATA PLATES AND INSTRUCTION HOLDERS			18-1
	DATA PLATES	18		18-1
GROUP 95	GENERAL USE STANDARDIZED PARTS			
	9501 - BULK MATERIAL			BULK-1
	BULK	BULK		BULK-1
Section	III.	Special Tools List (Not Applicable)		
Section	IV.	Cross-Reference Indexes		
		NATIONAL STOCK, NUMBER INDEX .....		I-1
		PART NUMBER INDEX.....		I-3
		FIGURE AND ITEM NUMBER INDEX .....		I-8
<b>APPENDIX</b>	<b>G</b>	<b>ILLUSTRATED LIST OF MANUFACTURED ITEMS.....</b>		<b>G-1</b>
<b>APPENDIX</b>	<b>H</b>	<b>TORQUE LIMITS.....</b>		<b>H-1</b>
<b>APPENDIX</b>	<b>I</b>	<b>WARRANTY .....</b>		<b>I-1</b>
<b>ALPHABETICAL INDEX.....</b>				<b>INDEX 1</b>

# CHAPTER 1

## INTRODUCTION

### Section I. GENERAL INFORMATION

Scope.....	1-1	Warranty.....	1-2
Maintenance Forms, Records and Reports .....	1-1	Preparation for Storage or Shipment.....	1-2
Hand Receipt (-HR) Manuals .....	1-1	Safety, Care, and Handling .....	1-2
Destruction of Army Material to Prevent Enemy Use .....	1-1	List of Abbreviations .....	1-2
Reporting of Equipment Improvement Recommendations (EIR) .....	1-1	Metric Units .....	1-2

#### 1-1. SCOPE

**a. Type of Manual:** Operator's, organizational, direct support, and general support maintenance (including repair parts and special tools list (RPSTL)).

**b. Model Numbers and Equipment Name:**  
M989 – Heavy Expanded Mobility Ammunition Trailer (HEMAT), 11 Ton.

**c. Purpose of Equipment:** Designed for transporting 22,000 pounds (9979.2 kg) of payload.

(1) Four evenly distributed MLRS pods side by side, two high or

(2) Eight 40 by 48 inch ammunition pallets.

#### 1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 750-8, The Army Maintenance Management System (TAMMS) User's Manual.

#### 1-3. HAND RECEIPT (-HR) MANUALS

Hand receipt manual is not required for this equipment.

#### 1-4. DESTRUCTION OF ARMY MATERIAL TO PREVENT ENEMY USE

Refer to TM 750-244-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use, for procedures on destruction of military vehicles.

#### 1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your HEMAT needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. If you have Internet access, the easiest and fastest way to report problems or suggestions is to go to <https://aepps.ria.army.mil/aeppspublic.cfm> (scroll down and choose the "Submit Quality Deficiency Report" bar). The Internet form lets you choose to submit an Equipment Improvement Recommendation (EIR) or a Product Quality Deficiency Report (PQDR). You may also submit your information using an SF Form 368 (Product Quality Deficiency Report). You can send your SF Form 368 via e-mail, regular mail, or facsimile using the addresses/facsimile numbers specified in DA PAM 750-8, The Army Maintenance Management System (TAMMS) Users Manual. We will send you a reply.

1-6. WARRANTY

The M989 HEMAT Trailer is warranted by the Beta Manufacturing Company, parts only, for a period of 12 months after the Government acceptance date. For further warranty provisions and for instructions on filing warranty claim, see Appendix I.

1-7. PREPARATION FOR STORAGE OR SHIPMENT

Refer to TM 38-470, Storage and Maintenance of Army Prepositioned Stock Materiel, for preservation, packaging, marking, and preparation for storage or shipment of the M989 series HEMAT.

1-8. SAFETY, CARE, AND HANDLING

Deleted

1-9. LIST OF ABBREVIATIONS

The following abbreviations are used in this technical manual:

HEMAT	Heavy Expanded Mobility Ammunition Trailer
HEMTT	Heavy Expanded Mobility Tactical Truck
LH	left hand
MLRS	Multiple Launch Rocket Systems
RH	right hand
SPLL	Self Propelled Loader Launcher

1-10. METRIC UNITS

The equipment described herein is non-metric and does not require metric common or special tools; therefore, metric units are not supplied. Tactical instruction will include metric units in addition to English units. Clarity of instruction is not impaired.



## Section II. EQUIPMENT DESCRIPTION AND DATA

	Page		Page
Equipment Characteristics, Capabilities and Features . . . . .	1-3	Equipment Data . . . . .	1-5
Description of Major Components . . . . .	1-3	Data Plates . . . . .	1-6

### 1-11. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

- Can be towed by HEMTT and SPL.
- Can carry up to 22,000 pounds (9972.2 kg) of munitions cargo at 50 mph (80.5 kph) highway only.
- Gates may be installed or removed.
- Has blackout lights.
- Has jackknife warning indicators.

### 1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

**a. Coupler(1).** Attaches to towing vehicle pintle for towing operations.

**b. Safety Chains (2).** Attach to towing vehicle to prevent breakaway.


**c. Landing Gear (3).** Supports front end of HEMAT when not connected to towing vehicle. Stowed in the horizontal position when HEMAT is hooked up.

**d. Storage Box (4).** For storage of inter-vehicular air hoses and cable, fire extinguisher, SPL adapter, lug wrench and other tools. Cover hinged in rear, located forward in tongue.

**e. Tie Down Rings (5).** Used to secure cargo. Are recessed in frame pockets.

**f. Pod Stops (6).** One in each corner of the bed to permit anchoring MLRS pods.

**g. Manifest Holder (7).** Used to store cargo manifests.



TA252 130

## 1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (cont)

**h. Tandem Axles(8).** Consists of the suspension system, air brake system, axles, and the tires.

**i. Frame (9).** Constructed of steel with a wooden floor. Provides the load bearing surface, the mounting for the axles and suspension, and the mounting for the coupler.

**j. Service Brakes (10).** Brakes are applied to HEMAT wheels through towing vehicle air system, and intervehicular air hoses.

**k. Gates ( 11 ).** Used to retain cargo within floor area when raised and locked in position. Are hinged on the frame for quick installation and removal.

**l. Lifting Eyes ( 12 ).** Slide bolt type located at corners of frame for lifting entire trailer when extended. Can be locked in retracted position.

**m. Rubber Bumpers (13).** Prevents damage to the HEMAT and the dock when moving the HEMAT into the dock for loading or unloading.

**n. Lights (14 and 15).** Consists of the clearance marker, stop, blackout and turn signal lights, Actuated by towing vehicle through intervehicular cable.


**o. Splash Guards ( 16 ).** Keeps mud and water from being splashed off the rear tires during rainy weather. Will also keep most of the rocks thrown up when traveling unimproved roads from being thrown off to the rear.

**p. Reflectors (17).** Provide more visibility of HEMAT in addition to lights.

**q. Spare Tire Carrier ( 18 ).** Carries spare tire and permits raising and lowering of tire for use.

**r. Jackknife Warning Indicators ( 15 and 19 ).** Consists of tongue-mounted clearance marker lights (15 ) and black vertical markings ( 19 ).

**s. Intervehicular Air Hose Dummy Couplers (20).** Located on the trailer tongue, provides stowage connection for air hoses.



TA252131

---

**1-13. EQUIPMENT DATA**


---

**Height** . . . . . **68in. (1727.2 mm)**  
**Length** . . . . . **265 in. (6.73 meters)**  
**Width** . . . . . **96 in. (2438.4 mm)**

**Weight**

**Empty** . . . . . **6,950 lbs. (3 152.5 kg)**  
**Payload** . . . . . **22,000 lbs. (9972.2 kg)**

**T i r e s**

**Size** . . . . . **15:00 x 19.5, load range G 14 ply**  
**Inflation Pressure** . . . . . **85 psi (4.07 Kpa)**

**Wheels and Rims Size** . . . . . **19.5 i nch x 12.25 inch**

**Axles**

**Manufacturer** . . . . . **Dana-Rockwell**  
**Model Number** . . . . . **D-21**  
**Capacity** . . . . . **44,000 lbs. (1995.8 kg)**

**B r a k e s**

**Manufacturer** . . . . . **Dana-Rockwell**  
**Type** . . . . . **Drum, 16-1/2 inches x 7 inches**

**Landing Gear**

**Manufacturer** . . . . . **Stowell Industries Inc.**  
**Model Number** . . . . . **48000**  
**Type** . . . . . **Telescopic, manual, handcrank**  
**Capacity** . . . . . **8,000 l bs. (3628.8 kg)**

**Suspension**

**Manufacturer** . . . . . **Reyco**  
**Type** . . . . . **HW Slipper Spring**

**Air System**


**Manufacturer** . . . . . **Bendix**  
**Type** . . . . . **FMVSS-121**

**Electrical System** . . . . . **24dc negative ground**

**Fire Extinguisher** . . . . . **Type 10BC**

# 1-14. DATA PLATES


Sample data plates shown below.

2/83		GVWR	---	LBS
		GAWB	---	LBS
		TIRE	15x19.5G	
		RIM	19.5x12.25	
VIN USR		INCHES	85	
CLASSIFICATION		TRAILER WGT	6950	LBS
MODEL		OPERATING AT	50	★ MPH
 <b>Beta Company</b> A unit of <b>Stowell Industries</b>		GWR	★ 28950	LBS
		GAWB	★ 14937	LBS
		CAPACITY	★ 22000	LBS
		CAPACITY BASED ON A VERTICAL HITCH LOAD OF		1700

CERTIFICATION PLATE (1)

MAKE BETA COMPANY Unit of Stowell Industries Milwaukee, WI 53207  
 MODEL M989  
 MANUFACTURER'S SERIAL NO. **IS9US1723DMO63043**  
 REGISTRATION NUMBER **PK04T3**  
 NSN 2330-01-1093-258  
 VEHICLE CURB WEIGHT **6950** LBS  
 PAYLOAD (MAX) 22,000 LBS  
 GROSS WEIGHT RATING (MAX) **28,950** LBS  
 DATE OF DELIVERY **2/83**  
 WARRANTY 12 MONTHS  
 CONTRACT NUMBER DAAL0781C-4122  
 US PROPERTY


IDENTIFICATION PLATE (2)

AXLE LOAD (EMPTY) 6475 LBS.		TONGUE LOAD (EMPTY) 475 LBS.
OVER-ALL LENGTH 265 IN OVER-ALL HEIGHT 68 IN OVER-ALL WIDTH 96 IN SHIPPING CUBAGE 1002 CU. FT. SHIPPING WEIGHT 6950 LBS		
SHIPPING TONNAGE 15 TONS <b>WARNING: DO NOT SHIP WITH TRAILER RESTING ON LANDING GEAR.</b> *BLOCK AGAINST FRAME.		


INSTRUCTION (LOAD) PLATE (3)

TA252132


# 1-14. DATA PLATES (cont)



LUBRICATION PLATE (4)




WARRANTY DECAL (7)



AIR EMERGENCY  
PLATE (5)



AIR SERVICE





## CHAPTER 2

### OPERATING INSTRUCTIONS

#### Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS & INDICATORS

	Page		Page
Lighting System . . . . .	2-1	Storage Box, . . . . .	2-5
Air Brake System . . . . .	2-2	Fire Extinguisher . . . . .	2-5
Coupler and Safety Chains . . . . .	2-3	SPLL Adapter . . . . .	2-5
Spare Tire Carrier . . . . .	24	Lifting Eyes . . . . .	2-6
Landing Gear . . . . .	24	Gates . . . . .	2-6

#### I 2-1. LIGHTING SYSTEM I

**a. Lights.** The HEMAT lights are operated by the towing vehicle through the intervehicular cable. Lights include the following:

(1) Two rear composite lights ( 1), each containing a stoplight, turn-signal light, a blackout stoplight, and blackout marker light.



(2) Four red clearance marker lights (2),

one on each side rearward and one on each corner of rear.

(3) Three rear red marker lights (3).

(4) Four amber clearance marker lights (4), one on each side forward and one on each side of front corner, and two amber clearance marker lights (5) one on each side of tongue.


(5) Two blackout amber clearance marker lights (6) one on each side of tongue.



TA252 134


## 2-1. LIGHTING SYSTEM (cont)

**b. InterVehicular Cable.** The intervehicular cable ( 1 ) is used to connect the HEMAT lighting system to the towing vehicle electrical system during towing operations. The cable plugs are keyed so they can be connected to the HEMAT and towing vehicle receptacles in only one way. The lights are operated from the towing vehicle. The cable is stowed in the storage box when not in use.



## 2-2. AIR BRAKE SYSTEM

**a. Service Brakes.** The service brakes (1) are expanding-shoe on drum type with dust shields on inside of brake housings. The brake shoes are actuated by individual air chambers (2) through camshafts. The air chambers are connected to the air system valves and tanks through hoses. The service brakes are normally locked as parking brakes when the HEMAT is disconnected from the towing vehicle. Refer to paragraph 2-2c for operation of the trailer parking brake control.



TA252135



## 2-2. AIR BRAKE SYSTEM (cont)

**b. Intervehicular Air Hoses.** Air for operation of the HEMAT brakes is provided from the towing vehicle through intervehicular air hoses (3). One hose is for service brake operation; the other hose is for emergency operation. Both hoses have gladhand couplings (4) for quick secure connection to the towing vehicle. Rubber straps (5) are provided to connect the air hoses to the tongue and prevent dragging.


### WARNING

Do not actuate the trailer parking brake control unless the HEMAT is on level terrain. Without brakes the HEMAT may roll and move out of control causing possible injury or damage.

**c. Trailer Parking Brake Control.** Pushing in the brake control knob (6) permits the crew to unlock the HE MAT brakes when the HE MAT is disconnected from the towing vehicle. If there is not enough air in the HE MAT air tanks, the knob will pop out to the normal position and the parking brakes will remain locked. A guard (7) prevents accidental valve actuation.

### NOTE


The HEMAT brakes can also be released mechanically by caging the brake chamber springs (para. 2-27).



## 2-3. COUPLER AND SAFETY CHAINS

**a. Coupler ( 1 ).** The coupler is a lunette type used to connect the HEMAT to the towing vehicle pintle during transporting. The coupler is bolted to the trailer frame. Height can be adjusted by re-mounting the coupler in a series of holes in the trailer tongue. The coupler should be mounted in the position that will cause the HEMAT to ride closest to level.

**b. Safety Chains ( 2 ).** Two safety chains are provided on the forward end of the frame. Their purpose is to prevent a breakaway if the pintle-coupler connections should fail. The safety chains are connected to towing vehicle after the coupler is connected to towing pintle. The chains are hooked around the trailer tongue when not in use.



TA252136

## 2-4 SPARE TIRE CARRIER

The spare tire carrier holds the spare tire under the trailer frame and permits lowering or raising the spare tire.

**a.** The spare tire is supported by a pickup tire plate (1) which is connected to the carrier shaft (2) by cables (3). As the shaft turns the cables wind or unwind to raise or lower the spare tire.

### WARNING

Spare tire will drop to the ground as soon as ratchet is released. Stand clear to prevent possible injury.

**b.** A ratchet and pawl (4) prevents slippage when raising the spare tire. To lower the spare tire, the ratchet (4) is manually released; the shaft turns counterclockwise. To raise the spare tire, the carrier shaft is turned clockwise using the tire lug wrench (5). Once the spare is raised, it is secured to four fixed studs (6) with wheel nuts.

### NOTE

Whenever the spare tire is dropped, inspect cables (3) for fraying, corrosion and other defects.

## 2-5. LANDING GEAR




The landing gear is used to support the front end of the HEMAT when uncoupled. It can be used during the loading or unloading of the trailer. The landing gear is placed in the vertical position for use and the horizontal position for storage.

**a. Crank ( 1).** Operates the landing gear. Crank is bolted to gear shaft and can be swung around for storage.

### WARNING

Do not attempt to pull plunger unless trailer is connected to towing vehicle pintle if trailer is loaded. The load may cause the trailer to tip forward and cause injury.

**b. Plunger (2).** When pulled with no load on landing gear allows shoe (3) to free fall to ground with no load on landing gear. Plunger is spring loaded.



TA252137


## 2-5. LANDING GEAR (cont)

**c. Crank Stow Bracket (4).** Stows the crank when the crank is not in use.

**d. Leg (5).** Supports the weight of the trailer when extended. Slides into housing when retracted.


**e. Landing Gear Shoe (3).** Keeps the legs from sinking into the ground.

**f. Hitch Pin Assembly (6).** Locks the landing gear in vertical or horizontal position. Removed to turn unit.



## I 2-6. STORAGE BOX I

The storage box (1), located in the trailer tongue, is used to stow the intervehicular cable, fire extinguisher, SPLL adapter, lug wrench and other tools. The box is fitted with a heavy gauge, steel cover (2), which is hinged at the rear end. A support strut (3) is provided to hold the cover open when necessary and a latch (4) to permit locking the cover down.




## I 2-7. FIRE EXTINGUISHER I

The fire extinguisher (1) is a standard 10BC type. It is mounted in quick release brackets (2) inside the storage box.

## 2-8. SPLL ADAPTER

The Self Propelled Loader Launcher (SPLL) adapter (3) is used only when the HEMAT must be connected for emergency SPLL operation. The adapter extends the towing lunette coupler (4) to allow additional trailer-vehicle clearance.



TA252138

## 2-9. LIFTING EYES

The lifting eyes ( 1 ) provide lift points to lift the unloaded HEMAT if necessary. A pin and chain ( 2 ) holds each of the four lifting eyes in the retracted position. The pins are pulled and the lifting eyes pushed out for use.

## 2-10. GATES

a. The gates are used to retain the cargo within the floor area of the HEMAT, Six gates are provided as follows:



(1) One front gate (1).

(2) One rear gate (2).

(3) One left hand rear gate (3) and one right hand front gate which are the same.

(4) One left hand front gate (4) and one right hand rear gate which are the same.

b. The gates are normally installed at the outside edges of the cargo area in the vertical upright position, but can be swung down to clear the cargo area if necessary. In the upright position, each gate is attached to the adjacent two by pin type latch locks (5). The latch pins are fastened to heavy aircraft wires which are secured to the gates. The lower edge of each gate is hinged by two pins and ear type fasteners (6). The right hand rear gate and left hand front gate are also secured to the trailer frame by vertical slide bolts (7) which enter pockets in the frame.



TA252139

## Section II. OPERATOR PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

	Page
Maintenance Forms and Records . . . . .	2-7
Operator/Crew Preventive Maintenance	
Checks and Services . . . . .	2-7

### I 2-11. MAINTENANCE FORMS AND RECORDS I

Every mission begins and ends with the paperwork. There isn't much of it, but you have to keep it up. The forms and record you fill out have several uses. They are a permanent record of the services, repairs and modifications made on your vehicle. They are reports to organizational maintenance and to your Commander. And they are a checklist for you when you want to know what is wrong with the vehicle after its last use, and whether those faults have been fixed. For the information you need on forms and records, see DA Pam 738-750.

### 2-12. OPERATOR/CREW PREVENTIVE MAINTENANCE CHECKS AND SERVICES

**a.** Do your before (B) PREVENTIVE MAINTENANCE just before you operate the vehicle. Pay attention to the CAUTIONS and WARNINGS.

**b.** Do your (D) PREVENTIVE MAINTENANCE during operation. (During operation means to monitor the vehicles and its related components while they are actually being operated).

**c.** Do your after (A) PREVENTIVE MAINTENANCE right after operating the vehicle. Pay attention to the CAUTIONS and WARNINGS.

**d.** Do your (W) PREVENTIVE MAINTENANCE weekly.

**e.** If something doesn't work, troubleshoot it with the instructions in this manual and notify your supervisor.

**f.** Always do your PREVENTIVE MAINTENANCE in the same order so it gets to be a habit. Once you've had some practice, you'll spot anything wrong in a hurry.

**g.** If anything looks wrong and you can't fix it, write it on your DA Form 2404. If you find

something seriously wrong, report it to organizational maintenance RIGHT NOW.

**h.** When you do your PREVENTIVE MAINTENANCE, take along the tools you need to make all the checks. You always need a rag or two.

#### WARNING

Dry cleaning solvent (P-D-680) used to clean parts is potentially dangerous to personnel and property. Do not use near open flame or excessive heat. Flash point of solvent is 138°F (59°C).

**(1)** Keep it clean: Dirt, grease, oil and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use dry cleaning solvent (P-D-680) on all metal surfaces. Use soap and water when you clean rubber or plastic material.

**(2)** Bolts, nuts and screws: Check them all for obvious looseness, missing, bent or broken condition. You can't try them all with a tool, of course, but look for chipped paint, bare metal, or rust around bolt heads. If you find one you think is loose, tighten it, or report it to organizational maintenance if you can't tighten it.

**(3)** Welds: Look for loose or chipped paint, rust, or gaps where parts are welded together. If you find a bad weld, report it to organizational maintenance.



**(4)** Electric wires and connectors: Look for cracked or broken insulation, bare wires and loose or broken connectors. Tighten loose connectors and make sure the wires are in good shape.

**(5)** Air hose lines: Look for wear, damage and leaks, and make sure clamps and fittings are tight. If a leak comes from a loose fitting or connector, tighten it. If something is broken or worn out, report it to organizational maintenance.

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services

**NOTE**



Within designated interval, these checks are to be performed in the order listed.

<b>B - Before</b>		<b>D - During</b>			<b>A - After</b>		<b>W - Weekly</b>	
<b>Item No.</b>	<b>B</b>	<b>Interval</b>	<b>D</b>	<b>A</b>	<b>W</b>	<b>ITEM TO BE INSPECTED</b>		<b>Equipment Will Be Reported Not Ready/ Available If</b>
						<b>Procedure: Check For and Have Repaired, Filled, or Adjusted as Needed.</b>		
						<b>NOTE</b>		
						Perform weekly as well as before PMCS if:		
						a. You are the assigned operator but have not operated vehicle since the last weekly.		
						b. You are operating the vehicle for the first time.		
1	•					<b>INTERVEHICULAR CABLE</b>		
						Check intervehicular cable ( 1 ) for cuts, breaks, and frayed wires or damaged cable plugs (2). Replace if defective.		
								
2	•					<b>INTERVEHICULAR AIR HOSES</b>		
	•					a. Check intervehicular air hoses (1) and straps (2) for cuts, breaks, and damaged gladhand (3). If damaged, notify organizational maintenance.		
	•					b. Check packing (4). Replace if defective.		
								TA252140

**Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (cont)****NOTE**

Within designated interval, these checks are to be performed in the order listed.

**B – Before****D – During****A – After****W – Weekly**


Item No.	Interval				ITEM TO BE INSPECTED Procedure: Check For and Have Repaired, Filled, or Adjusted as Needed.	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W		
3	•				<b>COUPLER AND SAFETY CHAINS</b> Check for loose, missing or damaged coupler (1) or safety chains (2) and shackles (3). Notify organizational maintenance of defects. 	Coupler and/or safety chain and shackle are missing or damaged.
4		•			<b>LANDING GEAR (1)</b>  Check operation for binding, physical damage or missing parts. Notify organizational maintenance of defects. 	Landing gear does not operate.

TA252141

**Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (cent)****NOTE**

Within designated interval, these checks are to be performed in the order listed.

**B – Before****D – During****A – After****W – Weekly**

Item No.	Interval				ITEM TO BE INSPECTED Procedure: Check For and Have Repaired, Filled, or Adjusted as Needed.	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W		
5	•			•	<b>TIRES</b> <ol style="list-style-type: none"> <li>Check for tire pressure of 85 PSI (4.07 KPa) when tires (1) are cool.</li> <li>Check tires for cuts, foreign objects or unusual tread wear. Remove any stones from between treads.</li> </ol>  <p>The diagram shows a side view of a vehicle chassis. Two wheels are visible. Arrows point to the tires, labeled '1', and the wheel nuts, labeled '2'. A third arrow points to the axle area, labeled '3'.</p>	Two tires are flat, missing or unserviceable.
6	•				<b>WHEELS</b> <p>Check wheels (2) for damage and wheel nuts (3) for obvious looseness and presence.</p> <p><b>NOTE</b> Report any loose wheel nuts to organizational maintenance for torquing.</p>	Missing wheel nut.



TA252142



**Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (cent)****NOTE**

Within designated interval, these checks are to be performed in the order listed.

**B – Before****D – During****A – After****W – Weekly**


Item No.	Interval				ITEM TO BE INSPECTED Procedure: Check For and Have Repaired, Filled, or Adjusted as Needed.	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W		
7				•	<b>GATES</b> Inspect gates for damaged latch pins (1), hinges (2), panels (3) and slide bolts (4). Replace defective gates. 	
8	•	•	•		<b>TIE DOWN RINGS, POD STOPS AND FLOOR BOARDS</b> <ol style="list-style-type: none"> <li>Inspect for damaged or missing tie down rings (1).</li> <li>Inspect for loose, missing or damaged pod stops (2).</li> <li>Inspect for loose, damaged or warped floor boards (3). Notify Organizational Maintenance.</li> </ol> 	Missing tie down ring.  Missing or loose pod stops when required for mission.  Damaged or warped floor boards.

TA252143

**Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (cont)****NOTE**

Within designated interval, these checks are to be performed in the order listed.

**B – Before****D – During****A – After****W – Weekly**

Item No.	Interval				ITEM TO BE INSPECTED Procedure: Check For and Have Repaired, Filled, or Adjusted as Needed	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W		
9		•			<b>LIGHTS AND REFLECTORS</b> <p>a. Check all lights for proper operation.</p> <p style="text-align: center;"><b>NOTE</b></p> <p>An assistant is required while checking the brake lights with vehicle connected to prime mover.</p> <p>b. Check for damaged or missing reflectors.</p>	
10			•		<b>AIR TANKS</b> <p>a. Inspect both tanks (1) for damage and leakage.</p> <p style="text-align: center;"><b>WARNING</b></p> <p>Keep away from drain cocks when draining air tanks to prevent injury to eyes by compressed air.</p> <p>b. Open drain cocks (2) on air tanks to drain condensation.</p> <p>c. Close drain cocks.</p>  <p style="text-align: right;">TA252144</p>	Air leakage.

**Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (cont)**

## NOTE

Within designated interval, these checks are to be performed in the order listed.

## B – Before

**D – During**

### A — After

**W – Weekly**

[illegible]

### Section III. OPERATION UNDER USUAL CONDITIONS

	Page
Connecting HEMAT to Towing Vehicle . . .	2-14
Gate Installation . . . . .	2-18
Operation . . . . .	2-19
Disconnecting HEMAT from Towing Vehicle ..	2-21


	Page
Gate Removal . . . . .	2-23
Spare Tire Carrier . . . . .	2-24
Lifting Eyes . . . . .	2-26

#### 2-13. CONNECTING HEMAT TO TOWING VEHICLE


##### WARNING

Do not stand between towing vehicle and HEMAT when backing towing vehicle. Serious injury can result if personnel are caught between the vehicles.

- a. On towing vehicle, pull cotter pin (1) and open pintle (2). Back towing vehicle up until coupler is centered in towing vehicle pintle.




- b. Raise landing gear leg (3) using crank (4) until towing vehicle is supporting weight of trailer.



TA252145

## 2-13. CONNECTING HEMAT TO TOWING VEHICLE (cont)

- c. Close towing vehicle pintle (5) ensuring lock (6) is down in place, and install cotter pin to lock pintle.
- d. Attach safety chains (7) to towing vehicle ring (8).



- e. Connect intervehicular air hoses (9) to towing vehicle as follows:


### NOTE

Ensure service and emergency intervehicular air hoses are connected service to service and emergency to emergency on towing vehicle.

- (1) Remove intervehicular air hoses (9) from gladhand dummy coupler (10) on trailer tongue.
- (2) Remove dummy couplings (II).
- (3) Hold hose glandhand couplings (12) against the towing vehicle gladhand couplings (13) at a 90° angle and rotate until locked in place.

### NOTE

Be sure air hose strap is connected to tongue.



TA252146

## 2-13. CONNECTING HEMAT TO TOWING VEHICLE (cont)


f. Connect the HEMAT lighting system to the electrical system of the towing vehicle as follows:

- (1) Remove intervehicular cable (14) from storage box.
- (2) Open protective covers ( 1 5) of intervehicular cable. Lock each cover of intervehicular cable by sliding latch lock (16) in place.
- (3) Lift receptacle cover (17) on trailer.


### NOTE

Check receptacle for bent or broken pins.

- (4) Plug intervehicular cable into receptacle ( 18). Cable plugs are keyed **so** connection can be made only one way.
- (5) Connect opposite end of cable to tow-  
ing vehicle in the same way (steps (3)  
and (4)).




g. Pull plunger (19) out and raise shoe (20) using handle (21) until second lowest hole in shoe engages plunger detent.




TA252147

### 2-13. CONNECTING HEMAT TO TOWING VEHICLE (cont)


- h.** Crank landing gear leg up, using crank, until leg is fully retracted. Pull clip pin (22) and withdraw hitch pin (23) from flange (24).



- i.** Turn landing gear (25) to horizontal position so holes (26) in landing gear flange and frame flange are aligned.
- j** Pull crank (27) to disengage from landing gear shaft and stow crank in bracket (28).



- k.** Install hitch pin (29) in landing gear flange and install clip pin (30),



TA252148


## 2-14. GATE INSTALLATION

To install gates, proceed as follows:

- a. Using an assistant, hold left hand front gate rack horizontally and place next to left hand side of trailer forward.
- b. Position gate so both hinge pins ( 1 ) are alined with ears (2) on trailer frame.
- c. Move gate to engage hinge pins with holes in ears. Lift gate slightly to clear hinge stops if necessary.
- d. Lift up left hand front gate (3) to vertical.
- e. Engage slide bolt (4) on gate with pocket in frame to secure.
- f. Install left hand rear gate (steps a through d).
- g. Lift up left hand rear gate to vertical so holes in latch eyes (5) are aligned. Install latch pins (6) in latch eyes to secure.
- h. Install right hand rear gate in same manner as left hand front gate (steps a through e).
- i. Install right hand front gate in same manner as left hand rear gate (steps a through d and g).
- j. Install front gate and rear gate in same manner as left hand rear gate (steps a through d and g).

### NOTE

Gates can be lowered to permit better access and easier loading. Left hand front gate cannot be lowered unless left hand rear gate is lowered first. The same is true of the right hand rear gate.



TA252149



## 2-15. OPERATION

### a. Loading HEMAT.


- (1) Load cargo into HEMAT to distribute load weight as evenly as possible lengthwise and sidewise.
- (2) Secure load using tie down rings (1) which are located along edge of frame. Twenty-six tie down rings are provided.
- (3) If MLRS pods will be loaded on HEMAT, attach pod stops (2) to anchor plates in each corner of floor.

#### NOTE

Tie down ring (3) next to pod stop must be above edge of pod stop.

### b. Towing HEMAT.

- (1) **Driving.** When driving the towing vehicle with HEMAT, the overall length of the unit must be kept in mind when passing other vehicles and when turning. Because the unit is hinged in the middle, turning and backing are also affected. The HEMAT payload will affect stopping and off road maneuverability.
- (2) **Turning.** When turning corners, allow for the fact that the HEMAT wheels turn inside the turning radius of the towing vehicle. To make a right turn at a road intersection, drive the towing vehicle about halfway into the intersection and then cut sharply to the right. This will allow for the shorter turning radius of the HEMAT and will keep it off the curb.
- (3) **Stopping.** In normal operation, the brakes of the towing vehicle and the HEMAT are applied at the same time when the driver steps on the brake pedal. Brake pressure must be applied gradually and smoothly. The HEMAT brakes may be applied separately by using the brake control lever on the towing vehicle. On steep down grades or slippery surfaces, the HEMAT brakes must be applied before the vehicle



brakes. This will reduce the possibility of jackknifing.


- (4) **Parking.** When the towing vehicle and HEMAT are to be parked and left unattended, set the parking brake on the vehicle and apply the brakes on the HEMAT.

#### WARNING

Do not stand between towing vehicle and HEMAT when backing towing vehicle. Serious injury can result if personnel are caught between the vehicles.


- (5) **Jackknife Warning System.** To prevent jackknifing when backing the HEMAT is equipped with the following visible indicators:

- (a) A 2-inch vertical, black plate(1) mounted to the front gate 34 inches from each corner of the front gate.



## 2-15. OPERATION (cont)

- (b) A 2-inch black stripe (2) painted on each side of the tongue beam 7-3/4 inches forward of the bed.
- (c) An amber clearance marker light (3) mounted on the tongue strip.
- (d) A blackout clearance marker light (4) mounted directly above the amber light.



TA252218

### CAUTION

If the clearance marker lights and/or black stripes become visible during backing, the turn is too sharp and jackknifing is occurring.

- (6) **Backing.** When backing, the rear of the HEMAT will always move in the opposite direction of that in which the front wheels are turned. When the wheels of the towing vehicle are turned to the right, the rear of the HEMAT will go to the left. When the HEMAT has turned and backing in a straight line is required, turn the towing vehicle wheels in the direction that the HEMAT is moving. This will slowly bring the towing vehicle and the HEMAT in a straight line.

### CAUTION

Two ground guides are needed to back the HEMAT safely. Avoid backing up HEMTT/HEMAT system if possible. Refer to FM 21-60 for instructions on hand signals.

- (a) Adjust rear view mirrors on both sides of HEM MT for best visibility of the trailer and space behind.

- (b) Station one ground guide to the right or left rear of the trailer and the other ground guide to the left or right front of the towing vehicle. Front ground guide must be visible to operator at all times to provide backing instructions.

### CAUTION

Upon observing jackknife indicators operator must stop HEMTT immediately to prevent damage.




- (c) Back up slowly and pay close attention to ground guide's signals.

### c. Unloading HEMAT.

- (1) Remove any tie downs from the load.
- (2) Unload cargo.
- (3) Remove pod stops as necessary.

## 2-16. DISCONNECTING HEMAT FROM TOWING VEHICLE


- a. Remove crank (1) from bracket (2).
- b. Pull clip pin (3) and withdraw hitch pin (4).
- c. Swing crank (5) around so crank is lined with landing gear shaft (6). Push crank in to engage gear shaft.
- d. Turn landing gear to vertical position so holes in landing gear and frame flanges (7) are aligned. Install hitch pin (8) and clip pin (9).
- e. Crank landing gear down until shoe (10) is approximately one foot from ground.




TA252151

## 2-16. DISCONNECTING HEMAT FROM TOWING VEHICLE (cont)

- f. Pull free-fall plunger (11) so shoe (12) drops to ground.
- g. Crank landing gear leg (13) down, using crank (14), until coupler (lunette) is centered in towing vehicle pintle and landing gear is supporting weight of HEMAT.



- h. Disconnect intervehicular cable and stow in storage box.
- i. Disconnect intervehicular air hoses (15) and install dummy coupling (16).
- j. Install intervehicular air hoses (15) on gladhand dummy couplings (17).




- k. Disconnect safety chains (18) from towing vehicle and hook safety chain on the coupler plate.
- l. Remove cotter pin from towing vehicle pintle (19). Open towing vehicle pintle.

### WARNING

Crank landing gear leg until coupler clears towing pintle to prevent injury to personnel.

- m. Drive towing vehicle forward to clear HEMAT.




TA252152


## 2-17. GATE REMOVAL

To remove gates an assistant will be required. Proceed as follows:

- a. Hold rear gate in raised position and remove latch pins ( 1 ) from latch eyes (2). Lower rear gate down to horizontal position.
- b. Move rear gate endwise to disengage hinge pins with ears. Remove and stow gate.
- c. Lower and remove front gate in same way (steps a and b).
- d. Lower and remove right hand front gate and left hand rear gate in same way (steps a and b).



- e. Hold right hand rear gate (3) in raised position and remove latch pins from latch eyes. Disengage slide bolt (4) from pocket in frame and lower gate down to horizontal position.
- f. Move gate endwise to disengage hinge pins from ears. Remove and stow gate.
- g. Lower and remove left hand front gate in same way (steps e and f).



TA252153

## 2-18. SPARE TIRE CARRIER

### a. Removal of Spare Tire.



#### WARNING

Spare tire and plate will drop to the ground as soon as ratchet is released. Stand clear to prevent possible injury. Spare tire weighs approximately 250 pounds. Use care in handling to prevent injury.


#### NOTE

Assistance is required for these operations.

- (1) Remove four wheel nuts (1) from carrier studs to free spare tire (2).
- (2) Release pawl (3) from ratchet (4) on side of carrier using long shaft screwdriver or other suitable tool.



- (3) Manipulate tire plate (5) to pass it through wheel rim.
- (4) Remove spare tire from under trailer.




TA252154

**2-18. SPARE TIRE CARRIER (cont)****b. Installation of Spare Tire.****WARNING**

Spare tire weighs approximately 250 pounds. Use care in handling to prevent injury.

- (1) Inspect cable (1) for fraying, corrosion and looseness. Report defective condition to organizational maintenance.
- (2) Place spare tire (2) on ground below tire earner with valve stem down.
- (3) Insert tire plate (3) through rim so plate is level.
- (4) Check to be sure ratchet (4) and pawl (5) are engaged.
- (5) Engage lug wrench (6) with hex end of carrier shaft.
- (6) Turn lug wrench clockwise to take up slack in cable (7). Be sure tire plate is centered and leveled in wheel rim.
- (7) Continue to turn lug wrench to raise spare tire (8) fully until carrier studs (9) enter stud holes in rim,





- (8) Install four wheel nuts (10) to secure spare tire to carrier.
- (9) Remove lug wrench and place in storage box.

TA252155

## 2-19. LIFTING EYES

- a. To extend lifting eyes(1), pull out lock pins (2) and slide lifting eyes outward fully.
- b. To retract lifting eyes (3), slide lifting eyes inward fully so ears are over retaining blocks (4). Insert lock pins.



TA252156



## Section IV. OPERATION UNDER UNUSUAL CONDITIONS

	Page		Page
Operation in Extreme Cold . . . . .	2-27	Operation in Mud . . . . .	2-28
Operation in Extreme Heat . . . . .	2-27	Operation in Dusty or Sandy Areas . . . . .	2-28
Operation in Rainy or Humid Conditions . . . . .	2-27	Operation with Air Brake Failure . . . . .	2-28
Operation in Salt Water Areas . . . . .	2-27	Operation with SPL Adapter . . . . .	2-29
Operation in Snow . . . . .	2-27	Fresh Water Fording . . . . ., . . . . .	2-29

### 2-20. OPERATION IN EXTREME COLD

#### a. General.

- (1) Be careful when placing the HEMAT in operation after a shutdown. Congealed lubricants can cause part failure.
- (2) Tires may be frozen to the ground or have a flat spot if they were under-inflated.
- (3) Brakeshoes may be frozen to the brake drums. Notify organizational maintenance.
- (4) Refer to FM 9-207 and FM 21-305 for special instructions on driving hazards in snow and ice that may be encountered during extremely cold weather conditions.

#### b. At-Halt Parking.

- (1) For short shutdown periods, park in a sheltered spot out of the wind.
- (2) For long shutdown periods, if high, dry ground is not available, prepare a footing of planks or brush,
- (3) Remove all built-up ice and snow as soon as possible after shutdown.
- (4) Cover and shield the HEMAT with canvas covers (if available) but keep the ends of the covers off the ground to prevent them from freezing to the ground.

### 2-21. OPERATION IN EXTREME HEAT

- a. Do not park the HEMAT in the sun for long periods of time as heat and sunlight will shorten the life of the tires.
- b. Cover the HEMAT with canvas (if available) to protect it from heat, sun and dust.

### 2-22. OPERATION IN RAINY OR HUMID CONDITIONS

- a. Frequently inspect, clean, and lubricate inactive equipment to prevent rust and fungus accumulation.
- b. Check canvas covers (if available) periodically for deterioration and damage.

### 2-23. OPERATION IN SALT WATER AREAS

- a. Salt water will cause metal parts to rust and corrode. Clean, inspect, and lubricate frequently.
- b. Do not drive the HEMAT through more than 48 inches of water. Clean, inspect, and lubricate immediately after salt water fording or when the tactical situation permits.

### 2-24. OPERATION IN SNOW

Refer to FM 21-305 for special instructions on operations in snow.

## 2-25. OPERATION IN MUD

### CAUTION

Under no circumstances will the trailer be pushed at the rear or damage to trailer may result.

- a. If one or more wheels sink into the mud, it may be required to jack-up the mired wheel and insert planking or matting beneath it.
- b. Clean off all mud as soon after operation as possible.

## 2-26. OPERATION IN DUSTY OR SANDY AREAS

### CAUTION

Under no circumstances will the trailer be pushed at the rear or damage to trailer may result.

Frequently clean, inspect and lubricate the trailer.

## 2-27. OPERATION WITH AIR BRAKE FAILURE

### CAUTION

Do not attempt to operate the trailer with the air chamber springs caged except to move the vehicle out of the traveled portion of the highway in the event of an air system failure.

#### a. Caging Brake Air Chambers.


- (1) Block trailer to prevent movement by using chocks under wheels.

### WARNING

Do not remove flange nuts or bolts. High spring pressure inside of air chamber can cause injury if released.

- (2) Remove nut (1), washer (2) and release stud (3) from mounting pocket (4) on brake air chamber (5).
- (3) Remove plug (6).

- (4) Insert release stud (3) into chamber hole and turn one-quarter turn clockwise to engage stud in pressure plate.
- (5) Install nut (1) and washer (2) on release stud (3) and tighten nut to cage the air chamber springs.
- (6) Repeat steps (2) through (5) for remaining brake air chambers.
- (7) Remove chocks from under wheels.
- (8) Move trailer to side of road with caution.
- (9) Re-chock wheels to prevent trailer movement.



TA252157

#### b. Uncaging Brake Air Chambers.


- (1) Loosen and remove nut (1) and washer (2).
- (2) Turn release stud (3) one-quarter turn counterclockwise to free stud from pressure plate. Withdraw release stud.
- (3) Insert release stud (3) in pocket (4) and install nut (1) and washer (2) onto stud.
- (4) Install plug (6) in brake air chamber (5).
- (5) Remove wheel chocks.

## 2-28. OPERATION WITH SPLL ADAPTER

If it is necessary to tow the HEMAT with a SPLL vehicle, the SPLL adapter must be attached to the tongue of the trailer to allow additional clearance between the towing vehicle and trailer. All other operational procedures are the same as those described in Chapter 2, Section 111.


### a. SPLL Adapter Installation.

- (1) Remove one hex nut (1) and cap screw (2) to detach SPLL adapter from inside tool box.
- (2) Remove three hex nuts (1), four lock washers (4) and three cap screws (2) from slot (5) in SPLL adapter (3).
- (3) Attach SPLL adapter (3) under tongue (6) with four hex nuts (1), lock washers (4) and cap screws (2). Tighten hex nuts.
- (4) Push trailer parking brake control knob (7) to release parking brakes.



### b. Removal of SPLL Adapter.

- (1) Remove four hex nuts (1), lock washers (4) and cap screws (2) to detach SPLL adapter (3) from underside of trailer tongue (6).
- (2) Install three hex nuts (1), four lock washers (4) and three cap screws (2) in slot (5) in SPLL adapter (3).
- (3) Fasten SPLL adapter (3) to trailer frame in tool box with one hex nut (1) and cap screw (2). Tighten hex nut.



## 2-29. FRESH WATER FORDING

Maximum fording depth of the HEMAT is 48 inches. No special maintenance is required.

TA252 158



## CHAPTER 3

### OPERATOR MAINTENANCE

#### Section 1. LUBRICATION INSTRUCTIONS

General . . . . .	Page 3-1	Lubrication Chart . . . . .	Page 3-1
-------------------	-------------	-----------------------------	-------------

#### 3-1. GENERAL

**a. Lubrication Instructions.** The lubrication chart (para. 3-2) prescribes cleaning and lube procedures, proper materials for lubeing, and lube in-

tervals. The location of fittings and points is also included. An overall view showing lube points precedes the detailed views.

#### 3-2. LUBRICATION CHART

Lubrication instructions are mandatory.

Service intervals are based on normal operation. Lube more often during constant use and lube less often during inactive periods.

Relubricate after salt water fording.

Clean fittings before lubricating.

Dotted lines indicate lube points on both sides of the equipment.

DO NOT overlubricate; wipe off excess lubricant.

#### KEY

Lubricants	Above +32°F (0°C)	Expected Temperature +40°F to -10°F (+4°C to -23°C)	*0°F to -65°F (-18°C to -54°C)
<b>GAA</b> Grease, Lubricating, Automotive and Artillery (item 4, app E)	GAA	GAA	GAA
<b>OE</b> Lubricating Oil, Internal Com- bustion Engine (item 6, app E)	OE/HDO30	OE/HDO10	
<b>OEA</b> Lubricating Oil, Internal Com- bustion Engine, Subzero (item 7, app E)			* OEA

\*For Artic operation, refer to FM 9-207.

Landing Gear  
(See Detail A) (C)

Landing Gear  
Crank  
(See Detail A) (C)

Landing Gear  
Pivot Collar  
(See Detail A) (C)

Landing Gear  
Plunger  
(See Detail A) (C)

Wheel Bearings  
(See Detail E) (O)

S GAA

W OE

S GAA

W OE

S GAA

OE


W Cover Hinge  
(See Detail B) (C)

GAA S Slack Adjuster  
(See Detail D) (C)

GAA S Camshaft Bearings  
(See Detail C) (C)

GAA S Slack Adjuster  
(See Detail D) (C)

GAA S Camshaft Bearings  
(See Detail C) (C)




**NOTE**

Lubricate gate hinge pins and gate lock pins as  
required with OE (C).


Intervals: W – Weekly S – Semiannually

TA252159


**DETAIL A  
LANDING GEAR (4 POINTS)**




**DETAIL B  
COVER HINGE (1 POINT)**



**DETAIL C  
CAMSHAFT BEARINGS (8 POINTS)**




**DETAIL D  
SLACK ADJUSTERS (4 POINTS)**



**DETAIL E  
WHEEL BEARINGS (4 POINTS)**

Service and lubricate (para. 4-14).



TA252160

Section II. OPERATOR TROUBLESHOOTING PROCEDURES

Symptom Index . . . . .	Page 3-4	Troubleshooting Table . . . . .	Page 3-4
-------------------------	----------	---------------------------------	----------

3-3. SYMPTOM INDEX

	Page No.
<b>BRAKES</b>	
Brakes will not release ., . . . .	3-6
Grabbing brakes . . . . .	3-7
Hard pulling . . . . .	3-7
<b>ELECTRICAL SYSTEM</b>	
All lamps do not light . . . . .	3 4
One or more (but not all) lights will not light.....	3-5
Dim or flickering lights ., . . . .	3-6
<b>LANDING GEAR</b>	
Landing gear is difficult to operate . . . . .	3-7
<b>TIRES</b>	
Excessively worn, scuffed, or flat spots on tires, . . . . .	3-8

I 3-4. TROUBLESHOOTING TABLE I

- a. Table 3-1 lists the common malfunctions which you may find during the operation of the HEMAT or its components. You should perform the test/inspections and corrective maintenance in the order listed.
- b. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or it is not corrected by the listed corrective actions, notify your supervisor.

Table 3-1. Operator Troubleshooting Table

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

ELECTRICAL SYSTEM

1. ALL LAMPS DO NOT LIGHT.

- step 1. Check lights on towing vehicle including turn signals and stop lights.
- a. If towing vehicle lights do not light, notify organizational maintenance.
- b. If towing vehicle lights come on, proceed to step 2.
- Step 2. Check intervehicular cable.
- a. If cable is not properly connected, reconnect cable.
- b. If cable is properly connected, proceed to step 3.



**Table 3-1. Operator Troubleshooting Table (Continued)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
<b>ELECTRICAL SYSTEM (cont)</b>		
<b>1. ALL LAMPS DO NOT LIGHT (cont).</b>		
Step 3.	Check connectors for dirty or corroded pins. Check for damaged pins.	<ul style="list-style-type: none"> <li>a. If pins are dirty or corroded, clean the pins.</li> <li>b. If pins are damaged, notify organizational maintenance.</li> <li>c. If the above steps do not correct the malfunction, notify organizational maintenance.</li> </ul>
<b>2. ONE OR MORE (BUT NOT ALL) LIGHTS WILL NOT LIGHT.</b>		
Step 1.	Check for burned out or defective lamps.	<ul style="list-style-type: none"> <li>a. If lamps are burned out or defective, replace lamps (para. 3-5).</li> <li>b. If lamps are not burned out or defective, proceed to step 2.</li> </ul>
Step 2.	Check for broken lead wires or loose connections.	<ul style="list-style-type: none"> <li>a. If connections are loose, tighten connections.</li> <li>b. If lead wires are broken, notify organizational maintenance.</li> <li>c. If connections are not loose or broken, proceed to step 3.</li> </ul>
step 3.	Check light assembly for damage.	<ul style="list-style-type: none"> <li>a. If light assembly is damaged, notify organizational maintenance.</li> <li>b. If lens and light assembly are not damaged, proceed to step 4.</li> </ul>
step 4.	Check for dirty or corroded bulb socket.	<ul style="list-style-type: none"> <li>a. If socket is dirty, clean socket.</li> <li>b. If the above steps do not correct the malfunction, notify organizational maintenance.</li> </ul>

**Table 3-1. Operator Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
--------------------	---------------------------	--------------------------

**ELECTRICAL SYSTEM****3. DIM OR FLICKERING LIGHTS.**

- Step 1. Check electrical connections for loose, dirty, or corroded pins.
- a. If connections are loose, tighten connections.
  - b. If connector pins are dirty or corroded, clean pins.
  - c. If connections are tight and clean, proceed to step 2.
- Step 2. Check for defective lamp.
- a. If lamp is defective, replace lamp (para. 3-5).
  - b. If lamp is not defective and malfunction is not corrected, notify organizational maintenance.

**BRAKES****1. BRAKES WILL NOT RELEASE.**

- Step 1. Check that towing vehicle to HEMAT air supply is turned on.
- a. If air is shut off, turn on air supply.
  - b. If air supply is on, proceed to step 2.
- Step 2. Check connections of air hoses between towing vehicle and HEMAT.
- a. If air hoses are not properly connected (Emergency to Emergency, Service to Service), reconnect air hoses.
  - b. If air lines are connected properly, proceed to step 3.
- Step 3. Disconnect air hoses from HEMAT to towing vehicle.
- a. Operate brake release valve. Brakes should release.
  - b. If brakes do not release, notify organizational maintenance.

**Table 3-1. Operator Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
--------------------	---------------------------	--------------------------

**BRAKES****2. GRABBING BRAKES.****WARNING**

Keep away from drain cocks when draining air tanks to prevent injury to eyes by compressed air.

Check for moisture in air tanks by opening drain cocks.

- a. If moisture is in tanks, allow to drain.
- b. If tanks are dry and malfunction is not corrected, notify organizational maintenance.

**3. HARD PULLING.**

Check for cross connected air hoses.

- a. If air hoses are cross connected, connect properly.
- b. If air hoses are connected properly, notify organizational maintenance

**LANDING GEAR****1. LANDING GEAR IS DIFFICULT TO OPERATE.**

- Step 1. Check for dirt, debris and other foreign materials.
  - a. Remove dirt, debris and other foreign materials.
  - b. If landing gear does not operate properly, proceed to step 2.

- Step 2. Check for lack of lubrication.
  - a. Lubricate landing gear (para. 3-2).
  - b. If landing gear has sufficient grease, proceed to step 3.

- Step 3. Check for misaligned, bent, or damaged landing gear.
 

If landing gear is misaligned, bent, or damaged, notify organizational maintenance.

**Table 3-1. Operator Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
<b>TIRES</b>		
<b>1. EXCESSIVELY WORN OR SCUFFED TIRES OR FLAT SPOTS ON TIRES.</b>		
Step 1.	Check tire pressure.	<ul style="list-style-type: none"> <li>a. If tire pressure is less than 85 psi (4.07 KPa), inflate tires to 85 psi (maximum).</li> <li>b. If tire pressure is 85 psi, proceed to step 2.</li> </ul>
Step 2.	Check for loose, cracked, or broken wheels.	<ul style="list-style-type: none"> <li>a. If wheel nuts are loose, tighten nuts.</li> <li>b. If wheel is cracked or broken, replace with spare wheel and tire (para. 3-6).</li> <li>c. If wheel is secure and not cracked or broken, proceed to step 3.</li> </ul>
Step 3.	Check suspension system for damaged rubber bushings, springs and loose or missing bolts and nuts.	<ul style="list-style-type: none"> <li>a. If suspension system is damaged or has loose or missing bolts and nuts, notify organizational maintenance.</li> <li>b. If suspension system is not damaged and all hardware is complete and secure, and problem still exists, notify organizational maintenance.</li> </ul>

### Section III. OPERATOR MAINTENANCE PROCEDURES

Electrical System . . . . . Page  
3-9

Wheels and Tires . . . . . Page  
3-10

#### 3-5. ELECTRICAL SYSTEM

**a. General.** Maintenance of the electrical system at crew level is limited to replacement of the lamps in the composite lights, marker lights and/or running lights.


**b. Composite Lights.** Replace lamps as follows:

- (1) Loosen six captive screws ( 1 ) and remove lens assembly (2) with packing (3).
- (2) Remove defective lamp (4, 5 or 6) by pressing in and rotating lamp counterclockwise until it releases; withdraw lamp from socket.
- (3) Insert new lamp in socket, press in and rotate lamp clockwise until it locks in place.

#### NOTE


Be sure preformed packing (3) is seated between light body and lens assembly to seal the unit properly.

- (4) position lens assembly (2) on body and tighten six captive screws (1 ).



**c. Clearance Marker Lights.** Replace lamps as follows:

- (1) Remove two screws (1) and light cover (2).
- (2) Remove lamp (3) by pressing in and rotating lamp counterclockwise until it releases; withdraw lamp from socket.
- (3) Insert new lamp in socket, press in and rotate lamp clockwise until it locks in place.
- (4) Position light cover (2) on body and install two screws ( 1 ) to attach covers.



TA252161

### 3-6. WHEELS AND TIRES

#### Materials/Tools

Lug wrench (in tool box)  
Tire changing block (in tool box)  
Breaker bar  
Prime mover jack

**a. General.** Maintenance of the wheels and tires is limited to exchanging a defective wheel and tire with a serviceable wheel and tire. Refer to paragraph 2- I 8 for operation of the spare tire carrier.


#### b. Removal of Wheels and Tires.

- ( 1 ) Using lug wrench and breaker bar from tool box, loosen wheel nuts on the wheel but do not remove.

#### NOTE

Right wheel nuts are turned counterclockwise to loosen and left wheel nuts are turned clockwise to loosen.

- (2) Place tire changing block (1) in front of good tire (2).
- (3) Pull HEMAT forward so tire is up on block.
- (4) Place jack (3) underneath equalizer hanger and socket (4).
- (5) Jack up equalizer hanger, making sure jack head enters socket (4).
- (6) Remove wheel nuts (5). Remove wheel and tire (6).



TA252162

**3-6. WHEELS AND TIRES (cont)****c. Installation of Wheels and Tires.**

- (1) Place spare wheel and tire (6) over wheel lugs and install the wheel nuts (5). Tighten wheel nuts using the lug wrench.


**NOTE**

Right wheel nuts are turned clockwise to tighten and left wheel nuts are turned counterclockwise to tighten.

- (2) Lower jack (3) until tire is on ground. Remove jack.

**CAUTION**

Failure to tighten wheel nuts may result in fatigue rupture of the wheel studs.



TIGHTENING  
SEQUENCE  
FOR LUG NUTS

TA252163

- (3) Retighten wheel nuts using lug wrench and breaker bar.
- (4) Pull HEMAT forward off tire changing block ( 1 ).
- (5) Remove tire changing block ( 1 ). Stow block and lug wrench in tool box.
- (6) Notify organizational maintenance of tire change so wheel nuts may be torqued to 450-500lb-ft (610-678 Nm) and tire repaired.





## CHAPTER 4

### FIELD MAINTENANCE INSTRUCTIONS (ORGANIZATIONAL MAINTENANCE)

#### Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

	Page
Common Tools and Equipment .....	4-1
Special Tools, TMDE and Support Equipment .....	4-1
Repair Parts .....	4-1

#### 4-1. COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment, refer to the table of organization and equipment (TOE) or the modified table of organization and equipment (MTOE) applicable to your unit.

#### 4-2. SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

Tire iron T47A (reference 7, app B, section III)  
Tire iron T46B (reference 8, app B, section III)  
Locking jaw pliers (reference 9, app B, section III)

#### 4-3. REPAIR PARTS

Repair parts are listed and illustrated in appendix F of this manual.

Section II. SERVICE UPON RECEIPT OF MATERIAL

	Page
Unpacking and Checking the Equipment .....	4-2
Service the Equipment.....	4-2

4-4. UNPACKING AND CHECKING THE EQUIPMENT

- a. Remove any metal strapping, plywood, tapes, seals, wrapping paper or any other shipping and protective items.

WARNING

Solvent cleaning compound is an environmentally compliant product and is low in toxicity. However, it may be irritating to the eyes and skin due to its base stock. The use of protective gloves and goggles is required. Use the cleaning compound in well-ventilated areas and keep away from open flames and other sources of ignition.

- b. If any exterior parts are coated with rust preventive compound, remove it with solvent cleaning compound.
- c. Inspect the equipment for damage incurred during shipment.
- d. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with the instructions of DA Pam 750-8.

4-5. SERVICING THE EQUIPMENT

- a. Perform the preventive maintenance checks and services contained in Tables 2-1 and 4-1.b.
- b. Lubricate all points as shown in the Lubrication Instructions (Chapter 3, Section I) regardless of interval.
- c. Schedule the next preventive maintenance checks and services on DD Form 314, Preventive Maintenance Schedule and Record.
- d. Report all deficiencies on DA Form 2407 if the deficiencies appear to involve unsatisfactory design.
- e. Perform a break-in road test of 25 miles at a maximum speed of 50 miles per hour.

## Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

General.....	Page 4-3
Organizational Preventive Maintenance Checks and Services .....	4-3

### 4-6. GENERAL

To ensure that the trailer is ready for operation at all times, it must be inspected systematically so that defects may be discovered and corrected before they result in serious damage or failure. Table 4-1 contains a tabulated listing of preventive maintenance checks and services to be performed by organizational maintenance personnel. All deficiencies and shortcomings will be recorded as well as the corrective action taken on DA Form 2404 at the earliest possible opportunity.

### 4-7. ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES

- a. The item numbers of table 4-1 indicate the sequence of the PMCS. Perform at the intervals shown below:
    - (1) Do your semiannual (S) PREVENTIVE MAINTENANCE once each 6 months.
    - (2) Do your annual (A) PREVENTIVE MAINTENANCE once each year.
  - b. If something doesn't work, troubleshoot it with the instructions in this manual or notify your supervisor.
  - c. Always do your preventive maintenance in the same order, so it gets to be a habit. Once you've had some practice, you'll spot anything wrong in a hurry.
  - d. If anything looks wrong and you can't fix it, write it down on your DA Form 2404. If you find something seriously wrong, report it to direct support as soon as possible.
- (1) Keep it clean: Dirt, grease, oil, and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use solvent cleaning compound to clean metal surfaces. Use soap when you clean rubber or plastic material.
  - (2) Bolts, nuts, and screws: Check that they are not loose, missing, bent, or broken. You can't try them all with a tool, of course; but look for chipped paint, bare metal, or rust around bolt heads. Tighten any that you find loose.
  - (3) Welds: Look for loose or chipped paint, rust, or gaps where parts are welded together. If you find a bad weld, report it to direct support maintenance.
  - (4) Electric wires and connectors: Look for cracked or broken insulation, bare wires, and loose or broken connectors. Tighten loose connections and make sure the wires are in good condition.
  - (5) Air hoses: Look for wear, damage, and leaks. Make sure clamps and fittings are tight. If a leak comes from a loose fitting or connector, tighten it. If something is broken or worn out, either correct it or report it to your supervisor. (Refer to App B.)

### WARNING

**Solvent cleaning compound is an environmentally compliant product and is low in toxicity. However, it may be irritating to the eyes and skin due to its base stock. The use of protective gloves and goggles is required. Use the cleaning compound in well-ventilated areas and keep away from open flames and other sources of ignition.**

Table 4-1. Organizational Preventive Maintenance Checks and Services

S – Semiannually

A - Annually


Item No.	Interval		ITEM TO BE INSPECTED Procedure:
	S	A	
1			<p style="text-align: center;"><b>NOTE</b></p> <p>Perform operator/crew PMCS prior to or in conjunction with organizational PMCS if:</p> <ol style="list-style-type: none"> <li>There is a delay between the daily operation of organizational PMCS.</li> <li>Regular operator is not assisting/participating.</li> </ol> <ul style="list-style-type: none"> <li><b>WHEELS AND TIRES</b></li> </ul> <p>Rotate and match tires (1) according to tread design and degree of wear. See TM 9-2610-200-20 for acceptable limits in matching tires. Tighten wheel nuts (2) to 450-500 lb-ft. (610-678 N•m).</p>  <p style="text-align: right;">TA252164</p>
2			<ul style="list-style-type: none"> <li><b>SERVICE BRAKES</b></li> </ul> <ol style="list-style-type: none"> <li>Inspect hub and drum for visible wear and scoring (para 4-14c).</li> <li>Inspect wheel bearings for visible wear and seal for deterioration and damage (para 4-14c).</li> <li>Inspect brake shoes for wear (para 4-15a).</li> <li>Inspect camshafts for visible wear and damage (para 4-15b).</li> <li>Inspect camshaft bearings for visible wear (para 4-15b).</li> </ol>

Table 4-1. Organizational Preventive Maintenance Checks and Services (cont)





Item No.	Interval		ITEM TO BE INSPECTED Procedure:
	S	A	
3	•		<p><b>BRAKE AIR CHAMBERS</b></p> <p><b>WARNING</b></p> <p>Do not attempt to disassemble brake air chambers (1). The springs inside the chambers are under heavy tension and may cause severe injury if released during disassembly.</p> <p>Inspect brake air chambers (1) for visible damage, particularly push rod boots. Replace defective boots.</p> 
4	•		<p><b>SLACK ADJUSTERS</b></p> <p>a. Inspect slack adjusters (1) for damage.</p> <p>b. Remove dust shield (2) and check brake shoe (3) clearance (para 4-15c).</p>  <p style="text-align: right;">TA252165</p>

Table 4-1. Organizational Preventive Maintenance Checks and Services (cont)



S – Semiannually

A - Annually

Item No.	Interval		ITEM TO BE INSPECTED Procedure:
	S	A	
5	•		<p>SPRINGS AND U-BOLTS</p> <p>a. Inspect springs (1) for sagging and broken leaves. Notify direct support maintenance.</p> <p>b. Inspect U-bolts (2) for breakage and loose nuts. Tighten loose nuts to 350 lb-ft (475 Nm). Replace defective U-bolt(s). Notify direct support maintenance.</p> 
6	•		<p>AXLES</p> <p>Inspect axles (1) for cracks, damaged brackets (2), pads (3), and axle bumpers (4). Replace defective axle(s). Notify direct support maintenance.</p> 

TA252166

Table 4-1. Organizational Preventive Maintenance Checks and Services (cont)

Item No.	Interval		ITEM TO BE INSPECTED Procedure:
	S	A	
7		•	<p><b>WIRING HARNESS</b></p> <p>Inspect wiring harness (1) for loose mounting, broken wires, damaged insulation and connections. Repair or replace defective wiring harness (para 4-13).</p> 
8		•	<p><b>FLOOR BOARDS AND FRAME</b></p> <p>a. Inspect floorboards (1) for breakage and warpage. Report deficiencies to direct support maintenance.</p> <p>• b. Inspect storage box cover (2) for loose hinge or damaged cover. Replace defective parts (para 4-30).</p> <p>• c. Inspect bumpers and splash guards for deterioration and damage. Replace defective bumpers (para 4-24) and splash guards (para 4-34).</p> <p>• d. Inspect frame (3) for peeling paint, distortion and other damage. Report deficiencies to direct support maintenance.</p>  <p style="text-align: center;">TA252167</p>





Section IV. ORGANIZATIONAL TROUBLESHOOTING PROCEDURES

Symptom Index . . . . .	Page 4-9	Troubleshooting Table . . . . .	Page 4-9
-------------------------	-------------	---------------------------------	-------------

4-8. SYMPTOM INDEX

	Page No.
BRAKES	
Brakes will not release . . . . .	4-11
No brakes or weak brakes . . . . .	4-11
Slow brake application or slow release . . . . .	4-12
Grabbing brakes . . . . .	4-13
Hard pulling (one or more brake drums running hot) . . . . .	4-13
ELECTRICAL SYSTEM	
All lamps do not light . . . . .	4-10
One or more (but not all) will not light . . . . .	4-10
Dim or flickering lights . . . . .	4-10
LANDING GEAR	
Difficulty in lowering or raising landing gear . . . . .	4-14
SPRINGS AND SUSPENSION	
Improper spring action . . . . .	4-14
TIRES	
Excessively worn, scuffed tires, or flat spots on tires . . . . .	4-15

4-9. TROUBLESHOOTING TABLE

- a. Table 4-2 lists the common malfunctions which may be found during the operation or maintenance of the HEMAT or components. You should perform the test/inspections and corrective actions in the order listed.
- b. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or it is not corrected by the listed corrective actions, notify your supervisor.

**Table 4-2. Troubleshooting Table****MALFUNCTION****TEST OR INSPECTION****CORRECTIVE ACTION****ELECTRICAL SYSTEM****(See Schematic Diagram, page no. 4-21)****1. ALL LAMPS DO NOT LIGHT.**

Step 1. Check intervehicular cable (para. 4-12).

- a. If cable is defective, replace cable.
- b. If cable is not defective, proceed to step 2.

Step 2. Check for ground or open circuit in wiring (para. 4-12).

If wiring has a ground or open circuit, repair or replace wiring (para. 4-13).

**2. ONE OR MORE LAMPS (BUT NOT ALL) WILL NOT LIGHT.**

Step 1. Check for defective light assemblies (para. 4-12).

- a. Replace defective light assemblies.
- b. If light is not damaged, proceed to step 2.

Step 2. Check for ground or open circuit in wiring (para. 4-12).

If wiring has a ground or open circuit, repair or replace wiring.

**3. DIM OR FLICKERING LIGHTS.**

Step 1. Check for defective light assemblies (para. 4-12).

- a. Replace or repair defective light assemblies.
- b. If light assemblies are not defective, proceed to step 2.

Step 2. Check for intermittent ground or open circuit (para. 4-12).

If wiring is defective, repair or replace wiring.

**Table 4-2. Troubleshooting Table (Continued)**

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<b>BRAKES</b>		
<b>1. BRAKES WILL NOT RELEASE.</b>		
Step 1.	Check operation of air brake chambers (Table 2-1).	<ul style="list-style-type: none"> <li>a. If one air brake chamber does not release, replace defective brake chamber.</li> <li>b. If all air brake chambers do not release, proceed to step 2.</li> </ul>
Step 2.	Check operation of parking brake control (Table 2-1).	<ul style="list-style-type: none"> <li>a. If parking brake control does not operate, replace parking brake control.</li> <li>b. If replacing parking brake control does not correct the defect, proceed to step 3.</li> </ul>
Step 3.	Check trailer valve operation for application of emergency air to air brake chambers.	If emergency air is not being applied to air brake chambers, replace trailer valve,
<b>2. NO BRAKES OR WEAK BRAKES.</b>		
Step 1.	Check for low air pressure (leakage at connection, air lines or valves) (Table 2-1).	<ul style="list-style-type: none"> <li>a. If air lines/connections are leaking, repair or replace as needed,</li> <li>b. If valve is leaking, replace defective valve.</li> <li>c. If air lines connections or valves are not leaking, proceed to step 2.</li> </ul>
Step 2.	Inspect for grease on brake lining.	<ul style="list-style-type: none"> <li>a. If grease is present on brake linings, replace defective oil seals and brake shoes.</li> <li>b. If grease is not present on brake lining, proceed to step 3.</li> </ul>
Step 3.	Check for worn brake lining (Table 4-1).	<ul style="list-style-type: none"> <li>a. If brake lining is worn, replace brake shoe.</li> <li>b. If brake lining is not worn, proceed to step 4.</li> </ul>
Step 4.	Check brake adjustment (para. 4-15c).	<ul style="list-style-type: none"> <li>a. Adjust brake shoes if out of adjustment.</li> <li>b. If brakes are adjusted, proceed to step 5.</li> </ul>

**Table 4-2. Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
<b>BRAKES</b>		
<b>2. NO BRAKES OR WEAK BRAKES (cont).</b>		
Step 5.	Check for relay valve operation by observing action of air brake chambers.	<ul style="list-style-type: none"> <li>a. If air brake chambers do not operate, replace relay valve (para. 4-18a).</li> <li>b. If action of air brake chambers is not positive, replace relay valve.</li> <li>c. If a single air brake chamber does not operate properly, replace brake chamber (para. 4-16).</li> </ul>
<b>3. SLOW BRAKE APPLICATION OR SLOW RELEASE.</b>		
Step 1.	Check for low air pressure (leakage at connections, air lines or valves) (Table 2-1).	<ul style="list-style-type: none"> <li>a. If air lines/connections are leaking, repair or replace as needed.</li> <li>b. If valve is leaking, replace defective valve.</li> <li>c. If air lines/connections and valves are not leaking, proceed to step 2.</li> </ul>
Step 2.	Remove and check for restrictions in air lines and hoses (para. 4-17).	<ul style="list-style-type: none"> <li>a. If air lines or hoses are restricted, replace as required.</li> <li>b. If air lines or hoses are not restricted, proceed to step 3.</li> </ul>
Step 3.	Check for damaged or broken brake shoe springs (para. 4-15a).	<ul style="list-style-type: none"> <li>a. If a spring is defective, replace spring.</li> <li>b. If any spring is not defective, proceed to step 4.</li> </ul>
Step 4.	Check for air brake chamber operation (Table 2-1).	<ul style="list-style-type: none"> <li>a. If one air brake chamber operates slowly, replace defective brake chamber.</li> <li>b. If all air brake chambers operate slowly, replace relay valve.</li> <li>c. If all air brake chambers still operate slowly, replace trailer valve.</li> </ul>

**Table 4-2. Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
<b>BRAKES (cont)</b>		
<b>4. GRABBING BRAKES.</b>		
Step 1.	Check brake adjustment (para. 4-15c).	a. If brakes are out of adjustment, adjust brakes. b. If brakes are not out of adjustment, proceed to step 2.
Step 2.	Check for grease on brake lining.	a. If grease is present, replace brake shoes and oil seals. b. If grease is not present on brake lining, proceed to step 3.
Step 3.	Check for cracked, scored, or deformed brake drum (Table 4-1).	a. If brake drum is cracked, scored, or deformed, replace brake drum. b. If brake drum is not cracked, scored, or deformed, proceed to step 4.
Step 4.	Check for worn or loose brake linings (Table 4-1).	If linings are worn or damaged, replace brake shoes.
<b>5. HARD PULLING (ONE OR MORE BRAKE DRUMS RUNNING HOT).</b>		
Step 1.	Check for cross connected air hoses.	a. If hoses are cross connected, correct hoses properly. (See air system diagram, page 4-37). b. If hoses are not cross connected, proceed to step 2.
Step 2.	Check brake adjustment (para. 4-15c).	a. If brakes are out of adjustment, adjust brakes. b. If brakes are not out of adjustment, proceed to step 3.
Step 3.	Check for weak or broken brake shoe springs (para. 4-15a).	If a spring is defective, replace spring.

Table 4-2. Troubleshooting Table (cont)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

LANDING GEAR

DIFFICULTY IN LOWERING OR RAISING LANDING GEAR.

- Step 1. Inspect for misaligned or damaged landing gear leg.
- a. If leg is damaged or misaligned, replace landing gear
  - b. If leg is not damaged or misaligned, proceed to Step 2.
- Step 2. Inspect for damaged gearing.
- If gearing is damaged, replace landing gear.

SPRINGS AND SUSPENSION

IMPROPER SPRING ACTION.

- Step 1. Check for loose or damaged U-bolts.
- a. If U-bolts are loose, tighten U-bolts.
  - b. If U-bolts are damaged, replace U-bolts. Notify direct support maintenance.
  - c. If U-bolts are not damaged, proceed to Step 2.
- Step 2. Check for broken or weak spring leafs.
- a. If spring leafs are broken or weak, replace spring leaf(s). Notify direct support maintenance.
  - b. If springs are not broken or weak, proceed to Step 3.
- Step 3. Check torque rods for looseness or damage.
- If torque rods are loose or damaged, replace torque rod(s). Notify direct support maintenance.

**Table 3-1. Operator Troubleshooting Table (cont)**

<b>MALFUNCTION</b>	<b>TEST OR INSPECTION</b>	<b>CORRECTIVE ACTION</b>
--------------------	---------------------------	--------------------------

**TIRES****EXCESSIVELY WORN OR SCUFFED TIRES OR FLAT SPOTS ON TIRES.****NOTE**

Refer to para. 3-6 for jacking procedure.

Step 1. Check for loose wheels.

- a. If wheels are loose, tighten wheel nuts.
- b. If wheels are not loose, proceed to Step 2.

Step 2. Check for loose wheel bearings (para. 4-14e).

- a. If wheel bearings are loose, adjust wheel bearings.
- b. If wheel bearings are not loose, proceed to Step 3.

Step 3. Check suspension system for damaged rubber bushings, springs, and loose or missing bolts and nuts.

- a. If suspension system is damaged or has loose or missing bolts and nuts, replace defective components. Notify direct support maintenance.
- b. If suspension system is not damaged and all hardware is complete and secure, replace defective components. Notify direct support maintenance.

## Section V. MAINTENANCE OF ELECTRICAL SYSTEM

Composite Lights . . . . .	Page 4-16
Clearance Marker Lights . . . . .	4-17

Testing Electrical System . . . . .	Page 4-17
Wiring Harness . . . . .	4-18

### 4-10. COMPOSITE LIGHTS

#### Materials/Tools

General mechanics tool kit

#### a. Removal.

- (1) Tag and disconnect connectors (1) from wiring harness. Remove plastic tyrap (2).
- (2) Remove two cap screws (3) and lock washers (4) to detach each composite light (5). Remove light (5).

#### b. Repair.

- (1) Loosen six captive screws (6) and remove lens (7).


#### NOTE

Do not remove packing (8) unless damaged.

- (2) Replace any defective lamps (9, 10 and 11).
- (3) Install new packing (8) if packing was removed in lens (6) and fasten unit to body (12) with captive screws (6).

#### c. Installation.

- (1) Install composite light (5) on trailer with two cap screws (3) and lock washers (4).
- (2) Connect connectors (1) to wiring harness. Make sure that tag or marker numbers on wires correspond. Install tyrap (2).



TA252170



## 4-11. CLEARANCE MARKER LIGHTS

### Materials/Tools

General mechanics tool kit


All clearance marker lights (1) are identical except for the lenses.

#### a. Removal.

- (1) Disconnect light connector from harness connector.
- (2) Remove two screws (2) and lens (3).
- (3) Remove lamp (4).
- (4) Remove two screws (5) and light housing (6).
- (5) Push shell (7) back on wire and remove C-washer (8) and shell (7). Remove terminal (9) if damaged.

#### b. Installation.

- (1) Install terminal (9) if removed. Insert terminal (9) through shell (7). Install C-washer (8) on terminal (9) and pull shell (7) over terminal.
- (2) Mount light housing (6) to trailer with two screws (5).
- (3) Install lamp (4).
- (4) Install lens (3) with two screws (2).
- (5) Connect connector to wiring harness.



TA252171

## 4-12. TESTING ELECTRICAL SYSTEM

### Materials/Tools

Multimeter

#### a. Check for Grounds.

- (1) Disconnect all wiring connectors at the lights. Be sure identification markers are present on individual wires before disconnecting. If not, tag wires.

#### NOTE

Check for continuity on grounds using the multimeter on a low ohms scale.

- (2) Check for continuity between wiring harness connector pin D and the chassis. If the circuit is open, repair ground lead on wiring harness.
- (3) Check for grounds between wiring harness connector pins A, B, C, E, F and J and pin D (ground). (Refer to schematic diagram, page 4-2 1.) There should be an open circuit between the connectors pins. If there is continuity between any connector pin as specified, that circuit is grounded and the wiring harness must be repaired or replaced.
- (4) Remove all lamps from lights (para. 4-10 and 4-11).
- (5) Check for grounds from each light lead wire and the chassis (ground). There should be an open circuit between each lead wire and the chassis. If there is continuity on any lead wire, the wire is grounded and must be repaired or the light replaced.

## 4-12. TESTING ELECTRICAL SYSTEM (cont)

### b. Check Wiring Harness Continuity.

- (1) Install all lamps in lights (para. 4-10 and 4-11).
- (2) Check for continuity between each light lead wire and the chassis. If there is an open circuit, first check lamp. If lamp is defective replace it. If there is still an open circuit, repair lead wire or replace light.
- (3) Connect all wire connectors at lights.
- (4) Check for continuity between wiring harness connector pins A, B, C, E, F and J and pin D (ground). Each circuit should indicate continuity. If not, there is a broken wire and wiring must be repaired or replaced.

### c. Check Intervehicular Cable Continuity.

Check for continuity between individual connector pins and socket on opposite ends of cable at terminals A, B, C, D, E, F and J. Each circuit should indicate continuity. If any circuit is open, replace cable.

## 4-13. WIRING HARNESS

### Materials/Tools

General mechanics tool kit  
Electrical tool kit  
Soldering iron  
Wiping rag (item 10, app E)

### NOTE

Remove complete harness only if required to effect repair or replacement.

### a. Removal.

- (1) Tag and disconnect harness connectors (1 and 2) at all lights.
- (2) Remove tyrap (3) around harness (4) at composite light mounting bracket.

- (3) Remove nuts (5) from studs (6) at 19 positions along frame securing wiring harness (4) and remove clamps (7) from harness.
- (4) Remove four lock nuts (8) and cap screws (9) to free ground lead (11), connector (12) and cover (13) from frame. Remove lock washer (10).

### NOTE

To make installation easier, tape connector bundles to main harness if desired.

- (5) Feed wire harness (4) through grommets (14 and 15) and along frame while pulling harness through frame hole for connector (12). Continue to do this until the entire harness can be pulled out through the hole.

### b. Cleaning and Inspection.

- (1) Clean wiring harness with a clean rag.
- (2) Inspect wiring for cuts, breaks and loose connections, and connectors and cover for damage.

### c. Repair.

- (1) If connector (12) is damaged, and harness is in good condition, replace connector. Unsolder individual wires from connector and re-solder wires to new connector as shown on the schematic diagram, page 4-21.
- (2) If any connector terminal (1) is damaged, replace it. Push back shell (2) on wire to expose terminal (1), remove defective terminal, and crimp a new terminal on end of wire. Pull shell over terminal.
- (3) If individual harness wires extending from the harness loom are broken, cut off defective piece of wire and splice on new length of wire. Install new terminal (1) and shell to new wire (step 2).


**4-13. WIRING HARNESS (cont)**

- (4) If wire leads have damaged insulation, tape over damaged insulation where required. If wires within the harness loom are defective, replace wiring harness.
- (5) Replace deteriorated grommets in frame holes.

**d. Installation.****CAUTION**

Do not damage wiring or insulation during installation of wiring harness.

- (1) Feed wiring harness (4) through the frame hole for connector (12).



TA252172

#### 4-13. WIRING HARNESS (cont)

(2) Run wiring harness (4) along frame and through grommets (14 and 15) as shown. Run harness over cross beams and inside of main beam. Install clamps (7) over harness and attach to studs (6) with nuts (5) in 19 places. Run rear of harness through grommet (14) to left side.


(3) Position connector (12) and cover (13) on frame. Connector must have A contact upward. Install cap screws (9) and

lock nuts (8). Be sure ground lead (11) and lock washer (10) are under one of the lock nuts.


(4) Install tyrraps (3) around composite light wires and mounting bracket.

(5) Connect connectors (1 and 2) to all lights.

(6) Connect HEMAT to towing vehicle and check operation of all lights.



TA252172



ELECTRICAL  
SCHEMATIC DIAGRAM

Section VI. MAINTENANCE OF AIR BRAKE SYSTEM

	Page		Page
Air Lines .....	4-30	Hubs and Drums .....	4-22
Air Valves .....	4-33	Service Brakes .....	4-24
Air Tanks .....	4-36	Brake Air Chamber .....	4-29

4-14. HUBS AND DRUMS

Materials/Tools

- Solvent cleaning compound (Item 3, app E)
- Wiping rag (Item 10, app E)
- Grease GAA (Item 4, app E)
- Hub cap gasket (app F)
- Hub oil seal (app F)
- General mechanics tool kit
- Ratchet, 3/4 inch drive
- Bearing nut wrench, 3/4 inch drive, 3-1/4 inch
- Bearing nut wrench, 3/4 inch drive, 3-7/8 inch
- Torque wrench, 3/4 inch drive, 0-600 lb-ft.
- Two pry bars

a. Removal.

- (1) Chock wheels.
- (2) Drain air tanks.
- (3) Cage air brake chamber (para. 2-27a).
- (4) Remove wheel and tire (para. 3-6).
- (5) Back off slack adjuster (para. 4-15c).
- (6) Remove six hex bolts (1), hub cap (2) and gasket (3).
- (7) Remove outer spindle nut (4) using 3-1/4 inch bearing nut wrench and ratchet. Remove spindle lock (5).
- (8) Loosen inner spindle nut (6) using 3-7/8 inch bearing nut wrench and ratchet until nut is flush with outside edge of hub (7).
- (9) Using two pry bars force hub-drum assembly (7 through 16) out against nut (6).

- (10) Remove nut (6) and outer bearing cone (8).
- (11) Remove hub-drum assembly (9 through 16) as a unit and place on clean work surface with hub (7) upward.
- (12) Using brass drift drive out bearing cone (9) and seal (10) and then drive out bearing cup (11).
- (13) Turn unit so hub is down. Using brass drift drive out bearing cup (12).
- (14) Only remove back nuts (13), washers (14) and drum (15) from hub (7) if studs (16) are damaged.
- (15) Remove studs (16) from hub (7) only if damaged.

b. Cleaning.

WARNING

Solvent cleaning compound is an environmentally compliant product and is low in toxicity. However, it may be irritating to the eyes and skin due to its base stock. The use of protective gloves and goggles is required. Use the solvent cleaning compound in well-ventilated areas and keep away from open flames and other sources of ignition.

- (1) Clean all parts thoroughly using a brush and solvent cleaning compound. Allow to air dry.
- (2) Clean spindle (17) on axle (18) with wiping cloth.

## 4-14. HUBS AND DRUMS (cont)

### c. Inspection.

- (1) Inspect bearings visually for wear and scoring flat spots and overheating (discoloration).
- (2) Inspect brake drum visually for deep coring, excessive wear (ridge) and other irregularities. Repair or replace brake drum. Notify direct support maintenance.
- (3) Inspect hub cap, nuts, lock and hub for cracks and other damage.
- (4) Inspect spindle for damaged threads, evidence of seizure and rough surfaces. Replace axle. Notify direct support maintenance.

### d. Repair.

Repair gasket, seal and all defective parts.


### e. Installation.

- (1) Install studs (16) in hub (7) if removed.
- (2) Install inner bearing cup (11) in hub (7), with narrow edge outward. Seat with steel drift.
- (3) Pack inner bearing cone (9) with grease GAA and install in cup.
- (4) To assure proper fit, place seal (10) on spindle up to first rubber rib. The correct seal will not go on any further due to designed interference.
- (5) Place seal (10) on rear of hub (7) with the words "OIL SIDE" facing inward. Make sure that seal is straight. Using a hammer and piece of flat hardwood, tap the seal into hub until seal bottoms out.
- (6) Install outer bearing cup (12) in hub (7). Pack hub cavity with grease GAA up to level of inside diameter of outer bearing cup (12).
- (7) Install drum (15) on hub (7) with back nuts (13) and washers (14) if removed. Tighten nuts (13) to 300-330 lb-ft.
- (8) Pack outer bearing cone (8) with grease GAA and install in cup (12).

### NOTE

Be sure there is no brake drag between brake shoes and drum.

- (9) Install inner spindle nut (6) on spindle (17) and tighten nut against bearing while turning brake drum (15) by hand. When there is a slight bind, back off inner spindle nut 1/3 turn to allow free rotation of wheel.
- (10) Install spindle lock (5) and outer spindle nut (4). Tighten outer spindle nut to 250-400 lb-ft.
- (11) Repack hub cap (2) with grease GAA.
- (12) Install hub cap (2) and new gasket (3) with six hex bolts (1).
- (13) Rotate brake drum (15) to assure free movement without binding.
- (14) Uncage air brake chamber (para. 2-27 b).
- (15) Install wheels and tires (para. 3-6).



TA252173

#### 4-14. HUBS AND DRUMS (cont)

- (16) Close air tank drain cocks.
- (17) Remove chocks.
- (18) Adjust brakes (para. 4-15c).
- (19) Lower trailer.

#### 4-15. SERVICE BRAKES



##### Materials/Tools

Solvent cleaning compound (Item 3, app E)  
 Wiping rag (Item 10, app E)  
 General mechanics tool kit  
 Lock ring pliers  
 Pry bars

##### a. Brake Shoes.

##### (1) Removal.

- (a) Remove wheels and tires (para. 3-6) and hubs and drum (para. 4-14a).
- (b) Apply a 9/16 inch wrench to hex head (1) of worm shaft and push in against the slack adjuster (2) to un-lock the worm shaft.
- (c) Turn the hex head (1) of the worm shaft counterclockwise to back off slack adjuster to low part of cam(3).
- (d) Drive out brake anchor pins (4).
- (e) Remove two retaining springs (5).
- (f) Remove brake shoe assemblies (6) with retract springs (7), springs (8) and rollers (9).
- (g) Remove retract spring (7) from brake shoe assemblies (6).



TA252174



#### 4-15. SERVICE BRAKES (cont)

- (h) Remove roller retaining springs (8) and rollers (9) from brake shoe assemblies (6).
- (i) Drive out spring pins (10) from brake shoe assemblies (6).
- (j) Remove bushings (11) spider (12) if worn.

#### (2) Cleaning.

##### WARNING

**Solvent cleaning compound is an environmentally compliant product and is low in toxicity. However, it may be irritating to the eyes and skin due to its base stock. The use of protective gloves and goggles is required. Use the solvent cleaning compound in well-ventilated areas and keep away from open flames and other sources of ignition.**

##### CAUTION

Do not allow lubricants or solvents to get on brake shoes. These materials will do damage to brake linings and result in poor braking action.

##### WARNING

**DO NOT use a dry brush or compressed air to clean brake shoes. There may be asbestos dust on brake shoes which can be dangerous to your health if you breathe it. Dampen surface of lining with water and use a soft bristle brush.**

- (a) Clean all parts except brake shoes with a brush and solvent cleaning compound.
- (b) Clean brake shoes with soft bristle brush.

#### (3) Inspection.

- (a) Inspect brake shoes for wear and scoring. Replace brake shoes if linings are worn to less than 5/16-inch thick at any place on the linings.

- (b) Inspect springs for kinks, corrosion and distortion.
- (c) Inspect rollers, anchor pins, spring pins and bushings for wear, corrosion and other damage.
- (a) Using brass drift drive out bearing cone (9) and seal (10) and then drive out bearing cup (11).

#### (4) Repair.

Replace all defective parts.

#### (5) Installation of Brake Shoes.


- (a) Install bushings (11) in axle spider (12) if removed.
- (b) Drive spring pins (9) into brake shoe assemblies (6).
- (c) Install rollers (9) on brake shoe assemblies (6) and secure with retaining springs (8).
- (d) Install retract spring (7) on spring pins (9) on brake shoe assemblies (6).
- (e) Position brake shoe assemblies (6) with springs (7 and 9) and rollers so rollers engage cam (3) and shoes straddle spindle (13).
- (f) Install two retaining springs (5) on brake shoe assemblies (6).
- (g) Pry up upper brake shoe assembly (6) and insert anchor pin (4) in upper bushing (11).
- (h) Pry down lower brake shoe assembly (6) and insert anchor pin (4) in lower bushing (11).
- (i) Install hubs and drums (para. 4-14e).
- (j) Install wheels and tires (para. 3-6).
- (k) Adjust brakes (para. 4-15c).

# **4-15. SERVICE BRAKES (cont)**

## **b. Camshaft and Bearings.**

### **(1) Removal.**

- (a) Chock wheels.
- (b) Cage air brake chamber (para. 2-27 a).
- (c) Drain air tanks.
- (d) Remove wheels and tires (para. 3-6).
- (e) Remove hubs and drum (para. 4-14a, steps 1 through 4).
- (f) Remove brake shoes (para. 4-15a (1)).
- (g) Remove lock ring (1) and slack adjuster (2) (para. 4-15d (1)).
- (h) Remove lock ring (4) using lock ring pliers. Withdraw camshaft (3) part way and remove washer (5).
- (i) Remove three hex nuts (6), lock washers (7) and screws (8) to remove bearing assembly (9).
- (j) Remove grease fitting (10).
- (k) Separate brackets (11 and 12) and remove bearing (13).
- (l) Remove seals (14) from brackets and discard seals.
- (m) Remove grease fitting (15).
- (n) Remove seals (16) and bushing (17) from axle spider (18). Discard seals.
- (o) Remove six self-tapping screws (20) and dust shield (21) from axle.



TA252176

**4-15. SERVICE BRAKES (cont)****(2) Installation.**

- (a) Install bushing (17) in spider (18). Make sure hole in bushing aligns with hole in spider for grease fitting (15).
- (b) Install new seals (16) and grease fitting (15).
- (c) Install new seals (14) in brackets (11 and 12).
- (d) Place bearing (13) between brackets (11 and 12) so hole in bearing aligns with hole in bracket (11). Insert grease fitting (10) through bracket hole and install in bearing.
- (e) Install bearing assembly (9) on axle bracket (19) with three screws (8), lock washers (7) and hex nuts (6).
- (f) Coat length of camshaft (3) with grease GAA and insert through bushing (17). Place washer (5) on camshaft and insert camshaft through bearing assembly (9).
- (g) Install lock ring (4) using lock ring pliers.
- (h) Install slack adjuster and lock ring (para. 4-15d (2)).
- (i) Install brake shoes (para. 4-15a (5)).

**NOTE**


It may be necessary to remove slack adjuster to align camshaft with shoe anchor pins.

- (j) Install hubs and drums (para. 4-14 e).
- (k) Install wheels (para. 3-6).
- (l) Install dust shield (21) with six self-tapping screws (20) after brake adjustment (para. 4-15c).

**c. Brake Adjustment (Slack Adjustment).****NOTE**

Brake adjustment must be done with brake air chambers uncaged, air in the system and dust shield removed.

- (1) Jack up wheel to be adjusted (para. 3-6).
- (2) Apply a 9/16 inch wrench to hex head (1) of worm shaft and push in against the slack adjuster (2) to unlock the worm shaft.
- (3) Turn the hex head (1) of the worm shaft clockwise on slack adjuster until the wheel cannot be turned.
- (4) Back off the worm shaft hex head (1) until the wheel turns freely. Check clearance between brake shoes and drum with feeler gage. Clearance should be 0.005 inch. Adjust worm shaft hex head (1) to meet specified clearance.
- (5) Lower jack and remove from axle (para. 3-6).
- (6) Repeat steps (1) through (5) for other slack adjusters as required.
- (7) Install dust shield (para. 4-15b2).



## 4-15. SERVICE BRAKES (cont)

### d. Slack Adjusters.

#### (1) Removal.

- (a) Chock wheels.
- (b) Cage air brake chamber (para. 2-27 a).
- (c) Drain air tanks.
- (d) Remove cotter pin (1) and headed pin (2) from rod end (3).
- (e) Remove lock ring (4) with lock ring pliers. Remove slack adjuster (5) from camshaft (6). Pull slack adjuster arm away from push rod end to clear. Use soft-faced hammer to tap slack adjuster off if necessary.

#### (2) Installation.

- (a) Install slack adjuster (5) on camshaft (6). Turn camshaft to align slack adjuster with push rod end. Use soft-faced hammer to tap in place if necessary.

#### NOTE

The center hole of the three holes on the slack adjuster must be aligned with push rod end. If it is not, reinstall slack adjuster.

- (b) Install lock ring (4) on camshaft (6) using lock ring pliers.
- (c) Install headed pin (2) through center hole of slack adjuster (5) and push rod end (3).


- (d) Install cotter pin (1) in pin (2).

- (e) Lubricate slack adjuster with grease-GAA.

- (f) Uncage air chambers (para. 2-27b).

- (g) Close air tank drain cocks.

- (h) Adjust brakes (para. 4-15c).



TA252175

## 4-16. BRAKE AIR CHAMBER

### Materials/Tools

General mechanics tool kit

#### WARNING



Do not attempt to disassemble the brake air chamber. The springs inside the chamber are under heavy tension and may cause severe injury if released during disassembly,

#### a. Removal.

- (1) Cage air chambers (para. 2-27a).
- (2) Drain air tanks.
- (3) Tag and disconnect air hoses (1 and 2) from brake air chamber (3).
- (4) Remove cotter pin (4) and headed pin (5).
- (5) Remove two hex nuts (6) and lock washers (7). Withdraw brake air chamber (3).
- (6) Remove elbows (8).
- (7) Loosen nut (9) and remove clevis (10) and nut from push rod.
- (8) Remove plate (11) and boot (12) from air chamber,
- (9) Uncage air chamber (para. 2-27b).

#### b. Installation.

- (1) Install boot (12) and plate (11) on air chamber.
- (2) Install nut (9) and clevis (10) on push rod.
- (3) Cage new brake chamber (para. 2-27a).
- (4) Install elbows (8).
- (5) With brake air chamber spring caged, measure length of push rod. Length should be 7 inches.
- (6) If push rod length is not 7 inches, loosen hex nut and turn push rod end on or off push rod to adjust length. Tighten hex nut against push rod end to 15-25 lb-ft.



TA252178

#### 4-16. BRAKE AIR CHAMBER (cont)

- (7) Mount air chamber (3) with two hex nuts (6) and lock washers (7).

##### NOTE

It may be necessary to turn slack adjuster adjustment screw to adjust chamber push rod.

- (8) Align rod end (10) with center hole in slack adjuster (13). Install headed pin (5) and cotter pin (4).
- (9) Uncage brake air chamber spring (para. 2-27 b).
- (10) Connect air hoses (1 and 2).
- (11) Adjust brakes (para. 4-15c).

#### 4-17. AIR LINES

##### Materials/Tools

Anti-seize tape (item 12, app E)

General mechanics tool kit

##### a. Removal of Air Hoses and Fittings.

##### NOTE

Tag all hoses before disconnecting.

- (1) Remove intervehicular air hoses (1) and gladhands (2) from drawbar. Remove packing (3) from gladhands.
- (2) Remove hoses (4 and 5) from air chambers (6), trailer valve (7) and relay valve (8).
- (3) Remove elbows (9) from air chambers (6).
- (4) Remove elbows (10) from trailer valve (7).
- (5) Remove drain cocks (11) from air tanks (12).

##### b. Installation of Air Hoses and Fittings.

- (1) Install drain cocks (11) in air tanks (12).
- (2) Install elbows (10) in trailer valve (7).

- (3) Install elbows (9) in air chambers (6).
- (4) Connect hoses (4 and 5) to air chambers (6), trailer valve (7) and relay valve (8).
- (5) Install packings (3) in gladhands (2).
- (6) Connect gladhands (2) to intervehicular air hoses (1).
- (7) Connect air hoses (1) to drawbar couplings.

##### c. Removal of Tubing and Fittings.


##### NOTE

Tag all air lines before disconnecting.


- (1) Remove 5 wire clips (1) and 14 wire clips (2) as required.
- (2) Remove tube and nut assemblies (3 through 8) from relay valve (9), trailer valve (10), parking brake control (11) and air tanks (12).
- (3) Remove elbows (13, 14 and 15).
- (4) Remove connectors (16 and 17) and elbows (18).
- (5) Remove relay valve (9) and reducer (19).

##### d. Repair of Tube and Nut Assemblies.


- (1) Unscrew tubing nut from body and remove body.
- (2) Remove tube insert from inside of nylon tubing.
- (3) Remove tubing nut and sleeve from nylon tubing.



TA252179



**HOSES, AIR CHAMBERS AND TANKS**



**TUBING AND VALVES**

#### 4-17. AIR LINES (cont)

- (4) Cut nylon tubing to length as listed below:

Tube and Nut Assembly	Length of Tubing
3 .....	60 inches
4 .....	24 inches
5 .....	12 inches
6 .....	155 inches
7 .....	98 inches
8 .....	206 inches


- (5) Place tubing nut on nylon tubing and install compression sleeve.
- (6) Install tube insert in tubing so insert bottoms out in tubing.
- (7) Place body over end of tubing and insert and tighten tubing nut.

#### e. Installation of Tubing and Fittings.

##### NOTE

Use anti-seize tape on all pipe threads.

- (1) Install reducer (19) and relay valve (9).
- (2) Install connectors (16 and 17).
- (3) Install elbows (13, 14, 15 and 18).
- (4) Connect tube and nut assemblies (3 through 8) to relay valve (9), trailer valve (10), parking brake control (11) and air tanks (12).
- (5) Install wire clips (1 and 2).



TA252180



## 4-18. AIR VALVAE

### Materials/Tools

Anti-seize tape (item 12, app E)  
General mechanics tool kit

#### a. Relay Valve.

##### (1) Removal.


- (a) Drain air tanks.
- (b) Tag and disconnect four hoses (1 through 4) from relay valve (5).
- (c) Disconnect tube and nut assembly (6). Remove connector (7).
- (d) Turn relay valve (5) counterclockwise to remove from tank (8).

##### (2) Installation.

#### NOTE

Use anti-seize tape on all pipe fittings.

- (a) Position relay valve (5) on nipple on tank (8). Turn clockwise to install. The valve must be vertical and the joint tight.
- (b) Install connector (7) on relay valve (5). Connect tube and nut assembly (6) to connector making sure compression insert bottoms in connector.
- (c) Install four hoses (1 through 4).



TA252181

## 4-18. AIR VALVES (cont)

### b. Trailer Valve.

#### (1) Removal.


- (a) Drain air tanks.
- (b) Tag and disconnect hoses (1 through 4) from trailer valve (5).
- (c) Remove two elbows (6).
- (d) Disconnect three tube and nut assemblies (7, 8 and 9). Remove connectors (10, 11 and 12).
- (e) Turn trailer valve (5) counterclockwise to remove from tank (13).

#### (2) Installation.

##### NOTE

Use anti-seize tape on all pipe fittings.

- (a) Position trailer valve (5) on tank (13) and turn clockwise to install. The valve must be vertical and the joint tight.
- (b) Install connectors (10, 11 and 12) on valve. Connect tube and nut assemblies (7, 8 and 9) making sure compression inserts bottom in connectors.
- (c) Install two elbows (6).
- (d) Install four hoses (1 through 4).



TA252182

## 4-18. AIR VALVES (cont)


### c. Parking Brake Control.

#### (1) Removal.

- (a) Drain air tanks.
- (b) Tag and disconnect tube and nut assemblies (1, 2 and 3). Remove two elbows (4) and connector (5) from parking brake control (6).
- (c) Drive out roll pin in knob (7) and pull off knob.
- (d) Remove hex nut (8). Withdraw control (6) from inside storage box.

#### (2) Installation.

- (a) Place parking brake control (6) into hole in frame. Install hex nut (8).
- (b) Place knob (7) on control shaft and install roll pin to secure.
- (c) Install elbows (4) and connector (5) on parking brake control (6).
- (d) Connect tube and nut assemblies (1, 2 and 3) making sure compression inserts bottom in elbows and connector.
- (e) Close air tank drain cocks.



#### 4-19. AIR VALVBES (cont)

##### Materials/Tools

General mechanics tool kit


##### a. Removal.

- (1) Disconnect all hoses (para. 4-1 7a) and air lines (para. 4-17c) to air tanks (1 and 2).
- (2) Remove relay valve (para. 4-18a) and trailer valve (para. 4- 18b).
- (3) Remove drain cocks (3).
- (4) Remove four lock nuts (4) and cap-screws (5) from ends of main air tank (1). Remove air tank.
- (5) Support reserve air tank (2) and remove four lock nuts (6) and capscrews (7) to free air tank and brackets (8). Remove tank and brackets.


- (6) Loosen brackets (8) and slide off air tank (2).

##### b. Installation.

- (1) Install two brackets (8) on reserve air tank (2). Do not tighten.
- (2) Position air tank (2) with brackets on frame so bracket mounting holes are alined with holes in frame.
- (3) Install four cap screws (7) and lock nuts (6) to mount tank and brackets.
- (4) Tighten clamping hardware on brackets (8) to secure tank.
- (5) Position main air tank (1) on frame and install four cap screws (5) and lock nuts (4) to secure.
- (6) Install relay valve (para. 4-18a) and trailer valve (para. 4-18b).
- (7) Install drain cocks (3).
- (8) Connect all hoses (para. 4-17b) and air lines (para. 4- 17e) to air tanks.



TA252184



TA252169

AIR SYSTEM  
DIAGRAM

## Section VII. MAINTENANCE OF WHEELS AND TIRES

	Page		Page
Tire Dismounting . . . . .	4-38	Tire Repair . . . . .	443
Tire Cleaning and Inspection . . . . .	4-42	Tire Mounting . . . . .	443

### 4-20. TIRE DISMOUNTING

#### Materials/Tools


Tire and rim lubricant (item 5, app E)  
 Wiping rag (item 10, app E)  
 Tire irons T47A (reference 7, app B, section III)  
 Tire iron T46B (reference 8, app B, section III)  
 Locking jaw pliers (reference 9, app B, section III)  
 Bead breaking chisel  
 3 lb. cross peen hammer  
 Tire mounting pedestal, part number EX-1002  
 (refer to app G)

Tire dismounting is a three person operation.

#### WARNING

Do not attempt to dismount tire until tire has been completely deflated. When released suddenly air under pressure can cause serious injury.

- a. Deflate tire completely by removing valve core with core remover.
- b. Place wheel (1) and tire (2) on flat surface. Hold bead breaking chisel (3) on bead next to rim of wheel and hammer the chisel until bead breaks away from rim. Continue to move chisel around circumference of rim until the bead is completely free. One person should hold the chisel and a second person use the hammer (4).
- c. Turn wheel and tire over and repeat step b to free second bead from wheel.




---


**4-20. TIRE DISMOUNTING (cont)**


---

- d. Place wheel (1) and tire (2) on pedestal (5) with valve stem (6) upward. Position wheel and tire so three holes (7) in top of pedestal are aligned with wheel mounting holes.
- e. Install three hex bolts (8), flat washers (9) and hex nuts (10) to secure wheel and tire to pedestal (5). Mounting hardware is supplied with pedestal.
- f. Apply tire and rim lubricant to bead all around circumference.




- g. Insert straight ends of long tire irons (11 and 12) between bead and rim approximately 6 inches on each side of stem (6).
- h. Hold long tire irons (11 and 12) in position and insert short tire iron (13) between bead and rim on side directly opposite stem (6).




TA252186

#### 4-20. TIRE DISMOUNTING (cont)

- i. Lever short tire iron (13) down and hold in position to separate bead from rim and guide tire bead into groove in wheel during tire removal.
- j. With one person holding short tire iron (13) down and another person holding long tire iron (11) up, lever other long tire iron (12) down across wheel and tire to raise bead over rim.



- k. With one person holding tire irons (12 and 13) down, lever long tire iron (11) down across wheel and tire to raise more of bead over rim and hold in place. Two persons are needed to lever tire iron (11) down.
- l. Remove short tire iron (13).




TA252187




#### 4-20. TIRE DISMOUNTING (cont)

- m. Hold tire iron (11) down and remove tire iron (12). Insert tire iron (12) between bead and rim at another position on rim to take another small bite of bead. Continue to hold tire iron (11) down and lever tire iron (12) down across wheel (1) and tire (2) to raise more of bead over rim.
- n. Remove either tire iron (11 or 12) and repeat step m until bead is completely free of rim. Remove both tire irons.




- o. Apply tire and rim lubricant to lower tire bead.
- p. Insert straight end of long tire irons (11 and 12) between lower bead and rim approximately 1 inch on each side of stem (6). Scissors cross tire iron (11 and 12) and lever down across tire (2).



TA252188

**4-20. TIRE DISMOUNTING (cont)**

- q. Bear down on long tire irons (11 and 12) to raise lower bead above rim. Insert short tire iron (13) from underneath between long tire irons. Lever short tire iron up and bear down on long tire irons to separate lower bead from rim.
- r. Remove tire irons (11, 12 and 13) and tire (2).
- s. Remove nut and washer securing valve stem in wheel and remove valve stem.

**4-21. TIRE CLEANING AND INSPECTION****Materials/Tools**

Wiping rag (item 10, app E)

Stiff bristle brush

TA252189

- a. Cleaning.
  - (1) Remove all buildup of dirt, grease and foreign material from wheel using a stiff bristle brush.
  - (2) Remove all foreign material from inside of tire. Clean bead area with a stiff bristle brush.
- b. Inspection.
  - (1) Wheels. Inspect wheels for cracks, dents, deformed lug bolt holes, rust, corrosion, marred paint, and distortion.

**CAUTION**

If mounting face of wheel is not flat or ball seats are damaged, do not put wheel in service.

- (2) Tires. Inspect tires in accordance with TM9-2610-200-24.

## 4-22. TIRE REPAIR

- a. Repair tires in accordance with TM-9-2610-200-24.
- b. Replace defective rims.

## 4-23. TIRE MOUNTING

### Materials/Tools


Tire and rim lubricant (item 5, app E)  
 Wiping rag (item 10, app E)  
 Tire irons T47A (reference 7, app B, section III)  
 Tire iron T46B (reference 8, app B, section III)  
 Locking jaw pliers (reference 9, app B, section III)  
 3 lb. cross peen hammer  
 Tire mounting pedestal, part number EX-1002  
 (refer to app G)

### CAUTION

If mounting face of wheel is not flat or ball seats are damaged, do not put wheel in service.

Tire mounting is a three-person operation.

- a. Remove nut and washer from tire valve. Insert valve stem from inside rim, through valve hole and seat valve stem base against rim. Install washer and nut on stem and tighten nut.
- b. Lubricate tire bead liberally with tire and rim lubricant.
- c. Position tire (1) on wheel (2) at an angle so part of lower bead is below wheel rim on side opposite valve stem. Clamp locking jaw pliers (3) on rim directly opposite valve stem. The pliers will keep lower bead from coming over rim when mounting.
- d. Insert curved end of long tire iron (4) between lower bead and rim approximately 8 to 10 inches from position of locking jaw pliers (3). Push down on tire where pliers are located and lever tire iron to force lower bead down over rim. Make sure that lower bead at location of pliers goes into groove in wheel rim.




TA252190

---


**4-23. TIRE MOUNTING (cont)**

---

- e. Hold long tire iron (4) down in first position. Insert curved end of long tire iron (5) between bead and rim several inches from tire iron (4) and lever another bite of bead over rim.



- f. Hold tire iron (5) down. Remove tire iron (4) and insert between bead and rim on opposite side of pliers (3). Lever tire iron (4) to force another bite of bead over rim.
- g. Repeat step f using tire irons alternately and working toward stem until entire bead is over rim. Remove locking jaw pliers (3) after more than half the bead is over rim.



- h. Apply tire and rim lubricant liberally around circumference of upper bead.

TA252191

#### 4-23. TIRE MOUNTING (cont)

- i. Position tire (1) so part of upper bead is below rim on side opposite valve stem. Clamp locking jaw pliers (3) on rim on side opposite valve stem.
- j. Insert curved end of long tire iron (4) between upper bead and rim approximately 10 to 12 inches from position of locking jaw pliers (3). Push down on tire (1) where pliers are located and lever tire iron to force upper bead down over rim.
- k. Hold tire iron (4) down. Insert curved end of other tire iron (5) between bead and rim several inches from tire iron (4), and lever another bite of bead down over rim.
- l. Repeat step k using tire irons alternately and working around bead and rim until entire upper bead is down over rim.
- m. Remove tire irons (4 and 5) and pliers (3).
- n. Remove hex nuts (6), flat washers (7) and hex bolts (8). Remove wheel (2) and tire (1) from pedestal (9).

#### o. Inflate Tire.

- (1) Stand tire upright and hold while applying air. Applying body weight to top of tire will usually seat tire beads and tire will inflate.




#### CAUTION

Excessive pressure will damage tire internal structure.

#### NOTE

If tire beads do not seat during inflation, put a bead expander around outside center of tire to compress tire and force beads to seat. If a bead expander is not available, use load binder and chain. Apply only enough pressure on tire to lightly seal beads against rim.

- (2) Inflate tire to 85 psi (4.07 KPa).



TA252192

## Section VIII. MAINTENANCE OF FRAME AND TOWING COMPONENTS

	Page
Bumpers . . . . .	4-46
Coupler . . . . .	4-46
Safety Chains . . . . .	4-47
Lifting Eyes . . . . .	4-47
Spare Tire Carrier . . . . .	4-48



	Page
Landing Gear . . . . .	4-49
Storage Box Cover . . . . .	4-50
Pod Stops . . . . .	4-50

### 4-24. BUMPERS

#### Materials/Tools

General mechanics tool kit  
Torque wrench, 3/8 inch drive, 0-150 lb-ft.  
Socket, 3/4 inch, 3/8 inch drive

- a. Removal.** Remove two hex nuts (1), lock washers (2), cap screws (3), flat washers (4) to remove each of two bumpers (5).
- b. Installation.** Install each bumper (5) with two cap screws (3), flat washers (4), lock washers (2) and hex nuts (1). Tighten hex nut to 35 lb-ft.




### 4-25. COUPLER

#### Materials/Tools

General mechanics tool kit  
Four lock washers, 3/4 inch  
Torque wrench, 3/4 inch drive, 0-600 lb-ft.  
Socket, 1-1/8 inch, 3/4 inch drive

- a. Removal.** Remove four hex nuts (1), lock washers (2), cap screws (3) and coupler (4). Discard lock washers.
- b. Installation.** Mount coupler (4) on frame with four cap screws (3), new lock washers (2) and hex nuts (1). Tighten hex nuts to 300 lb-ft.



TA252193

## 4-26. SAFETY CHAINS

### Materials/Tools


General mechanics tool kit  
Torque wrench, 3/4 inch drive, 0-600 lb-ft.  
Socket, 1-5/16 inch, 3/4 inch drive

**a. Removal.** Remove jam nuts (1), cap screws (2) and shackle (3) with safety chain (4). Slide shackle from chain link.

**b. Installation.** Insert shackle (3) through end link on safety chain (4). Mount shackles with chain to frame with cap screws (2) and jam nuts (1). Tighten jam nuts until shackle is snug on frame.

### NOTE

Minimum backoff torque for jam nut (1) is 30 lb-ft.



## 4-27. LIFTING EYES

### Materials/Tools


General mechanics tool kit  
Torque wrench, 3/8 inch drive, 0-150 lb-ft.  
Socket, 7/16 inch, 3/8 inch drive

### a. Removal.

- (1) Extend lifting eye (1).
- (2) Remove two hex nuts (2), lock washers (3) and cap screws (4) to remove pin and chain (5) and block (6).
- (3) Slide out lifting eyes (1).

### b. Installation.

- (1) Slide lifting eyes (1) into channels at corners of frame.
- (2) Fasten block (6) and pin and chain (5) to frame with two cap screws (4), lock washers (3) and hex nuts (2). Tighten hex nuts to 8 lb-ft.



TA252194

## 4-28. SPARE TIRE CARRIER

### Materials/Tools

Dry cleaning solvent (item 3, app E)

Wiping rag (item 10, app E)

General mechanics tool kit

Torque wrench, 3/8 inch drive, 0-150 lb-ft.

Socket, 1/2 inch, 3/8 inch drive

### a. Removal.


- (1) Remove spare tire (para. 2-18a).
- (2) Place wheel nuts (1) on studs (2).
- (3) Remove nuts (3), lock washers (4) and clamps (5). Remove pickup member (6).

- (4) Unwind cable (7) from shaft (8). Pull cable from two holes (9) in shaft.

### NOTE

Main member (10) is welded to frame and cannot be removed.

- (5) Remove cotter pin (11) and two flat washers (12). Withdraw shaft (8) from main member (10), and pawl plate (13).
- (6) Remove three lock nuts (14) and cap screws (15) to detach pawl plate (13) from main member.



TA252195



**4-28. SPARE TIRE CARRIER (cont)****b. Installation.**

- (1) Mount pawl plate (13) on main member (10) with three cap screws (15) and lock nuts (14).
- (2) Slide shaft (8) through pawl plate (13) and main member (10). Install two flat washers (12) and cotter pin (11).
- (3) Feed ends of cable (7) through holes (9) in shaft (8) so free lengths are equal.
- (4) With each half of cable (7) on same side of shaft (8), rotate shaft several turns to wrap cable on shaft.
- (5) Insert free ends of cable (7) into outer most holes in pickup member (6) and bend each end inward approximately 3 inches.
- (6) Install clamps (5), lock washers (4) and nuts (3) on pickup member (6) so both ends of cable (7) are secured by each clamp. Tighten nuts (3) on clamps to 10 lb- ft.
- (7) Install spare tire (para. 2-18b).

**4-29. LANDING GEAR****Materials/Tools**

General mechanics tool kit

**a. Removal.**

- (1) Remove lock nut (1), flat washers (2), cap screw (3) and crank (4) from landing gear (5).
- (2) Remove pin assembly (6).
- (3) Rotate landing gear (5) to the upside down vertical position so channel (7) disengages collar on trailer frame.
- (4) Remove landing gear.

**b. Installation.**

- (1) Hold landing gear (5) in upside down vertical position and place it so channel (7) is alined with collar on trailer frame.
- (2) Rotate landing gear (5) on frame to normal horizontal or vertical position. Install pin assembly (6) to secure.


**NOTE**

Insure landing gear is cranked all the way up and plunger is in second lowest hole.

- (3) Install crank (4) and cap screw (3), flat washers (2) and lock nut (1).

**NOTE**

Do not over tighten nut (1).




TA252196

#### 4-30. STORAGE BOX COVER

##### Materials/Tools

General mechanics tool kit  
Torque wrench, 3/8 inch drive, 0-150 lb-ft.  
Socket, 9/16 inch, 3/8 inch drive

- a. Removal.** Remove six flanged nuts (1) and six carriage bolts (2) from cover (3) and lift cover from frame tongue.
- b. Installation.** Position cover (3) on frame tongue and install six carriage bolts (2) and flanged nuts (1) to secure.



#### 4-31. POD STOPS

##### Materials/Tools


General mechanics tool kit

- a. Removal.** Remove six screws (1), nuts (2) and pod stop (3).

##### NOTE

Tie down ring must be in the up position for pod stop installation.

- b. Installation.** Install pod stop (3) with six screws (1) and nuts (2).



TA252197

---

**4-32. U-BOLTS**

---

■ Paragraph 4-32 has been rescinded.

## Section IX. MAINTENANCE OF BODY COMPONENTS

	Page
Reflectors . . . . .	4-52
Splash Guards . . . . .	4-53
Data Plates . . . . .	4-53
Manifest Holder . . . . .	4-54

	Page
Air Line Guards . . . . .	4-54
Clearance Light Mounting Bracket . . . . .	4-54
Jackknife Strips . . . . .	4-55


### 4-33. REFLECTORS

#### Materials/Tools

1/4 inch wrench

**b. Installation.** Install each red reflector (5) and amber reflector (3) with two self-tapping screws (1).

**a. Removal.** Remove two self-tapping screws (1) to remove any defective reflector (2). Amber reflectors (3) are located forward each side of frame (4). Red reflectors (5) are located on rear and each side rear of frame.




TA252199

#### 4-34. SPLASH GUARDS

##### Materials/Tools

General mechanics tool kit  
Torque wrench, 3/8 inch drive, 0-150 lb-ft.  
Socket, 1/2 inch, 3/8 inch drive

- a. **Removal.** Remove four hex nuts (1) and cap screws (2) to remove each mud flap (3) and backing strap (4).
- b. **Installation.** Install each mud flap (3) and backing strap (4) with four cap screws (2) and hex nuts (1). Tighten hex nuts to 15 lb-ft.




#### 4-35. DATA PLATES

##### Materials/Tools

General mechanics tool kit  
Blind head riveter  
Rivets

- a. **Removal.**
  - (1) Remove four pop rivets (1) to detach any defective identification plate (2), instruction plate (3), lubrication plate (4) or certification plate (5).
  - (2) Remove two pop rivets (6) to detach defective service identification plate (7) or emergency identification plate (8).
- b. **Installation.**
  - (1) Install service identification plate (7) and emergency identification plate (8) with two pop rivets (6) each.
  - (2) Install identification plate (2), instruction plate (3), lubrication plate (4) and certification plate (5) with four pop rivets (1) each.




TA252200

#### 4-36. MANIFEST HOLDER

##### Materials/Tools

Open end wrench, 5/16 inch

- a. **Removal.** Remove four self-tapping screws (1) and manifest holder (2).
- b. **Installation.** Mount manifest holder (2) on front side rack with four self-tapping screws (1).




#### 4-37. AIR LINE GUARDS

##### Materials/Tools

Open end wrench, 7/16 inch

- a. **Removal.** Remove two nuts (1) and air line guard (2).
- b. **Installation.** Mount air line guard (2) with two nuts (1).




#### 4-38. CLEARANCE LIGHT MOUNTING BRACKETS

##### Materials/Tools

Open end wrench, 7/16 inch

- a. **Removal.** Remove four nuts (1) and mounting bracket (2).
- b. **Installation.** Attach mounting bracket (2) with four nuts (1).




TA252201

**4-39. JACKKNIFE STRIPS****Materials/Tools**

General mechanics tool kit

- a. Removal.** Remove two screws (1) and jackknife strip (2).
- b. Installation.** Mount jackknife strip (2) with two screws (1).



TA252238





## CHAPTER 5

### FIELD MAINTENANCE INSTRUCTIONS (DIRECT SUPPORT MAINTENANCE)

#### Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

	Page
Common Tools and Equipment .....	5-1
Special Tools, TMDE and Support Equipment .....	5-1
Repair Parts .....	5-1

#### **5-1. COMMON TOOLS AND EQUIPMENT**

For authorized common tools and equipment, refer to the table of organization and equipment (TOE) or the modified table of organization and equipment (MTOE) applicable to your unit.

#### **5-2. SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT**

Hub extension, part number P-1000 (refer to app G).

#### **5-3. REPAIR PARTS**

Repair parts are listed and illustrated in Appendix F of this manual.

## Section II. MAINTENANCE OF SERVICE BRAKES

	Page
Relining Brake Shoes .....	5-2
Turning Drums .....	5-3

### 5-4. RELINING BRAKE SHOES

#### Materials/Tools

Cleaning compound (Item 1, app E)  
 Brake linings  
 Lining rivets  
 Brake and clutch reliner  
 Air filtering respirator  
 Safety glasses

#### NOTE

Procedures are given for one brake shoe; there are eight.

- Remove rivets (1) from brake shoe (2), and remove and discard old brake linings (3 and 4).


#### WARNING

**DO NOT use a dry brush or compressed air to clean brake shoes. There may be asbestos dust on brake shoes which can be dangerous to your health if you breathe it. (Dampen surface of lining with water and use a soft bristle brush.)**

- Clean brake shoe (2) thoroughly, using a brush and water to remove mud, and cleaning compound to remove grease and oil.
- Position new cam end brake lining (3) on the brake shoe (2).

#### NOTE

Be sure cam end lining is installed on cam end of shoe. Cam end lining is tapered more toward the end of shoe than anchor end lining. Cam end of shoe has two holes in each shoe bracket. Anchor end of shoe has one hole in each bracket.



#### NOTE

If brake drums have been machined (para. 5-5), install shims between the brake shoe and brake lining of the same thickness as the metal removed from the brake drums.

- Install rivets (1) in the two center holes of the brake shoe (2) and brake lining (3) to secure the brake lining.
- Install the remaining rivets (1) in the brake lining (3) to secure it to the brake shoe (2).
- Check the contact of the brake lining with the brake shoe. A 0.005 inch feeler gage should not enter between the brake shoe and brake lining at any point.

#### 5-4. RELINING BRAKE SHOES (cont)

- g. Install anchor end lining (4) in same way (Steps c through f).
- h. Repeat Steps c through g for remaining brake shoes.
- i. Check shoes against drum for contact. Brake shoes must have 80 percent contact between lining and drum surface. It is necessary that the contact be in the middle of the lining surface and continuous.

#### WARNING

**Asbestos dust is dangerous to your health. Wear respirator to avoid inhaling dust.**

- j. If lining to drum surface contact is not 80 percent, the shoes should be circle ground to comply.

#### 5-5. TURNING DRUMS

##### Materials/Tools


Cleaning compound (Item 1, app E)

Wiping rag (Item 1, app E)

Brake drum lathe

Safety glasses

- a. Clean brake drum with cleaning compound to remove dirt and grease.
- b. Inspect the brake drum for warpage, cracks, scored braking surface, and out-of-round condition. If inspection shows the brake drum to be in unsatisfactory condition, refinish the brake drum in the following manner:
- c. Measure the inside diameter of the brake drum. New brake drums measure 16.490 to 16.510 inches. Brake drums should be refinished if scoring or run-out exceeds 0.006 inch.
- d. Brake drums having an inside diameter larger than 16.650 inches must be replaced.



TA252203

- e. Install brake drum on lathe; and refinish surface, taking off as little of the metal as possible to true the surface. If refinishing requires removal of more than 0.070 inch of metal (0.140 inch in diameter), replace the brake drum.

Finish inside diameter to 200 microinches.

Section III. MAINTENANCE OF SUSPENSION

	Page
Springs and Suspension.....	5-4
Torque and Adjustment.....	5-6
Axle Replacement .....	5-8

5-6. SPRINGS AND SUSPENSION

Materials/Tools

General mechanics tool kit  
Open end wrench, 1-5/16 inch  
Ratchet, 3/4 inch drive  
Socket, 1-5/16 inch, 3/4 inch drive  
Torque wrench, 3/4 inch drive, 0-600 lb-ft.  
Safety glasses

NOTE

Following procedures are for one complete axle suspension. If only one wheel requires maintenance, perform steps for that wheel only.

a. Removal.

- (1) Jack up front or rear axle high enough to relax tension on springs.
- (2) Block up corners of trailer (front or rear).
- (3) Remove two hex nuts (1), bolts (2), and torque arm (3).

CAUTION

The rollers for front and rear springs at either end are all different. Do not mix up parts.

- (4) Remove hex nut (4), bolt (5), and roller (6).
- (5) Remove hex nut (7), bolt (8) and roller (9).
- (6. Support spring (10) to prevent it from dropping. Remove four hex nuts (11) and bottom plate (12).
- (7) Remove spring (10) and U-bolts (13).
- (8) Remove two screws (14), lock washers (15), flat washers (16) and bumper (17).
- (9) Perform same procedure to remove other axle suspension components if necessary.


B. Installation.

- (1) Install each bumper (17) on studs and secure with flat washers (16), lock washers (15) and nuts (14).
- (2) Place U-bolts (13) over axle (18) at mounting pads (19).

NOTE

Hook end of all springs must be toward equalizer bolt (12).

- (3) Raise spring (10) and support in position under mounting pad (19).
- (4) Install bottom plate (12) with four hex nuts (11) but do not tighten nuts.
- (5) Install roller (9), bolt (8) and hex nut (7). Tighten nut fully but roller must be free to rotate.
- (6) Install roller (6), bolt (5) and hex nut (4). Tighten nut fully but roller must be free to rotate.
- (7) Adjust position of spring (10) if necessary so spring is centered. Tighten nuts (11) to 350 lb-ft (475 Nm).
- (8) Install torque arm (3), bolts (2) and hex nuts (1). Tighten nuts to 250 lb-ft (339 Nm).
- (9) Perform same procedure for other axle suspension components if necessary.
- (10) Remove blocking from under corners of trailer.
- (11) Lower axle and remove jacks.
- (12) Adjust torque arms (para. 5-7).



## 5-7. TORQUE ARM ADJUSTMENT

### Materials/Tools

Hub extensions, part number P-1000, four required  
(refer to app G)

Pipe wrench, 18 inch

Tape measure, 50 foot


Torque wrench, 1/2 inch drive, 0-175 ft-lbs.

General mechanics tool kit


### NOTE

After suspension installation aline axles to insure proper tracking of HE-MAT and to avoid excessive tire wear.


- a. Level the empty trailer.
- b. Make certain that the equalizers are level and that all spring ends are bearing on wear pads.
- c. Remove six screws (1), hub cap (2) and gasket (3) at each wheel hub (4).
- d. Install hub extension (5) on each wheel hub (4) with screws (1).
- e. Measure distance between center of hole (6) to left hand hub extension (7) and record as LL.
- f. Measure distance between center of hole (8) to right hand hub extension (9) and record as LR.
- g. Distance LL should equal LR if axle is alined. If the LL does not equal LR, loosen clamp bolts (10) and turn rod (11) to adjust length of torque arm (12) and aline axle. If LL is greater than LR, shorten torque arm. If LL is less than LR, lengthen torque arm.



TA252205

**5-7. TORQUE ARM ADJUSTMENT (cont)**

- h. Check distances LL and LR and continue to adjust torque arm until LL equals LR. Tighten clamp bolts (10) on front torque arm (12) to 55-60 lb-ft (74.6-81.3 Nm).
- i. Measure spacing SL between hub extensions (7 and 13) and record.
- j. Measure spacing SR between hub extensions (9 and 14) and record.
- k. Spacing SL should equal SR. If SL does not equal SR, loosen clamp bolts (10) on rear torque arm (15) and turn rod (11) to adjust. If SL is greater than SR, shorten torque arm. If SL is less than SR, lengthen torque arm.
- l. Check spacing SL and SR and continue to adjust torque arm until SL equals SR. Tighten clamp bolts (10) on rear torque arm (15) to 55-60 lb-ft (74.6-81.3 Nm).
- m. Remove screws (1) and hub extensions (5).
- n. Install hub caps (2) and gaskets (3) with screws (1).



TA252206

## 5-8. AXLE REPLACEMENT

### Materials/Tools

Cleaning compound (item 1, app E)

Wiping rag (item 10, app E)

Welding machine

Welder tool kit

Personnel: 2 required

Safety glasses

### NOTE

If an axle is to be removed for replacement or repair, remove axle and suspension together and disassemble after removal.

#### a. Removal.

- (1) Disconnect air hoses from brake air chambers (para. 4-16, Steps 1 through 3).
- (2) Use a suitable lifting device to lift trailer and relax spring tension.
- (3) Remove torque arms and spring rollers (para. 5-6a, Steps 3 through 5).
- (4) Roll rear axle assembly with wheel and suspension from underneath trailer.
- (5) Remove springs from axle (para. 5-6a, Steps 6 and 7).

#### b. Disassembly.

- (1) Jack up axle assembly and place on jack stands.
- (2) Remove tires and wheels (para. 3-6 b).
- (3) Remove hubs and drums (para. 4-14a).
- (4) Remove brakes (1) (para. 4-15a), slack adjuster (1) (para. 4-15d), and cam shafts and bearings (1) (para. 4-15b).
- (5) Remove air brake chambers (para. 4-16a).

#### c. Cleaning.

Clean axle thoroughly, using a brush and water to remove mud, and cleaning compound to remove grease and oil. Wipe off.

#### d. Inspection.

Inspect axle for cracks, breaks, broken or distorted brackets (1) and pads (2), corrosion and other damage.

#### e. Repair.


- (1) Straighten distorted air brake chamber brackets (1), spring mounting pads (2), or axle bumpers (3), if possible. If brackets, pads or axle bumpers cannot be straightened, the axle must be replaced.
- (2) Repair broken welds.
- (3) Repaint the axle (chapter 5, section III).

#### f. Assembly.

- (1) Install camshafts and bearings (5) (para.4-15b), slack adjusters (3) (para. 4-15d), and brakes (5) (para. 4-15a).
- (2) Install hubs and drums (para. 4-14f).
- (3) Install air brake chambers (para. 4-16d).
- (4) Install wheels and tires (para. 3-6c).

#### g. Installation.

- (1) Install springs on axle (para. 5-6b, Steps 2 through 5).
- (2) Roll axle assembly with wheels and suspension underneath HEMAT. Position unit underneath suspension hangers.
- (3) Install spring rollers and torque arms (para. 5-6b, Steps 6 through 9).
- (4) Lower trailer.
- (5) Connect air hoses to air brake chambers.
- (6) Close drain cocks on air tanks.
- (7) Adjust torque arms (para. 5-7).
- (8) Uncage brakes (para. 2-27b).
- (9) Adjust air brake chamber (para. 4-16b).
- (10) Adjust brakes (4-15c).





## Section IV. MAINTENANCE OF BODY COMPONENTS

Floor Boards.....	Page 5-9
Gates .....	5-10

### 5-9. FLOOR BOARDS

#### Materials/Tools

Portable electric drill  
Twist drill, No. J  
Countersink  
Screwdriver bit (app D)  
Safety glasses

#### a. Inspection.

Inspect all floor boards for breakage and warpage. Replace floor boards selectively after inspection for defects.

#### b. Removal.

Remove torx screws as required to remove any given floorboard (A through G).

#### c. Repair.

Refer to appendix G for manufacturing information.

#### d. Installation.


#### NOTE

Floor boards F and G must be selectively fit to match existing planking. After initial fitting of the width, mark the floor board for cutting. Saw or plane the floor board using power equipment. Repeat operation until floor board fits in space. There should be a tight fit for all floor boards.

- (1) Place replacement floor board in position on frame. Mark location of mounting holes.
- (2) Remove boards. Then using a No. J drill bit (0.277 inch) and drill, bore holes in floor board to match mounting holes in frame. Countersink holes.
- (3) Install torx screws as required to secure floor board to frame. Heads of screws should be below surface of boards.

#### NOTE

Trailers (VIN 1S9US1722DM-063127 and after) are equipped with ship lap lumber. Refer to Bulk Items in Appendix F.



TA252208

## 5-10. GATES

### Materials/Tools

Cleaning compound (Item 1, app E)  
 Wiping rag (item 10, app E)  
 Shop equipment, welding  
 Tool kit, welding  
 Swaging tool

#### a. Cleaning.




Clean gates thoroughly using a stiff bristle brush and water to remove mud, and cleaning compound to remove grease and oil. Wipe off.

#### b. Inspection.

Inspect gates for marred paint, corrosion, cracks, breaks, broken welds and other damage.

#### c. Repair.

- (1) Straighten bent tie down hooks (1), latch ears (2), and latch pins (3). Be sure holes in ears are aligned so pins can enter holes without binding.
- (2) Replace missing retaining cables (4). Use 6 inch length of 1/8 inch diameter 7 x 7 stainless steel aircraft cable and two swaging sleeves, part number MS51844-2 to fabricate each retaining cable.
- (3) Straighten bent hinge pins (5).
- (4) Straighten bent slide bolts (6).
- (5) If damage to gate is not too extensive, straighten member where possible. Weld up cracks in broken welds.
- (6) Clean frame.
- (7) Repaint gate (Chapter 5, Section III).



## 5-11. FRAME

### Materials/Tools

Cleaning compound (item 1, app E)

Shop equipment, welding

Tool kit, welder

**a. Cleaning.** Clean frame thoroughly using a stiff bristle brush and water to remove mud, and cleaning compound to remove grease and oil.


**b. Inspection.** Inspect frame for marred paint, corrosion, cracks, breaks, broken welds and other damage.

### c. Repair.

(1) If damage to frame is not too extensive, straighten member where possible. Weld up cracks or broken welds.

(2) Clean frame.

(3) Repaint frame (chapter 5, section III).



TA252210

### Section III. PAINTING INSTRUCTIONS

	Page
Materials and Tools . . . . .	5-12
Painting Procedure . . . . .	5-12

#### 5-12. MATERIALS AND TOOLS

##### a. Materials.

- (1) Coating, polyurethane (item 2, app E)
- (2) Primer coating (item 8, app E)
- (3) Primer coating (item 9, app E)
- (4) Thinner (item 13, app E)
- (5) Dry cleaning solvent (item 3, app E)

##### b. Tools.

- (1) Power driven compressor unit
- (2) Paint spray gun
- (3) Spray gun paint cup
- (4) Rubber air hose
- (5) Eye goggles
- (6) Air filtering respirator
- (7) Stiff bristle wire brush

#### 5-13. PAINTING PROCEDURE

##### WARNING

The resin and hardener contained in the two-part epoxy coating may cause irritation to the skin and eyes. Plastic gloves should be worn while handling these materials. Wipe these materials from the skin using dry cleaning solvent (item 3, app E), and wash with soap and warm water if contact is made. Wear goggles when applying coating to prevent contact with the eyes.

##### WARNING

Coatings can cause internal injury during prolonged breathing of vapors. Wear respirator to prevent inhaling vapors. Use adequate ventilation.

##### NOTE

Coatings are very water sensitive. Take care to insure that water or high humidity do not come in contact with coatings at any time during reduction, application or drying.

##### NOTE

Do not attempt using these paints below 60 degrees F (15.5 degrees C), as proper curing will not take place.

##### NOTE

Once coating is mixed, a chemical reaction begins which will cause coating to completely harden. This begins to occur in 6 to 8 hours. All coatings should be used and entire paint system completely cleaned within this time period. If cleaning is not accomplished in time, remaining mixed coating will harden throughout paint system. System should be cleaned only with solvent specifically recommended by the paint manufacturer.

##### a. Primer Coating.

- (1) Clean area to be painted to remove all dirt, grease, oil, rust and scale. Surface may be cleaned using dry cleaning solvent, wire brush or by sandblasting as required.
- (2) Mix two-part epoxy primer coating in accordance with manufacturers instructions.

**5-13. PAINTING PROCEDURE**

- (3) Using painting equipment apply an even coating of primer coating without runs or sags.
- (4) Allow primer coating to dry for a minimum of 1 hour before applying top coating.

**b. Top Coating.**

- (1) Mix two-part epoxy top coating in accordance with manufacturers instructions.
- (2) Using painting equipment apply an even coating of the top coating without runs or sags.
- (3) Allow finish coating to dry for 3 hours before handling.

## Section IV. PREPARATION FOR STORAGE OR SHIPMENT

	Page
Preparation for Storage or Shipment . . . .	5-14
Preparation for Use After Storage . . . . .	5-14

### 5-14. PREPARATION FOR STORAGE OR SHIPMENT

#### a. Air Brake System.

- (1) Open drain cocks on both air tanks on the trailer.
- (2) Cage all four air brake chambers (para. 2-27a).

#### b. Tires.

- (1) Reduce tire pressure to 20 psi (cold).
- (2) Adjust landing gear to level trailer.
- (3) Fold all trailer side gates down to shade tires from sun's rays.

### 5-15. PREPARATION FOR USE AFTER STORAGE

#### a. Tires. Inflate tires to 85 psi (cold).

#### b. Gates. Raise gates to locked vertical position.

#### c. Air System.

- (1) Close air tank drain cocks.
- (2) Uncage air brake chambers (para. 2-27 b).

#### d. Perform operator/crew and organizational preventive maintenance services.

CHAPTER 6

SUSTAINMENT MAINTENANCE INSTRUCTIONS  
(GENERAL SUPPORT/DEPOT MAINTENANCE)

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

	Page
Common Tools and Equipment .....	6-1
Special Tools, TMDE and Support Equipment .....	6-1
Repair Parts .....	6-1

**6-1. COMMON TOOL AND EQUIPMENT**

For authorized common tools and equipment, refer to the table of organization and equipment(TOE) or the modified table of organization and equipment (MTOE) applicable to your unit.

**6-2. SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT**

Hub extension, part number P-1000 (refer to Appendix G).

**6-3. REPAIR PARTS**

Repair parts are listed and illustrated in Appendix F of this manual.

## 6-4. FRAME

### Materials/Tools

Cleaning compound (Item 1, Appendix E)  
Shop equipment, welding  
Tool kit, welder  
Safety glasses

#### a. Cleaning.


Clean frame thoroughly using a stiff bristle brush and water to remove mud, and cleaning compound to remove grease and oil.

#### b. Inspection.

Inspect frame for marred paint, corrosion, cracks, breaks, broken welds, and other damage.

#### c. Repair.

- (1) If damage to frame is not too extensive, straighten member where possible. Weld up cracks or broken welds.
- (2) Clean frame.
- (3) Repaint frame (Chapter 7, Painting Instructions).



TA252210



## CHAPTER 7

### PAINTING INSTRUCTIONS

	Page
Materials and Tools .....	7-1
Painting Procedure .....	7-1

#### 7-1. MATERIALS AND TOOLS

##### a. Materials.

- (1) Coating, polyurethane (item 2, app E)
- (2) Primer coating (item 8, app E)
- (3) Primer coating (item 9, app E)
- (4) Thinner (item 13, app E)
- (5) Dry cleaning solvent (item 3, app E)

##### b. Tools

- (1) Power driven compressor unit
- (2) Paint spray gun
- (3) Spray gun paint cup
- (4) Rubber air hose
- (5) Eye goggles
- (6) Air filtering respirator
- (7) Stiff bristle wire brush

The following precautions must be taken whenever using CARC paint:

- **NEVER** cut CARC-coated materials without high-efficiency, air-purifying respirators in use.
- **DO NOT** grind or sand painted equipment without high-efficiency, air-purifying respirators in use.
- **BE AWARE** of CARC paint exposure symptoms; symptoms can occur a few days after initial exposure. Seek medical help immediately if symptoms are detected.

#### WARNING

Coatings can cause internal injury during prolonged breathing of vapors. Wear respirator to prevent inhaling vapors. Use adequate ventilation.

#### NOTE

Coatings are very water sensitive. Take care to insure that water or high humidity do not come in contact with coatings at any time during reduction, application or drying.

#### NOTE

Do not attempt using these paints below 60 degrees F (15.5 degrees C), as proper curing will not take place.

#### 7-2. PAINTING PROCEDURE

#### WARNING

**Chemical Agent Resistant Coating (CARC) paint contains Hexamethylene Diisocyanate (HDI), which is highly irritating to the skin and respiratory system. High concentrations of HDI can produce symptoms of itching and reddening of the skin, a burning sensation in the throat and nose, and watering of the eyes. In extreme concentrations, HDI can cause cough, shortness of breath, pain during respiration, increased sputum production, and chest tightness.**

<b>7-2. PAINTING PROCEDURE (cont)</b>
---------------------------------------

**NOTE**

Once coating is mixed, a chemical reaction begins which will cause coating to completely harden. This begins to occur in 6 to 8 hours. All coatings should be used and entire paint system completely cleaned with this time period. If cleaning is not accomplished in time, remaining mix coating will harden throughout paint system. System should be cleaned only with solvent specifically recommended by the paint manufacturer.

**a. Primer Coating.**

- (1) Clean area to be painted to remove all dirt, grease, oil, rust and scale. Surface may be cleaned using dry cleaning solvent, wire brush or by sandblasting as required.
- (2) Mix two-part epoxy primer coating in accordance with manufacturers instructions.
- (3) Using painting equipment apply an even coating of primer coating without runs or sags.
- (4) Allow primer coating to dry for a minimum of 1 hour before applying top coating.

**b. Top Coating**

- (1) Mix two-part epoxy top coating in accordance with manufacturers instructions.
- (2) Using painting equipment apply an even coating of top coating without runs or sags
- (3) Allow finish coating to dry for 3 hours before handling.

## CHAPTER 8

### PREPARATION FOR STORAGE OR SHIPMENT

	Page
Preparation for Storage or Shipment.....	8-1
Preparation for Use After Storage.....	8-1

#### 8-1. PREPARATION FOR STORAGE OR SHIPMENT

##### a. Air Brake System.

- (1) Open drain cocks on both air tanks on the trailer.
- (2) Cage all four air brake chambers (para. 2-27a).

##### b. Tires

- (1) Do not reduce tire pressure.
- (2) Adjust landing gear to level trailer.
- (3) Fold all trailer side gates down to shade tires from sun's rays.

#### 8-2. PREPARATION FOR USE AFTER STORAGE

##### a. Gates. Raise gates to locked vertical position.

##### b. Tires. Check tire pressure and inflate tires to 85 psi (586 kPa) (cold), if necessary.

##### c. Air System.

- (1) Close air tank drain cocks.
- (2) Uncage air brake chambers (para. 2-27b).

##### d. Perform operator/crew and organizational preventive maintenance services.



## APPENDIX A

### REFERENCES

#### A-1. SCOPE

This appendix lists all forms, field manuals, technical manuals, and other publications referenced in this manual and which apply to the operation, organizational, direct, and general support maintenance of the M989.

#### A-2. PUBLICATION INDEX

DA Pam 25-30, Consolidated Index of Army Publications and Blank Forms, should be consulted frequently for latest changes or revisions and for new publications relating to materiel covered in this technical manual.

#### A-3. FORMS

Refer to DA Pam 750-8, The Army Maintenance Management System (TAMMS) User's Manual, for instructions on maintenance forms.

Equipment Inspection and Maintenance Worksheet.....	DA Form 2404
Maintenance Request .....	DA Form 2407
Maintenance Schedule and Record .....	DD Form 314
Product Quality Deficiency Report.....	SF 368
Recommended Changes to Publications and Blank Forms.....	DA Form 2028

#### A-4. FIELD MANUALS

Manual for the Wheeled Vehicle Driver.....	FM 21-305
NBC Decontamination .....	FM 3-11.5
NBC Protection .....	FM 3-11.4
Northern Operations.....	FM 31-71
Operation and Maintenance of Ordnance Materiel in Cold Weather (0°to-65°F) .....	FM 9-207
Visual Signals .....	FM 21-60

#### A-5. TECHNICAL BULLETINS

Color, Marking, and Camouflage Painting of Military Vehicles, Construction Equipment, and Materials Handling Equipment.....	TB 43-0209
--	------------

A-6. TECHNICAL MANUALS

Inspection, Care, and Maintenance of Antifriction Bearings.....TM 9-214

Materials Used for Cleaning, Preserving, Abrading, and Cementing

    Ordnance Materiel and Related Items Including Chemicals.....TM 9-247

Organizational, Direct Support and General Support Care, Maintenance,

    and Repair of Pneumatic Tires and Inner Tubes ..... TM 9-2610-200-24

Procedures for Destruction of Trek-Automotive Equipment to Prevent Enemy Use ..... TM 750-244-6

A-7. OTHER PUBLICATIONS

Expendable/Durable Items (Except Medical, Class V,

    Repair Parts, and Heraldic Items) .....CTA 50-970

■ Operator’s Manual for Welding Theory and Application..... TC 9-237

## APPENDIX B

### MAINTENANCE ALLOCATION CHART (MAC)

#### Section I. INTRODUCTION

##### **B-1. GENERAL**

**a.** This introduction provides a general explanation of all maintenance and repair functions authorized at the two maintenance levels under the Two-Level Maintenance System concept.

**b.** Section II. The MAC (immediately following the introduction) designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component levels, which are shown on the MAC in column (4) as:

Field – includes two columns, Unit maintenance and Direct Support maintenance. The Unit maintenance column is divided again into two more subcolumns, (C) for Operator or Crew and (O) for Unit Maintenance.

Sustainment – includes two subcolumns, General Support (H), and Depot (D).

**c.** Section III. The tools and test equipment requirements (immediately following the MAC) list the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from the MAC.

**d.** Section IV. The remarks (immediately following the tools and test requirements) contain supplemental instructions and explanatory notes for a particular maintenance function.

##### **B-2. MAINTENANCE FUNCTIONS**

Maintenance functions are limited to and defined as follows:

**a. Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel). This includes scheduled inspection and gagings and evaluation of cannon tubes.

**b. Test.** To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards on a scheduled basis, i.e., load testing of lift devices and hydrostatic testing of pressure hoses.

**c. Service.** Operations required periodically to keep an item in proper operating condition; e.g., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases. This includes scheduled exercising and purging of recoil mechanisms. The following are examples of service functions:

1. Unpack. To remove from packing box for service or when required for the performance of maintenance operations.
2. Repack. To return item to packing box after service and other maintenance operations.
3. Clean. To rid the item of contamination.
4. Touch up. To spot paint scratched or blistered surfaces.
5. Mark. To restore obliterated identification.

**d. Adjust.** To maintain or regulate, within prescribed limits, by bringing into proper position, or by setting the operating characteristics to specified parameters.

**e. Align.** To adjust specified variable elements of an item to bring about optimum or desired performance.

**B-2. MAINTENANCE FUNCTIONS (cont)**

**f. Calibrate.** To determine and cause corrections to be made or to be adjusted on instruments of test, measuring, and diagnostic equipment used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

**g. Remove/Install.** To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

**h. Paint.** To prepare and spray color coats of paint so that the ammunition can be identified and protected. The color indicating primary use is applied, preferably, to the entire exterior surface as the background color of the item. Other markings are to be repainted as original so as to retain proper ammunition identification.

**i. Replace.** To remove an unserviceable item and install a serviceable counterpart in its place "Replace" is authorized by the MAC and assigned maintenance level is shown as the third position code of the Source, Maintenance, and Recoverability (SMR) code.

**j. Repair.** The application of maintenance services, including fault location/troubleshooting, removal/installation, disassembly/assembly procedures and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

**NOTE**

The following definitions are applicable to the "repair" maintenance function:

Services. Inspect, test, service, adjust, align, calibrate, and/or replace.

Fault location/troubleshooting. The process of investigating and detecting the cause of equipment malfunctioning; the act of isolating a fault within a system or Unit Under Test (UUT).

Disassembly/ assembly. The step-by-step breakdown (taking apart) of a spare/functional group coded item to the level of its least component, that is assigned an SMR code for the level of maintenance under consideration (i.e., identified as maintenance significant).

Actions. Welding, grinding, riveting, straightening, facing, machining, and/or resurfacing.

**k. Overhaul.** That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

**l. Rebuild.** Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (e.g., hours/ miles) considered in classifying Army equipment/components.



<b>B-3. EXPLANATION OF COLUMNS IN THE MAC</b>
---

**a. Column (1) Group Number.** Column (1) lists Functional Group Code (FGC) numbers, the purpose of which is to identify maintenance significant components, assemblies, sub-assemblies, and modules with the Next Higher Assembly (NHA).

**b. Column (2) Component/Assembly.** Column (2) contains the item names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

**c. Column (3). Maintenance Function.** Column (3) lists the functions to be performed on the item listed in column (2). (For a detailed explanation of these functions refer to "Maintenance Functions" outlined above.)

**d. Column (4) Maintenance Level.** Column (4) specifies each level of maintenance authorized to perform each function listed in column (3), by indicating work time required (expressed as man hours in whole hours or decimals) in the appropriate subcolumn. This work time figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function varies at different maintenance levels, appropriate work time figures are to be shown for each level. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC. The symbol designations for the various maintenance levels are as follows:

Field:

C..... Operator or Crew maintenance  
O..... Unit maintenance  
F..... Direct Support maintenance

Sustainment:

L..... Specialized Repair Activity  
H..... General Support maintenance  
D..... Depot maintenance

#### NOTE

The "L" maintenance level is not included in column (4) of the MAC. Functions to this level of maintenance are identified by work time figure in the "H" column of column (4), and an associated reference code is used in the REMARKS column (6). This code is keyed to the remarks and the SRA complete repair application is explained there.

**e. Column (5) Tools and Equipment Reference Code.** Column (5) specifies, by code, those common tool sets (not individual tools), common Test, Measurement and Diagnostic Equipment (TMDE), and special tools, special TMDE and special support equipment required to perform the designated function. Codes are keyed to the entries in the tools and test equipment table.

**f. Column (6) Remarks Code.** When applicable, this column contains a letter code, in alphabetical order, which is keyed to the remarks table entries.

**B-4. EXPLANATION OF COLUMNS IN THE  
TOOLS AND TEST EQUIPMENT  
REQUIREMENTS**

**Column (1) Tool or Test Equipment Reference Code.** The tool or test equipment reference code correlates with a code used in column (5) of the MAC.

**Column (2) Maintenance Level.** The lowest level of maintenance authorized to use the tool or test equipment.

**Column (3) Nomenclature.** Name or identification of the tool or test equipment.

**Column (4) National Stock Number (NSN).** The NSN of the tool or test equipment.

**Column (5) Tool Number.** The manufacturer's part number, model number, or type number.

**B-5. EXPLANATION OF COLUMNS IN THE  
REMARKS**

**Column (1) Remarks Code.** The code recorded in column (6) of the MAC.

**Column (2) Remarks.** This column lists information pertinent to the maintenance function being performed as indicated in the MAC.

## Section II. MAINTENANCE ALLOCATION CHART

(1)  GROUP NO.	(2)  COMPONENT/ ASSEMBLY	(3)  MAINTENANCE FUNCTION	(4)  MAINTENANCE CATEGORY					(5)  TOOLS AND EQPT.	(6)  REMARKS
			FIELD		SUSTAINMENT				
			UNIT		DIRECT SUPPORT	GENERAL SUPPORT	DEPOT		
			C	O	F	H	D		
06	ELECTRICAL SYSTEM								
0609	LIGHTS	Inspect Replace Repair	0.1	0.5 0.5				1 1	
0609	LAMPS	Inspect Replace	0.1 0.5					1	
0613	HARNESS, WIRING	Inspect Replace Repair		0.5 2.0 1.0				1 1	
0613	CABLE, INTER- VEHICULAR	Inspect Replace	0.1 0.1					1	
11	AXLE								
1100	AXLE ASSEMBLY	Inspect Replace Repair		0.5	8.0 2.0			4	
12	BRAKES								
1202	SERVICE BRAKE ASSEMBLY	Adjust Replace Repair		0.5 1.8 3.0				1,2,3 1,2,3 1,2,3	
1202	BRAKE SHOE ASSEMBLY	Inspect Replace Repair		0.3 1.5	2.5			1,2,3 4	
1202	SLACK ADJUSTER	Service Replace		0.3 0.7				1,2,3 1,2,3	
1202	CAMSHAFT ASSEMBLY	Inspect Service Replace		1.0 0.3 1.5				1,2,3 1,2,3	
1208	AIR BRAKE SYSTEM	Test		0.3					
1208	BRAKE AIR CHAMBER	Inspect Adjust Replace		0.3 0.2 1.0				1,2,3 1,2,3	

## Section II. MAINTENANCE ALLOCATION CHART (continued)

(1)  GROUP NO.	(2)  COMPONENT/ ASSEMBLY	(3)  MAINTENANCE FUNCTION	(4)  MAINTENANCE CATEGORY					(5)  TOOLS AND EQPT.	(6)  REMARKS
			FIELD			SUSTAINMENT			
			UNIT		DIRECT SUPPORT	GENERAL SUPPORT	DEPOT		
			C	O	F	H	D		
1208	AIR HOSE AND FITTINGS	Inspect Replace	0.5	2.0	2.0			1,2,3	
	AIR RESERVOIRS	Service Replace	0.2	1.5				1,2,3	
	VALVE, TRAILER	Replace		0.5				1,2,3	
	VALVE, RELAY								
	VALVE, BRAKE, RELEASE	Replace		0.5				1,2,3	
		Replace		0.7				1,2,3	
13	WHEELS				2.0				
1311	WHEELS ASSEMBLY	Inspect Replace	0.2 1.0					2,3	
1311	HUB AND DRUM	Inspect Replace Repair		0.3 1.5				1,2,3 4	
1311	BEARING WHEEL	Service Inspect Adjust Replace		0.5 0.3 0.5 1.0				2,3 2,3	
1311	SEAL,WHEEL	Replace		1.0				2,3	
1313	TIRES	Inspect Service Repair Replace	0.1 0.2			1.5			2,3 2,3
				0.6					
15	FRAME AND TOWING								
1501	FRAME	Inspect Repair	0.2	0.4		*		4,5,6	
1501	BUMPERS	Replace		0.2				1,2	
1501	POD STOPS	Inspect Replace	0.1	0.3				2	

## Section II. MAINTENANCE ALLOCATION CHART (continued)

(1)  GROUP NO.	(2)  COMPONENT/ ASSEMBLY	(3)  MAINTENANCE FUNCTION	(4)  MAINTENANCE CATEGORY					(5)  TOOLS AND EQPT.	(6)  REMARKS
			FIELD		SUSTAINMENT				
			UNIT		DIRECT SUPPORT	GENERAL SUPPORT	DEPOT		
			C	O	F	H	D		
1503	SAFETY CHAINS	Inspect Replace	0.1	0.3				1,2,3	
1503	COUPLING	Inspect Replace	0.1	0.3				1,2,3	
1503	SPLL ADAPTER	Inspect	0.1						
1504	SPARE TIRE CARRIER	Inspect Service Replace		0.3 1.0 1.8				1,2,3 1,2,3	
1507	LANDING GEAR	Inspect Service Replace	0.2	0.2 0.1				1,2	
16	SPRINGS & SUSPENSION								
1601	SPRINGS AND LINERS	Inspect Replace		0.1	2.0			4	
1601	U-BOLTS (One)	Replace			1.0			3	
1605	TORQUE RODS	Adjust Replace			2.0 0.5			4	
18	BODY								
1801	GATES	Inspect Replace Repair	0.1 0.1		*10			1,2,3	
1805	FLOOR BOARDS	Inspect Replace		0.2	*10			4	
22	ACCESSORIES								
2202	REFLECTORS	Inspect Replace	0.1	0.3				1,2	
2210	DATA PLATES	Replace		0.3				2,3	

\*Depends on extent of repair.

**Section III. TOOLS AND TEST EQUIPMENT REQUIREMENTS**

(1) REFERENCE CODE	(2) LEVEL MAINTENANCE	(3) NOMENCLATURE	(4) NATIONAL/NATO STOCK NUMBER	(5) TOOL NUMBER
1	O, F	TOOL KIT, GENERAL MECHANIC AUTO; SC 5180-90-CL-N26	5180-00-177-7033	W33004
2	O, F	SHOP EQUIPMENT, AUTO MAINT & REPAIR: ORG MAINT COMMON NO. 1 – LESS POWER; SC 4910-95-CL-A74	4910-00-754-0654	W32593
3	O, F	SHOP EQUIPMENT, AUTO MAINT & REPAIR: ORG COMMON NO. 2 – LESS POWER; SC 4910-95-CL-A72	4910-00-754-0650	W32730
4	F, H	SHOP EQUIPMENT, AUTO MAINT & REPAIR, FM BASIC, LESS POWER; SC 4910-95-CL-A31	4910-00-754-0705	T24660
5	F	SHOP EQUIPMENT, WELDING: FM; SC 3470-90-CL-A08	3470-00-357-7268	T16714
6	F	TOOL KIT, WELDERS; SC 5180-90-CL-N39	5180-00-754-0661	W58075
7	O	TIRE IRON, 52 IN. LG (2)	5120-01-170-5008	T47A
8	O	TIRE IRON, 36 IN. LG (1)	5120-01-171-8259	T46B
9	O	LOCKING JAW PLIERS	5120-00-494-1911	10R

**Section IV. REMARKS**

REFERENCE CODE	REMARKS
	NONE

## APPENDIX C

### COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS

#### Section I. INTRODUCTION

##### C-1. SCOPE

This appendix lists components of end item and basic issue items for the trailer to help you inventory items required for safe and efficient operation.

##### C-2. GENERAL

The Components of End Item and Basic Issue Items Lists are divided into the following sections:

###### **a. Section II. Components of End Item.**

This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

**b. Section III. Basic Issue Items.** These are the minimum essential items required to place the trailer in operation, to operate it, and to perform emergency repairs. Although shipped separately, packaged BII must be with the trailer during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorization of the end item.

##### C-3. EXPLANATION OF COLUMNS

The following provides an explanation of columns found in the tabular listings:

**a. Column (1) - Illustration Number (Illus Number).** This column indicates the number of the illustration in which the item is shown.

**b. Column (2) - National Stock Number.** Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

**c. Column (3) - Description.** Indicates the National item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the FSCM (in parentheses) followed by the part number.

**d. Column (4) - Unit of Measure (U/M).** Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr).

**e. Column (5) - Quantity Required (Qty Rqr).** Indicates the quantity of the item authorized to be used with/on the equipment.

## SECTION II. COMPONENTS OF END ITEM

(1)	(2)	(3)	(4)	(5)
ILLUS	NATIONAL STOCK	DESCRIPTION	USABLE	QTY
NUMBER	NUMBER	FSCM AND PART NUMBER	ON CODE	RQR


NONE

## SECTION III. BASIC ISSUE ITEMS


(1)	(2)	(3)	(4)	(5)
ILLUS	NATIONAL STOCK	DESCRIPTION	USABLE	QTY
NUMBER	NUMBER	FSCM AND PART NUMBER	ON CODE	RQR

C-1	5995-00-038-3914	INTERVEHICULAR CABLE (19207) 7728812	EA	1
C-2	5120-01-170-4972	LUG WRENCH (TR1) (75204) 32501	EA	1
C-3	5120-01-170-4980	LUG WRENCH HANDLE (22271) A3800-941	EA.	1
C-4	4210-00-889-2221	FIRE EXTINGUISHER, TYPE BC (29743) PA-27BC W/D.B8-1	EA.	1
C-5	5340-01-089-4997	NUCLEAR TIEDOWN STRAP (19207) 11669588	EA.	8
		TIRE CHANGING BLOCK B7924 (NOT ILLUSTRATED) (APPENDIX G)	EA.	1
		TIRE MOUNTING PEDESTAL EX-1002 (NOT ILLUSTRATED) (APPENDIX G)	EA.	1







**Figure C-1. Intervehicular Cable**




**Figure C-3. Lug Wrench Handle**



**Figure C-2. Lug Wrench**



**Figure C-4. Fire Extinguisher**



**C-5. Nuclear Tiedown Strap**

TA252216



**APPENDIX D**  
**ADDITIONAL AUTHORIZATION LIST**

**Section I. INTRODUCTION**

**D-1. SCOPE**

This appendix lists additional items you are authorized for the support of the trailer.

**D-2. GENERAL**

This list identifies items that do not have to accompany the trailer and that do not have to be turned in with it. These items are all authorized to you by CTA, MTOE, TDA, or JTA.

**D-3. EXPLANATION OF LISTING**

National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment. The items are listed in alphabetical sequence by item name under the type document (i.e., CTA, MTOE, TDA, or JTA) which authorizes the item(s) to you.

**Section II. ADDITIONAL AUTHORIZATION LIST**

(1) National Stock Number	(2) Description		(3)	(4)
	FSCM & Part Number	Usable On Code	U/M	Qty Auth
	<b>3240</b> Torx Screwdriver Bit TX40 (Vermont American, Lincolnton, NC)  MTOE AUTHORIZED ITEMS NONE  CTA AUTHORIZED ITEMS NONE		Ea.	1



## APPENDIX E

## EXPENDABLE SUPPLIES AND MATERIALS LIST

**E-1. SCOPE**

This appendix lists expendable supplies and materials you will need to operate and maintain the trailer. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

**E-2. EXPLANATION OF COLUMNS**

**a. Column 1 – Item Number.** This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "Use cleaning compound, item 5, app. E".)

**b. Column 2 – Level.** This column identifies the lowest level of maintenance that requires the listed item.

C	Operator/Crew
O	Organizational Maintenance
F	Direct Support Maintenance
H	General Support Maintenance

**c. Column 3 – National Stock Number.** This is the National Stock Number assigned to the item; use it to request or requisition the item.

**d. Column 4 – Description.** Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

**e. Column 5 – Unit of Measure (U/M).** Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	C	6850-00-597-9765	CLEANING COMPOUND, SOLVENT 1-gal. (3.78-liter) can (81349) MIL-C 18718	GL
2	F	8010-01-160-6744	COATING POLYURETHANE Forest Green (81349) MIL-C-46168A	GL
3	O	6850-01-474-2302 6850-01-474-2309	CLEANING COMPOUND, SOLVENT (81349) MIL-PRF-680 1-gal. (3.78-liter) can 5-gal. (18.9-liter) can	GL GL
4	C	9150-00-065-0029 9150-00-935-1017 9150-00-190-0904 9150-00-190-0907	GREASE, AUTOMOTIVE AND ARTILLERY: GAA (81349) MIL-G 10924 2-1/4 oz. (63.79-g) tube 14-oz. (396.89-g) cartridge 1-lb. (0.454-kg) can 35-lb. (15.89-kg) can	OZ OZ LB LB
5	O	2640-00-256-5527	LUBRICANT, TIRE AND RIM (81349) 1-gal. (3.78 LITER) can	GL
6	C	9150-00-189-6727 9150-00-186-6681	LUBRICATING OIL, INTERNAL COMBUSTION ENGINE: OE (81349)MIL-L-2104 HDO10, 1-qt (0.95-liter) can HDO30, 1-qt (0.95-liter) can	QT QT
7	O	9150-00-402-2372 9150-00-402-4478	LUBRICATING OIL, INTERNAL COMBUSTION ENGINE: subzero (81349) MIL-L-46167 1-qt (0.95-liter) can 5-gal.(18.92-liter) can	QT GL
8	F	8010-00-264-8866	PRIMER COATING, EPOXY (81349) MIL-P-52192	GL
9	F	8010-00-229-4813	PRIMER COATING, EPOXY-POLYIMIDE (81349) MIL-P-23377	GL

# APPENDIX F

## ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

### Section I. INTRODUCTION

#### F-1. SCOPE

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Unit, Direct Support and General Support Maintenance of the HEMAT. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

#### F-2. GENERAL

In addition to Section 1. Introduction, this Repair Parts and Special Tools List is divided into the following sections:

**a. Section II. Repair Parts List.** A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair kits are listed separately in their own functional group within Section II. Repair parts for reparable special tools are also listed in the section. Items listed are shown on the associated illustration (s)/figure(s).

**b. Section III. Special Tools List.** A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

**c. Section IV. Cross-reference Indexes.** A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration

figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross-references NSN, FSCM/CAGE, and part numbers.

#### F-3. EXPLANATION OF COLUMNS (SECTIONS II AND III)

**a. ITEM NO. (Column (1)).** Indicates the number used to identify items called out in the illustration,

**b. SMR CODE (Column (2)).** The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instructions, as shown in the following breakout:

##### Source Code

1st two positions      XXxxx

How you get an item.

##### Maintenance Code

XXxxx		
<b>3d position</b>		<b>4th position</b>
Who can install, replace, or use the item.		Who can do complete repair* on the item.

##### Recoverability Code

xxxxX

**5th position**

Who determines disposition action on an unserviceable item.

*- Complete Repair:* Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

**(1) Source Code.** The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:

<u>Code</u>	<u>Application/Explanation</u>
PA PB PC** PD PE PF PG	Stocked items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code.  * * Items coded PC are subject to deterioration.
KD KF KB	Items with these codes are not to be requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.
MO- ( <i>Made at UM/ AVUM Level</i> ) MF- ( <i>Made at DS/ AVUM Level</i> ) MH- ( <i>Made at GS Level</i> ) ML- ( <i>Made at Spe- cialized Repair Activity (SRA)</i> ) MD- ( <i>Made at Depot</i> )	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in this RPSTL. If the item is authorized to you by the 3d position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.
AO- ( <i>Assembled by UM/AVUM Level</i> ) AF- ( <i>Assembled by DS/AVIM Level</i> ) AH- ( <i>Assembled by GS Category</i> ) AL- ( <i>Assembled by SRA</i> ) AD- ( <i>Assembled by Depot</i> )	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3d position code of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.
XA -	Do not requisition an "XA" -coded item. Order its next higher assembly. (Also refer to the NOTE following.)
XB -	If an "XB" item is not available from salvage, order it using the FSCM/CAGE and part number given.

XC -	Installation drawing, diagram, instruction sheet, field service drawing, that is identified by the manufacturer's part number.
XD -	Item is not stocked. Order an "XD" -coded item through normal supply channels using the FSCM/CAGE and part number given, if no NSN is available,

**NOTE:** Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 700-42.

(2) **Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to one of the following levels of maintenance,

<u>Code</u>	<u>Application/Explanation</u>
c -	Crew or operator maintenance done within unit maintenance or aviation unit maintenance.
o -	Unit maintenance or aviation unit category can remove, replace, and use the item.
F -	Direct support or aviation intermediate level can remove, replace, and use the item.
H -	General support level can remove, replace, and use the item.
L -	Specialized repair activity can remove, replace, and use the item.
D -	Depot level can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i. e., perform all authorized repair functions). (NOTE: Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.) This position will contain one of the following maintenance codes:

<u>Code</u>	<u>Application/Explanation</u>
O -	Unit maintenance or aviation unit is the lowest level that can do complete repair of the item.



<i>F</i> -	Direct support or aviation intermediate is the lowest level than can do complete repair of the item.
<i>H</i> -	General support is the lowest level that can do complete repair of the item.
<i>L</i> -	Specialized repair activity is the lowest level that can do complete repair of the item.
<i>D</i> -	Depot is the lowest level that can do complete repair of the item.
<i>Z</i> -	Nonreparable. No repair is authorized.
<i>B</i> -	No repair is authorized. (No parts or special tools are authorized for the maintenance of a "B"-coded item.) However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) **Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

<u>Code</u>	<u>Application/Explanation</u>
<i>Z</i> -	Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the 3d position of the SMR code.
<i>O</i> -	Reparable item. When uneconomically reparable, condemn and dispose of the item at unit maintenance or aviation unit level.
<i>F</i> -	Reparable item. When uneconomically reparable, condemn and dispose of the item at the direct support or aviation intermediate level.
<i>H</i> -	Reparable item. When uneconomically reparable, condemn and dispose of the item at the general support level.
<i>D</i> -	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item not authorized below depot level.
<i>L</i> -	Reparable item. Condemnation and disposal of item not authorized below specialized repair activity (SRA).
<i>A</i> -	Item requires special handling or condemnation procedures because of specific reasons (e. g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

**c. FSCM/CAGEC (Column (3)).** The Federal Supply Code for Manufacturer (FSCM)/Commercial and Government Entity (CAGE) Code (C) is a 5-digit alphanumeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

**d. PART NUMBER (Column (4)).** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

**NOTE:** When you use an NSN to requisition an item, the item you receive may have a different part number from the part ordered.

**e. DESCRIPTION AND USABLE ON CODE (UOC) (Column (5)).** This column includes the following information:

(1) The Federal item name and, when required, a minimum description to identify the item.

(2) Physical security classification. Not Applicable.

(3) Items that are included in kits and sets are listed below the name of the kit or set on Figure KIT.

(4) Spare/repair parts that make up an assembled item are listed immediately following the assembled item line entry.

(5) Part numbers for bulk materials are referenced in this column in the line item entry for the item to be manufactured/fabricated.

(6) When the item is not used with all serial numbers of the same model, the effective serial numbers are shown on the last line(s) of the description (before UOC).

(7) The usable on code, when applicable (see paragraph 5, Special Information). Not Applicable.

(8) In the Special Tools List section, the basis of issue (BOI) appears as the last line(s) in the entry for each special tool, special TMDE, and other special support equipment. When density of equipments supported exceeds density spread indicated in the basis of issue, the total authorization is increased proportionately.

(9) The statement "END OF FIGURE" appears just below the last item description in Column 5 for a given figure in both Section H and Section III.

**f. QTY (Column (6)).** The QTY (quantity per figure column) indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column

in lieu of a quantity indicates that the quantity is variable and the quantity may vary from application to application.

#### F-4. EXPLANATION OF COLUMNS (SECTION IV)

##### a. NATIONAL STOCK NUMBER (NSN) INDEX.

**(1) STOCK NUMBER column.** This column lists the NSN by National Item Identification Number (NIIN) sequence. The NIIN consists of the last nine NSN

digits of the NSN (i.e., 5305-01-674-1467). When

##### NIIN

using this column to locate an item, ignore the first 4 digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

**(2) FIG. column.** This column lists the number of the figure where the item is identified/located. The figures are in numerical order in Section II and Section III.

**(3) ITEM column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

**b. PART NUMBER INDEX.** Part numbers in this index are listed by part number in ascending alphanumeric sequence (i. e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers O through 9 and each following letter or digit in like order).

**(1) FSCM/CAGEC column.** The Federal Supply Code for Manufacturer (FSCM)/Commercial and Government Entity (CAGE) Code (C) is a 5-digit alphanumeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

**(2) PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

**(3) STOCK NUMBER column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and FSCM/CAGEC columns to the left.

**(4) FIG. column.** This column lists the number of the figure where the item is identified/located in Section II and III.

**(5) ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column,

##### c. FIGURE AND ITEM NUMBER INDEX,

**(1) FIG. column.** This column lists the number of the figure where the item is identified/located in Sections H and 111.

**(2) ITEM column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

**(3) STOCK NUMBER column.** This column lists the NSN for the item.

**(4) FSCM/CAGEC column.** The Federal Supply Code for Manufacturer (FSCM)/Commercial and Government Entity (CAGE) Code (C) is a 5-digit alphanumeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

**(5) PART NUMBER column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards and inspection requirements to identify an item or range of items.

---

#### F-5. SPECIAL INFORMATION

---

**a. USABLE ON CODE.** The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC: ..... " in the Description column (justified left) on the first line following applicable item description/nomenclature. Not Applicable.

**b. FABRICATION INSTRUCTIONS.** Bulk materials required to manufacture items are listed in the Bulk Material Functional Group of this RPSTL. Part numbers for bulk materials are also referenced in the Description column of the line item entry for the item to be manufactured/fabricated. Detailed fabrication instructions for items source coded to be manufactured or fabricated are found in Appendix G of this manual,

**c. ASSEMBLY INSTRUCTIONS.** Detailed assembly instructions for items source coded to be assembled from component spare/repair parts are found in Chapters 4 and 5 of this manual. Items that make up the assembly are listed immediately following the assembly item entry or reference is made to an applicable figure.

**d. KITS.** Line item entries for repair parts kits appear in group 9401 in Section II. Not Applicable.

**e. INDEX NUMBERS.** Items which have the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the National Stock Number/Part Number Index and the bulk material list in Section II.

**f. ASSOCIATED PUBLICATIONS.** Not Applicable.

**F-6. HOW TO LOCATE REPAIR PARTS**

**a. When National Stock Number or Part Number is Not Known:**

**(1) First.** Using the table of contents, determine the assembly group or subassembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and listings are divided into the same groups.

**(2) Second.** Find the figure covering the assembly group or subassembly group to which the item belongs.

**(3) Third.** Identify the item on the figure and use the Figure and Item Number Index to find the NSN.

**b. When National Stock Number or Part Number is Known:**


**(1) First.** Using the National Stock Number or Part Number Index, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence (see paragraph 4 .a. (1)). The part numbers in the Part Number index are listed in ascending alphanumeric sequence (see paragraph 4.b). Both indexes cross-reference you to the illustration/figure and item number of the item you are looking for.

**(2) Second.** Turn to the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

**F-7. ABBREVIATIONS**

For standard abbreviations see MIL-STD-12D, Military Standard Abbreviations for Use on Drawings, Specifications, Standards, and in Technical Documents.

<u>Abbreviations</u>	<u>Explanation</u>
NIIN . . . . .	National Item Identification Number (consists of the last 9 digits of the NSN)
RPSTL . . . . .	Repair Parts and Special Tools List






TA505785

FIGURE 1. LIGHTS.

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 06 ELECTRICAL SYSTEM					
GROUP 0609 LIGHTS					
FIG. 1 LIGHTS					
1	PAOZZ	96906	MS51851-45	SCREW,TAPPING,THREA	30
2	PAOOO	96906	MS35423-1	LIGHT,MARKER,CLEARA AMBER	6
3	PAOZZ	96906	MS35421-1	.LENS,LIGHT	1
4	PAOZZ	96906	MS15570-1251	.LAMP,INCANDESCENT	1
5	PAOZZ	51831	8338567	WASHER,SLOTTER	15
6	PAOZZ	51831	8338566	SHELL,ELECTRICAL CO	15
7	PAOOO	96906	MS35423-2	LIGHT,MARKER,CLEARA RED	7
8	PAOZZ	96906	MS15570-1251	.LAMP,INCANDESCENT	1
9	PAOZZ	96906	MS35421-2	.LENS,LIGHT	1
10	PAOOO	96906	MS52125-2	STOP LIGHT-TAILLIGHT COMPOSITE	2
* 11	XAOZZ	19207	11639520	.BODY ASSEMBLY	1
12	PAOZZ	96906	MS15570-89	.LAMP,INCANDESCENT	1
13	PAOZZ	96906	MS35478-1073	.LAMP,INCANDESCENT	1
14	PAOZZ	19207	11639519-2	.PACKING,PREFORMED	1
15	PAOZZ	19207	11639535	.LENS,LIGHT	1
16	PAOZZ	96906	MS15570-1251	.LAMP,INCANDESCENT	2
17	PAOZZ	96906	MS35338-46	WASHER,LOCK	4
18	PAOZZ	96906	MS18154-58	SCREW,CAP,HEXAGON H	4
19	PAOOZ	96906	MS35424-1	LIGHT,MARKER,CLEARA BLACKOUT	2
20	PAOZZ	96906	MS15570-1251	.LAMP,INCANDESCENT	1
21	PAOZZ	96906	MS35420-1	.LENS,LIGHT	1

END OF FIGURE



TA505786 ■


FIGURE 2. WIRING HARNESS AND CABLE.

## SECTION II

TM 9-2330-368-14&amp;P C02

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 0613 HULL OR CHASSIS WIRING HARNESS					
FIG. 2 WIRING HARNESS AND CABLE					
1	PAOZZ	06383	PLT3I	STRAP, TIEDOWN, ELECT	2
2	PAOZZ	96906	MS35489-114	GROMMET, NONMETALLIC	4
3	PAOZZ	75272	COV-1509	CLAMP, LOOP	20
4	PAOZZ	90763	D0142095-EBG	NUT, STAMPED	20
5	PAOZZ	70485	2570	GROMMET, NONMETALLIC	4
6	PBOOO	22271	7901	WIRING HARNESS, BRAN	1
7	PAOZZ	96906	MS27144-2	.CONNECTOR, PLUG, ELEC	23
8	MFFZZ	22271	9023-500	.HARNESS, MAIN MAKE FROM PART NO. M-13486/1-5	1
*9	PAOZZ	96906	MS75021-1	.CONNECTOR, RECEPTACLE	1
10	PAOZZ	19207	7731428	COVER, ELECTRICAL CO	1
11	PAOZZ	96906	MS90725-6	SCREW, CAP, HEXAGON H	4
12	PAOZZ	96906	MS35338-44	WASHER, LOCK	1
13	PAOZZ	81349	M45913/1-4CG5C	NUT, SELF-LOCKING, HE	4

END OF FIGURE



TA505787 ■


FIGURE 3, AXLE,



## SECTION II

TM9-2330-368-14&amp;PC01

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 11 REAR AXLE					
GROUP 1100 REAR AXLE ASSEMBLY					
FIG. 3 AXLE					
* 1	PAFZZ	22271	10408	.NUT,PLAIN,HEXAGON	2
* 2	PAFZZ	97271	10409	.WASHER,KEYWAY	2
* 3	PAFZZ	22271	10406	.NUT,PLAIN,OCTAGON	2
* 4	PBFZZ	22271	C9005-361	.AXLE,VEHICULAR,NOND	1
END OF FIGURE					



TA505788


FIGURE 4. SERVICE BRAKES.

## SECTION II

TM 9-2330-368-14&amp;P C02

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 12 BRAKES					
GROUP 1202 SERVICES BRAKES					
FIG. 4 SERVICE BRAKES					
1	PAOZZ	22271	16355	PIN, SHOULDER, HEADLE	4
2	PAOZZ	62707	M16WJ101	SPRING, HELICAL, EXTE	2
*3	PAOFF	97271	16130	BRAKE SHOE	4
*4	PAFZZ	22271	16567	. LINING, FRICTION	4
*5	PAFZZ	22271	M10HM100	. RIVET, TUBULAR	96
*6	PAFZZ	22271	16566	. LINING, FRICTION	4
7	PAOZZ	22271	16034	BUSHING, SLEEVE	4
8	PAOZZ	22271	16101	SPRING, HELICAL, EXTE	2
*9	PAOZZ	30516	1Z6152	ROLLER	8
*10	PAOZZ	97271	M16WJ103	SPRING, BRAKE ROLLER RETAINING	4
11	PAOZZ	22271	16361	PIN, RETURN SPRING	4
12	PAOZZ	22271	16343	ADJUSTER, SLACK, BRAK	2
13	PAOZZ	22271	9008-555	PARTS KIT, BEARING , CAMSHAFT	2
14	PAOZZ	96906	MS16624-1150	RING, RETAINING	4
*15	PAOZZ	97271	M16WKR10-236	CAMSHAFT, ACTUATING, RIGHT	1
*15	PAOZZ	97271	M16WKL10-236	CAMSHAFT, ACTUATING, LEFT	1
16	PAOZZ	22271	16055	SEAL, PLAIN ENCASED	4
17	PAOZZ	22271	16033	BUSHING, SLEEVE	2
18	PAOZZ	22271	16029	WASHER, FLAT	2
19	PAOZZ	96906	MS15003-4	FITTING, LUBRICATION	2
20	PAOZZ	22271	M10HM115	SCREW, TAPPING THREA	12
*21	PAOZZ	62707	M16WB100	SHIELD, BRAKE DISK	2

END OF FIGURE



TA252223



FIGURE 5. AIR BRAKE SYSTEM.

## SECTION II

TM 9-2330-368-14&amp;P C02

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 1208 AIRBRAKE SYSTEM					
FIG. 5 AIRBRAKE SYSTEM					
1	PAOZZ	79470	C5405X8	ELBOW,TUBE	8
2	PAOZZ	22271	B2600-942	HOSE ASSEMBLY,NONME	4
3	PAOZZ	80000	B2600-943	HOSE ASSEMBLY,NONME	4
4	PAOZZ	22271	2500-915	TANK,PRESSURE	1
5	PAOZZ	81349	B1821BH038C100D	SCREW,CAP,HEXAGON H	8
6	PAOZZ	96906	MS35649-2382	NUT,PLAIN,HEXAGON	8
7	PAOZZ	79146	61K-8-6	ELBOW,PIPE	2
8	PFOZZ	82722	221399	STRAP,RETAINING	2
9	PAOZZ	22271	2500-916	TANK,PRESSURE	1
10	PAOZZ	79146	56D-4	COCK,POPPET DRAIN	2
11	PAOZZ	96906	MS20913-6S	PLUG,PIPE	1
12	PAOZZ	22271	B2600-944	HOSE ASSEMBLY,NONME	1
13	PAOZZ	58536	A52484-1	COUPLING HALF,QUICK	2
14	PAOZZ	96906	MS35748-1	PACKING,PREFORMED	2
15	PAOZZ	13174	C606	HOSE,NONMENTALLIC	43
16	PAOZZ	79146	HO-159-6	INSERT,TUBE FITTING	12
17	PAOZZ	16662	AC2569	COUPLING,TUBE	3
18	XDOZZ	06853	102276	VALVE,RELAY	1
19	PAOZZ	79146	61T-G-12X8	REDUCER,PIPE	1
20	PAOZZ	75272	COV-070921	HOOK,SUPPORT	16
21	PAOZZ	18076	S325-G14	CLAMP,LOOP	5
22	PAOZZ	0EAK3	SK-6006-3	ELBOW,TUBE TO BOSS	3
23	PAOZZ	06853	7012-21	VALUE,BRAKE	1
24	PAOZZ	22271	2605-150	ELBOW,TUBE	2
25	PAOZZ	93061	68AB-6-2	ADAPTER,STRAIGHT,PI	1
26	PAOZZ	96906	MS39182-5	ELBOW,PIPE TO TUBE	2
27	PAOZZ	81343	6-4 100202BA(LON G NUT)	ELBOW,PIPE TO TUBE	1
28	PAOZZ	06853	101112	VALVE,VACUUM REGULA	1
29	PAOZZ	96906	B1821BH025C100D	SCREW,CAP,HEXAGON H	1
30	PAOZZ	96906	MS27183-3	WASHER,FLAT	1
31	XDOZZ	22271	2360-442	STRAP,RETAINING	1
32	PAOZZ	22271	3800914	STRAP,RUBBER	1
*33	PAOZZ	22271	3617-084	NUT,SELF-LOCKING,HE	1

END OF FIGURE



TA505790

FIGURE 6. AIR BRAKE CHAMBER.

## SECTION II

TM9-2330-368-14&amp;PC01

(1)	(2)	(3)	(4)	(5)	(6)
ITEM	SMR		PART		
NO	CODE	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES (UOC)	QTY
GROUP 1208 AIRBRAKE SYSTEM					
FIG. 6 AIRBRAKE CHAMBER					
* 1	PAOOO	50153	163046	CHAMBER,AIR BRAKE	4
2	PAOZZ	50153	11M011	.STUD ASSEMBLY,RELEA	1
3	PAOZZ	96906	MS51968-20	.NUT,PLAIN,HEXAGON	1
* 4	PAOOO	50153	11M018-1/2	.CLEVIS,ROD END	1
5	PAOZZ	96906	MS24665-387	..PIN,COTTER	1
6	PAOZZ	50153	11M061	..PIN,STRAIGHT,HEADED	1
7	PAOZZ	50153	11M012	.PLUG,CHAMBER TOP	1

END OF FIGURE




FIGURE 7. WHEELS AND HUBS.

TA505791 ■




## SECTION II

TM 9-2330-368-14&amp;P C02

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 13 WHEELS AND TRACKS					
GROUP 1311 WHEEL ASSEMBLY					
FIG. 7 WHEELS AND HUBS					
1	PACZZ	09386	37889	NUT,PLAIN,SINGLE BA LEFT	20
1	PACZZ	09386	37888	NUT,PLAIN,SINGLE BA RIGHT	20
2	PCOZZ	22337	RA-27970	WHEEL,PNEUMATIC TIR	5
*3	PAOZZ	80201	40136	.SEAL,PLAIN ENCASED	2
*4	PAOZZ	60038	663	CONE AND ROLLERS,TA	2
*5	PAOZZ	60038	653	CUP,TAPERED ROLLER	2
*6	PAOZZ	22271	10151	NUT,SELF-LOCKING,HE	20
*7	PAOZZ	96906	MS27183-23	WASHER,FLAT	20
*8	PAOFF	22271	16258	BRAKE DRUM	2
*9	PAOOO	22271	K21-HQ104	HUB,BODY	2
*10	PAOZZ	09386	95693	.STUD,SHOULDERED RIGHT	10
*10	XDOZZ	09386	95694	.STUD,SHOULDERED LEFT	10
*11	PAOZZ	22271	M10HM15	.SCREW,TAPPING,THREA	12
*12	PAOZZ	22271	10070	.COVER,ACCESS	2
*13	PAOZZ	62707	M10HG108	.GASKET,HUB CAP	2
*14	PAOZZ	60038	HM212049	.CONE AND ROLLERS,TA	2
*15	PAOZZ	60038	HM212011	.CUP,TAPERED ROLLER	2

END OF FIGURE




TA252226

FIGURE 8. TIRES.

## SECTION II


TM9-2330-368-14&amp;PC01

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 1313 TIRES, TUBES, TIRE CHAINS					
FIG. 8 TIRES					
* 1	PAOFF	81348	ZZ-T-381/15-9.5/ P3A/G/TBHR	TIRE,PNEUMATIC	5
2	PAOZZ	96906	MS51368-2	VALVE,PNEUMATIC TIR	5
END OF FIGURE					



TA252227

Figure 9. Frame Components (Sheet 1 of 2)



TA252228





Figure 9. Frame Components (Sheet 2 of 2)



(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 15 FRAME, TOWING ATTACHMENTS, DRAWBARS, AND ARTICULATION SYSTEMS					
GROUP 1501 FRAME ASSEMBLY					
FIG. 9 FRAME COMPONENTS					
1	PAOZZ	96906	MS51851-66	SCREW, TAPPING, THREA	6
2	PAOZZ	22271	3800-924	HOLDER, MANIFEST	1
3	PAOZZ	96906	MS51967-14	NUT, PLAIN, HEXAGON	4
4	PAOZZ	02978	ERNA245	WASHER, LOCK	4
5	PAOZZ	22271	430000	BUMPER, RUBBER	2
6	PAOZZ	96906	MS27183-19	WASHER, FLAT	4
7	PAOZZ	96906	MS90725-117	SCREW, CAP, HEXAGON H	4
8	PAOZZ	96906	MS35691-9	NUT, PLAIN, HEXAGON	8
9	PAOZZ	22271	C3800-925	GUARD, SPLASH, VEHICU	2
10	PAOZZ	22271	C6260-535	SPACER, PLATE	2
11	PAOZZ	96906	MS90725-36	BOLT, MACHINE	8
12	PAOZZ	96906	MS90725-18	SCREW, CAP, HEXAGON H	8
13	XDOZZ	22271	A6200-903	BLOCK, LOCKING PIN	4
14	PAOZZ	96906	MS35338-44	WASHER, LOCK	8
15	PAOZZ	96906	MS35649-2252	NUT, PLAIN, HEXAGON	8
16	PFOZZ	22271	B9916	EYE, LIFTING	4
17	PAOZZ	22271	A7909	PIN, QUICK RELEASE	4
18	PAOZZ	22271	3600-917	SCREW, CAP, SOCKET HE	24
19	PAOZZ	22271	3608-504	BOLT, SQUARE NECK	2
20	PFOZZ	22271	D9934	DOOR, ACCESS	1
21	PAOZZ	22271	A5200-934	BRACKET, ANGLE	2
22	PAOZZ	96906	MS51851-45	SCREW, TAPPING, THREA	4
23	PAOZZ	22271	3600-916	NUT, SERRATED FLANGE	24
* 24	PAOZZ	22271	3617-089	NUT FLANGED	2
25	PAOZZ	22271	B5200-932	BRACKET, CLEARANCE LIGHT MOUNTING	2
26	PAOZZ	22271	A6260-211	STRIP, JACKKNIFE	2

END OF FIGURE

9  
10 THRU 14





TA505795

FIGURE 10. SAFETY CHAINS AND COUPLERS.



(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 1503 PINTLES AND TOWING ATTACHMENTS					
FIG. 10 SAFETY CHAINS AND COUPLER					
1	PAOZZ	96906	MS90727-189	SCREW,CAP,HEXAGON H	4
2	PAOZZ	74410	DB-1385	COUPLER,DRAWBAR	1
3	PAOZZ	96906	MS35338-51	WASHER,LOCK	4
4	PAOZZ	96906	MS51968-23	NUT,PLAIN,HEXAGON	4
5	PAOZZ	96906	MS90728-215	SCREW,CAP,HEXAGON H	2
6	PAOZZ	75535	G215	SHACKLE	2
7	PAOZZ	96906	MS35691-65	NUT,PLAIN,HEXAGON	2
8	PAOZZ	22271	C3810-230	CHAIN ASSEMBLY,SING	2
* 9	PBOOO	8W862	D-7544	DRAWBAR ASSEMBLY	1
10	PAOZZ	96906	MS90727-189	.SCREW,CAP,HEXAGON H	8
11	XDOZZ	22271	D7545	.BEAM,SPLL ADAPTER	1
12	PAOZZ	74410	DB-1385	.COUPLER,DRAWBAR,RIN	1
13	PAOZZ	96906	MS35338-51	.WASHER,LOCK	8
14	PAOZZ	96906	MS51968-23	.NUT,PLAIN,HEXAGON	8

END OF FIGURE




TA505796 ■

FIGURE 11. SPARE TIRE CARRIER.

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 1504 SPARE WHEEL CARRIER AND TIRE LOCK					
FIG. 11 SPARE TIRE CARRIER					
* 1	XDOOO	22271	D7914	CARRIER,TIRE	1
* 2	XAOZZ	22271	D9914	.MAINMEMBER (WELDER TO FRAME)	1
* 3	PAOZZ	96906	MS51922-1	.NUT,SELF-LOCKING,HE	3
* 4	PAOZZ	22271	B9912	.PAWL PLATE ASSEMBLY	1
* 5	PAOZZ	96906	MS90725-8	.SCREW,CAP,HEXAGON H	3
* 6	XDOZZ	22271	A7918	.ROPE,WIRE	1
* 7	PAOZZ	22271	B9913	.SHAFT ASSEMBLY	1
* 8	PAOZZ	09386	37888	.NUT,PLAIN,SINGLE BA	4
* 9	PAOZZ	71747	CHF-H92-1/4	.CLAMP,WIRE ROPE,SAD	2
* 10	PAOZZ	96906	MS35338-45	.WASHER,LOCK	4
* 11	PAOZZ	96906	MS24665-495	.PIN,COTTER	1
* 12	PAOZZ	96906	MS27183-27	.WASHER,FLAT	2

END OF FIGURE



TA252231


FIGURE 12. LANDING GEAR.

## SECTION II

TM 9-2330-368-14&amp;P C02

(1)	(2)	(3)	(4)	(5)	(6)
ITEM	SMR		PART		
NO	CODE	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES (UOC)	QTY
				GROUP 1507 LANDING GEAR, LEVELING JACKS	
				FIG. 12 LANDING GEAR	
1	PAOZZ	96906	MS90725-68	.SCREW,CAP,HEXAGON H	1
2	PAOZZ	96906	MS27183-13	.WASHER PLAIN	2
3	PAOZZ	99411	LG0083-01	.CRANK,HAND	1
4	PAOZZ	96906	MS51922-17	.NUT,SELF-LOCKING,HE	1
*5	PAOZZ	1URV4	182800	.SUPPORT,RETRACTABLE	1
5	PAOZZ	22271	3870-412	.GEAR, LANDING	1
6	PAOZZ	22271	A7546	.PIN,ASSEMBLY,LOCK	1

END OF FIGURE



NOTE: LEFT HAND SIDE SHOWN; RIGHT HAND SIDE SAME.

TA252232


FIGURE 13. SUSPENSION AND SPRINGS.

## SECTION II

TM 9-2330-368-14&amp;P C02

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 16 SPRINGS AND TORQUE RODS					
GROUP 1601 SPRINGS					
FIG. 13 SUSPENSION AND SPRINGS					
1	PAFZZ	99062	0001-008	SCREW,CAP,HEXAGON H	8
2	PAFZZ	96906	MS35691-70	NUT,PLAIN,HEXAGON	24
3	PAFZZ	96906	MS35691-38	NUT,PLAIN,HEXAGON	6
4	PAFZZ	99062	0378	SPACER,SLEEVE	4
5	PAFZZ	1WZH5	24213-130	BOLT,U	8
6	PAOZZ	22271	430000	BUMPER,RUBBER	4
7	PAOZZ	96906	MS27183-19	WASHER,FLAT	8
8	PAOZZ	96906	MS35338-48	WASHER,LOCK	8
9	PAOZZ	96906	MS90725-117	SCREW,CAP,HEXAGON H	8
10	PAFZZ	96906	MS90727-174	SCREW,CAP,HEXAGON H	4
11	PAFZZ	99062	0741-01	SPACER,SLEEVE	2
12	PAFZZ	96906	MS35691-54	NUT,PLAIN,HEXAGON	4
13	PAFZZ	99062	0732	SPACER,SLEEVE	2
14	PAFZZ	96906	MS90727-127	SCREW,CAP,HEXAGON H	4
15	PAFZZ	99062	0727	SPACER,SLEEVE	2
16	PAFZZ	99062	0079-01X	SPRING,ASSEMBLY,LEA	4
17	PAFZZ	99062	0338-05	RETAINER,NUT AND BO	4

END OF FIGURE



TA252233


Figure 14. Torque Arms



## SECTION II

TM 9-2330-368-14&amp;P C02

(1)	(2)	(3)	(4)	(5)	(6)
ITEM	SMR		PART		
NO	CODE	FSCM	NUMBER	DESCRIPTION AND USABLE ON CODES (UOC)	QTY
				GROUP 1604 TORQUE RODS	
				FIG. 14 TORQUE RODS	
1	PAFZZ	92967	71500	TORQUE ROD,TANDEM A	2
2	PAFZZ	99062	1035-20	TORQUE ROD,TANDEM A	2
				END OF FIGURE	




TA252234

Figure 15. Gates

## SECTION II

TM9-2330-368-14&amp;P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 18 BODY					
GROUP 1801 BODY					
FIG. 15 GATES					
1	PAOZZ	22271	3800-953	STAKE,VEHICLE BODY	1
2	PAOZZ	22271	3800-951	STAKE,VEHICLE BODY	2
3	PAOZZ	22271	3800-952	STAKE,VEHICLE BODY	1
4	PAOZZ	22271	3800-950	STAKE,VEHICLE BODY	2
END OF FIGURE					




TA252235

**Figure 16. Floor Boards**

## SECTION II

TM9-2330-368-14&amp;P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 1805 DECK					
FIG. 16 FLOOR BOARDS					
1	PAFZZ	22271	3600-901	SCREW,TAPPING,THREA	64
2	MFFZZ	22271	D7907-B	BOARD,DECK MAKE FROM PART NO. A3850 -901	2
3	MFFZZ	22271	D7907-D	BOARD,DECK MAKE FROM PART NO. A3850 -901	2
4	MFFZZ	22271	D7907-G	BOARD,DECK MAKE FROM PART NO. A3850 -901	1
5	MFFZZ	22271	D7907-C	BOARD,DECK MAKE FROM PART NO. A3850 -901	2
6	MFFZZ	22271	D7907-F	BOARD,DECK MAKE FROM PART NO.A3850 -901	1
7	MFFZZ	22271	D7907-E	BOARD,DECK MAKE FROM PART NO A3850 -901	2
8	MFFZZ	22271	D7907-A	BOARD,DECK MAKE FROM PART NO. A3850- -901	2
END OF FIGURE					




TA252236

**Figure 17. Reflectors**

## SECTION II

TM9-2330-368-14&amp;P

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
GROUP 22 BODY CHASSIS AND HULL ACCESSORY ITEMS					
GROUP 2202 ACCESSORY ITEMS					
FIG. 17 REFLECTORS					
1	PAOZZ	96906	MS35387-2	REFLECTOR,INDICATIN RED	2
2	PAOZZ	96906	MS35387-1	REFLECTOR,INDICATIN AMBER	4
3	PAOZZ	96906	MS51851-45	SCREW,TAPPING,THREA	12
END OF FIGURE					



TA505803



FIGURE 18. DATA PLATES.



(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODE (UOC)	(6) QTY
GROUP 2210 DATA PLATES					
FIG. 18 DATA PLATES					
1	PBOZZ	07707	AD46BS	RIVET,BLIND	20
2	PBOZZ	22271	C3800-907	PLATE,ID	1
3	PBOZZ	22271	C7543	PLATE,IDENTIFICATIO	1
4	PBOZZ	22271	C3800-906	PLATE,INSTRUCTION	1
5	PBOZZ	22271	C3800-908	PLATE,INSTRUCTION	1
6	PAOZZ	22279	A7919	PLATE,IDENTIFICATIO	1
7	PAOZZ	22271	A3800921	DECAL,WARRANTY	1

END OF FIGURE



## SECTION II

TM9-2330-368-14&amp;PC01

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
				GROUP 95 GENERAL USE STANDARDIZED PARTS	
				GROUP 9501 BULK MATERIAL	
				FIG. BULK	
1	PAOZZ	81349	M13486-1-5	WIRE,ELECTRICAL	V
* 2	PAFZZ	22271	A3850-910	LUMBER,SOFTWOOD BOARD	V
				END OF FIGURE	



## CROSS-REFERENCE INDEXES

## NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-00-003-9252	9	1	5310-00-584-5272	9	4
6240-00-019-0877	1	4		13	8
	1	8	5310-00-584-7888	10	3
	1	16		10	13
	1	20	5310-00-594-8038	7	1
2530-00-021-2364	5	23		11	8
5310-00-056-3395	5	6	4730-00-595-0083	5	13
5305-00-068-0502	2	11	6240-00-617-0991	1	13
4730-00-069-1186	5	17	5310-00-637-9541	1	17
5305-00-071-2233	9	12	4730-00-698-5001	5	24
5310-00-087-4652	12	4	5305-00-716-8128	9	7
5310-00-087-7493	12	2		13	9
5310-00-088-1251	2	13	6220-00-726-1916	1	7
	11	3	5305-00-726-2561	13	10
5330-00-090-2128	5	14	6220-00-752-5992	1	21
3110-00-100-0335	7	5	5305-00-762-6041	10	1
3110-00-100-0670	7	4		10	10
5935-00-115-2307	2	7	5310-00-763-8901	10	4
5305-00-115-9526	1	18		10	14
4730-00-142-3075	5	25	5310-00-763-8905	6	3
6240-00-143-3159	1	12	5310-00-768-0318	9	3
4730-00-143-9282	5	26	4730-00-771-5308	5	16
6145-00-152-6499	BULK	1	5935-00-773-1428	2	10
4730-00-172-0028	4	19	5365-00-803-7299	4	14
5325-00-174-9328	2	2	5310-00-809-3079	9	6
6220-00-179-4324	1	15		13	7
9905-00-202-3639	17	1	5310-00-809-8533	7	7
9905-00-205-2795	17	2	5310-00-809-8541	11	12
4730-00-221-2140	5	11	5310-00-833-8567	1	5
5305-00-225-3839	5	29	2610-00-840-9270	8	1
	11	5	5935-00-846-3883	2	9
5315-00-234-1626	6	5	5310-00-891-1709	9	8
5315-00-234-1664	11	11	5310-00-891-1733	13	3
5305-00-269-3218	12	1	5310-00-891-3405	13	12
5310-00-273-7771	7	1	5310-00-891-3425	10	7
4730-00-278-4822	5	7	5305-00-942-2196	5	5
5975-00-282-2707	2	1	5305-00-945-6412	13	14
4730-00-289-0155	5	22	5310-00-951-4679	5	30
3110-00-293-8997	7	15	5320-00-965-7109	18	1
3110-00-293-8998	7	14	5310-00-997-1888	9	15
6220-00-299-7425	1	3	4720-01-014-4915	5	15
6220-00-299-7426	1	9	5310-01-019-6527	13	2
5310-00-407-9566	11	10	4730-01-043-8150	5	19
5330-00-462-0907	1	14	5330-01-049-4093	7	3
4730-00-555-1764	5	1	4030-01-050-8140	10	6
2640-00-555-2829	8	2	5340-01-071-2047	5	20
6220-00-577-3434	1	2	5306-01-075-8519	9	11
6220-00-577-3435	1	19	2530-01-084-6975	6	7
5310-00-582-5965	2	12	6220-01-093-4439	1	10
	9	14	2530-01-095-3561	6	2

## CROSS-REFERENCE INDEXES

## NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG	ITEM	STOCK NUMBER	FIG	ITEM
5325-01-105-9454	2	5	5315-01-162-8987	4	11
5340-01-116-4684	6	4	2530-01-163-7340	5	4
5315-01-121-1859	6	6	2510-01-163-7361	15	3
5305-01-138-7735	10	5	2510-01-163-7362	15	1
2530-01-147-1568	6	1	5310-01-163-9313	7	6
4720-01-150-3623	5	3	5310-01-163-9317	9	23
4720-01-216-4076	5	12	2510-01-164-0040	15	2
4720-01-152-5476	5	2	2510-01-164-1847	15	4
3040-01-153-1826	11	7	4820-01-164-5891	5	28
2590-01-153-1827	12	5	2540-01-164-7252	10	2
9905-01-153-1842	18	2		10	12
5360-01-390-6448	4	2	5305-01-164-8381	13	1
5360-01-153-1849	4	8	5305-01-164-9723	16	1
5306-01-153-1856	13	5	5315-01-165-1472	4	1
2530-01-153-1859	14	1	5305-01-165-5589	9	18
5365-01-153-1862	13	15	2510-01-165-6140	13	16
5365-01-153-1863	13	4	5305-01-165-7520	7	11
2510-01-153-1866	13	17	5330-01-165-8667	4	16
5340-01-153-1870	12	3	3120-01-165-8748	4	17
5340-01-153-1876	7	12	5365-01-166-0789	13	11
9905-01-153-8217	18	6	5307-01-166-3690	7	10
9905-01-155-3852	18	5	5365-01-166-6728	13	13
4010-01-155-3884	10	8	3120-01-167-2468	4	13
2530-01-155-3885	14	2	5305-01-167-5490	1	1
2530-01-155-3901	5	9		9	22
5365-01-155-3933	9	10		17	3
9905-01-155-7345	18	3	2590-01-169-9734	9	25
9905-01-155-7346	18	4	5340-01-170-1294	2	3
2530-01-155-7498	3	4	2590-01-170-4949	9	2
2590-01-155-7621	2	6	2590-01-171-4483	9	26
2540-01-156-8099	9	5	5340-01-171-5923	9	21
	13	6	5340-01-172-5633	5	21
2530-01-157-4174	7	2	5310-01-173-1097	2	4
5320-01-157-6210	4	5	4820-01-181-5601	5	10
2530-01-157-6246	4	6	2510-01-188-7402	9	16
2530-01-157-6247	4	4	5315-01-220-6245	4	9
5340-01-158-3086	5	8	4030-01-212-3551	11	9
5340-01-158-3269	9	20	2530-01-217-8156	4	21
2530-01-158-7147	4	12	5975-01-230-4370	1	6
3040-01-158-7163	7	9	5310-01-237-2011	9	24
3040-01-158-8583	11	4	5310-01-237-6693	5	33
2530-01-158-9212	7	8	2530-01-257-7591	5	32
2540-01-159-6199	10	9	DELETED		
5310-01-160-4550	4	18	5305-01-257-7634	4	20
5340-01-161-2693	12	6	5306-01-257-7659	9	19
5340-01-161-6239	9	17	2540-01-261-4068	9	9
5310-01-162-2514	3	1	5510-01-263-3109	BULK	2
5310-01-162-2522	3	2	2530-01-352-7863	4	15
5310-01-162-6010	3	3	2530-01-392-8613	4	15
3120-01-162-8657	4	7			

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## PART NUMBER INDEX

CAGEC	PART NUMBER	STOCK NUMBER	FIG	ITEM
79146	AC2569	4730-00-069-1186	5	17
07707	AD46BS	5320-00-965-7109	18	1
22271	A3850-910	5510-01-263-3109	BULK	2
22271	A5200-934	5340-01-171-5923	9	21
22271	A6200-903		9	13
58536	A52484-1	4730-00-595-0083	5	13
22271	A6260-211	2590-01-171-4483	9	26
22271	A7546	5340-01-161-2693	12	6
22271	A7909	5340-01-161-6239	9	17
22271	A7918		11	6
22279	A7919	9905-01-153-8217	18	6
81349	B1821BH025C100D	5305-00-225-3839	5	29
			11	5
81349	B1821BH038C100D	5305-00-942-2196	5	5
22271	B2600-944	4720-01-216-4076	5	12
22271	B2600-942	4720-01-152-5476	5	2
80000	B2600-943	4720-01-150-3623	5	3
22271	B5200-932	2590-01-169-9734	9	25
1URV4	182800	2590-01-153-1827	12	5
22271	B9912	3040-01-158-8583	11	4
22271	B9913	3040-01-153-1826	11	7
22271	B9916	2510-01-188-7402	9	116
71747	CHF-H92-1/4	4030-01-212-3551	11	9
75272	COV-070921	5340-01-071-2047	5	20
75272	COV-1509	5340-01-170-1294	2	3
22271	C3800-906	9905-01-155-7346	18	4
22271	C3800-907	9905-01-153-1842	18	2
22271	C3800-908	9905-01-155-3852	18	5
22271	C3800-925	2540-01-261-4068	9	9
22271	C3810-230	4010-01-155-3884	10	8
79470	C5405X8	4730-00-555-1764	5	1
13174	C606	4720-01-014-4915	5	15
22271	C6260-535	5365-01-155-3933	9	10
22271	C7543	9905-01-155-7345	18	3
22271	C9005-361	2530-01-155-7498	3	4
8W862	D-7544	2540-01-159-6199	10	9
74410	DB-1385	2540-01-164-7252	10	2
			10	12
90763	D0142095-EBG	5310-01-173-1097	2	4
22271	D7545		10	11
22271	D7907-A		16	8
22271	D7907-B		16	2
22271	D7907-C		16	5
22271	D7907-D		16	3
22271	D7907-E		16	7
22271	D7907-F		16	6
22271	D7907-G		16	4
22271	D7914		11	1
22271	D9914		11	2
22271	D9934	5340-01-158-3269	9	20
02978	ERNA245	5310-00-584-5272	9	4
75535	G215	4030-01-050-8140	10	6
60038	HM212011	3110-00-293-8997	7	15
60038	HM212049	3110-00-293-8998	7	14
79146	HO-159-6	4730-00-771-5308	5	16

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## PART NUMBER INDEX

CAGEC	PART NUMBER	STOCK NUMBER	FIG	ITEM
99411	LG0083-01	5340-01-153-1870	12	3
96906	MS15003-4	4730-00-172-0028	4	19
96906	MS15570-1251	6240-00-019-0877	1	4
			1	8
			1	16
			1	20
96906	MS15570-89	6240-00-143-3159	1	12
96906	MS16624-1150	5365-00-803-7299	4	14
96906	MS18154-58	5305-00-115-9526	1	18
96906	MS20913-6S	4730-00-221-2140	5	11
96906	MS24665-387	5315-00-234-1626	6	5
96906	MS24665-495	5315-00-234-1664	11	11
96906	MS27144-2	5935-00-115-2307	2	7
96906	MS27183-13	5310-00-087-7493	12	2
96906	MS27183-19	5310-00-809-3079	9	6
			13	7
96906	MS27183-23	5310-00-809-8533	7	7
96906	MS27183-27	5310-00-809-8541	11	12
96906	MS27183-3	5310-00-951-4679	5	30
96906	MS35338-44	5310-00-582-5965	2	12
			9	14
96906	MS35338-45	5310-00-407-9566	11	10
96906	MS35338-46	5310-00-637-9541	1	17
96906	MS35338-48	5310-00-584-5272	13	8
96906	MS35338-51	5310-00-584-7888	10	3
			10	13
96906	MS35387-1	9905-00-205-2795	17	2
96906	MS35387-2	9905-00-202-3639	17	1
96906	MS35420-1	6220-00-752-5992	1	21
96906	MS35421-1	6220-00-299-7425	1	3
96906	MS35421-2	6220-00-299-7426	1	9
96906	MS35423-1	6220-00-577-3434	1	2
96906	MS35423-2	6220-00-726-1916	1	7
96906	MS35424-1	6220-00-577-3435	1	19
96906	MS35478-1073	6240-00-617-0991	1	13
96906	MS35489-114	5325-00-174-9328	2	2
96906	MS35649-2252	5310-00-997-1888	9	15
96906	MS35649-2382	5310-00-056-3395	5	6
96906	MS35691-38	5310-00-891-1733	13	3
96906	MS35691-54	5310-00-891-3405	13	12
96906	MS35691-65	5310-00-891-3425	10	7
96906	MS35691-70	5310-01-019-6527	13	2
96906	MS35691-9	5310-00-891-1709	9	8
96906	MS35748-1	5330-00-090-2128	5	14
96906	MS39182-8	4730-00-143-9282	5	26
96906	MS51368-2	2640-00-555-2829	8	2
96906	MS51851-45	5305-01-167-5490	1	1
			9	22
			17	3
96906	MS51851-66	5305-00-003-9252	9	1



## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## PART NUMBER INDEX

CAGEC	PART NUMBER	STOCK NUMBER	FIG	ITEM
96906	MS51922-17	5310-00-087-4652	12	4
96906	MS51967-14	5310-00-768-0318	9	3
96906	MS51968-20	5310-00-763-8905	6	3
96906	MS51968-23	5310-00-763-8901	10	4
			10	14
96906	MS52125-2	6220-01-093-4439	1	10
96906	MS75021-1	5935-00-846-3883	2	9
96906	MS90725-117	5305-00-716-8128	9	7
			13	9
96906	MS90725-18	5305-00-071-2233	9	12
96906	MS90725-36	5306-01-075-8519	9	11
96906	MS90725-6	5305-00-068-0502	2	11
96906	MS90725-68	5305-00-269-3218	12	1
			11	5
96906	MS90727-127	5305-00-945-6412	13	14
96906	MS90727-174	5305-00-726-2561	13	10
96906	MS90727-189	5305-00-762-6041	10	1
			10	10
96906	MS90728-215	5305-01-138-7735	10	5
22271	M10HM100	5320-01-157-6210	4	5
22271	M10HM115	5305-01-257-7634	4	20
81349	M13486-1-5	6145-00-152-6499	BULK	1
62707	M16WB100	2530-01-217-8156	4	21
62707	M16WJ101	5360-01-390-6448	4	2
97271	M16WJ103		4	10
97271	1Z6152	5315-01-220-6245	4	9
97271	M16WKL10-236	2530-01-392-7863	4	15
97271	M16WKR10-236	2530-01-392-8613	4	15
81349	M45913/1-4CG5C	5310-00-088-1251	2	13
			11	3
06383	PLT3I	5975-00-282-2707	2	1
22337	RA-27970	2530-01-157-4174	7	2
0EAK3	SK-6006-3	4730-00-289-0155	5	22
18076	S325-G14	5340-01-172-5633	5	21
81348	ZZ-T-381/15-9.5/ P3A/G/TBHR	2610-00-840-9270	8	1
99062	0001-008	5305-01-164-8381	13	1
99062	0079-01	2510-01-165-6140	13	16
99062	0338-05	2510-01-153-1866	13	17
99062	0378	5365-01-153-1863	13	4
99062	0727	5365-01-153-1862	13	15
99062	0732	5365-01-166-6728	13	13
99062	1035-20	2530-01-155-3885	14	2
99062	0741-01	5365-01-166-0789	13	11
22271	10001	5305-01-165-7520	7	11
22271	10070	5340-01-153-1876	7	12
22271	10071		7	13
06853	101112	4820-01-164-5891	5	28
22271	10151	5310-01-163-9313	7	6

## SECTION IV

TM 9-2330-368-14&P C02  
CROSS-REFERENCE INDEXES

## PART NUMBER INDEX

CAGEC	PART NUMBER	STOCK NUMBER	FIG	ITEM
06853	102276		5	18
22271	10406	5310-01-162-6010	3	3
22271	10408	5310-01-162-2514	3	1
97271	10409	5310-01-162-2522	3	2
50153	11M011	2530-01-095-3561	6	2
50153	11M012	2530-01-084-6975	6	7
50153	11M018-1/2	5340-01-116-4684	6	4
50153	11M061	5315-01-121-1859	6	6
19207	11639519-2	5330-00-462-0907	1	14
19207	11639520		1	11
19207	11639535	6220-00-179-4324	1	15
22271	16029	5310-01-160-4550	4	18
22271	16033	3120-01-165-8748	4	17
22271	16034	3120-01-162-8657	4	7
22271	16055	5330-01-165-8667	4	16
22271	16101	5360-01-153-1849	4	8
97271	16130		4	3
22271	16258	2530-01-158-9212	7	8
50153	163046	2530-01-147-1568	6	1
22271	16343	2530-01-158-7147	4	12
22271	16355	5315-01-165-1472	4	1
22271	16361	5315-01-162-8987	4	11
22271	16566	2530-01-157-6246	4	6
22271	16567	2530-01-157-6247	4	4
22271	20101	3040-01-158-7163	7	9
82722	221399	5340-01-158-3086	5	8
22271	2360-442		5	31
1WZH5	24213-130	5306-01-153-1856	13	5
22271	2500-915	2530-01-163-7340	5	4
22271	2500-916	2530-01-155-3901	5	9
70485	2570	5325-01-105-9454	2	5
22271	2605-150	4730-00-698-5001	5	24
22271	3600-901	5305-01-164-9723	16	1
22271	3600-916	5310-01-163-9317	9	23
22271	3600-917	5305-01-165-5589	9	18
22271	3608-504	5306-01-257-7659	9	19
22271	3617-084	5310-01-237-6693	5	33
22271	3617-089	5310-01-237-2011	9	24
01212	370036A	5330-01-049-4093	7	3
09386	37888	5310-00-594-8038	7	1
			11	8
09386	37889	5310-00-273-7771	7	1
22271	3800-924	2590-01-170-4949	9	2
22271	3800-950	2510-01-164-1847	15	4
22271	3800-951	2510-01-164-0040	15	2
22271	3800-952	2510-01-163-7361	15	3
22271	3800-953	2510-01-163-7362	15	1
22271	3800914	2530-01-257-7591	5	32
22271	430000	2540-01-156-8099	9	5
			13	6

## SECTION IV

TM 9-2330-368-14&P C02  
CROSS-REFERENCE INDEXES

## PART NUMBER INDEX

CAGEC	PART NUMBER	STOCK NUMBER	FIG	ITEM
79146	56D-4	4820-01-181-5601	5	10
81343	6-4 100202BA		5	27
79146	61K-8-6	4730-00-278-4822	5	7
79146	61T-G-12X8	4730-01-043-8150	5	19
60038	653	3110-00-100-0335	7	5
60038	663	3110-00-100-0670	7	4
93061	68AB-6-2	4730-00-142-3075	5	25
06853	7012-21	2530-00-021-2364	5	23
92967	71500	2530-01-153-1859	14	1
19207	7731428	5935-00-773-1428	2	1
22271	7901	2590-01-155-7621	2	6
51831	8338566	5975-01-230-4370	1	6
51831	8338567	5310-00-833-8567	1	5
22271	9008-555	3120-01-167-2468	4	13
22271	9023-500		2	8
09386	95693	5307-01-166-3690	7	10
09386	95694		7	10

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## FIGURE AND ITEM NUMBER INDEX

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
BULK	1	6145-00-152-6499	81349	M13486-1-5
BULK	2	5510-01-263-3109	22271	A3850-910
1	1	5305-01-167-5490	96906	MS51851-45
1	2	6220-00-577-3434	96906	MS35423-1
1	3	6220-00-299-7425	96906	MS35421-1
1	4	6240-00-019-0877	96906	MS15570-1251
1	5	5310-00-833-8567	51831	8338567
1	6	5975-01-230-4370	51831	8338566
1	7	6220-00-726-1916	96906	MS35423-2
1	8	6240-00-019-0877	96906	MS15570-1251
1	9	6220-00-299-7426	96906	MS35421-2
1	10	6220-01-093-4439	96906	MS52125-2
1	11		19207	11639520
1	12	6240-00-143-3159	96906	MS15570-89
1	13	6240-00-617-0991	96906	MS35478-1073
1	14	5330-00-462-0907	19207	11639519-2
1	15	6220-00-179-4324	19207	11639535
1	16	6240-00-019-0877	96906	MS15570-1251
1	17	5310-00-637-9541	96906	MS35338-46
1	18	5305-00-115-9526	96906	MS18154-58
1	19	6220-00-577-3435	96906	MS35424-1
1	20	6240-00-019-0877	96906	MS15570-1251
1	21	6220-00-752-5992	96906	MS35420-1
2	1	5975-00-282-2707	06383	PLT3I
2	2	5315-00-174-9328	96906	MS35489-114
2	3	5340-01-170-1294	75272	COV-1509
2	4	5310-01-173-1097	90763	D0142095-EBG
2	5	5325-01-105-9454	70485	2570
2	6	2590-01-155-7621	22271	7901
2	7	5935-00-115-2307	96906	MS27144-2
2	8		22271	9023-500
2	9	5935-00-846-3883	96906	MS75021-1
2	10	5935-00-773-1428	19207	7731428
2	11	5305-00-068-0502	96906	MS90725-6
2	12	5310-00-582-5965	96906	MS35338-44
2	13	5310-00-088-1251	81349	M45913/1-4CG5C
3	1	5310-01-162-2514	22271	10408
3	2	5310-01-162-2522	97271	10409
3	3	5310-01-162-6010	22271	10406
3	4	2530-01-155-7498	22271	C9005-361
4	1	5315-01-165-1472	22271	16355
4	2	5360-01-390-6448	62707	M16WJ101
4	3		97271	16130
4	4	2530-01-157-6247	22271	16567
4	5	5320-01-157-6210	22371	M10HM100
4	6	2530-01-157-6246	22271	16566
4	7	3120-01-162-8657	22271	16034
4	8	5360-01-153-1849	22271	16101
4	9		97271	M16WJ104
4	10		97271	M16WJ103
4	11	5315-01-162-8987	22271	16361

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## FIGURE AND ITEM NUMBER INDEX

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
4	12	2530-01-158-7147	22271	16343
4	13	3120-01-167-2468	22271	9008-555
4	14	5365-00-803-7299	96906	MS16624-1150
4	15	2530-01-392-7863	97271	M16WKL10-236
4	15	2530-01-392-8613	97271	M16WKR10-236
4	16	5330-01-165-8667	22271	16055
4	17	3120-01-165-8748	22271	16033
4	18	5310-01-160-4550	22271	16029
4	19	4730-00-172-0028	96906	MS15003-4
4	20	5305-01-257-7634	22271	M10HM115
4	21	2530-01-217-8156	62707	M16WB100
5	1	4730-00-555-1764	7947D	C5405X8
5	2	4720-01-152-5476	22271	B2600-942
5	3	4720-01-150-3623	80000	B2600-943
5	4	2530-01-163-7340	22271	2500-915
5	5	5305-00-942-2196	81349	B1821BH038C-100D
5	6	5310-00-056-3395	96906	MS35649-2382
5	7	4730-00-278-4822	79146	61K-8-6
5	8	5340-01-158-3086	82722	221399
5	9	2530-01-155-3901	22271	2500-916
5	10	4820-01-181-5601	79146	56D-4
5	11	4730-00-221-2140	96906	MS20913-6S
5	12	4720-01-216-4076	22271	B2600-944
5	13	4730-00-595-0083	58536	A5284-1
5	14	5330-00-090-2128	96906	MS35748-1
5	15	4720-01-014-4915	13174	C606
5	16	4730-00-771-5308	79146	HO-159-6
5	17	4730-00-069-1186	79146	AC2569
5	18		06853	102276
5	19	4730-01-043-8150	79146	61T-G-12X8
5	20	5340-01-071-2047	75272	COV-070921
5	21	5340-01-172-5633	18076	S325-G14
5	22	4730-00-289-0155	0EAK3	SK-6006-3
5	23	2530-00-021-2364	06853	7012-21
5	24	4730-00-698-5001	22271	2605-150
5	25	4730-00-142-3075	93061	68AB-6-2
5	26	4730-00-143-9282	96906	MS39182-8
5	27		81343	100202BA
5	28	4820-01-164-5891	06853	101112
5	29	5305-00-225-3839	81349	B1821BH025C-100D
5	30	5310-00-951-4679	96906	MS27183-3
5	31		22271	2360-442
5	32	2530-01-257-7591	22271	3800914
5	33	5310-01-237-6693	22271	3617-084
6	1	2530-01-147-1568	50153	163046
6	2	2530-01-095-3561	50153	11M011
6	3	5310-00-763-8905	96906	MS51968-20
6	4	5340-01-116-4684	50153	11M018-1/2
6	5	5315-00-234-1626	96906	MS24665-387
6	6	5315-01-121-1859	50153	11M061

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## FIGURE AND ITEM NUMBER INDEX

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
6	7	2530-01-084-6975	50153	11M012
7	1	5310-00-273-7771	09386	37889
7	1	5310-00-594-8038	09386	37888
7	2	2530-01-157-4174	22337	RA-27970
7	3	5330-01-049-4093	01212	370036A
7	4	3110-00-100-0670	60038	663
7	5	3110-00-100-0335	60038	653
7	6	5310-01-163-9313	22271	10151
7	7	5310-00-809-8533	96906	MS27183-23
7	8	2530-01-158-9212	22271	16258
7	9	3040-01-158-7163	22271	20101
7	10		09386	95694
7	10	5307-01-166-3690	09386	95693
7	11	5305-01-165-7520	22271	10001
7	12	5340-01-153-1876	22271	10070
7	13		22271	10071
7	14	3110-00-293-8998	60038	HM212049
7	15	3110-00-293-8997	60038	HM212011
8	1	2610-00-840-9270	81348	ZZ-T-381/15-9.5/ P3A/G/TBHR
8	2	2640-00-555-2829	96906	MS51368-2
9	1	5305-00-003-9252	96906	MS51851-66
9	2	2590-01-170-4949	22271	3800-924
9	3	5310-00-768-0318	96906	MS51967-14
9	4	5310-00-584-5272	02972	ERNA245
9	5	2540-01-156-8099	22271	430000
9	6	5310-00-809-3079	96906	MS27183-19
9	7	5305-00-716-8128	96906	MS90725-117
9	8	5310-00-891-1709	96906	MS35691-9
9	9	2540-01-261-4068	22271	C3800-925
9	10	5365-01-155-3933	22271	C6260-535
9	11	5306-01-075-8519	96906	MS90725-36
9	12	5305-00-071-2233	96906	MS90725-18
9	13		22271	A6200-903
9	14	5310-00-582-5965	96906	MS35338-44
9	15	5310-00-997-1888	96906	MS35649-2252
9	16	2510-01-188-7402	22271	B9916
9	17	5340-01-161-6239	22271	A7909
9	18	5305-01-165-5589	22271	3600-917
9	19	5306-01-257-7659	22271	3608-504
9	20	5340-01-158-3269	22271	D9934
9	21	5340-01-171-5923	22271	A5200-934
9	22	5305-01-167-5490	96906	MS51851-45
9	23	5310-01-163-9317	22271	3600-916
9	24	5310-01-237-2011	22271	3617-089
9	25	2590-01-169-9734	22271	B5200-932
9	26	2590-01-171-4483	22271	A6260-211
10	1	5305-00-762-6041	96906	MS90727-189
10	2	2540-01-164-7252	74410	DB-1385
10	3	5310-00-584-7888	96906	MS35338-51
10	4	5310-00-763-8901	96906	MS51968-23

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## FIGURE AND ITEM NUMBER INDEX

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
10	5	5305-01-138-7735	96906	MS90728-215
10	6	4030-01-050-8140	75535	G215
10	7	5310-00-891-3425	96906	MS35691-65
10	8	4010-01-155-3884	22271	C3810-230
10	9	2540-01-159-6199	8W862	D-7544
10	10	5305-00-762-6041	96906	MS90727-189
10	11		22271	D7545
10	12	2540-01-164-7252	74410	DB-1385
10	13	5310-00-584-7888	96906	MS35338-51
10	14	5310-00-763-8901	96906	MS51968-23
11	1		22271	D7914
11	2		22271	D9914
11	3	5310-00-088-1251	96906	MS51922-1
11	4	3040-01-158-8583	22271	B9912
11	5	5305-00-225-3839	96906	MS90725-8
11	6		22271	A7918
11	7	3040-01-153-1826	22271	B9913
11	8	5310-00-594-8038	09386	37888
11	9	4030-01-212-3551	71747	CHF-H92-1/4
11	10	5310-00-407-9566	96906	MS35338-45
11	11	5315-00-234-1664	96906	MS24665-495
11	12	5310-00-809-8541	96906	MS27183-27
12	1	5305-00-269-3218	96906	MS90725-68
12	2	5310-00-087-7493	96906	MS27183-13
12	3	5340-01-153-1870	99411	LG0083-01
12	4	5310-00-087-4652	96906	MS51922-17
12	5	2590-01-153-1827	1URV4	182800
12	6	5340-01-161-2693	22271	A7546
13	1	5305-01-164-8381	99062	0001-008
13	2	5310-01-019-6527	96906	MS35691-70
13	3	5310-00-891-1733	96906	MS35691-38
13	4	5365-01-153-1863	99062	0378
13	5	5306-01-153-1856	1WZH5	24213-130
13	6	2540-01-156-8099	22271	430000
13	7	5310-00-809-3079	96906	MS27183-19
13	8	5310-00-584-5272	96906	MS35338-48
13	9	5305-00-716-8128	96906	MS90725-117
13	10	5305-00-726-2561	96906	MS90727-174
13	11	5365-01-166-0789	99063	0741-01
13	12	5310-00-891-3405	96906	MS35691-54
13	13	5365-01-166-6728	99062	0732
13	14	5305-00-945-6412	96906	MS90727-127
13	15	5365-01-153-1862	99062	0727
13	16	2510-01-165-6140	99062	0079-01
13	17	2510-01-153-1866	99062	0338-05
14	1	2530-01-153-1859	92967	71500
14	2	2530-01-155-3885	99062	1035-20
15	1	2510-01-163-7362	22271	3800-953
15	2	2510-01-164-0040	22271	3800-951
15	3	2510-01-163-7361	22271	3800-952
15	4	2510-01-164-1847	22271	3800-950

## SECTION IV

TM 9-2330-368-14&amp;P C02

## CROSS-REFERENCE INDEXES

## FIGURE AND ITEM NUMBER INDEX

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
16	1	5305-01-164-9723	22271	3600-901
16	2		22271	D7907-B
16	3		22271	D7907-D
16	4		22271	D7907-G
16	5		22271	D7907-C
16	6		22271	D7907-F
16	7		22271	D7907-E
16	8		22271	D7907-A
17	1	9905-00-202-3639	96906	MS35387-2
17	2	9905-00-205-2795	96906	MS35387-1
17	3	5305-01-167-5490	96906	MS51851-45
18	1	5320-00-965-7109	07707	AD46BS
18	2	9905-01-153-1842	22271	C3800-907
18	3	9905-01-155-7345	22271	C7543
18	4	9905-01-155-7346	22271	C3800-906
18	5	9905-01-155-3852	22271	C3800-908
18	6	9905-01-153-8217	22279	A7919



## APPENDIX G


### ILLUSTRATED LIST OF MANUFACTURED ITEMS

#### **G-1 . INTRODUCTION**

This appendix includes complete instructions for making items authorized to be manufactured or fabricated at organizational maintenance. A part number index in alphanumeric order is provided for cross-referencing the part number of the item to be manufactured to the figure which covers the fabrication criteria. All bulk materials needed for manufacture of an item are listed in a tabular list on the illustrations.

#### **G-2. MANUFACTURED ITEMS PART NUMBER INDEX**

<b>Part Number</b>	<b>Figure Number</b>
B7924	G-4
D7907-A	G-2
D7907-B	G 2
D7907-C	G-2
D7907-D	G-2
D7907-E	G-2
D7907-F	G-2
D7907-G	G-2
EX- 1002	G-3
P-1000	G-1




ITEM	QTY	DESCRIPTION
1	1	TUBE, 4-3/4 OD x 1/8 WALL x 9 LG, HR STEEL
2	1	FLANGE, 1/4 THICK, 6-1/2 OD x 4-1/2 ID, HR STEEL

NOTE: ALL DIMENSIONS ARE IN INCHES.

TA252211

Figure G-1. Hub Extension Part No. P-1000



#### PLANKING SIZE CHART


ITEM	WIDTH & LENGTH	QTY.	CUT FROM
A	7-1/2 IN. x 89-3/16 IN.	2	7-1/2 IN. x 8 FT-0 IN.
B	7-1/2 IN. x 8 FT-10-3/16 IN.	2	7-1/2 IN. x 10 FT-0 IN.
C	7-1/2 IN. x 83-7/8 IN.	2	7-1/2 IN. x 8 FT-0 IN.
D	7-1/2 IN. x 64-3/16 IN.	2	7-1/2 IN. x 10 FT-0 IN.
E	7-1/2 IN. x 47-3/16 IN.	2	DROP-OFF
F	* x 89-3/16 IN.	1	7-1/2 IN. x 8 FT-0 IN.
G	* x 8 FT-10-3/16 IN.	1	7-1/2 IN. x 10 FT-0 IN.

#### NOTES

1. CUT ALL FLOOR BOARDS FROM 7-1/2 INCH BY 10 FOOT FLOOR BOARD.
2. CUT FLOOR BOARDS D AND E FROM ONE LENGTH OF BOARD.
3. FLOOR BOARDS F AND G MUST BE SELECTIVELY FIT DURING INSTALLATION. 1 INDICATES VARIABLE WIDTH.

TA252212

**Figure G-2. Floor Boards Part No. D7907-A THRU D7907-G**



#### PEDESTAL INSTALLATION AND SET-UP


1. SECURELY LAG BOLT THE BOTTOM PLATE OF THE PEDESTAL TO CONCRETE FLOOR USING EIGHT 1/2 INCH DIA. GRADE 8 BOLTS.
2. USE ITEMS 5, 6 AND 7 TO FASTEN WHEEL AND TIRE TO TOP OF PEDESTAL.

ITEM	QTY.	DESCRIPTION
1	1	PLATE, 3/8 x 16 x 16, HR STEEL, ASTM A36
2	1	PLATE, 3/8 x 13 DIA, HR STEEL, ASTM A36
3	3	PLATE, 3/8 x 4 x 6, HR STEEL, ASTM A36
4	3	ANGLE, 3/8 x 3-1/2 x 3-1/2 x 18-1/4, STEEL, ASTM A36
5	3	BOLT, HEX HEAD, 3/4-16NF x 2, GRADE 8 STEEL
6	3	NUT, PLAIN, HEX, 3/4-16NF, GRADE 8 STEEL
7	3	WASHER, FLAT, HEAVY, 3/4, STEEL

NOTE: ALL DIMENSIONS ARE IN INCHES

TA252239


Figure G-3. Tire Mounting Pedestal Part No. EX-1002



**MATERIAL: HARDWOOD BLOCK (GRAIN PARALLEL TO 15 LENGTH.  
NOTE: TREAT WOOD WITH WOOD PRESERVATIVE.**

TA252240

**Figure G-4. Tire Changing Block Part No. B7924**



PLANK CHART, SHIP LAP			
LTR.	FACE X LENGTH	PCS. REQ.	CUT FROM RANDOM LENGTHS
A	7-1/2 IN. x 89-3/16 IN.	2	9 FT. to 14 FT.
B	7-1/2 IN. x 8 FT.-10-3/16 IN.	2	
C	7-1/2 IN. x 83-7/8 IN.	2	
D	7-1/2 IN. x 64-3/16 IN.	2	DROP-OFFS FROM A, B & C
E	7-1/2 IN. x 47-3/16"	2	
F*	7-1/2 IN. x 89-3/16 IN.	1	9 FT. to 14 FT.
G*	7-1/2 IN. x 8 FT.-10-3/16 IN.	1	

#### NOTES

1. CUT ALL BOARDS FROM 7-1/2 INCH BY 14 FOOT FLOOR BOARD.
2. USE DROP-OFFS FROM BOARDS A, B AND C TO MAKE UP BOARDS D AND E.
3. FLOOR BOARD F AND G MUST BE SELECTIVELY FIT DURING INSTALLATION.  
\* INDICATES VARIABLE WIDTH.
4. SHIP LAP TABS TO BE TOWARD LEFT (ROAD) SIDE OF TRAILER.

TA252255

**Figure G-5. Ship Lap Floor Boards Part No. D7907A THRU D7907G (D REV)**

## APPENDIX H

### TORQUE LIMITS

#### H-1. GENERAL

Use a torque wrench to check torque or tighten nuts and capscrews to specified torque. Special torque values are indicated in the maintenance procedures. For standard torque values should be used for other threaded fasteners. Refer to following tables H-1 and H-2.

**Table H-1. Standard Torque Values**

SUGGESTED TORQUE VALUES $\pm$ 5 PERCENT TO PRODUCE CORRESPONDING BOLT LOADS						
Size	SAE GRADE 5			SAE GRADE 8		
	Clamp Load (lbs.)	Assembly Torque		Clamp Load (lbs.)	Assembly Torque	
		Dry (lb-in.)	Lube (lb-in.)		Dry (lb-in.)	Lube (lb-in.)
1/4-20	2020	8	75	2860	12	9
1/4-28	2320	10	86	3280	14	10
5/16-18	3340	17	13	4720	25	18
5/16-24	3700	19	14	5220	25	20
3/8-16	4940	30	23	7000	45	35
3/8-24	5600	35	25	7900	50	35
7/16-14	6800	50	35	9550	70	55
7/16-20	7550	55	40	10700	80	60
1/2-13	9050	75	55	12750	110	80
1/2-20	10700	90	65	14400	120	90
9/16-12	11600	110	80	16400	150	110
9/16-18	12950	120	90	18250	170	130
5/8-11	14400	150	110	20350	220	170
5/8-18	16950	180	130	23000	240	180
3/4-10	21300	260	200	30100	380	280
3/4-16	23800	300	220	33600	420	320
7/8-9	27000	400	300	41600	600	460
7/8-14	29800	440	320	45800	660	500
1-8	35500	580	440	54500	900	680
1-12	38800	640	480	59700	1000	740

**Table H-2. Self-Locking Nut Breakaway Torque Values**

<b>Thread Size</b>	<b>Minimum Breakaway Torque (lb -in.)</b>	<b>Thread Size</b>	<b>Minimum Breakaway Torque (lb -in.)</b>
10-32	2.0	5/8-18	32.0
1/4-28	3.5	3/4-16	50.0
5/16-24	6.5	7/8-14	70.0
3/8-24	9.5	1-12	90.0
7/16-20	14.0	1-1/8-12	117.0
1/2-20	18.0	1-1/4-12	143.0
9/16-18	24.0		
<p style="text-align: center;"><b>NOTE</b></p> <p>To determine breakaway torque, thread nut onto screw or bolt until at least two threads stick out. Nut shall not make contact with a mating part. Stop the nut. Torque necessary to begin turning nut again is the breakaway torque. Do not reuse self-locking nuts that do not meet minimum breakaway torque.</p>			



## ALPHABETIC INDEX

Subject, Para

**A**

Abbreviations, 1-9

Air Brake Chambers

Adjustment, 4-16e

Caging, 2-27a

Cleaning and Inspection, 4-16b

Installation, 4-16d

Removal, 4-16a

Uncaging, 2-27b

Air Brake System

Air Hoses, 4-17a

Diagram, page 4-17

Testing (see crew PMCS)

Tubing and Fittings, 4-17b

Air Chambers (see air brake chambers)

Air Hoses

Installation, 4-17b

Removal, 4-17a

Air Lines

Installation, 4-17e

Removal, 4-17c

Repair, 4-17d

Air Tanks

Installation, 4-19b

Removal, 4-19a

Air Valves

Relay Valve, 4-18a

Trailer Valve, 4-18b

Axles

Assembly, 5-8t

Cleaning, 5-8c

Data, 1-13

Disassembly, 5-8b

Inspection, 5-8d

Installation, 5-8g

Location, 1-12

Removal, 5-8a

Repair, 5-8e

Subject, Para

**B**

Brakes

Adjustment, 4-15d

Description, 2-2a

Location, 1-12

Maintenance, 4-15

Brake Drums

Installation, 4-14e

Removal, 4-14a

Turning, 5-5

Brake Shoes

Relining, 5-4

Removal, 4-15a

Installation, 4-15a

Bumpers, Rear

Installation, 4-24b

Location, 1-12

Removal, 4-24a

Bumper, Spring

Installation, 5-6b

Removal, 5-6a

**C**

Camshaft and Bearings, 4-15b

Clearance Marker Lights

Description, 2- 1a

Installation, 4-11b

Removal, 4-11a

Composite Lights

Description, 2-1a

Installation, 4-10c

Removal, 4- 10a

Repair, 4-10b

Connecting HEMAT, 2-13

Coupler

Connection of, 2-13

Disconnection of, 2-16

Installation, 4-25b

Location, 1-12

Removal, 4-25a

Subject, Para

**D**

Data Plates  
    Installation, 4-35b  
    Location, 1-14  
    Removal, 4-35a  
  
Disconnecting HEMAT, 2-16

**E**

Electrical System  
    Operator Maintenance, 3-5  
    Testing, 4-12  
  
Equipment Characteristics, Capabilities and Features, 1-11  
  
Equipment Data, 1-13

**F**

Fire Extinguisher, 2-7  
  
Floor Boards  
    Inspection,  
    Repair, 5-9  
  
Fording, 2-28  
  
Frame  
    Location, 1-12  
    Repair, 5-11

Fresh Water Fording, 2-28

**G**

Gates  
    Description, 2-10  
    Location, 1-12  
    Installation, 2-14  
    Removal, 2-17  
    Repair, 5-10

**H**

Hubs and Drums  
    Cleaning, 4-14b  
    Inspection, 4-14c  
    Installation, 4-14e  
    Lubrication, 4-14e  
    Removal, 4-14a  
    Repair, 4-14d

Subject, Para

**I**

Inter-vehicular Air Hoses  
    Description, 2-2b  
  
Intervehicular Cable  
    Description, 2-1b

**J**

Jacking Procedure, 3-6

**L**

Landing Gear  
    Description, 2-5  
    Installation, 4-29b  
    Location, 1-12  
    Operation, 2-13, 2-16  
    Removal, 4-29a

Lifting Eyes  
    Description, 2-9  
    Installation, 4-27b  
    Location, 1-12  
    Removal, 4-27a  
    Use of, 2-19

Lights  
    Crew Maintenance, 3-5  
    Description, 2-1  
    Location, 1-12  
    Organizational Maintenance, 4-10, 4-11

Load Pod Stops  
    Installation, 4-31b  
    Location, 1-12f  
    Removal, 4-31a  
    Use of, 2-15a and c

Loading HEMAT, 2-15a

Lubrication Chart, 3-2

**M**

Maintenance Forms and Records, 2-11

Major Components, 1-12

Manifest Holder  
    Installation, 4-36b  
    Location, 1-12a  
    Removal, 4-36a

Marker Lights (see Clearance Marker Lights)

Subject, Para

**O**

Operation, 2-15

**P**

Painting

Materials and Tools, 7-1

Painting Procedure, 7-2

Parking Brake Control

Description, 2-2c

Installation, 4-18c (2)

Removal, 4-18c (1)

PMCS

Operator, 2-12

Organizational, 4-7

Preparation for Storage or Shipment, 8-1

Preparation for Use After Storage, 8-2

**R**

Reflectors

Installation, 4-33b

Location, 1-12

Removal, 4-33a

Relay Valve, 4-18a

Installation, 4-18a (2)

Removal, 4-18a (1)

**S**

Safety Chains

Connection of, 2-13

Description, 2-3a

Disconnection of, 2-16

Location, 1-12

Removal, 4-26a

Service Brakes

Adjustment, 4-15d

Description, 2-2a

Location, 1-12

Maintenance, 4-15

Slack Adjusters, 4-15c

Spare Tire Carrier

Description, 24

Installation, 4-28b

Location, 1-12

Operation, 2-18

Removal, 4-28a

Subject, Para

**S (Con't)**

Splash Guards

Installation, 4-34b

Location, 1-12

Removal, 4-34a

SPLL Adapter

Description, 2-8

Use of, 2-29

Stop and Tail Light (see Composite Light)

Storage Box

Location, 1-12

Description, 2-6

Storage Box Cover

Installation, 4-30b

Removal, 4-30a

Suspension

Data, 1-13

Installation, 5-6b

Removal, 5-6a

**T**

Tie Down Rings, 1-12

Tires

Cleaning and Inspection, 4-21

Data, 1-13

Dismounting, 4-20

Mounting, 4-23

Repair, 4-22

Torque Arms

Adjustment, 5-7

Inspection, Table 4-1

Towing HEMAT, 2-15b

Trailer Parking Brake Control (see Parking Brake Control)

Trailer Valve, 4-18b

Installation, 4-18b (2)

Removal, 4-18b (1)

Subject, Para

**U**

■ U-Bolts  
    Inspection, Table 4-1

Unloading HEMAT, 2-15c

**W**

Warranty, 1-6

Wheels and Tires  
    Installation, 3-6b  
    Removal, 3-6c

Wiring Harness  
    Cleaning, 4-13b  
    Inspection, 4-13b  
    Installation, 4-13d  
    Removal, 4-13a  
    Repair, 4-13c  
    Testing, 4-12

By Order of the Secretary of the Army:

**JOHN A. WICKHAM, JR.**  
*General, United States Army*  
*Chief of Staff*

Official

**R.L. DILWORTH**  
*Brigadier General United States Army*  
*The Adjutant General*

Distribution:

To be distributed in accordance with DA Form 12-32, Operator, Organizational and Direct and General Support maintenance requirements for Multiple Launch Rocket System (MLRS).

\*U.S. GOVERNMENT PRINTING OFFICE: 1986 641 -025/201 52



## THE METRIC SYSTEM AND EQUIVALENTS

### LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches  
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches  
 1 Kilometer = 1000 Meters = 0.621 Miles

### WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces  
 1 Kilogram = 1000 Grams = 2.2 Lb.  
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

### LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces  
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

### SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches  
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet  
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

### CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches  
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

### TEMPERATURE


${}^{\circ}\text{F} - 32 = {}^{\circ}\text{C}$   
 212° Fahrenheit is equivalent to 100° Celsius  
 90° Fahrenheit is equivalent to 32.2° Celsius  
 32° Fahrenheit is equivalent to 0° Celsius  
 ${}^{\circ}\text{C} + 32 = {}^{\circ}\text{F}$

### APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621







This fine document...

Was brought to you by me:



### [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)