DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

TMDERS MAINFRAME, TEKTRONIX MODEL TM 515

(NSN 6695-01-074-7953)

Current as of 5 December 1979

Headquarters, Department of the Army, Washington, DC 8 January 1980

REPORTING OF ERRORS

You can help improve this publication by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications, should be mailed directly to Commander, US Army Missile Command, ATTN: DRSMI-MFM, Redstone Arsenal, AL 35809. A reply will be furnished directly to you.

				Paragraph	Page	
SECTION 1.	INTRODUCTIO	N				
	Scope	1	1			
	General				1	
	Explanation of o		1			
	Special information	4	5			
	How to locate re		5			
	Abbreviations		6			
II.	REPAIR PARTS LIST				9	
	Functional	Group	Model	Part		
	group	title	No.	No.		
	6692 TMI	DERS Mainframe	TM 515	MIS30526/ITY3		
III.	NATIONAL STOCK NUMBER AND PART					
	NUMBER INDEX					

Change 1 i

Section 1. INTRODUCTION

- **1. Scope.** This manual lists spares and repair parts that are required for maintenance of the TMDERS Mainframe, Tektronix Model TM 515. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.
- 2. General. This repair parts and special tools list (RPSTL) is divided into the following sections:
 - a. Section 1. Introduction.
- b. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National Stock Number (NSN) sequence.
- c. Section III. NSN and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all NSN's appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance

3. Explanation of Columns

- a. Illustration. This column is divided as follows:
 - (1) Figure Number . Indicates the figure number of the illustration on which the item is shown.
 - (2) Item Number. The number used to identify item called out in the illustration.
- b. Source, Maintenance, and Recoverability (SMR) Codes.
- (1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

- PA Item procured and stocked for anticipated or known usage.
- PB Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
- PC Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
- PD Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
- PE Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
- PF Support equipment which will not be stocked but which will be centrally procured on demand.

Change 1

- PG Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
- KD An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
- KF An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
- KB Item included in both a depot overhaul/repair kit and a maintenance kit.
- MO Item to be manufactured or fabricated at organizational level.
- MF Item to be manufactured or fabricated at the direct support maintenance level.
- MH Item to be manufactured or fabricated at the general support maintenance level.
- MD Item to be manufactured or fabricated at the depot maintenance level.
- AO Item to be assembled at organizational level.
- AF Item to be assembled at direct support maintenance level.
- AH Item to be assembled at general support maintenance level.
- AD Item to be assembled at depot maintenance level.
- XA Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB Item is not procured or stocked. If not available through salvage, requisition.
- XC Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.
- XD A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) Maintenance Code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

2

TM 9-6695-245-34P

Code Application/Explanation

- C Crew or operator maintenance performed within organizational maintenance.
- O Support item is removed, replaced, used at the organizational level.

- F Support item is removed, replaced, used at the direct support level.
- H Support item is removed, replaced, used at the general support level.
- D Support items that are removed replaced, used at depot, mobile depot, or specialized repair activity only.
- (b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

- O The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F The lowest maintenance level capable of complete repair of the support item is the direct support level.
- H The lowest maintenance level capable of complete repair of the support item is the general support level.
- D The lowest maintenance level capable of complete repair of the support item is the depot level.
- L Repair restricted to (enter applicable designated specialized repair activity), Specialized Repair Activity.
- Z Nonreparable. No repair is authorized.
- B No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.
- (3) Recoverability Code. .Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows: Recoverability

Codes Definition

- Z Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- O Reparable item. When uneconomically reparable, condemn and dispose at organizational level.
- F Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.

- H Reparable item. When uneconomically reparable, condemn and dispose at the general support level.
- D Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- L Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
- Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.
 - c. National Stock Number (NSN). Indicates the NSN assigned to the item and which will be used for requisitioning.
- d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

- e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. The physical security classification of the item is indicated by the parenthetical entry (insert applicable physical security classification abbreviation, e.g., Phy Sec C1 (C)-Confidential, Phy Sec Cl (S)-Secret, Phy Sec C1 (T)-Top Secret). Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column. When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, special Test, Measurement, and Diagnostic Equipment (TMDE), and other special support equipment. When density of equipments supported exceeds density spread indicated in the BOI, the total authorization is increased accordingly.
- g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of quantity indicates that no specific quantity is applicable (e.g., shims, spacers, etc).

4. Special Information

- **a.** Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.
- **b.** Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing as a minimum, the following as exception data.
 - (1) Component stock number of the individual end item to be repaired.
 - (2) Component manufacturer's equipment model number and serial number.
 - (3) The equipment manufacturer's stock number as listed in the appropriate manual for the desired repair part.
- (4) The repair part reference, designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.
 - (5) The technical specification of the repair part as contained in the appropriate manufacturer's manual.
- (6) The title and date of the manufacturer's manual from which the information in paragraphs a, b(3), (4), and (5) above was taken.

NOTE

Repair parts should not be requisitioned for plug-in boards identified in the plug-in board exchange program, except by the depot designated to perform the repair. Repair of calibration set components, with plug-in board assemblies or subassemblies designated as program exchange replacements with a recoverability code of L, will be accomplished by replacing the plug-in board.

- c. The plug-in board exchange program functions are as follows:
- (1) Requisitioning instructions for initial issue plug-in boards will be provided since new instrument boards are included in the program.
- (2) As a plug-in board covered by the program fails, a replacement will be requisitioned. Requisitions will be submitted to Commander, US Army Missile Command, B64, Redstone Arsenal, AL 35809.
- (3) Simultaneously with c(2) above, the defective board being replaced will be shipped by certified mail, return receipt requested, to the following address:

Transportation Officer Anniston Army Depot M/F Field Service Stock Anniston, AL 36201

When requisitioning a replacement board, the turn-in document number of the replaced board shall be cited on the requisition.

5. How to Locate Repair Parts

- a. When NSN or reference number is unknown:
 - (1) First. Using the table of contents, determine the assembly (functional group) within the repair part belongs.

- (2) **Second**. Using the repair parts listing, find the functional group to which the repair part belongs and locate the item by description.
 - **b.** When NSN or reference number is known:
- (1) First. Using the index of NSN's and reference numbers, find the pertinent NSN or reference number. This index is in ascending NSN cross-referenced to the illustration figure number and item number.
- (2) Second. Using the repair parts listing, find the figure and item number, and locate the figure and item number in the repair parts list.
- **6. Abbreviations**. The abbreviations listed below may appear in this RPSTL:

AC	alternating current
ACC	accordance
ACCUR	accuracy
AL	aluminum
AMP	ampere
ASSY	assembly
ASTM	American Standard
	for Testing Materiel
ATTEN	attenuation
AWG	American Wire
	Gage
BAN	banana
BLK	black
BR	brass
C	centigrade, calibration
0.11	cycles per second
CAL	calibrate
CAP	capacitance
CD	code
CER	ceramic
COAX	coaxial
COMP	composition
COND	conductor
CONN	connector
CONS	consisting
CONT	continual
COP	copper
COR	
CPS	cycles per second
CU	cubic
CUR	current
CYL	cylinder
DBL	decibel
DC	double
DEG	direct current
DET	degree
DIA	detector
DIM	diameter
DIV	dimension
DPDT	division
DPL	double pole double throw
ELEC	deployment electrical
EQUIPM	equipment
F	Fahrenheit
FED	Federal
FIN	finish
1 11N	IIIIIOII

FLGflange	
FREQfrequency	
FSCMFederal supply code	e for manufacturers
FT foot	
GCgigacycles	
GEN generator	
GHZgigahertz	
GPMgallons per minute	
GRAD graduation	
H high	
HD head	
HYDRhydraulic	
HZ hertz	
IDinside diameter	
IN inch	
INCLinclusive	
Kthousand (prefix)	
KC kilocycles	
KG kilograms	
KHZ kilohertz	
KMHZ thousand megahert	7
KVkilovolts	_
LAB laboratory	
LB pounds	
LG length	
LTlight	
_·	

M	thousand	RPM	revolutions per
MA	milliampere		minute
MAX	maximum	S	single
MC	megacycles	SEC	seconds
MFD	millifarads	SECT	section
MFR	manufacturer	SERR	serrated
MG	milligrams	SHK	shank
MHZ	megahertz	SNG	single
MIN	minimum, minutes	SPEC	
ML	milliliters	SPL	special
MM	millimeters	SQ	square
MOD	modified	STD	standard
MSEC	milliseconds	STGT	straight
MTL	material	SW	switch
MV	millivolts	SWR	standing wave
MW	milliwatts		ratio
NBS	National Bureau	SYS	system
	Standards	TEL	telescopic
NEG	negative	TERM	terminal
NO	number	THD	thread
NOM	nominal	THERM	thermometer
NPT	National Pipe	THK	thick
141	Thread	TSTR	tester
NSN	National stock	U	unit
11011	number	UF	microfarads
OA	overall	UHF	ultra high frequency
OD	outside diameter	V	volts
OPER		VAC	
OZ	operating	VAC	volts alternating
PCS	ounce	VDC	current, vacuum
	pieces	VHF	volts direct current
PCT PF	percent	VSWR	very high frequency
PK	picofarads	V3VVK	voltage standing
PLTD	peck	W	wave ratio
PN	plated	WT	watts, with, width
	part number	VV I	weight
POS PP	positive		
PSI	peak-to-peak		
P31	pounds per square inch		
PWR			
REF	power reference		
REP			
REQ	repetition		
REQMTS	required		
RES	requirements resistance		
RF			
	radio frequency		
RG RH	range		
RL	right hand reel		
RM	rack mounted		
RMS			
ROT	root mean square		
NO1	rotating		

SECTION II. REPAIR PARTS LIST

SECTION II. REPAIR PARTS LIST							(0)	
	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
						DESCRIPTION		QTY
			NATIONAL			DESCRIPTION		INC
11.1.1	STRATI	SMR	STOCK		PART			IN
	ON	CODE	NUMBER	FSCM	NUMBER	USUABLE ON CODE	U/M	UNI
								Т
(a)	(b)	1	İ	İ	İ	GROUP 6692	j .	
FIG	ITEM					MAINFRAME, TMDERS		
NO.	NO.					TM 515		
						MIS30526/1TY3		
						80009 18876		
			5040.00.040.0400			OADAOITOD EIVED OED	EA	
1	10	PAFZZ	5910-00-943-9192	283-0022-00	80009	CAPACITOR.FIXED CER	EA	1
1	20	PAFZZ	5910-00-577-1346	DA149-00108	71590	CAPACITOR, FIXEC. CER.	EA	12
1	30	PAFZZ	5910-01-022-3075	290-0637-00	80009	CAPACITOR.FIXEC.ELE.	EA	4
1	40	PAFZZ	5910-00-467-1548	60010444	56289	CAPACITOR, FIXED, ELE	EA	2
1	50	PAFZZ	5910-00-43E-3382	152-0040-00	80009	CAPACITOR	EA	2
1	60	PAFZZ	6695-01-08L-1050	670-4021-00	80009	CIRCUIT CARD. ASSY	EA	1
1	70	PAFZZ	6695-01-086-1051	670-4021-01	0009	CIRCUIT CARD ASSY	EA	1
1	80	PAFZZ	6695-01-018-1052	670-4364-00	80009	CIRCUIT CARD ASSY	EA	1
1	90	PAFZZ	6695-01-086-1053	670-4364-01	00009	CIRCUIT CARD ASSEMBLY	EA	1
1	100	PAFZZ	6695-01-086-1054	670-4022-00	80009	CIRCUIT CAPRD ASSY	EA	1
1	110	PAFZZ	6695-01-086-1055	670-4022-01	80009	CIRCUIT CARD ASSY	EA EA	1
1	120	PAFZZ	6695-0I-086-1056	670-4220-00	80009	CIRCUIT CARD ASSY	EA	2
1	130	PAFZZ	6695-01-086-1057	670-4220-01	80009	CIRCUIT CARD ASSY	EA	1
1	140	PAFZZ	6695-01-086-1058	670-5204-00	00009	CIRCUIT CARD ASSY	EA	2
1	150	PAFZZ	5935-00-599-8548	131-1078-00	80009	CONNECTOR, RECEPTACLE	EA	5
1	160	PAFZZ	4140-00-726-9755	WR2AI	82877	FAN.TUOEAXIAL	EA	2
1	170	PAFZZ	4140-00-917-3914	AO-86312	82877	FAN,TUEAIAL	EA	1
1	180	PAFZZ	5920-00-83S-2318	MDA3	71400	FUSE,CARTRIDGE159-0005-00 FSCM	EA	1
1	190	PAFZZ	5920-00-284-7079	AOC21/2	71400	FUSE,CARTRIDGE159-O126-00 FSCM	EA	2
1	200	PAFZZ	5905-00-138-4927	RCR42G102JS	81349	RESISTOR.FIXED,COMP	EA	5
1	210	PAFZZ	5905-00-494-4622	RCR32G182JS	81349	RESISTOR,FIXED,COMP	EA EA	10
1	220	PAFZZ	5905-00-283-7474	G81025	01121	RESISTOR.FIXEO COMP	EA	3
1	230	PAFZZ	5905-00-110-0992	RCR32G51IJS	81349	RESISTOR,FIXED,COMP	EA	3
1	240	PAFZZ	5961-00-131-1197	152-0274-00	80009	SEMICONDUCTOR DEVICE	EA	2
1	250	PAFZZ	5930-00-377-9979	260-0907-00	800C9	SWITCH.THERMOSTATIC	EA	2
1	260	PAFZZ	5950-01-064-1163	120-1031-00	00009	TRANSFORMER.POWER	EA	1
1	270	PPFZZ	5961-00-370-1271	151-0373-00	80009	TRANSISTOR	EA	5
1	280	PAFZZ	5961-00-551-0637	151-0436-00	S0009	TRANSISTOR	EA	5
							EA	

9 (10 blank)

Change 1

TM 9-6695-245-34P

SECTION III. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUM	MBER	FIGURE NO.		ITEM NO.
5905-00-11-C992 5961-00-131-1197 5905-00-138-4927 5905-00-283-1474 5920-00-284-7C79 5961-00-370-1271 5930-00-377-5579 5910-00-436-3382 5910-00-467-1548 5905-00-494-4622 5961-00-551-C637 5913-00-577-1346 5935-00-599-8548 4140-00-726-5755	1 1 1 1 1 1 1 1 1 1 1 1 1 1	23C 24C 200 22C 19C 27C 250 50 40 210 28C 2C 15C 16C	920-00-839- 414000-091' 5910-0 943- 5913-1-322- 5950-01-064 6695-01-086 6695-01-086 6695-01-086 6695-01-086 6695-01-086 6695-01-086	7-3914 9192 3C75 I-1163 I-1050 I-1051 I-1052 I-1053 I-1054 I-1055 I-1056 I-1057	1 1 1 1 1 1 1 1 1 1		180 170 10 30 260 60 70 80 90 100 110 120 130 140
PART NUMBER	FSCMNO.	FIG. ITEM NO.	PART NUMBER	FSCM	FIG.ITEM NO.	NO.	
AGC 2- 1/2 A0-86312 DA149-001CB G81025 MDA3 RCc32G182JS RCR32G51IJS RCR42G102JS WR2A1 120-1031-CC 131-1378-CC 151-0436-0C 152-0040-00	71400 82877 71590 01121 71400 81349 81349 81349 82877 80009 80009 80009	1190 152-02 1 170 1 20 1 220 1 180 1 210 1 230 1 200 1 160 1 260 1 150 1 270 1 280 1 50	274-00 800 260-3907-00 283-0022-00 290-0637-00 670-4021-01 670-4022-00 673-4022-01 670-4220-00 670-4220-01 670-4364-00 670-4364-01 670-5204-00 68010444	80009 80009 80009 80009 80009 80009 80009 80009 80009 80009 80009 56289	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	240 250 10 30 63 70 100 110 120 130 80 90 140 40	

By Order of the Secretary of the Army:

E. C. MEYER General, United States Army Chief of Staff

Official:

J. C. PENNINGTON
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-34A, requirements for Calibration Procedures Publications.

*U. S. GOVERNMENT PRINTING OFFICE: 1981-546-033/2981

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers