DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

DUAL POWER SUPPLY, TEKTRONIX MODEL PS503

(NSN 6695-01-076-8966)

Current as of 5 December 1979

Headquarters, Department of the Army, Washington, DC
10 January 1980

REPORTING OF ERRORS

You can help improve this publication by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications, should be mailed directly to Commander, US Army Missile Command, ATTN: DRSMI-MFM, Redstone Arsenal, AL 35809. A reply will be furnished directly to you.

		Paragraph	Page
SECTION I.	INTRODUCTION		
	Scope	1	1
	General	2	1
	Explanation of columns	3	1
	Special information	4	5
	How to locate repair parts	5	5
	Abbreviations	6	6
II.	REPAIR PARTS LIST		9

Functional group	Group title	Mode No.	Part No.
6697	Dual Power Supply	PS503	MIS30526/6

III.	NATIONAL STOCK NUMBER AND PART NUMBER INDEX	11

Section I. INTRODUCTION

1. Scope. This manual lists spares and repair parts that are required for maintenance of the Dual Power Supply, Tektronix Model PS503. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General. This repair parts and special tools list (RPSTL) is divided into the following sections:

a. Section I. Introduction.

b. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National Stock Number (NSN) sequence.

c. Section III. NSN and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all NSN's appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.

PG - Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.

KD - An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.

KF - An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.

KB - Item included in both a depot overhaul/repair kit and a maintenance kit.

MO - Item to be manufactured or fabricated at organizational level.

MF - Item to be manufactured or fabricated at the direct support maintenance level.

MH - Item to be manufactured or fabricated at the general support maintenance level.

MD - Item to be manufactured or fabricated at the depot maintenance level.

AO - Item to be assembled at organizational level.

AF - Item to be assembled at direct support maintenance level.

AH - Item to be assembled at general support maintenance level.

AD - Item to be assembled at depot maintenance level.

XA - Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.

XB - Item is not procured or stocked. If not available through salvage, requisition.

XC - Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.

XD - A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance Code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
C -	Crew or operator maintenance performed within organizational maintenance.
O -	Support item is removed, replaced, used at the organizational level.
F -	Support item is removed, replaced, used at the direct support level.
H -	Support item is removed, replaced, used at the general support level.
D -	Support items that are removed replaced, used at depot, mobile depot, or specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
O -	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H -	The lowest maintenance level capable of complete repair of the support item is the general support level.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to (enter applicable designated specialized repair activity), Specialized Repair Activity.
Z -	Nonreparable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) Recoverability Code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Codes	Definition
Z -	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
O -	Reparable item. When uneconomically reparable, condemn and dispose at organizational level.
F -	Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.

H - Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

D - Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.

L - Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.

A - Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. National Stock Number (NSN). Indicates the NSN assigned to the item and which will be used for requisitioning.

d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. The physical security classification of the item is indicated by the parenthetical entry (insert applicable physical security classification abbreviation, e.g., Phy Sec C1 (C) -Confidential, Phy Sec C1 (S) -Secret, Phy Sec C1 (T) -Top Secret). Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column. When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, special Test, Measurement, and Diagnostic Equipment (TMDE), and other special support equipment. When density of equipments supported exceeds density spread indicated in the BOI, the total authorization is increased accordingly.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of quantity indicates that no specific quantity is applicable (e.g., shims, spacers, etc).

4. Special Information

a. Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.

b. Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing as a minimum, the following as exception data.

(1) Component stock number of the individual end item to be repaired.

(2) Component manufacturer's equipment model number and serial number.

(3) The equipment manufacturer's stock number as listed in the appropriate manual for the desired repair part.

(4) The repair part reference designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.

(5) The technical specification of the repair part as contained in the appropriate manufacturer's manual.

(6) The title and date of the manufacturer's manual from which the information in paragraphs a, b(3), (4), and (5) above was taken.

NOTE

Repair parts should not be requisitioned for plug-in boards identified in the plug-in board exchange program, except by the depot designated to perform the repair. Repair of calibration set components, with plug-in board assemblies or subassemblies designated as program exchange replacements with a recoverability code of L, will be accomplished by replacing the plug-in board.

c. The plug-in board exchange program functions are as follows:

(1) Requisitioning instructions for initial issue plug-in boards will be provided since new instrument boards are included in the program.

(2) As a plug-in board covered by the program fails, a replacement will be requisitioned. Requisitions will be submitted to Commander, US Army Missile Command, B64, Redstone Arsenal, AL 35809.

(3) Simultaneously with c(2) above, the defective board being replaced will be shipped by certified mail, return receipt requested, to the following address:

Transportation Officer
Anniston Army Depot
M/F Field Service Stock
Anniston, AL 36201

When requisitioning a replacement board, the turn-in document number of the replaced board shall be cited on the requisition.

5. How to Locate Repair Parts

a. When NSN or reference number is unknown:

(1) First. Using the table of contents, determine the assembly (functional group) within which the repair part belongs.

(2) Second. Using the repair parts listing, find the functional group to which the repair part belongs and locate the item by description.

b. When NSN or reference number is known:

(1) First. Using the index of NSN's and reference numbers, find the pertinent NSN or reference number. This index is in ascending NSN cross-referenced to the illustration figure number and item number.

(2) Second. Using the repair parts listing, find the figure and item number, and locate the figure and item number in the repair parts list.

6. Abbreviations. The abbreviations listed below may appear in this RPSTL:

AC	alternating current
ACC	accordance
ACCUR	accuracy
AL	aluminum
AMP	ampere
ASSY	assembly
ASTM	American Standard for Testing Materiel
ATTEN	attenuation
AWG	American Wire Gage
BAN	banana
BLK	black
BR	brass
C	centigrade, calibration, cycles per second
CAL	calibrate
CAP	capacitance
CD	code
CER	ceramic
COAX	coaxial
COMP	composition
COND	conductor
CONN	connector
CONS	consisting
CONT	continual
COP	copper
COR	corrosion
CPS	cycles per second
CU	cubic
CUR	current
CYL	cylinder
DB	decibel
DBL	double
DC	direct current
DEG	degree
DET	detector
DIA	diameter
DIM	dimension
DIV	division
DPDT	double pole double throw
DPL	deployment
ELEC	electrical
EQUIPM	equipment
F	Fahrenheit
FED	Federal
FIN	finish
FLG	flange
FREQ	frequency
FSCM	Federal supply code for manufacturers
FT	foot
GC	gigacycles
GEN	generator
GHZ	gigahertz
GPM	gallons per minute
GRAD	graduation
H	high
HD	head
HYDR	hydraulic
HZ	hertz
ID	inside diameter
IN	inch
INCL	inclusive
K	thousand (prefix)
KC	kilocycles
KG	kilograms
KHZ	kilohertz
KMHZ	thousand megahertz
KV	kilovolts
LAB	laboratory
LB	pounds
LG	length
LT	light

M	thousand
MA	milliampere
MAX	maximum
MC	megacycles
MFD	millifarads
MFR	manufacturer
MG	milligrams
MHZ	megahertz
MIN	minimum, minutes
ML	milliliters
MM	millimeters
MOD	modified
MSEC	milliseconds
MTL	material
MV	millivolts
MW	milliwatts
NBS	National Bureau Standards
NEG	negative
NO	number
NOM	nominal
NPT	National Pipe Thread
NSN	National stock number
OA	overall
OD	outside diameter
OPER	operating
OZ	ounce
PCS	pieces
PCT	percent
PF	picofarads
PK	peck
PLTD	plated
PN	part number
POS	positive
PP	peak-to-peak
PSI	pounds per square inch
PWR	power
REF	reference
REP	repetition
REQ	required
REQMTS	requirements
RES	resistance
RF	radio frequency
RG	range
RH	right hand
RL	reel
RM	rack mounted
RMS	root mean square
ROT	rotating
RPM	revolutions per minute
S	single
SEC	seconds
SECT	section
SERR	serrated
SHK	shank
SNG	single
SPEC	specification
SPL	special
SQ	square
STD	standard
STGT	straight
SW	switch
SWR	standing wave ratio
SYS	system
TEL	telescopic
TERM	terminal
THD	thread
THERM	thermometer
THK	thick
TSTR	tester
U	unit
UF	microfarads
UHF	ultra high frequency
V	volts
VAC	volts alternating current, vacuum
VDC	volts direct current
VHF	very high frequency
VSWR	voltage standing wave ratio
W	watts, with, width
WT	weight

SECTION II. REPAIR PARTS LIST

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION *USABLE ON CODE*	(7) U/M	(8) QTY INC IN UNIT
						GROUP 6697 POWER SUPPLY, DUAL PS503 80009 MIS30526/6 18876		
1	10	PAFZZ	5910-00-782-7614	283-0081-00	80009	CAPACITOR, FIXED, CER	EA	1
1	20	PAFZZ	5910-00-139-0362	290-0522-00	80009	CAPACITOR, FIXED, ELE	EA	1
1	30	PAFZZ	5910-00-445-3272	VL1770	56289	CAPACITOR, FIXED, ELE	EA	1
1	40	PAFZZ	5910-00-407-1764	290-0320-00	80009	CAPACITOR, FIXED, ELE	EA	2
1	50	PAFZZ	5910-00-801-1005	9995456	18876	CAPACITOR, FIXED, CER	EA	3
1	60	PAFZZ	5910-00-879-0123	8959154-166	49671	CAPACITOR, FIXED, ELE	EA	2
1	70	PDFDD	6695-01-084-3984	670-3291-00	80009	CIRCUIT CARD ASSY	EA	1
1	80	PDFDD	6695-01-084-3985	670-3291-01	80009	CIRCUIT CARD ASSY	EA	1
1	90	PDFDD	6695-01-084-1887	670-3291-02	80009	CIRCUIT CARD ASSY	EA	1
1	100	PAFZZ	5910-00-436-3382	152-0040-00	80009	CAPACITOR	EA	4
1	110	PAFZZ	5961-01-039-1194	151-0506-00	80009	DIODE	EA	2
1	120	PAFZZ	5920-00-842-0224	159-0016-00	80009	FUSE	EA	2
1	130	PAFZZ	6240-00-008-4550	CM7220	71744	LAMP, INCANDESCENT	EA	2
1	140	PAFZZ	5962-00-365-5977	156-0277-00	80009	MICROCIRCUIT, LINEAR	EA	1
1	150	PAFZZ	5962-01-010-7442	156-0067-00	80009	MICROCIRCUIT, LINEAR	EA	6
1	160	PAFZZ	5940-00-902-5610	DF21WTC	58474	POST, BINDING, ELECTRONIC	EA	1
1	170	PAFZZ	5940-00-915-1024	129-0064-00	80009	POST, BINDING, ELECTRONIC	EA	1
1	180	PAFZZ	5940-00-733-6758	DF21GNC	58474	POST, BINDING, ELECTRONIC	EA	1
1	190	PAFZZ	5905-00-961-1683	EB2415	01121	RESISTOR, FIXED, COMP	EA	1
1	200	PAFZZ	5905-01-064-9049	MFF18X016G14001F	91637	RESISTOR, FIXED, FILM	EA	2
1	210	PAFZZ	5905-00-308-7594	RNC60K1212FS	81349	RESISTOR, FIXED, FILM	EA	2
1	220	PAFZZ	5905-01-011-8204	HB7515	01121	RESISTOR, FIXED, COMP	EA	2
1	230	PAFZZ	5905-00-110-7620	RCR07G102JS	81349	RESISTOR, FIXED, COMP	EA	6
1	240	PAFZZ	5905-00-008-8200	301-0152-00	80009	RESISTOR, FIXED, COMP	EA	1
1	250	PAFZZ	5905-00-405-7793	321-0170-00	80009	RESISTOR, FIXED, SOIL	EA	1
1	260	PAFZZ	5905-01-031-1408	RNC56K1300FS	81349	RESISTOR, FIXED, FILM	EA	1
1	270	PAFZZ	5905-00-441-7816	321-0192-00	80009	RESISTOR, FIXED, FILM	EA	1
1	280	PAFZZ	5905-01-007-6279	311-1310-00	80009	RESISTOR, VARIABLE	EA	1
1	290	PAFZZ	5905-00-131-9729	RCR07G302JS	81349	RESISTOR, FIXED, COMP	EA	1
1	300	PAFZZ	5905-00-426-7785	321-0254-00	80009	RESISTOR, FIXED, FILM	EA	2
1	310	PAFZZ	5905-00-105-7767	RCR07G474JS	81349	RESISTOR, FIXED, COMP 315-0474-00 FSCM 80009	EA	2
1	320	PAFZZ	5905-01-017-3200	91AR5K	73138	RESISTOR, VARIABLE	EA	2
1	330	PAFZZ	5905-01-036-9405	311-1561-00	80009	RESISTOR, VARIABLE	EA	2
1	340	PAFZZ	5905-00-369-6916	RCR32G122JS	81349	RESISTOR, FIXED, COMP	EA	2

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION *USABLE ON CODE*	(7) U/M	(8) QTY INC IN UNIT
1	350	PAFZZ	5905-00-104-8349	RCR20G511JS	81349	RESISTOR, FIXED, COMP	EA	2
1	360	PAFZZ	5905-00-120-9154	RCR07G471JS	81349	RESISTOR, FIXED, COMP	EA	3
1	370	PAFZZ	5905-00-111-4852	RCR20G2R7JS	81349	RESISTOR, FIXED, COMP 307-0051-00 FSCM 80009	EA	2
1	380	PAFZZ	5905-00-063-6850	308-0245-00	80009	RESISTOR, FIXED, WIREWOUND	EA	2
1	390	PAFZZ	5905-01-054-7338	311-1197-00	80009	RESISTOR, VARIABLE	EA	2
1	400	PAFZZ	5905-00-135-6046	RCR07G681JS	81349	RESISTOR, FIXED, COMP	EA	2
1	410	PAFZZ	5905-00-119-3504	RCR07G273JS	81349	RESISTOR, FIXED, COMP	EA	1
1	420	PAFZZ	5905-00-426-7701	321-0216-00	80009	RESISTOR, FIXED, FILM	EA	1
1	430	PAFZZ	5905-00-788-0302	321-0213-00	80009	RESISTOR, FIXED, FILM	EA	2
1	440	PAFZZ	5905-00-141-0600	RCR20G822JS	81349	RESISTOR, FIXED, COMP 301-0822-00-FSCM 80009	EA	2
1	450	PAFZZ	5905-00-430-0869	301-0302-00	80009	RESISTOR, FIXED, COMP	EA	3
1	460	PAFZZ	5905-00-136-8405	RCR07G131JS	81349	RESISTOR, FIXED, COMP	EA	2
1	470	PAFZZ	5905-00-106-1356	RCR07G152JS	81349	RESISTOR, FIXED, COMP	EA	1
1	480	PAFZZ	5905-01-046-2548	321-0282-00	80009	RESISTOR, FIXED, FILM	EA	1
1	490	PAFZZ	5905-01-044-8431	321-0224-00	80009	RESISTOR, FIXED, FILM	EA	1
1	500	PAFZZ	5905-01-007-6279	311-1310-00	80009	RESISTOR, VARIABLE	EA	1
1	510	PAFZZ	5961-00-936-7719	IR69-6512	81483	SEMICONDUCTOR DEVICE	EA	2
1	520	PAFZZ	5961-00-436-2890	152-0280-00	80009	SEMICONDUCTOR DEVICE	EA	2
1	530	PAFZZ	5961-00-878-4286	JAN1N971B	81349	SEMICONDUCTOR DEVICE	EA	2
1	540	PAFZZ	5961-00-833-3043	JAN1N757A	81349	SEMICONDUCTOR DEVICE	EA	1
1	550	PAFZZ	5961-00-237-2353	SZ50646	04713	SEMICONDUCTOR DEVICE	EA	1
1	560	PAFZZ	5961-00-436-2888	152-0265-00	80009	SEMICONDUCTOR DEVICE	EA	2
1	570	PAFZZ	5961-00-899-8924	1N4152	80131	SEMICONDUCTOR DEVICE 152-0141-02 FSCM 80009	EA	13
1	580	PAFZZ	5961-01-018-2610	150-1001-00	80009	LIGHT EMITTING DIODE	EA	3
1	590	PAFZZ	5930-01-034-6694	260-1310-01	80009	SWITCH, PUSH	EA	1
1	600	PAFZZ	5961-00-951-8757	JAN2N2222A	81349	TRANSISTOR	EA	1
1	610	PAFZZ	5961-00-105-7680	151-0208-00	80009	TRANSISTOR	EA	1
1	620	PAFZZ	5961-00-498-2093	151-0136-02	80009	TRANSISTOR	EA	1
1	630	PAFZZ	5961-00-365-9935	151-0347-00	80009	TRANSISTOR	EA	2
1	640	PAFZZ	5961-00-246-2427	2N4249	80131	TRANSISTOR	EA	2
1	650	PAFZZ	5961-00-359-9493	151-0350-00	80009	TRANSISTOR	EA	2
1	660	PAFZZ	5961-00-925-3777	JAN2N2907A	81349	TRANSISTOR	EA	1
1	670	PAFZZ	5961-01-025-2643	X43C181	03508	TRANSISTOR	EA	1

SECTION III. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.
6240-00-008-4550	1	130
5905-00-008-8200	1	240
5905-00-063-6850	1	380
5905-00-104-8349	1	350
5961-00-105-7680	1	610
5905-00-105-7767	1	310
5905-00-106-1356	1	470
5905-00-110-7620	1	230
5905-00-111-4852	1	370
5905-00-119-3504	1	410
5905-00-120-9154	1	360
5905-00-131-9729	1	290
5905-00-135-6046	1	400
5905-00-136-8405	1	460
5910-00-139-0362	1	20
5905-00-141-0600	1	440
5961-00-237-2353	1	550
5961-00-246-2427	1	640
5905-00-308-7594	1	210
5961-00-359-9493	1	650
5962-00-365-5977	1	140
5961-00-365-9935	1	630
5905-00-369-6916	1	340
5905-00-405-7793	1	250
5910-00-407-1764	1	40
5905-00-426-7701	1	420
5905-00-426-7785	1	300
5905-00-430-0869	1	450
5961-00-436-2888	1	560
5961-00-436-2890	1	520
5910-00-436-3382	1	100
5905-00-441-7816	1	270
5910-00-445-3272	1	30
5961-00-498-2093	1	620
5940-00-733-6758	1	180
5910-00-782-7614	1	10
5905-00-788-0302	1	430
5910-00-801-1005	1	50
5961-00-833-3043	1	540
5920-00-842-0224	1	120
5961-00-878-4286	1	530
5910-00-879-0123	1	60
5961-00-899-8924	1	570
5940-00-902-5610	1	160
5940-00-915-1024	1	170
5961-00-925-3777	1	660
5961-00-936-7719	1	510
5961-00-951-8757	1	600
5905-00-961-1683	1	190
5905-01-007-6279	1	280
5905-01-007-6279	1	500
5962-01-010-7442	1	150
5905-01-011-8204	1	220
5905-01-017-3200	1	320
5961-01-018-2610	2	580
5961-01-025-2643	1	670
5905-01-031-1408	1	260
5930-01-034-6694	1	590
5905-01-036-9405	1	330
5961-01-039-1194	1	110
5905-01-044-8431	1	490
5905-01-046-2548	1	480
5905-01-054-7338	1	390
5905-01-064-9049	1	200
6695-01-084-1887	1	90
6695-01-084-3984	1	70
6695-01-084-3985	1	80

PART NUMBER	FSCM	FIG. NO.	ITEM NO.
CM7220	71744	1	130
DF21GNC	58474	1	180
DF21WTC	58474	1	160
EB2415	01121	1	190
HB7515	01121	1	220
IR69-6512	81483	1	510
JAN1N757A	81349	1	540
JAN1N971B	81349	1	530
JAN2N2222A	81349	1	600
JAN2N2907A	81349	1	660
MFF18X016G14001F	91637	1	200
RCR07G102JS	81349	1	230
RCR07G131JS	81349	1	460
RCR07G152JS	81349	1	470
RCR07G273JS	81349	1	410
RCR07G302JS	81349	1	290
RCR07G471JS	81349	1	360
RCR07G474JS	81349	1	310
RCR07G681JS	81349	1	400
RCR20G2R7JS	81349	1	370
RCR20G511JS	81349	1	350
RCR20G822JS	81349	1	440
RCR32G122JS	81349	1	340
RNC56K1300FS	81349	1	260
RNC60K1212FS	81349	1	210
SZ50646	04713	1	550
VL1770	56289	1	30
X43C181	03508	1	670
1N4152	80131	1	570
129-0064-00	80009	1	170
150-1001-00	80009	1	580
151-0136-02	80009	1	620
151-0208-00	80009	1	610
151-0347-00	80009	1	630
151-0350-00	80009	1	650
151-0506-00	80009	1	110
152-0040-00	80009	1	100
152-0265-00	80009	1	560
152-0280-00	80009	1	520
156-0067-00	80009	1	150
156-0277-00	80009	1	140
159-0016-00	80009	1	120
2N4249	80131	1	640
260-1310-01	80009	1	590
283-0081-00	80009	1	10
290-0320-00	80009	1	40
290-0522-00	80009	1	20
301-0152-00	80009	1	240
301-0302-00	80009	1	450
308-0245-00	80009	1	380
311-1197-00	80009	1	390
311-1310-00	80009	1	280
311-1310-00	80009	1	500
311-1561-00	80009	1	330
321-0170-00	80009	1	250
321-0192-00	80009	1	270
321-0213-00	80009	1	430
321-0216-00	80009	1	420
321-0224-00	80009	1	490
321-0254-00	80009	1	300
321-0282-00	80009	1	480
670-3291-00	80009	1	70
670-3291-01	80009	1	80
670-3291-02	80009	1	90
8959154-166	49671	1	60
91AR5K	73138	1	320
9995456	18876	1	50

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

J. C. PENNINGTON
Major General, United States Army
The Adjutant General

Distribution:
To be distributed in accordance with DA Form 12-34A, requirements for Calibration Procedures Publications.

☆ U.S. GOVERNMENT PRINTING OFFICE: 1980-640-217/292

This fine document...

Was brought to you by me:

Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=http://www.liberatedmanuals.com/>Free Military and Government Manuals</A>

- Sincerely
  Igor Chudov
  http://igor.chudov.com/
- Chicago Machinery Movers