

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) VARIABLE POWER TRANSFORMER TF-171A/USM FSN 5950-503-0632

Headquarters, Department of the Army, Washington, D.C. 15 March 1974

Current as of August 1973

Table with 3 columns: Section, Paragraph, Page. Includes sections I through IX with sub-sections and corresponding page numbers.

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS, MISSOURI, TO MEET YOUR NEEDS WHILE WE REPLENISH OUR REGULAR STOCK.

\*This manual supersedes TM 11-5950-203-15P, 2 February 1968.

# SECTION I INTRODUCTION

---

## 1-1. Scope

This manual lists basic issue items, items troop installed or authorized, repair parts, and special tools required by the crew/operator for operation and required for the performance of organizational, direct support, general support, and depot maintenance of the TF-171A/USM. The PCCN for the TF-171A/USM is GTEADS for all models.

## 1-2 General

This basic issue items, items troop installed or authorized, repair parts and special tools list is divided into the following sections -

*a. Basic Issue Items List - Section II.* Not applicable.

*b. Items Troop Installed or Authorized List - Section III.* Not applicable.

*c. Prescribed Load Allowance (PLA) - Section IV.* Not applicable.

*d. Repair Parts List - Section V.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

*e. Special Tools, Test and Support Equipment - Section VI.* Not applicable.

*f. Repair Parts List - Section VII.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

*g. Special Tools, Test and Support Equipment - Section VIII.* Not applicable

*h. Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section IX.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

## 1-3 Explanation of Columns

The following provides an explanation of columns found in the tabular list.

*a. Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or

overhaul of end items. Source codes are -

<i>Code</i>	<i>Explanation</i>
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfitting. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at direct support maintenance level.
MH	Item to be manufactured or fabricated at general support maintenance level.
MD	Item to be manufactured or fabricated at depot maintenance level.

<i>Code</i>	<i>Explanation</i>
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
XD	Support items can be requisitioned with justification.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows:

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O	Support item is removed, replaced, used at the organizational level of maintenance.

**NOTE**

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational main tenance.

F	Support item is removed, replaced, used at the direct support maintenance level.
H	Support item is removed, replaced, used at the general support maintenance.
D	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest

maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multiservice equipmenffsystems or when a code is entered, this position -will contain one of the following maintenance codes as assigned by the service(s) that require the code:

<i>Code</i>	<i>Application/Explanation</i>
O	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F	The lowest maintenance level capable of complete repair of the support item is direct support.
H	The lowest maintenance level capable of complete repair of the support item is general support.
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
L	Repair restricted to designated Specialized Repair Activity.
Z	Nonrepairable. No repair is authorized.
B	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows:

<i>Code</i>	<i>Explanation</i>
Z	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.

<i>Code</i>	<i>Explanation</i>
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).
	<i>b. Federal Stock Number.</i> Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.
	<i>c. Description.</i> Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.
	<i>d. Unit of Measure (U/M).</i> Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required unite of measure will be requisitioned.
	<i>e. Quantity Furnished with Equipment (Basic Issue Items Only).</i> Not applicable.
	<i>f. Quantity Authorized (Items Troop Installed or Authorized Only).</i> Not applicable.
	<i>g. Quantity Incorporated in Unit.</i> This column indicates the quantity of the item used in the equipment.
	<i>h. 15-Day organizational Maintenance Allowances.</i>
	(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2
	(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to the Commanding General, US Army Electronics Command, ATTN: AMSEL-MA-CRA, Fort Monmouth, NJ., 07703.
	(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other support equipment.
	<i>i. 30-Day DS/GS Maintenance Allowances.</i>

**NOTE**

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

*j. 1-Year Allowances Per 100 Equipments Contingency Planning Purposes.* Column intentionally left blank

*k. Depot Maintenance Allowance Per 100 Equipments.* This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.

*l. Illustration.* Not applicable.

### 1-4. Special Information

Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

<i>Code</i>	<i>Used on</i>
A9M	TF-171A/USM

### 1-5. Location of Repair Parts

*a.* This manual contains one cross reference index (see IX) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacture's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

*b.* When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stack numbers (see IX), and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec V and VII) and locate the figure number (col 7a - 20P, 10a - 34P) and item number or reference designation (col 7b - 20P, 10b - 34P) as noted in the FSN index.

*c.* When the figure and item number or reference designation are known, scrutinize columns 7a and 7b - 20P and 10a and 10b - 35P, of the repair parts list (see V and VII) until the item is located.

*d.* When the FSN, reference number, figure number, and item number are not known, scrutinize column 3 of the repair parts list (sec V and VII), which is arranged in alphabetical order.

## **1-6 Abbreviations**

Not applicable.

## **1-7. Reporting of Equipment Manual Improvements**

The reporting of errors, omissions, and recommenda-

tions for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, AITN: AMSEL-MA-CRA, Fort Monmouth, NJ., 07703.

TM11-5950-203-14P

SECTION V

(1)	(2)	(3)	(4)	(5)	(6)	(6)				(7)	
SMR	FEDERAL	DESCRIPTION		UNIT	QTY	15-DAY ORGANIZATIONAL				ILLUSTRATION	
CODE	STOCK			OF	INC	MAINTENANCE ALW				(A)	(B)
	NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	MEAS	IN	(A)	(B)	(C)	(D)	FIGURE	ITEM
					UNIT	1-5	6-20	21-50	51-100	NO	NO
PACZZ	5950-629-4400	KNOB NO-REF-DESIG C3606 (12522)		EA	1	*	*	*	*		

SECTION II  
(1)

(2)

(3)

TM11-5950-203-14P  
(4)

(5)

(6)

(7)

(8)

(9)

(10)

SMR CODE	FEDERAL STOCK NUMBER	DESCRIPTION REFERENCE NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	30-DAY DS MAINT ALLOWANCE			30-DAY GS MAINT ALLOWANCE			1-YR ALW PER 100 EQUIP CNTGCV	DEPOT MAINT ALW PER 100 EQUIP	(A)	(B)	
						(A)	(B)	(C)	(A)	(B)	(C)	NO	NO	FIGURE	ITEM	
		GROUP 0001 TRANSFORMER, VARIABLE POWER TF- 171A/USM														
PAFZZ	5977-583-9256	ARM, ELECTRICAL BRUSH NO-REF-DESIG 30008 (12522)		EA	1	*	*	*	*	*	*					5
PAFZZ	5940-615-2728	TERMINAL BOARD NO-REF-DESIG 83595 (12522)		EA	1	*	*	*	*	*	*					3
PAFZZ	5977-629-9496	HOLDER, ELECTRICAL CONTACT BRUSH NO-REF- DESIG A8593 (12522)		EA	2	*	*	*	*	*	*					3
PAHZZ	5950-629-4399	BUSHING, SLEEVE NO-REF-DESIG A4848 (12522)		EA	1				*	*	*					3
PAFZZ	5950-629-1350	DIAL CONTROL NO-REF-DESIG C3609 (12522)		EA	1	*	*	*	*	*	*					2
PACZZ	5950-629-4400	KNOB NO-REF-DESIG C3606 (12522)		EA	1	*	*	*	*	*	*					3
PAFZZ	5340-721-6876	RING, RETAINING NO-REF-DESIG 5100125 (79136)		EA	1	*	*	*	*	*	*					2

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER  
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO		
5340-721-4816			5950-629-4400				
5940-615-2728			5977-583-9256				
5950-629-1350			5977-629-9496				
5950-629-4399							
REFERENCE NO	MFG CODE	FIG NO	ITEM NO	REFERENCE NO	MFG CODE	FIG NO	ITEM NO
A4848	12522			C3609	12522		
A8593	12522			30008	12522		
B3595	12522			5100125	79136		
C3606	12522						



By Order of the Secretary of the Army:

**CREIGHTON W. ABRAMS**  
*General, United States Army*  
*Chief of Staff*

Official:

**VERNE L. BOWERS**  
*Major General, United States Army*  
*The Adjutant General*

Distribution:

Active Army

CNGB (1)	SAAD (30)
TSG (1)	TOAD (14)
ACSE-E (2)	ATAD (10)
USAMB (10)	GENDEP (1)
USAARENBD (1)	Sig Sec GENDEP (2)
USMA (2)	Sig Dep (2)
TRADOC (2)	Sig FLDMS (1)
AMC (1)	Ft Richardson (ECOM Ofc) (1)
MICOM (1)	Units org under fol TOE
TECOM (2)	(1 cy each):
ARADCOM (2)	6-100
ARADCOM Rgn (1)	6-200
OS Maj Comd (2)	<del>6-300</del>
USACDCEC (10)	7
USACC (2)	11-15
HISA (ECOM) (18)	11-16
Ammies (1)	11-37
USASESS (5)	11-158
Svc Colleges (1)	11-500(AA-AC)
<b>Ft Huachuca (5)</b>	17
WSMR (1)	29-134
Ft Carson(5)	29-136
USAERDAA (1)	<del>44-446</del>
USAERDAW (1)	44-546
Army Day except	57
LBA n IW	

NG: State h< :2?,

USAR: None

For explanation of abbreviation used, see AR 310-50.

PIN:014442-CCO

This fine document...

Was brought to you by me:



## [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)