

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR'S ORGANIZATIONAL, DIRECT SUPPORT, AND  
GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND  
SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS)  
HEADSET, MICROPHONE H-63/U  
FSN 5965-237-0049

Headquarters, Department of the Army, Washington, D.C.

23 April 1973

*Current as of October 1972*

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope .....	1-1	2
General . . . . .	1-2	2
Explanation of columns .....	1-3	2
Special information . . . . .	1-4	4
Location of repair parts . . . . .	1-5	4
Abbreviations (Nonapplicable) . . . . .	1-6	4
Reporting of equipment manual improvement . . . . .	1-7	4
Items comprising an operable equipment . . . . .	1-8	4
II. BASIC ISSUE ITEMS LIST (Nonapplicable)		
III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST (Not applicable)		
IV. PRESCRIBED LOAD ALLOWANCE (Not applicable)		
V. REPAIR PARTS LIST . . . . .		<b>6</b>
VI. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
VII. REPAIR PARTS LIST .....		7
VIII. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
IX. INDEX—FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER .....		8

\*This manual supersedes TM 11-5965-249-15P, 6 November 1961.

# SECTION I

## INTRODUCTION

---

### 1-1. Scope

This manual lists basic issue items, items troop installed or authorized, repair parts, and special tools required by the crew/operator for operation and required for the performance of organizational, direct support, general support, and depot maintenance of the H-63/U. The PCCN for the H-63/U is GCMAAZ for all models.

### 1-2. General

This basic issue items, items troop installed or authorized, repair parts, and special tools list is divided into the following sections—

*a. Basic Issue Items List—Section II.* Not applicable.

*b. Items Troop Installed or Authorized List—Section III.* Not applicable.

*c. Prescribed Load Allowance (PLA)—Section IV.* Not applicable.

*d. Repair Parts List—Section V.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

*e. Special Tools, Test and Support Equipment—Section VI.* Not applicable.

*f. Repair Parts List—Section VII.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

*g. Special Tools, Test and Support Equipment—Section VIII.* Not applicable.

*h. Index—Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number—Section IX.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphabetic sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

### 1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

*a. Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the source for the listed items. Source codes are—

*Code*

*Explanation*

P—Repair parts, special tools and test equipment supplied from the GSA/DSA or Army supply system and authorized for use at indicated maintenance categories.

P2—Repair parts, special tools and test equipment which are procured and stocked for insurance purposes because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system.

P9—Assigned to items which are NSA design controlled: unique repair parts, special tools, test, measuring, and diagnostic equipment which are stocked and supplied by the Army COMSEC Logistic System and which are not subject to the provisions of AR 380-41.

P10—Assigned to items which are NSA design controlled: special tools, test, measuring, and diagnostic equipment for COMSEC support which are accountable under the provisions of AR 380-41 and which are stocked and supplied by the Army COMSEC Logistic System.

M—Repair parts, special tools and test equipment which are procured or stocked as such in the supply system but are to be manufactured at indicated maintenance levels.

A—Assemblies which are not procured or stocked as such but are made up of two or more units. Such component units carry individual stock numbers and descriptions, are procured and stocked separately, and can be assembled to

<i>Code</i>	<i>Explanation</i>
	form the required assembly at indicated maintenance categories.
X	Parts and assemblies that are not procured or stocked because the failure rate is normally below that of the applicable end item or component. The failure of such part or assembly should result in retirement of the end item from the supply system.
X1	Repair parts which are not procured or stocked. The requirement for such items will be filled by the next higher assembly or component.
X2	Repair parts, special tools and test equipment which are not stocked and have no foreseen mortality. The indicated maintenance category requiring such repair parts will attempt to obtain the parts through cannibalization or salvage. The item may be requisitioned, with exception data, from the end item manager for immediate use.
G	Major assemblies that are procured with PEMA funds for initial issue only as exchange assemblies at DS and GS level. These assemblies will not be stocked above DS and GS level or returned to depot supply level.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded X1 and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Indicates the lowest category of maintenance authorized to install the listed item. Capabilities of higher maintenance categories are considered equal or better. Maintenance codes are—

<i>Code</i>	<i>Explanation</i>
C	Crew/operator
O	---- Organizational maintenance
F	Direct support maintenance
H	. General support maintenance
D	Depot maintenance

(3) *Recoverability code.* Indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are nonrecoverable. Recoverability codes are—

<i>Code</i>	<i>Explanation</i>
R	Repair parts (assemblies and components), special tools and test equipment which are considered economically repairable

<i>Code</i>	<i>Explanation</i>
	at direct and general support maintenance levels. When the item is no longer economically repairable, it is normally disposed of at the GS level. When supply considerations dictate, some of these repair parts may be listed for automatic return to supply for depot level repair as set forth in AR 710-1. When so listed, they will be replaced by supply on an exchange basis.
S	Repair parts, special tools and test equipment, and assemblies which are economically repairable at DS and GS activities and which normally are furnished by supply on an exchange basis. When items are determined by a GSU to be uneconomically repairable, they will be evacuated to a depot for evaluation and analysis before final disposition.
T	High dollar value recoverable repair parts, special tools and test equipment which are subject to special handling and are issued on an exchange basis. Such items will be repaired or overhauled at depot maintenance activities only. No repair may be accomplished at lower levels.
U	Repair parts, special tools and test equipment specifically selected for salvage by reclamation units because of precious metal content, critical materials, high dollar value, or reusable casings or castings.

*b. Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

*c. Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM ) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

*d. Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation, e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Furnished with Equipment (Basic Issue Items Only)*. Not applicable.

f. *Quantity Authorized (Items Troop Installed or Authorized Only)*. Not applicable.

g. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment.

h. *15-Day Organizational Maintenance Allowances*.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to the Commanding General, US Army Electronics Command, ATTN: AMSEL-MA-CW, Fort Monmouth, N.J., 07703.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other support equipment.

i. *30-Day DS/GS Maintenance Allowances*.

#### NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

j. *1-Year Allowances Per 100 Equipments/Contingency Planning Purposes*. Column intentionally left blank.

k. *Depot Maintenance Allowance Per 100 Equipments*. This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.

l. *Illustration*. Not applicable.

### 1-4. Special Information

Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are—

Code  
AEJ

Used on  
H-63/U

### 1-5. Location of Repair Parts

a. This manual contains one cross reference index (sec IX) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec IX), and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec V and VII) and locate the figure number (col 7a—20P, 10a—34P) and item number or reference designation (col 7b—20P, 10b—34P) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b—20P and 10a and 10b—35P, of the repair parts list (sec V and VII) until the item is located.

d. When the FSN, reference number, figure number, and item number are not known, scrutinize column 3 of the repair parts list (sec V and VII), which is arranged in alphabetical order.

### 1-6. Abbreviations

Not applicable.

### 1-7. Reporting of Equipment Manual Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-CW, Fort Monmouth, N.J., 07703.

### 1-8. Items Comprising An Operable Equipment

FSN 5965-237-6049

Headset, Microphone  
H-63/U (1 ea)

(Next printed page is 6.)



SMR CODE	FEDERAL STOCK NUMBER	DESCRIPTION REFERENCE NUMBER & MFR CODE	USABLE ON CODE	(4)	(5)	(6)				(7)	
				UNIT OF MEAS	QTY INC IN UNIT	15-DAY ORGANIZATIONAL MAINTENANCE ALW				(A)	(B)
						(A)	(B)	(C)	(D)	FIGURE NO	ITEM NO
						1-5	6-20	21-50	51-100		
P-O-	5965-240-3819	ARM, MICROPHONE NO-REF-DESIG SUPPORT MIC INCL CABLE ASSY SCC201977 (80063)		EA	1	*	*	*	*		
P-O-	5965-243-0207	COVER, MICROPHONE CW-292/U NO-REF-DESIG (NOTE TO BE USED WITH MIC UNITS M-51/UR AND STD SIZE MIC UNITS M-6/UR AND M-6A/UR, CW292U (80058)		EA	1	*	*	*	*		
P-O-	5965-295-8966	MICROPHONE, CARBON M-51/UR NO-REF-DESIG M51UR (80058)		EA	1	*	*	*	*		
P-O-	5965-355-9214	MOUNTING NO-REF-DESIG MTS MIC BOOM-TO HEADSET SCC202030 (80063)		EA	1	*	*	*	*		
P-O-	5305-639-3264	SCREW, MACHINE NO-REF-DESIG RETAINS REC NO. 5-40 X 5-32 SCB202008 (80063)		EA	2	*	*	*	*		
P-O-	5310-209-0787	WASHER, LOCK NO-REF-DESIG FL NO. 5 SCREW 1905-00 (78189)		EA	2	*	*	*	*		

SMR CODE	FEDERAL STOCK NUMBER	DESCRIPTION REFERENCE NUMBER & MFR CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			(8) 1-YR ALW PER EQUIP CNTGCTY	(9) DEPOT MAINT ALW PER EQUIP	(10) ILLUSTRATION	
					1-20 (A)	21-50 (B)	51-100 (C)	1-20 (A)	21-50 (B)	51-100 (C)			(A) FIGURE NO	(B) ITEM NO
P-O-	5965-240-3819	ARM MICROPHONE NO-REF-DESIG SUPPORT MIC INCL CABLE ASSY SCC201977 (80063)	EA	1	*	*	*	*	*	*		5		
P-F-	5935-259-9794	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG 3, RD, FEMALE CONTS SCC201989 (80063)	EA	1	*	*	*	*	*	*		3		
P-F-	5995-542-6380	CORD ASSEMBLY, ELECTRICAL NO-REF-DESIG EARPHONE CORD SCD201983 (80063)	EA	1	*	*	*	*	*	*		5		
P-F-	5995-542-6383	CORD, ASSEMBLY, ELECTRICAL NO-REF-DESIG MIC CORD SCB202084 (80063)	EA	1	*	*	*	*	*	*		5		
P-O-	5965-243-0207	COVER, MICROPHONE CW-292/U NO-REF-DESIG (NOTE TO BE USED WITH MIC UNITS M-51/UR AND STD SIZE MIC UNITS M-6/UR AND M-64/UR, CW292U (80058)	EA	1	*	*	*	*	*	*		2		
P-F-	5965-244-1741	CUSHION, EARPHONE NO-REF-DESIG SCC53606 (80063)	EA	2	*	*	*	*	*	*		3		
P-F-	5965-239-3471	EARPHONE ELEMENT NO-REF-DESIG SCC105379 (80063)	EA	2	*	*	*	*	*	*		7		
P-F-	5965-280-3630	HEADBAND, HEADSET NO-REF-DESIG SCB84250 (80063)	EA	1	*	*	*	*	*	*		10		
P-F-	5935-636-6602	JACK, TELEPHONE NO-REF-DESIG J0055 (81349)	EA	1	*	*	*	*	*	*		3		
P-O-	5965-295-8966	MICROPHONE, CARBON M-51/UR NO-REF-DESIG M51UR (80058)	EA	1	*	*	*	*	*	*		10		
P-O-	5965-355-9214	MOUNTING NO-REF-DESIG MTS MIC BOOM-TO HEADSET SCC202030 (80063)	EA	1	*	*	*	*	*	*		1		
P-F-	5805-219-9709	MOUNTING NO-REF-DESIG LH REC ARM (SCB201986 (80063)	EA	1	*	*	*	*	*	*		1		
P-F-	5805-219-9710	MOUNTING NO-REF-DESIG RH REC ARM SCB84254 (80063)	EA	1	*	*	*	*	*	*		1		
P-O-	5305-639-3264	SCREW, MACHINE NO-REF-DESIG RETAINS REC NO. 5-40 X 5-32 SCB202008 (80063)	EA	2	*	*	*	*	*	*		5		
P-F-	5305-639-4717	SCREW, MACHINE NO-REF-DESIG SECURES REC, MTG TO HEADBAND SCB53608 (80063)	EA	2	*	*	*	*	*	*		5		
P-O-	5310-209-0787	WASHER, LOCK NO-REF-DESIG FL NO. 5 SCREW 1905-00 (78189)	EA	2	*	*	*	*	*	*		5		

TM11-5965-249-14P

SECTION IX  
INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER  
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5305-639-3264			5965-240-3819		
5305-639-4717			5965-243-0207		
5310-209-0787			5965-244-1741		
5805-219-9709			5965-280-3630		
5805-219-9710			5965-295-8966		
5935-259-9794			5965-355-9214		
5935-636-6602			5995-542-6380		
5965-239-3471			5995-542-6383		

REFERENCE NO	MFR CODE	FIG NO	ITEM NO	REFERENCE NO	MFR CODE	FIG NO	ITEM NO
CW292U	80058			SCB84254	80063		
JJ055	81349			SCC105379	80063		
MS1UR	80058			SCC201977	80063		
SCB201986	80063			SCC201989	80063		
SCB202008	80063			SCC202030	80063		
SCB202084	80063			SCC53606	80063		
SCB53608	80063			SCD201983	80063		
SCB84250	80063			1905-00	78189		

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS  
*General, United States Army*  
*Chief of Staff*

Official:

VERNE L. BOWERS  
*Major General, United States Army*  
*The Adjutant General*

Distribution:

To be distributed in accordance with DA Form 12-36, Sec I, organizational maintenance requirements for AN/TKQ-1 and DA Form 12-51, organizational maintenance requirements for AN/GLQ-2 and AN/VRC-35.

☆ U.S. GOVERNMENT PRINTING OFFICE : 1992 - 311-831 (60807)







This fine document...

Was brought to you by me:



## [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)