

TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR

PARTS AND SPECIAL TOOLS LIST

FOR

MAST AB-621/G

(NSN 5985-00-782-5278)

TECHNICAL MANUAL

No. 11-5895-334-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 20 September 1983

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LIST
FOR

MAST AB-621/G (NSN 5985-00-782-5278)

Current as of 18 May 1983

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2023-2 located in back of this manual direct to: Commander, US Army communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-ME-MP, For Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
SECTION	I. Introduction	1	
	II. Repair Parts List	5	
GROUP	00 Mast AB-621/G	5	1
	Mast AB-621/G, Carrier	7	2
SECTION	III. Special Tools List (Not applicable)		
	IV. National Stock Number and Part Number Index	8	

*This manual supersedes TM 11-5985-334-20P, 5 May 1977.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the AB-621/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>code</i>	<i>Definition</i>
-------------	-------------------

PA - Item procured and stocked for anticipated or known usage.

XB - Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage maybe used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

0 - Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

F - The lowest maintenance level capable of complete repair of the support item is the direct support level.

Z - Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability codes</i>	<i>Definition</i>
-----------------------------	-------------------

Z - Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

F - Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.

c. National Stock Number. Indicates the National

Stock number assigned to the item and will be used for requisitioning purposes.

d. *Federal Supply Code for Manufacturer (FSCM)*. The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. *Part Number*. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

f. *Description*. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M)*. Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit*. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publication pertains to the AB-621/G and its components:
TM 11-5985-334-14, Mast AB-621/G

b. The illustrations in this manual are identical to those published in TM 11-5985-334-30P. Only those parts assigned the third position SMR maintenance code "C" or "O" are listed in the tabular listing;

therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized item appear in this manual.

c. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN'S are established and published, submit exception requisitions to Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-MM, Fort Monmouth, New Jersey 07703 for the part required to support your equipment.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First*. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second*. Find the illustration covering the functional group to which the item belongs.

(3) *Third*. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth*. Using the Repair Parts Listing, find the figure and item number noted on the illustration.


b. When National stock number or part number is known.

(1) *First*. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second*. After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations


Not applicable.



EL2IP001

Figure 1. Mast AB-621/G.

SECTION II (1) ILLUSTRATION (A) (B) FIG ITEM NO NO		(2)	(3)	TM11-5985-334-20P (4) (5) FSCM PART NUMBER		(6) DESCRIPTION	(7)	(8) QTY INC IN UNIT
		SMR CODE	NATIONAL STOCK NUMBER				USABLE ON CODE U/M	
GROUP 00 MAST AB-621/G								
1	1	PAOZZ	5820-00-395-8807	80063	SC-D-66302	CARRYING CASE, GUY S	EA	1
1	2	XBOZZ	4030-00-187-5261	80058	GP-2	STAKE,GUY	EA	8
1	3	PAOZZ	5120-00-224-4105	81349	GGG-H-86	HAMMER,HAND	EA	1
1	4	PAOZZ	5985-00-237-0728	80063	SM-D-561874	SLEEVE,ANTENNA SUPP	EA	1
1	5	PAOZZ	5975-00-405-4507	80063	SM-D-561885	GUY	EA	4
1	6	PAOZZ	5306-00-405-4588	80063	SC-B-99880	BOLT,EYE	EA	5
1	7	PAOZZ	4030-00-159-7127	80063	SC-C-99881	SHACKLE	EA	5
1	8	PAOZZ	5985-00-233-9248	80063	SM-C-561895-1	BAG,SIGNAL EQUIPMENT	EA	1
1	9	PAOZZ	5985-00-233-9252	80063	SM-B-561884	HALYARD,ANTENNA	EA	1
1	10	PAOZZ	4030-00-189-6156	80063	SM-C-561898	GUY ATTACHMENT	EA	5
1	11	PAOZZ	4030-00-291-9354	80063	GP-112/G	STAKE,GUY	EA	4
1	12	PAOZZ	4030-00-189-6237	80063	SM-D-561896	CASE,STAKE,GUY	EA	1
1	13	PAOZZ	4030-00-189-6154	80063	SM-D-561869	GUY RING ASSEMBLY,U	EA	1
1	14	PAOZZ	8105-00-497-9628	80058	BG-102	GUY,BAG	EA	1
1	15	PAOZZ	5985-00-233-9249	80063	SM-C-561864	PEEP SIGHT ASSEMBLY	EA	1
1	16	PAOZZ	4030-00-189-6155	80063	SM-D-561868	GUY RING ASSEMBLY,M	EA	1
1	17	PAOZZ	5975-00-405-4505	80063	SM-D-561889	GUY	EA	4
1	18	PAOFF	5985-01-133-3584	80063	SM-D-561878	WINCH ASSEMBLY	EA	1
1	19	PAOFF	5985-01-124-8751	80063	SM-C-561860	LEVEL MAST ASSEMBLY	EA	1
1	20	PAOZZ	5120-00-169-2664	80063	SM-D-561899	WRENCH,SPANNER	EA	1
1	21	PAOZZ	4030-00-298-1382	80058	GP-113/G	STAKE,GUY	EA	5
1	22	PAOZZ	5975-00-405-4506	80063	SM-D-561887	GUY	EA	4



EL2IP002

Figure 2. Mast AB-621/G, Carrier.

SECTION II		TM11-5985-334-20P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION					DESCRIPTION		QTY	
(A)	(B)	NATIONAL		PART			INC	
FIG	ITEM	STOCK	FSCM	NUMBER		USABLE ON CODE	U/M	IN
NO	NO	NUMBER						UNIT
2	1	PAOZZ	5985-00-242-4286	80063	SM-D-561875		EA	8
2	2	PAOFF	5985-00-233-9247	80063	SM-D-561801		EA	1
2	3	PAOFF	5985-00-244-1693	80063	SM-D-561881		EA	1
					CASE,MAST			

STOCK NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
4030-00-159-7127	1	7	80058	BG-102	1	14
5120-00-169-2664	1	20	81349	GGG-H-86	1	3
4030-00-187-5261	1	2	80063	GP-112/G	1	11
4030-00-189-6154	1	13	80058	GP-113/G	1	21
4030-00-189-6155	1	16	80058	GP-2	1	2
4030-00-189-6156	1	10	80063	SC-B-99880	1	6
4030-00-189-6237	1	12	80063	SC-C-99881	1	7
5120-00-224-4105	1	3	80063	SC-D-66302	1	1
5985-00-233-9247	2	2	80063	SM-B-561884	1	9
5985-00-233-9248	1	8	80063	SM-C-561860	1	19
5985-00-233-9249	1	15	80063	SC-C-561864	1	15
5985-00-233-9252	1	9	80063	SM-C-561895-1	1	8
5985-00-237-0728	1	4	80063	SM-C-561898	1	10
5985-00-242-4286	2	1	80063	SM-D-561801	2	2
5985-00-244-1693	2	3	80063	SM-D-561868	1	16
4030-00-291-9354	1	11	80063	SM-D-561869	1	13
4030-00-298-1382	1	21	80063	SM-D-561874	1	4
5820-00-395-8807	1	1	80063	SM-D-561875	2	1
5975-00-405-4505	1	17	80063	SM-D-561878	1	18
5975-00-405-4506	1	22	80063	SM-D-561881	2	3
5975-00-405-4507	1	5	80063	SM-D-561885	1	5
5306-00-405-4588	1	6	80063	SM-D-561887	1	22
8105-00-497-9628	1	14	80063	SM-D-561889	1	17
5985-01-124-8751	1	19	80063	SM-D-561896	1	12
5985-01-133-3584	1	18	80063	SM-D-561899	1	20

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Commander
Stateside Army Depot
ATTN: AMSTA-US
Stateside, N.J. 07703

DATE SENT

10 July 1975

PUBLICATION NUMBER

TM 11-5840-340-20P

PUBLICATION DATE

23 Jan 78

PUBLICATION TITLE

Radar Set AN/PRC-76

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO	PARA- GRAPH	FIGURE NO	TABLE NO
33			
44		19	
45			

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

For item 2, change the NSN to read: 5835-00-134-9186.
Reason: Accuracy.

Identify the cover on the junction box (item no. 5).
Reason: It is a separate item and is not called out
on figure 19.

Add the cover of the junction box as an item in the
listing for figure 19.
Reason: Same as above

SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SSG I. M. DeSpirit of 999-1776

SIGN HERE

SSG I. M. DeSpirit

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS
ARE OBSOLETE.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

SAMPLE

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM. CAREFULLY TEAR
IT OUT, FOLD IT AND
DROP IT IN THE MAIL.

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-20P

PUBLICATION DATE

20 Sept. 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS
ARE OBSOLETE

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPE OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM. CAREFULLY TEAR
IT OUT, FOLD IT AND
DROP IT IN THE MAIL.

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-20P

PUBLICATION DATE

20 Sept. 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM. CAREFULLY TEAR
IT OUT, FOLD IT AND
DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-20P

PUBLICATION DATE

20 Sept. 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.
-------------	----------------	---------------	--------------

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS
ARE OBSOLETE

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPE OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

TEAR ALONG PERFORATED LINE

By Order OF the Secretary of the Army:

JOHN A. WICKHAM JR.
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

DISTRIBUTION:

To be distrib
Maintenance require

organizational

[NG OFFICE: 1983 - 605-040/333]

PIN # 017889-000

This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)