

TM 11-5985-334-30P

TECHNICAL MANUAL

**DIRECT SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)**

FOR

MAST AB-621/G

(NSN 5985-00-782-5278)

**HEADQUARTERS, DEPARTMENT OF THE ARMY
21 SEPTEMBER 1983**

TECHNICAL MANUAL
No. 11-5985-334-30P }

HEADQUARTERS
DEPARTMENT OF THE ARMY,
WASHINGTON, DC, 21 September 1983

DIRECT SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)
FOR
MAST AB-621/G (NSN 5985-00-782-5278)

Current as of 23 May 1983

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-ME-MP, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

SECTION	GROUP	Page	Illus Figure
I.		1	
II.	00	5	
	Mast AB-621/G	5	1
	Mast Carrier and Masts	9	2
	Upper Guy Ring Assembly	11	3
	Launcher Base and Elevator Assembly	13	4
	Launcher Top and Guide Plate Assembly	15	5
	Elevator Platform Assembly	17	6
	Reel Assembly	19	7
	Brake Assembly.....	21	8
01			
III.	01	5	
	Launcher Assembly (No parts authorized)		
IV.	00	5	1
	Special Tools List (Not applicable)		2
	National Stock Number and Part Number Index	21	8
		22	

* This manual supersedes TM 11-5985-334-34P, 6 July 1977.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of direct support maintenance of the AB-621/G. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA - Item procured and stocked for anticipated or known usage.	
XB - Item is not procured or stocked. If not available through salvage, requisition.	

NOTE

Cannibalization or salvage maybe used as a source of supply for any items source coded above except those coded XA and aircraft support item as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O - Support item is removed, replaced, used at the organizational level.	
F - Support item is removed, replaced, used at the direct support level.	

(b) The maintenance code entered in the fourth positions indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
Z -	Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability Codes</i>	<i>Definition</i>
Z - Nonreparable item.	When unserviceable, condemn and dispose at the level indicated in position 3.

Recoverability

Codes

Definition

F - Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

c. *National Stock Number*. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Federal Supply Code for Manufacturer (FSCM)*. The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. *Part Number*. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

f. *Description*. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M)*. Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit*. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publications pertain to the AB-621/G and its components:

TM 11-5985-334-15, Mast AB-621/G

TM 11-5985-334-20E Mast AB-621/G

b. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN's are established and published, submit exception requisitions to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-MM, Fort Monmouth, New Jersey 07703 for the part required to support your equipment.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First*. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second*. Find the illustration covering the functional group to which the item belongs.

(3) *Third*. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth*. Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First*. Using the index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second*. After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.





Figure 1. Mast AB-621/G.

TM 11-5985-334-30P

SECTION II (1) ILLUSTRATION (A) FIG NO	(2) ITEM NO	SMR CODE	TM11-5985-334-30P (3) NATIONAL STOCK NUMBER		(4) FSCM	(5) PART NUMBER	(6) DESCRIPTION	(7) USABLE ON CODE	(8) QTY INC IN UNIT U/M	
			GROUP 00 MAST AB-621/G							
1	1	PAOZZ	5820-00-395-8807	80063	SC-D-66302	CARRYING CASE,GUY S		EA	1	
1	2	XBOZZ	4030-00-187-5261	80058	GP-2	STAKE ,GUY		EA	8	
1	3	PAOZZ	5120-00-224-4105	81349	GGG-H-86	HAMMER,HAND		EA	1	
1	4	PAOZZ	5985-00-237-0728	80063	SM-D-561874	SLEEVE,ANTENNA SUPP		EA	1	
1	5	PAOZZ	5975-00-405-4507	80063	SM-D-561885	GUY		EA	4	
1	6	PAOZZ	5306-00-405-4588	80063	SC-B-99880	BOLT,EYE		EA	5	
1	7	PAOZZ	4030-00-159-7127	80063	SC-C-99881	SHACKLE		EA	5	
1	8	PAOZZ	5985-00-233-9248	80063	SM-C-561895-1	BAG,SIGNAL EQUIPMEN		EA	1	
1	9	PAOZZ	5985-00-233-9252	80063	SM-B-561884	HALYARD,ANTENNA		EA	1	
1	10	PAOZZ	4030-00-189-6156	80063	SM-C-561898	GUY ATTACHMENT		EA	5	
1	11	PAOZZ	4030-00-291-9354	80058	GP-112/G	STAKE ,GUY		EA	4	
1	12	PAOZZ	4030-00-189-6237	80063	SM-D-561896	CASE,STAKE ,GUY		EA	1	
1	13	PAOZZ	4030-00-189-6154	80063	SM-D-561869	GUY RING ASSEMBLY,U		EA	1	
1	14	PAOZZ	8105-00497-9628	80058	BG-102	GUY,BAG		EA	1	
1	15	PAOZZ	5985-00-233-9249	80063	SM-C-561864	PEEP SIGHT ASSEMBLY		EA	1	
1	16	PAOZZ	4030-00-189-6155	80063	SM-D-561868	GUY RING ASSEMBLY,M		EA	1	
1	17	PAOZZ	5975-00-405-4505	80063	SM-D-561889	GUY		EA	4	
1	18	PAOFF	5985-01-133-3584	80063	SM-D-561878	WINCH ASSEMBLY		EA	1	
1	19	PAOFF	5985-01-124-8751	80063	SM-C-561860	LEVEL MAST ASSEMBLY		EA	1	
1	20	PAOZZ	5120-00-169-2664	80063	SM-D-561899	WRENCH,SPANNER		EA	1	
1	21	PAOZZ	4030-00-298-1382	80058	GP-113/G	STAKE ,GUY		EA	5	
1	22	PAOZZ	5975-00-405-4506	80063	SM-D-561887	GUY		EA	4	



EL2IP002

Figure 2. Mast Carrier and Masts (Sheet 1 of 2).





Figure 2. Mast Carrier and Masts (Sheet 2 of 2).

EL21P009

TM 11-5985-334-30P

(1) FIG NO	(2) ITEM NO	(3) SMR CODE	TM11-5985-334-30P NATIONAL STOCK NUMBER		(4) FSCM	(5) PART NUMBER	(6) DESCRIPTION	(7) USABLE ON	CODE	(8) QTY INC IN UNIT
								U/M		
2	1	PAOZZ	5985-00-242-4286	80063	SM-D-561875		MAST SECTION		EA	8
2	2	PAOFF	5985-00-233-9247	80063	SM-D-561801		LAUNCHER ASSEMBLY		EA	1
2	3	PAOFF	5985-00-244-1693	80063	SM-D-561881		CASE,MAST		EA	1
2	4	PAFZZ	5340-01-146-7450	80063	SM-D-561883		HANDLE		EA	1
2	5	PAFZZ	5310-00-059-9264	96906	MS21045C6		NUT,SELF-LOCKING,HE		EA	15
2	6	PAFZZ	5306-00-582-9588	88044	AN6C13A		BOLT,MACHINE		EA	2
2	7	XBFZZ	5340-00-200-8630	80063	SC-C-76220		CATCH,CLAMPING		EA	3
2	8	XBFZZ		80063	SM-E-561882		FRAME,CASE		EA	1
2	9	XBFZZ	5315-00-840-0906	96906	MS16562-210		PIN,SPRING		EA	2
2	10	XBFZZ		80063	SM-C-728942		LEVEL		EA	1
2	11	XBFZZ		80063	SM-B-423625		MOUNTING,LEVEL		EA	1
2	12	XBFZZ		96906	MS24694-C54		SCREW,MACHINE		EA	2
2	13	XBFZZ	5310-00-059-9263	96906	MS21046-C3		NUT,SELF-LOCKING,HE		EA	2
2	14	XBFZZ	5310-00-167-0812	88044	AN960C10L		WASHER,FLAT		EA	2



EL2IP003

SECTION II		TM11-5985-334-30P		(6)		(7)		(8)	
(1) ILLUSTRATION (A)	(2) ITEM NO	(3) SMR CODE	NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	DESCRIPTION	USABLE ON	CODE	QTY INC IN UNIT
FIG NO	ITEM NO								
3	1	PAFZZ	5305-00-050-9234	96906	MS51957-68	SCREW,MACHINE		EA	6
3	2	PAFZZ	5310-00-933-8120	96906	MS35338-138	WASHER,LOCK		EA	6
3	3	PAFZZ	5310-00-550-5054	96906	MS15795-809	WASHER,FLAT		EA	6
3	4	XBFZZ		80063	SM-B-561872-1	COVER		EA	1
3	5	XBFZZ		80063	SM-B-561871-1	RACE,GUY RING		EA	1





Figure 4. Launcher Base and Elevator Assembly.


(1) FIG NO	(2) ITEM NO	SMR CODE	TM11-5985-334-30P		(6) DESCRIPTION	(7) USABLE ON	CODE	U/M	(8) QTY INC IN UNIT
			(3) ILLUSTRATION (A) (B)	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER				
4	1	XBFZZ		80063	SM-D-561846	BRACE ASSEMBLY		EA	2
4	2	XBFZZ		88044	AN509C10R10	SCREW,MACHINE		EA	8
4	3	PAFZZ	5310-00-263-2862	96906	MS21045C3	NUT,SELF-LOCKING,HE		EA	22
4	4	PAFZZ	5975-01-012-5445	80063	SM-B-561855	GUY		EA	1
4	5	PAFZZ	5310-00-823-8835	96906	MS21045C5	NUT,SELF-LOCKING,HE		EA	4
4	6	XBFZZ		80063	SM-B-561827-1	BRACKET,WHEEL		EA	2
4	7	PAFZZ	5306-00-156-2327	88044	AN3C6A	BOLT,MACHINE		EA	8
4	8	XBFZZ		80063	SM-B-561835-1	AXLE		EA	2
4	9	PAFZZ	5365-00-598-1840	96906	MS16633-4015	RING,RETAINING		EA	8
4	10	PAFZZ	5310-00-685-3744	88044	AN960C8	WASHER,FLAT		EA	8
4	11	XBFZZ		80063	SM-B-561911	WHEEL		EA	2
4	12	PAFZZ	5365-00-804-7645	96906	MS16624-4050	RING,RETAINING		EA	4
4	13	XBFZZ		80063	SM-B-561825	WHEEL ASSEMBLY		EA	4
4	14	XBFZZ		80063	SM-B-5618261	AXLE		EA	8
4	15	PAFZZ	5310-00-167-0806	88044	AN960C816	WASHER,FLAT		EA	4
4	16	PAFZZ	5315-00-242-7272	96906	MS35678-32	PIN,GROOVED,HEADLES		EA	4
4	17	PAFZZ	5305-00-207-2793	96906	MS24694C98	SCREW,MACHINE		EA	12
4	18	PAFZZ	5310-00-982-4988	96906	MS21045C4	NUT,SELF-LOCKING,HE		EA	14
4	19	XBFZZ		80063	SM-D-561805	BASE ASSEMBLY		EA	1
4	20	PAFZZ	5310-00-933-8118	96906	MS35338-135	WASHER,LOCK		EA	4
4	21	PAFZZ	5305-00-054-5646	73734	23021	SCREW MACHINE		EA	4
4	22	XBFZZ		80063	SM-D-558718-9	PLAT		EA	1
4	23	PAFZZ	5985-00-189-6606	80063	SM-D-561845	CUP ELEVATOR ASSEMB		EA	1
4	24	PAFZZ		80063	SM-B-561823	ELEVATOR ASSEMBLY		EA	1
4	25	PAFZZ	5306-00-150-9527	88044	AN3C5A	BOLT,MACHINE		EA	4
4	26	XBFZZ	5340-00-157-7657	80063	SM-B-561848-1	STRIKE,CATCH		EA	1
4	27	PAFZZ	5306-00-156-2332	88044	AN3C13A	BOLT,MACHINE		EA	4
4	28	XBFZZ	5340-00-157-7649	80063	SM-B-561848-2	STRIKE,CATCH		EA	1



EL2IPO05


Figure 5. Launcher Top and Guide Plate Assembly.

(1) FIG NO	(2) ITEM NO	SMR CODE	TM11-5985-334-30P		(6) DESCRIPTION	(7) USABLE ON	CODE	U/M	(8) QTY INC IN UNIT
			(3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER				
5	1	XBFZZ		80063	SM-B-561856	PULLEY,GROOVE		EA	1
5	2	PAFZZ	5306-00-156-2339	88044	AN4C7A	BOLT,MACHINE		EA	4
5	3	PAFZZ	5310-00-982-4988	96906	MS21045C4	NUT,SELF-LOCKING,HE		EA	14
5	4	XBFZZ		80063	SM-B-561857-1	BRACKET,PULLEY		EA	2
5	5	PAFZZ	5306-00-156-2343	88044	AN4C13A	BOLT,MACHINE		EA	1
5	6	XBFZZ		80063	SM-B-56185-1	SPACER,PULLEY		EA	1
5	7	XBFZZ	5305-00-527-4414	88044	AN509C10R10	SCREW		EA	8
5	8	XBFZZ		88044	AN509C616R26	SCREW		EA	8
5	9	XBFZZ	5305-00-052-9802	88044	AN509C10R8	SCREW,MACHINE		EA	8
5	10	XBFZZ	5340-00-157-7631	80063	SM-B-561923-1	STRIKE,CATCH		EA	4
5	11	PAFZZ	5310-00-263-2862	96906	MS21045C3	NUT,SELF-LOCKING,HE		EA	22
5	12	PAFZZ	5985-00-189-6629	80063	SM-D-561808	RING ASSEMBLY GUIDE		EA	2
5	13	XBFZZ		80063	SM-B-561854-1	PLATE,INSTRUCTION		EA	1
5	14	XBFZZ		88044	SMB-561917-1	SCREW,DRIVE		EA	3
5	15	PAFZZ	5306-00-582-9009	88044	AN6C17A	BOLT,MACHINE		EA	2
5	16	PAFZZ	5305-00-913-4084	80205	NAS1191C3P4	SCREW,SELF-LOCKING		EA	4
5	17	PAFZZ	5985-00-189-6632	80063	SM-D-561811	BRAKE ASSEMBLY MAST		EA	1
5	18	XBFZZ		80063	SM-B-561821-1	SPACER		EA	2
5	19	XBFZZ		80063	SM-B-561822-1	RETAINER,BRAKE		EA	1
5	20	XBFZZ	5305-00-068-5287	88044	AN507C832R7	SCREW,MACHINE		EA	2
5	21	XBFZZ		80063	SM-B-561810-1	SHAFT,ROLLER		EA	10
5	22	XBFZZ		80063	SM-B-561809-1	ROLLER,GUIDE		EA	10
5	23	PAFZZ	5365-00-286-8718	96906	MS16633-4037	RING,RETAINING		EA	20
5	24	XBFZZ	5305-00-054-9242	88044	AN509C416R14	SCREW,MACHINE		EA	7
5	25	PAFZZ		88044	AN509C616R17	SCREW		EA	10
5	26	XBFZZ		80063	SM-E-561807	GUIDE,PLATE		EA	1



EL2IP006


(1) FIG NO	(2) ITEM NO	SMR CODE	TM11-5985-334-30P		(6) DESCRIPTION	(7) USABLE ON	CODE	U/M	(8) QTY INC IN UNIT
			(3) ILLUSTRATION (A) (B)	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER				
6	1	XBFZZ	5315-00-058-9756	96906	MS16562-227	PIN,SPRING		EA	1
6	2	PAFZZ	5360-00-469-3710	96906	MS24585C155	SPRING,HELICAL,COMP		EA	1
6	3	XBFZZ		80063	SM-B-561843-1	POINTER,INNER		EA	1
6	4	XBFZZ		88044	AN509C416R15	SCREW		EA	2
6	5	PAFZZ	5305-00-054-6649	96906	MS51957-25	SCREW,MACHINE		EA	2
6	6	XBFZZ		80063	SM-C-561844-1	GUARD,AZIMUTH RING		EA	1
6	7	XBFZZ	5305-00-781-9478	88044	AN509C8R6	SCREW,MACHINE		EA	4
6	8	XBFZZ		80063	SM-B-561842-1	POINTER,OUTER		EA	1
6	9	PAFZZ	5305-00-054-6668	96906	MS51957-43	SCREW,MACHINE		EA	2
6	10	XBFZZ		80063	SM-B-561912	SCREW,MACHINE		EA	6
6	11	PAFZZ	5305-00-066-7328	96906	MS24693C27	SCREW,MACHINE		EA	6
6	12	PAFZZ	5305-00-206-3677	88044	AN507C632R4	SCREW,MACHINE		EA	4
6	13	PAFZZ	5315-00-058-9698	96906	MS16562-191	PIN,SPRING		EA	1
6	14	XBFZZ		80063	SM-D-561828-2	CUP,ELEVATOR		EA	1
6	15	XBFZZ		80063	SM-B-561834-1	SLEEVE		EA	1
6	16	XBFZZ		80063	SM-B-561916-1	WASHER		EA	1
6	17	XBFZZ		88044	AN509C10R13	SCREW,MACHINE		EA	2
6	18	XBFZZ		80063	SM-B-561836-32	PIN,INDEX,ASSEMBLY		EA	1



EL2IP007

Figure 7. Reel Assembly.

(1) FIG NO	(2) ITEM NO	SMR CODE	TM11-5985-334-30P		(6) DESCRIPTION	(7) USABLE ON	CODE	U/M	(8) QTY INC IN UNIT
			(3) ILLUSTRATION (A) (B)	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER				
7	1	XBFZZ	5975-01-012-5445	80063	SM-B-561855	GUY		EA	1
7	2	PAFZZ	5325-00-281-8638	96906	MS21332-1	FASTENER,SNAPSLIDE		EA	2
7	3	XBFZZ		88044	AN509C416R20	SCREW		EA	4
7	4	XBFZZ		80063	SM-D-561850	PLATE,REAR		EA	1
7	5	XBFZZ		96906	MS16532-192	PIN,SPRING		EA	1
7	6	XBFZZ		88044	AN507CA2BR12	SCREW		EA	4
7	7	PAFZZ	5306-00-156-2341	88044	AN4C11A	BOLT,MACHINE		EA	2
7	8	PAFZZ	5305-00-059-3660	96906	MS51958-64	SCREW,MACHINE		EA	1
7	9	XBFZZ		80063	SM-C-561851	PLATE,FRONT		EA	1
7	10	XBFZZ		80063	SM-C-561859-1	TEE REEL SUPPORT		EA	1
7	11	XBFZZ		80063	SM-D-560051-1	PLATE,INSTRUCTION		EA	1
7	12	PAFZZ	5985-00-233-9251	80063	SM-D-561849	REEL ASSEMBLY		EA	1



EL 2IP008

Figure 8. Brake Assembly.

(1) FIG NO	(2) ITEM NO	(3) SMR CODE	TM11-5985-334-30P			(6) DESCRIPTION	(7) USABLE ON	(8) QTY INC IN UNIT
			NATIONAL STOCK NUMBER	FSCM	PART NUMBER			
8	1	PAFZZ	3040-00-138-5651	80063	SM-C-561812	BRAKE SHOE		EA 1
8	2	XBFZZ		80063	SM-C-561816	LEVER, REAR		EA 1
8	3	PAFZZ	5310-00-268-6025	88044	AN315C5R	NUT, PLAIN, HEXAGON		EA 1
8	4	PAFZZ	5306-00-180-1921	88044	AN5C12A	BOLT, MACHINE		EA 2
8	5	XBFZZ		80063	SM-B-561847	BOLT, EYE		EA 1
8	6	XBFZZ		80063	SM-B-561818	LINK, BRAKE		EA 2
8	7	PAFZZ	5306-00-156-2344	88044	AN4C14A	BOLT, MACHINE		EA 2
8	8	XBFZZ		80063	SM-B-561819-1	HANDLE, BRAKE		EA 1
8	9	XBFZZ		96906	MS35678-19	PIN, GROOVED, HEADLES		EA 1
8	10	XBFZZ		80063	SM-B-561820-1	PIN, STRAIGHT, HEADLE		EA 1
8	11	XBFZZ		80063	SM-C-561817-1	LETTER, FRONT		EA 1
8	12	XBFZZ	3040-00-427-7749	80063	SM-C-561814	BRAKE SHOE		EA 1

SECTION IV

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

TM11-5985-334-30P

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
FSCM	PART NUMBER	FIGURE NO	ITEM NO	FSCM	PART NUMBER
5305-00-050-9234	3	1	5985-00-233-9247	2	2
5305-00-052-9802	5	9	5985-00-233-9248	1	8
5305-00-054-5646	4	21	5985-00-233-9249	1	15
5305-00-054-6649	6	5	5985-00-233-9251	7	12
5305-00-054-6668	6	9	5985-00-233-9252	1	9
5305-00-054-9242	5	24	5985-00-237-0728	1	4
5315-00-058-9698	6	13	5985-00-242-4286	2	1
5315-00-058-9756	6	1	5315-00-242-7272	4	16
5305-00-059-3660	7	8	5985-00-244-1693	2	3
5310-00-059-9263	2	13	5310-00-263-2862	4	3
5310-00-059-9264	2	5	5310-00-263-2862	5	11
5305-00-066-7328	6	11	5310-00-268-6025	8	3
5305-00-068-5287	5	20	5325-00-281-8638	7	2
3040-00-138-5651	8	1	5365-00-286-8718	5	23
5306-00-150-9527	4	25	4030-00-291-9354	1	11
5306-00-156-2327	4	7	4030-00-298-1382	1	21
5306-00-156-2332	4	27	5820-00-395-8807	1	1
5306-00-156-2339	5	2	5975-00-405-4505	1	17
5306-00-156-2341	7	7	5975-00-405-4506	1	22
5306-00-156-2343	5	5	5975-00-405-4507	1	5
5306-00-156-2344	8	7	5306-00-405-4588	1	6
5340-00-157-7631	5	10	3040-00-427-7749	8	12
5340-00-157-7649	4	28	5360-00-469-3710	6	2
5340-00-157-7657	4	26	5310-00-550-5054	3	3
4030-00-159-7127	1	7	5306-00-582-9009	5	15
5310-00-167-0806	4	15	5306-00-582-9588	2	6
5310-00-167-0812	2	14	5365-00-598-1840	4	9
5120-00-169-2664	1	20	5310-00-685-3744	4	10
5306-00-180-1921	8	4	5305-00-781-9478	6	7
4030-00-187-5261	1	2	5365-00-804-7645	4	12
4030-00-189-6154	1	13	5310-00-823-8835	4	5
4030-00-189-6155	1	16	5315-00-840-0906	2	9
4030-00-189-6156	1	10	5305-00-913-4084	5	16
4030-00-189-6237	1	12	5310-00-933-8118	4	20
5985-00-189-6606	4	23	5310-00-933-8120	3	2
5985-00-189-6629	5	12	5310-00-982-4988	4	18
5985-00-189-6632	5	17	5310-00-982-4988	5	3
5340-00-200-8630	2	7	5975-01-012-5445	7	1
5305-00-206-3677	6	12	5985-01-124-8751	1	19
5305-00-207-2793	4	17	5985-01-133-3584	1	18
5120-00-224-4105	1	3	5340-01-146-7450	2	4
FSCM	PART NUMBER	FIGURE NO	ITEM NO	FSCM	PART NUMBER
88044	AN3C13A	4	27	96906	MS16562-227
88044	AN3C5A	4	25	96906	MS16624-4050
88044	AN3C6A	4	7	96906	MS16633-4015
88044	AN31C5R	8	3	96906	MS16633-4037
88044	AN4C11A	7	7	96906	MS21045C3
88044	AN4C13A	5	5	96906	MS21045C3
88044	AN4C14A	8	7	96906	MS21045C4
88044	AN4C7A	5	2	96906	MS21045C5
88044	AN5C12A	8	4	96906	MS21045C6
88044	AN507CA2BR12	7	6	96906	MS21046-C3
88044	AN507C632R4	6	12	96906	MS21332-1
88044	AN507C832R7	5	20	96906	MS24585C155
88044	AN509C10R10	4	2	96906	MS24693C27
88044	AN509C10R13	6	17	96906	MS24694-C54
88044	AN509C10R8	5	9	96906	MS24694C98
88044	AN509C416R14	5	24	96906	MS35338-135
88044	AN509C416R15	6	4	96906	MS35338-138
88044	AN509C416R20	7	3	96906	MS35678-19
88044	AN509C8R6	6	7	96906	MS35678-32
88044	AN6C13A	2	6	96906	MS51957-25
88044	AN6C17A	5	15	96906	MS51957-43
88044	AN960C10L	2	14	96906	MS51957-68
88044	AN960C8	4	10	80205	NAS1191C3P4
88044	AN960C816	4	15	80063	SC-B-99880
81349	GGG-H-86	1	3	80063	SC-C-76220
80058	GP-112/G	1	11	80063	SC-C-99881
80058	GP-113/G	1	21	80063	SC-D-66302
80058	GP-2	1	2	80063	SM-B-423625
96906	MS15795-809	3	3	80063	SM-B-561809-1
96906	MS16532-192	7	5	80063	SM-B-561810-1
96906	MS16562-191	6	13	80063	SM-B-561818
96906	MS16562-210	2	9	80063	SM-B-561819-1

FSCM	PART NUMBER	FIGURE NO	ITEM NO	FSCM	PART NUMBER	FIGURE NO	ITEM NO
80063	SM-B-561820-1	8	10	80063	SM-C-561860	1	19
80063	SM-B-561821-1	5	18	80063	SM-C-561864	1	15
80063	SM-B-561822-1	5	19	80063	SM-C-561894-1	1	14
80063	SM-B-561823	4	24	80063	SM-C-561895-1	1	8
80063	SM-B-561825	4	13	80063	SM-C-561898	1	10
80063	SM-B-5618261	4	14	80063	SM-C-728942	2	10
80063	SM-B-561827-1	4	6	80063	SM-D-558718-9	4	22
80063	SM-B-561834-1	6	15	80063	SM-D-560051-1	7	11
80063	SM-B-561835-1	4	8	80063	SM-D-561801	2	2
80063	SM-B-561836-32	6	18	80063	SM-D-561805	4	19
80063	SM-B-561842-1	6	8	80063	SM-D-561808	5	12
80063	SM-B-561843-1	6	3	80063	SM-D-561811	5	17
80063	SM-B-561847	8	5	80063	SM-D-561828-2	6	14
80063	SM-B-561848-1	4	26	80063	SM-D-561845	4	23
80063	SM-B-561848-2	4	28	80063	SM-D-561846	4	1
80063	SM-B-56185-1	5	6	80063	SM-D-561849	7	12
80063	SM-B-561854-1	5	13	80063	SM-D-561850	7	4
80063	SM-B-561855	7	1	80063	SM-D-561868	1	16
80063	SM-B-561856	5	1	80063	SM-D-561869	1	13
80063	SM-B-561857-1	5	4	80063	SM-D-561874	1	4
80063	SM-B-561871-1	3	5	80063	SM-D-561875	2	1
80063	SM-B-561872-1	3	4	80063	SM-D-561878	1	18
80063	SM-B-561884	1	9	80063	SM-D-561881	2	3
80063	SM-B-561911	4	11	80063	SM-D-561883	2	4
80063	SM-B-561912	6	10	80063	SM-D-561885	1	5
80063	SM-B-561916-1	6	16	80063	SM-D-561887	1	22
80063	SM-B-561923-1	5	10	80063	SM-D-561889	1	17
80063	SM-C-561812	8	1	80063	SM-D-561896	1	12
80063	SM-C-561814	8	12	80063	SM-D-561899	1	20
80063	SM-C-561816	8	2	80063	SM-E-561807	5	26
80063	SM-C-561817-1	8	11	80063	SM-E-561882	2	8
80063	SM-C-561844-1	6	6	88044	SMB-561917-1	5	14
80063	SM-C-561851	7	9	73734	23021	4	21
80063	SM-C-561859-1	7	10				

LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS

FIGURE NO.		ITEM NO.	
5305-00-527-4414		5	7
FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
88044	AN509C10R10	5	7
88044	AN509C616R17	5	25
88044	AN509C616R26	5	8

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)
Commander
Stateside Army Depot
ATTN: AMSTA-US
Stateside, N.J. 07703

DATE SENT

10 July 1975

PUBLICATION NUMBER

TM 11-5840-340-20P

PUBLICATION DATE

23 Jan 78

PUBLICATION TITLE

Radar Set AN/PRC-76

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

- | PAGE NO | PARA-GRAPH | FIGURE NO | TABLE NO | |
|---------|------------|-----------|----------|--|
| 33 | | | | For item 2, change the NSN to read: 5835-00-134-9186.
<u>Reason:</u> Accuracy. |
| 44 | | 19 | | Identify the cover on the junction box (item no. 5).
<u>Reason:</u> It is a separate item and is not called out on figure 19. |
| 45 | | | | Add the cover of the junction box as an item in the listing for figure 19.
<u>Reason:</u> Same as above |

TEAR ALONG PERFORATED LINE

SAMPLE

S

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER
SSG I. M. DeSpirit of 999-1776

SIGN HERE

DA FORM 2028-2
1 JUL 79PREVIOUS EDITIONS
ARE OBSOLETE.P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

SAMPLE

Commander

US Army Communications-Electronics Command
and Fort Monmouth

ATTN: DRSEL-ME-MP

Fort Monmouth, New Jersey 07703

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT, AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-30P

PUBLICATION DATE

21 Sept 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

**IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:**

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS
ARE OBSOLETEP.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPIE OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

TEAR ALONG PERFORATED LINE

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-30P

PUBLICATION DATE

21 Sept 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

**IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:**

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS
ARE OBSOLETEP.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPIE OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5985-334-30P

PUBLICATION DATE

21 Sept 1983

PUBLICATION TITLE

Mast AB-621/G

BE EXACT PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:PAGE
NO.PARA-
GRAPHFIGURE
NO.TABLE
NO.

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS
ARE OBSOLETEP.S...IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPIE OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Communications-Electronics Command
and Fort Monmouth
ATTN: DRSEL-ME-MP
Fort Monmouth, New Jersey 07703

By Order of the Secretary of the Army:

JOHN A. WICKMAN JR.
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Major General United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-51, Direct & General Support Maintenance Requirements for AB-621/G.

PIN : 054108-000

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](http://chicagomachinerymovers.com)