

TECHNICAL MANUAL
**ORGANIZATIONAL DIRECT SUPPORT, AND
GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS LISTS**
**(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)**
FOR
ECHO BOX TS-488A/UP
(NSN 6625-00-519-7594)

**HEADQUARTERS, DEPARTMENT OF THE ARMY
01 FEBRUARY 1978**

TECHNICAL MANUAL
No.11-6625-220-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 1 February 1978

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL
SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL
TOOLS)

FOR

ECHO BOX TS-488A/UP
(NSN 6625-00-519-7594)

Current as of 7 October 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 20282 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail. If there are no blank DA Forms 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DR-SELMA-Q, Fort Monmouth, New Jersey 07703. In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
SECTION	I. Introduction.....	1	
	II. Repair parts list	5	
GROUP	00. Echo Box TS-488A/UP	5	1
	01. Antenna bracket assembly	7	2
	02. Cable Assembly CG-92A/U	9	3
	03. Case assembly	11	4
	04. Panel assembly	13	5
	0401 Piston assembly	17	6
	0402 Waveguide assembly	19	7
	0403 Tuning drive assembly	21	8
SECTION	III. Special tools list (Not applicable)		
	IV. National stock number and part number index	23	

This manual supersedes TM 11-6625-220-24P, 27 February 1976.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the TS-488A/UP. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA --	Item procured and stocked for anticipated or known usage.

Code

XD - A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

O - Support item is removed, replaced, used at the organizational level.

H - Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

H - The lowest maintenance level capable of complete repair of the support item is the general support level.

Z - Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

codes Definition

Z - Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

Recoverability

codes

Definition

H – Reparable item. When uneconomically repairable, condemn and dispose at the general support level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer (FSCM)

The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M)* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two character alphabetical abbreviation (e.g., ea., in., pr., etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown

on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

The following publications pertain to the TS-488A/UP and its components:

TM 11-6625-220-10, Echo Box TS-488A/UP

TM 11-6625-220-25, Echo Box TS-488A/UP

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)




Figure 1. Echo Box TS-488A/UP.

ELOEF001

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
1	1	XDOZZ	5995-00-272-9118	G2103-7088-1	00341	WRENCH,ALLEN	EA	1
1	2	XDOZZ		G2103-7088-2	00341	WRENCH, ALLEN		
1	3	PAOHH		CG92AU	81349	CABLE ASSEMBLY.....		
1	4	XDOZZ		G2103-7126	00341	CHART,TROUBLESHOOTING		
1	5	XDHHH		G2103-7224	00341	PANEL ASSEMBLY.....		
1	6	PAOZZ		MS3397-11	96906	PLUG, CRANKCASE DEHYDRATOR.....		
1	7	XDHHH		G2103-7229	00341	CASE ASSEMBLY.....		
1	8	XDOHH		G2103-7230	00341	ANTENNA BRKT ASSY		
1	9	PAOZZ		AT63U	80058	ANTENNA,PICKUP		
					5			





Figure 2. Antenna Bracket Assembly.

LOEF002

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
2	1	XDHZZ		G2133-7116	00341	GROUP 01 ANTENNA BRACKET ASSEMBLY		
2	2	PAHZZ	5340-00-441-9405	G2103-7115	00341	BRACKET MOUNTING	EA	1
2	3	XDHZZ		AN935C8L	88044	CUP, SUCTION	EA	2
2	4	PAHZZ	5310-00-934-9759	AN340C8	88044	WASHER, LOCK	EA	1
2	5	PAHZZ	5305-00-054-6668	MSS157-43	96906	NUT,HEXAGON	EA	3
2	6	XDHZZ		G2103-7114	00341	SCREW,MACHINE.....	EA	1
					7	CLIP, FUSE	EA	1




ELOEFO03

Figure 3. Cable Assembly CG-92A/U.

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7) U/M	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE						
3	1	PAHZZ	5935-00-928-3127	UGL1185BU	81349 9	GROUP 02 CABLE ASSEMBLY CG-2A/U CONNECTOR, RECPT	EA	2



ELOEF004


ELOEF004

Figure 4. Case Assembly.

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
						GROUP 03 CASE ASSEMBLY		
4	1	PAHZZ	5305-00-054-6651	MS51957-27	96906	SCREW,MACHINE.....	EA	2
4	2	XDHZZ		AN935C6L	88044	WASHER,LOCK.....	EA	2
4	3	XDHZZ		G2103-7152	00341	RETAINER,SHELL.....	EA	1
4	4	XDHZZ		G2103-7151	00341	RETAINER,BASE.....	EA	1
4	5	XDHZZ		G2103-7233	00341	COVER ASSEMBLY.....	EA	1
4	6	XDHZZ		G2103-7127	00341	DECAL.....	EA	1
4	7	XDHZZ		G2103-7120	00341	CLIP, WRENCH	EA	1
4	8	XDHZZ		AN365C1032	88044	NUT,LOCKING	EA	2
4	9	XDHZZ		G2103-7123	00341	PLUG, DUMMY RECPT	EA	2
4	10	XDHZZ		G2103-7180	00341	GASKET,RUBBER	EA	1
4	11	XDHZZ		AN365C832	88044	NUT, LOCKING	EA	8
4	12	XDHZZ		G2103-7184	00341	BRACKT, MOUNTING.....	EA	1
4	13	XDHZZ		AN515C8-10	88044	SCREW,MACHINE.....	EA	2
4	14	XDHZZ		G2103-7140	00341	BUMPER,RUBBER	EA	8
4	15	XDHZZ		G2103-7232	00341	BOX ASSEMBLY.....	EA	1
4	16	PAHZZ	5305-00-054-6670	AN515C8-8	88044	SCREW,MACHINE.....	EA	6
4	17	XDHZZ		G2103-7234	00341	HANDLE ASSEMBLY.....	EA	2
4	18	XDHZZ		AN526C1032-10	88044	SCREW,MACHINE.....	EA	2
4	19	XDHZZ		G2103-7118	00341	GASKET,METAL	EA	2
					11			



ELOEF005

Figure 5. Panel Assembly.

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
						GROUP 04 PANEL ASSEMBLY		
5	1	XDHZZ		G2103-7106	00341	SCREW,CAPTIVE	EA	1
5	1	XDHZZ		G2103-7104	00341	SHELL,WIASHER	EA	1
5	3	XDHZZ		G2103-7105	00341	GASKET,WASHER	EA	1
5	4	XDHZZ		AN526C832R7	88044	SCREW, MACHTINE	EA	2
5	5	XDHZZ		AN526C1024R7	88044	SCREW,MACHINE	EA	4
5	5	XDHZZ		G2103-7183	00341	NUT,COUPLING.....	EA	1
5	6	XDHZZ		G2103-7182	00341	GASKET,CRYSTAL.....	EA	1
5	8	PAOZZ	5961-00-615-4309	JAN1N23WE	81350	SENICONDUCTOR, DIODE.....	EA	6
5	9	PAHHH	6625-00-563-5500	G2103-7204	00341	ASSEMBLY,WAVEGUIDE	EA	1
5	10	PAHZZ	5935-00-928-3127	UG1185BU	81349	CONNECTOR,RECPT	EA	3
5	11	XDHZZ		AN935C6L	88044	WASHER,LOCK	EA	4
5	12	XDHZZ		AN340C6	88044	NUT,HEXAGON	EA	2
5	13	PAHZZ	5910-0-170-2779	CP5JB1EF504K3	81349	CAPACITOR,CERAMIC	EA	1
5	14	XDHZZ		G2103-7167	00341	SPRING, HELICAL.....	EA	1
5	15	XDHHH		G2103-7211	00341	PISTON ASSEMBLY	EA	1
5	16	PAHZZ	6625-00-498-3975	G2103-7217	00341	TRANSDUCER.....	EA	2
5	17	PAHZZ	5310-00-193-7577	AN935C4	88044	WASHER,FLAT	EA	24
5	18	PAHZZ	5305-00-054-5648	MS51957-4	96906	SCREW, MACHINE.....	EA	8
5	19	XDHZZ		AN935C10L	88044	WASHER,LOCK	EA	2
5	20	PAHZZ	5310-00-934-9760	AN340C10	88044	NUT, HEXAGON	EA	2
5	21	XDHZZ		ANS15C8-7	88044	SCREW,MACHINE.....	EA	7
5	22	XDHZZ		AN935C8L	88044	WASHER,LOCK	EA	13
5	23	XDHZZ		G2103-7078	00341	BRACKET, CAVITY.....	EA	1
5	24	PAHZZ	5305-00-054-6668	MS51957-43	96906	SCREW,MACHINE.....	EA	6
5	25	XDHZZ		G2103-7222	00341	PLATE ASSEMBLY,FEED	EA	1
5	26	XDHZZ		G2133-7196	00341	CAVITY.....	EA	1
5	27	XDHZZ		AN365C632	88044	NUT LOCKING	EA	4
5	28	XDHZZ		G2103-7132	00341	WASHER, SHOULDER.....	EA	1
5	29	PAHHH	6625-00-563-5501	G2103-7214	00341	TUNING ASSEMBLY.....	EA	1
5	30	XDOZZ		G2103-7087	00341	HANDLE, PANEL	EA	2
5	31	PAHZZ	5305-00-763-6963	MSS51959-28	96906	SCREW,MACHINE	EA	4
5	32	XDHZZ		G2133-718	00341	GASKET, NONMETALLIC	EA	1
5	33	PAHZZ	6625-00-643-2192	MR36W0200CUAR	81349	METER,ELECTRICAL	EA	1
5	34	XDHZZ		MS35027-231	96906	SCREW,MACHINE	EA	3
5	35	PAHZZ	5310-00-934-9748	MS35649-244	96906	NUT, LOCKING	EA	14
5	36	PAHZZ	5310-00-584-3782	AN960C4L	88044	WASHER, FLAT	EA	6
5	37	XDHZZ		G2103-7133	00341	WASHER,NONMETALLIC	EA	6
5	38	XDHZZ		G2103-7076	00341	WINDOW,PLASTIC	EA	2
5	39	XDHZZ		AN505C4R7	88044	SCREW,MACHINE	EA	14
					13			

SECTION II

TM 11-6625-220-24P




Figure 6. Piston Assembly.

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
						GROUP 0401 PISTON ASSEMBLY		
6	1	PAHZZ	5305-00-054-6670	AN515C8-8	88044	SCREW, MACHINE.....	EA	3
6	2	XDHZZ		G103-7325	00341	SOCKET ASSEMBLY, PISTON	EA	1
6	3	PAHZZ	5305-00-763-7822	MS51959-14	96906	SCREW,MACHINE.....	EA	6
6	4	XDHZZ		G2103-7045	00341	NUT, PLATE.....	EA	3
6	5	XDHZZ		G2103-7025	00341	PISTON, CAVITY	EA	1
6	6	XDHZZ		AN216CP40	88044	BALL, METAL.....	EA	1
6	7	XDHZZ		G2103-7028	00341	SPRING,HELICAL.....	EA	1
6	8	XDHZZ		G2103-7029	00341	SHAFT,TAPE MOUNTING	EA	1
6	9	XDHZZ		G2103-7036	00341	TUBE, PISTON.....	EA	1
6	10	XDHZZ		G2103-7131	00341	PIN, ROLL	EA	2
6	11	XDHZZ		G2103-7166	00341	BOLT, SPECIAL PURPOSE.....	EA	1
6	12	XDHZZ		G2103-7164	00341	TAPE	EA	1
6	13	XDHZZ		G2103-7165	00341	BLOCK, TAPE	EA	1
6	14	XDHZZ		G2103-7030	00341	CLIP,SPRING.....	EA	1
					17			




Figure 7. Waveguide Assembly.

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
						GROUP 0402 WAVEGUIDE ASSEMBLY		
7	1	PAHZZ	5305-00-054-5638	MS51957-4	96906	SCREW, MACHINE.....	EA	8
7	2	PAHZZ	5310-00-928-2690	AN935C2	88044	WASHER, LOCK	EA	8
7	3	XDHZZ		02103-7156	00341	PLATE, SLIDE	EA	2
7	4	XDHZZ		G2103-7157-2	00341	YOKE,SUPPORT	EA	1
7	5	XDHZZ		AN51SC4-6	88044	SCREW,MACHINE	EA	8
7	6	XDHZZ		62103-7154	00341	BAR, GUIDE	EA	1
7	7	XDHZZ		G2103-7148	00341	SPRING, HELICAL	EA	2
7	8	XDHZZ		G2103-7143-2	00341	ROD,SUPPORT	EA	2
7	9	PAHZZ	6625-00-498-3975	C2103-7217	00341	TRANSDUCER	EA	1
7	10	XOHZZ		G2103-7142-1	00341	VANE, ATTENUATING	EA	2
7	11	PAHZZ	5305-00-059-8235	ANS508-4-2	88044	SCREW,MACHINE	EA	4
7	12	XDHZZ		G2103-7066	00341	WAVEGUIDE,RF	EA	1
7	13	XDHZZ		G2103-7143-1	00341	ROD,SUPPORT	EA	2
7	14	XDHZZ		G2103-7153	00341	BAR., GUIDE	EA	1
7	15	XDHZZ		G2103-7157-1	00341	YOKE, SUPPORT	EA	1
7	16	XDHZZ		G2103-7237	00341	CAP ASSEMBLY, CAPACITOR	EA	1
7	17	PAHZZ	5305-00-054-5637	AN515C2-4	88044	SCREW, MACHINE	EA	3
7	18	XDHZZ		G2103-7220	00341	SOCKET ASSEMBLY, CRYSTAL	EA	1
7	19	XDHZZ		G2103-7063	00341	CRYSTAL MOUNT,ELECTRIC	EA	1
7	20	XDHZZ		G2103-7135	00341	TERMINAL LUG	EA	1
7	21	XDHZZ		G2103-7056	00341	RETAINER, CRYSTAL	EA	1
7	22	XDHZZ		G2103-7055	00341	EXTRACTOR,CRYSTAL	EA	1
7	23	XDHZZ		02103-7058	00341	ASSEMBLY, BLOCK	EA	1
7	24	XDHZZ		G2103-7193	00341	ASSEMBLY, PLATE	EA	1
7	25	XDHZZ		G2103-7141	00341	BEARING,SLEEVE	EA	1
7	26	XDHZZ		G2103-7222	00341	ASSEMBLY, PLATE FEED	EA	1
7	27	XDHZZ		G2103-7144	00341	WASHER, SPRING	EA	1
7	28	XDHZZ		G2103-7134-1	00341	PIN,TAPER	EA	1'
7	29	XDHZZ		G2103-7223	00341	ASSEMBLY, DIAL	EA	1
7	30	PAHZZ	5305-00-282-2273	AN505C3-4	88044	SCREW,MACHINE	EA	4
7	31	XDHZZ		G2103-7067	00341	PLATE, SLIDE	EA	1
7	32	PAHZZ	5305-00-764-2966	AN505C2-3	88044	SCREW,MACHINE	EA	4
					19			




Figure 8. Tuning Drive Assembly.

ELOEF008

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)	
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT	
						GROUP 0403 TUNING DRIVE ASSEMBLY			
8	1	XDHZZ	G2103-7015	00341	SHAFT,ECCENTRIC.....		EA	1	
8	2	XDHZZ	G2103-7003	00341	BEARING, SLEEVE		EA	1	
8	3	XDHZZ	G2103-7013	00341	SHAFT, DIAL.....		EA	1	
8	4	XDHZZ	G2103-7134-2	00341	PIN, TAPER.....		EA	2	
8	5	XDHZZ	G2103-7024	00341	COLLAR,LOCATING.....		EA	2	
8	6	XDHZZ	G2103-7011	00341	HUB DIAL		EA	2	
8	7	XDHZZ	G2103-7010	00341	DIAL,FREOUENCY		EA	1	
8	8	XDHZZ	G2103-7112	00341	SCREW, MACHINE.....		EA	6	
8	9	XDHZZ	MS35336-3	96906	WASHER, LOCK		EA	6	
8	10	XDHZZ	G2103-7134-4	00341	PIN, TAPER.....		EA	3	
8	11	XDHHH	G2103-7117	00341	SPRING, HELICAL.....		EA	2	
8	12	XDHHH	G2103-7215	00341	GEAR ASSEMBLY.ANTI-BACKLASH		EA	1	
8	13	XDHZZ	G2103-7012	00341	BEARING, THRUST		EA	1	
8	14	XDHZZ	G2103-7004	00341	BEARING, SLEEVE		EA	1	
8	15	XDHZZ	G2103-7134-4	00341	PIN, TAPER.....		EA	1	
8	16	XDHZZ	G2103-7001	00341	FRAME,HEAD		EA	1	
8	17	XDHZZ	G2103-7002	00341	BEARING, SLEEVE		EA	1	
8	18	XDHZZ	G2103-7016	00341	GEAR, ARM		EA	1	
8	19	XDHZZ	G2103-7134-3	00341	PIN,TAPER.....		EA	1	
8	20	XDHZZ	G2103-7046	00341	GEAR, HELICAL		EA	1	
8	21	XDHZZ	G2103-7005	00341	BEARING,SLEEVE		EA	2	
8	22	XDHZZ	AN935C8L	88044	WASHER,LOCK.....		EA	3	
8	23	XDHZZ	AN500C8-4	88044	SCREW, MACHINE.....		EA	3	
8	24	XDHZZ	G2103-7039	00341	BEARING, SLEEVE		EA	1	
8	25	XDHZZ	G2103-7007	00341	BOX, TAPE DRIVE.....		EA	2	
8	26	PAHZZ	5310-00-534-3782	AN935C4L	88044	WASHER, FLAT		EA	4
8	27	PAHZZ	5305-00-054-5648	MS51957	96906	SCREW, MACHINE.....		EA	4
8	28	XDHZZ	G2103-7134-5	00341	PIN TAPER.....		EA	2	
8	29	XDHZZ	G2103-7041	00341	CAM,ECCENTRIC.....		EA	1	
8	30	XDHZZ	G2103-1031	00341	YOKE,TAPE		EA	2	
8	31	XDHZZ	AN935C3L	88044	WASHER, LOCK		EA	4	
8	32	XDHZZ	AN515C3-5	88044	SCREW, MACHINE.....		EA	4	
8	33	XDHZZ	G2103-7009	00341	BRACKET, GUIDE		EA	1	
8	34	XDHZZ	G2103-7210	00341	GEAR ASSEMBLY		EA	1	
8	35	XDHZZ	G2103-7040	00341	SPACER METALLIC		EA	1	
8	36	XDHZZ	G2103-7209	00341	GEAR ASSEMBLY.COMPOUND.....		EA	1	
8	37	XDHZZ	G2103-7186	00341	CLIP,RETAINING		EA	1	
8	38	XDHZZ	G2103-7020	00341	GEAR SPUR		EA	1	
8	39	XDHZZ	G2103-7023	00341	SHAFT,GEAR.....		EA	1	

SECTION II

TM 11-6625-220-24P

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION <i>USABLE ON CODE</i>	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM		U/M	QTY INC IN UNIT
8	40	XDHZZ		G2103-7022	00341	DIAL, FREQUENCY	EA	1
8	41	XDHZZ		AN515C6-5	88044	SCREW, MACHINE.....	EA	1
8	42	XDHZZ		AN935C6L	88044	WASHER,LOCK.....	EA	2
8	43	XDHZZ		G2103-7006	00341	PLATE, INDEX	EA	1
8	44	XDHZZ		G2103-7014	00341	GEAR, SPUR	EA	1
					22			

SECTION IV.

TM 11-6625-220-24P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
G2103-7132	00341	5	28	G2103-7193	00341	7	24
G2103-7133	00341	5	37	G2103-7196	00341	5	26
G2103-7134-1	00341	7	28	G2103-7204	00341	5	9
G2103-7134-2	00341	8	4	G2103-7209	00341	8	36
G2103-7134-3	00341	8	19	G2103-7210	00341	8	34
G2103-7134-4	00341	8	10	G2103-7211	00341	5	15
G2103-7134-5	00341	8	15	G2103-7214	00341	5	29
G2103-7134-5	30341	8	28	G2103-7215	00341	8	12
G2103-7135	00341	7	20	G2103-7217	00341	5	16
G2103-7140	00341	4	14	G2103-7217	00341	7	9
G2103-7141	00341	7	25	G2103-7220	00341	7	18
G2103-7142-1	30341	7	10	G2103-7222	00341	5	25
G2103-7143-1	00341	7	13	G2103-7222	00341	7	26
G2103-7143-2	00341	7	8	G2103-7223	00341	7	29
G2103-7144	00341	7	27	G2103-7224	00341	1	5
G2103-7148	00341	7	7	G2103-7227	00341	5	58
G2103-7151	00341	4	4	G2103-7229	00341	1	7
G2103-7152	00341	4	3	G2103-7230	00341	1	8
G2103-7153	00341	7	14	G2103-7232	00341	4	15
G2103-7154	00341	7	6	G2103-7233	00341	4	5
G2103-7156	00341	7	3	G2103-7234	00341	4	17
G2103-7157-1	00341	7	15	G2103-7237	00341	7	16
G2103-7157-2	00341	7	4	G2103-7325	00341	6	2
G2103-7164	00341	6	12	JAN1N23WE	81350	5	8
G2103-7165	00341	6	13	MR36W02CDCUAR	81349	5	33
G2103-7166	00341	6	11	M35027-231	96906	5	34
G2103-7167	00341	5	14	MS35336-3	96906	8	9
G2103-7180	00341	4	10	MS51957-43	96906	2	5
G2103-7181	00341	5	32	MS51957-43	96906	5	24
G2103-7182	00341	5	7				
G2103-7183	30341	5	6	UG1185BU	81349	3	1
G2103-7184	00341	4	12	UG1185BU	81349	5	10
G2103-7186	00341	8	37	UG1187BU	81349	5	56

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.
5310-00-193-7577	5	17	5310-00-584-3782	5	36
5305-00-282-2273	7	30	5310-00-584-3792	8	26
5355-00-519-7702	5	41	5310-00-928-2690	7	2

LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
AN935C2	88044	7	2	MS51957-27	96906	4	1
AN935C4	88044	5	17	MS91531-3P2M	96906	4	41
MS3397-11	96906	1	6				

ADDITIONAL LATEST NATIONAL STOCK NLHBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.
5305-054-6651	4	1
5305-00-05-8235	7	11
6685-00-641-8526	1	6

ADDITIONAL LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
CP5JB1EF504K1	81349	5	13	MS51957-14	96906	5	18
MS35649-244	96906	5	1	MS51957-14	96906	8	21
MS51957-4	96906	7	1	MS51959-14	96906	6	3
MS51957-12	96906	5	49	MS51959-28	96906	5	31

SECTION IV.
TM 11-6625-220-24P
NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NOTE: LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.		
5303-00-054-5637	7	17	6625-00-563-5530	5	9		
5305-00-054-5638	7	1	6625-40-563-5501	5	29		
5305-00-054-5646	5	49	5961-00-615-4309	5	8		
5305-00-054-5648	5	18	5310-00-638-9657	5	60		
5305-00-054-5648	2	7	6625-00-643-2192	5	33		
5305-00-054-6668	2	5	5305-00-163-6963	5	31		
5305-00-054-6668	5	24	5305-00-763-1822	6	3		
5305-00-054-6670	4	16	5305-00-764-2966	7	32		
5305-00-054-6670	6	1	5935-00-928-3126	5	56		
5910-00-170-2779	5	13	5935-00-928-3127	3	1		
5985-00-241-6701	1	9	5935-00-920-3127	5	10		
5995-00-272-9118	1	3	5310-00-434-9748	5	15		
5340-00-441-9405	2	2	5310-00-934-9159	2	4		
6625-00-498-3975	5	16	5310-00-934-9760	5	20		
6625-00-498-3975	7	9					
PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
AN216CP40	88044	6	6	02103-7013	00341	8	3
AN340C10	88044	5	20	G2103-7014	00341	8	44
				G2103-7015	00341	8	1
AN340C6	88044	5	12	G2103-7016	00341	8	18
AN340C8	88044	2	4	G2103-7020	00341	8	38
AN365C1032	88044	4	8	G2103-7022	00341	8	40
AN365C6323	88044	5	27	G7103-7023	00341	8	39
AN365C832	88044	4	11	G2103-7024	00341	8	5
				G2103-7025	00341	6	5
AN500C8-4	88044	9	23	G2133-7028	00341	6	7
AN505C2-3	88044	1	32	G2103-7329	00341	6	8
AN505C3-4	88044	7	30	G2103-7030	00341	6	14
				G2103-7031	00341	8	30
AN505C4R7	88044	5	39	G2103-3736	00341	6	9
				G2103-7039	00341	8	24
AN508-4-2	88044	7	11	G2103-7040	00341	8	35
AN515C2-4	88044	1	17	G2103-7041	00341	8	29
				G2103-7045	00341	6	4
AN515C3-5	88044	8	32	G2103-7046	00341	8	20
				G2103-7052	00141	5	61
				G2103-7055	00341	7	22
				G2103-7056	00341	7	21
AN515C4-6	88044	7	5	G2103-7058	00341	7	23
				G2103-7063	00341	7	19
AN515C6-5	88044	4	1	G2103-7066	00341	7	12
AN515C8-10	88044	4	13	G2103-7067	00341	7	31
AN515C8-7	88044	5	21	G2103-7068	00341	5	40
AN515C8-8	88044	4	16	G2103-7074	00341	5	41
AN515C8-8	88044	6	1	G2103-7076	00341	5	38
AN526C1024R7	88044	5	5	G2103-7071	00341	5	53
AN526C1032-10	88044	4	18	G2103-7078	00341	5	23
AN526C832R7	88044	5	4	G2103-7079	00341	5	55
AN935C10L	88044	5	19	G2103-7080	00341	5	42
				G2103-7081	00341	5	44
AN935C3L	88044	8	31	G2103-7082	00341	5	43
AN935C4L	88044	8	26	G2103-7083	00341	5	52
				G2103-7084	00341	5	51
AN935C6L	88044	4	2	G2103-7085	00341	5	50
AN935C6L	88044	5	11	G2103-1086	00341	5	45
AN935C6L	88044	8	42	G2103-7067	00341	5	30
AN935C8L	88044	2	3	G2103-7088-1	00341	1	1
AN935C8L	88044	5	22	G2103-7088-2	00341	1	2
AN935C8L	88044	5	22	G2103-7093	00341	5	59
AN960C4L	88044	5	36	G2103-7101	00341	5	54
AN960C6L	88044	5	60	G2103-7102	00341	5	46
AT680	80058	1	9	G2103-7103	00341	5	57
CG092AU	81349	1	3	G2103-7104	00341	5	2
				G2103-7105	00341	5	3
G2103-7001	00341	9	16	G2103-7106	00341	5	1
G2103-7002	00341	1	11	G2103-7112	00341	6	8
G2103-7003	00341	6	2	G2103-7114	00341	2	6
G2103-7004	00341	8	14	G2103-7115	00341	2	2
G2103-7005	00341	8	21	G2103-7116	00341	2	1
G2103-7006	00341	8	43	G2103-7117	00341	8	11
G2103-7007	00341	8	25	G2103-7118	00341	4	19
G2103-7008	00341	5	49	G2103-7120	00341	4	7
G2103-7009	00341	0	33	G2103-7123	00341	4	9
G2103-7010	00341	8	1	G2103-7126	00341	1	4
G2103-7011	00341	8	6	G2103-7127	00341	4	6
G2103-7012	00341	8	13	G2103-7131	00341	6	10

By Order of the Secretary of the Army:

BERNARD W. ROGERS
General, United States Army
Chief of Staff

Official:

J.C. PENNINGTON
Brigadier General, United States Army
The Adjutant General

Distribution:

Active Army:

USAISNSCOM (2)	MAAG (1)
COE (1)	USARMIS (1)
TSG (1)	USAERDAA (1)
USAARENBD (1)	USAERDAW (1)
DARCOM (1)	Units org under fol TOE: 1 ea.
TECOM (2)	1-55
USACC (4)	1-56
TRADOC (2)	7
OS Maj Comd (4)	7-100
MDW (1)	11-16
Armies (2)	11-97
Corps (2)	11-98
Fort Gillem (10)	11-117
Fort Gordon (10)	11-500(AA-AC)
Fort Huachuca (10)	17
Fort Carson (5)	17-100
HISA (Ft Monmouth) (33)	29-1
Ft Richardson (ECOM Ofc) (2)	29-15
Svc Colleges (1)	29-16
USASIGS (5)	29-21
USAICS (3)	29-25
USAADS (2)	29-26
USAFAFS (2)	29-35
USAARMS (2)	29-36
USAIS (2)	29-75
USAES (2)	29-79
AD (1) except	29-105
SAAD (30)	29-109
LBAD (14)	37
TOAD (14)	37-100
SHAD (3)	57
USA Dep (1)	57-100
Sig Sec USA Dep (1)	

ARNG: State AG (3); Units-Same as Active Army except allowance is one (1) copy per unit.

USAR: None

For explanation of abbreviations used, see AR 310-50.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

**THEN. . JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL.**

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT...PIN-POINT WHERE IT IS

**IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:**

WINE ALONG PERIODIC TABLE

PRINTED NAME, GRADE OR TITLE, AND THE FIRM/CODE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

**PREVIOUS EDITIONS
• ARE OBSOLETE.**

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

THE METRIC SYSTEM AND EQUIVALENTS

WEAR MEASURE

Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9(F - 32) = ^\circ C$
 212° Fahrenheit is equivalent to 100° Celsius

90° Fahrenheit is equivalent to 32.2° Celsius

32° Fahrenheit is equivalent to 0° Celsius

$9/5C + 32 = ^\circ F$

APPROXIMATE CONVERSION FACTORS

TO CHANGE

Inches.....
 Feet.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Fluid Ounces.....
 nts.....
 arts.....
 allons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pound-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

TO

Centimeters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Milliliters.....
 Liters.....
 Liters.....
 Liters.....
 Grams.....
 Kilograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Kilometers per Liter.....
 Kilometers per Hour.....

MULTIPLY BY

2.540
 0.305
 0.914
 1.609
 6.451
 0.093
 0.836
 2.590
 0.405
 0.028
 0.765
 29.573
 0.473
 0.946
 3.785
 28.349
 0.454
 0.907
 1.356
 6.895
 0.425
 1.609

TO CHANGE


Centimeters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Milliliters.....
 Liters.....
 Liters.....
 ers.....
 ms.....
 ograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Kilometers per Liter.....
 Kilometers per Hour.....

TO

Inches.....
 Feet.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Fluid Ounces.....
 Pints.....
 Quarts.....
 Gallons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pounds-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

MULTIPLY BY

0.394
 3.280
 1.094
 0.621
 0.155
 10.764
 1.196
 0.386
 2.471
 35.315
 1.308
 0.034
 2.113
 1.057
 0.264
 0.035
 2.205
 1.102
 0.738
 0.145
 2.354
 0.621



PIN: 005193-000

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](http://chicagomachinerymovers.com)