
TECHNICAL MANUAL

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

**FOR
TEST SET, PROPELLER SYNCHROPHASER COMPONENTS
AN/ASM -127
(NSN 1610-00-967-9651)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

DECEMBER 1978

TECHNICAL MANUAL
DEPARTMENT OF THE ARMY
No. 11-6625-549-40P

HEADQUARTERS
WASHINGTON, DC, 29 December 1978

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
FOR
TEST SET, PROPELLER SYNCHROPHASER COMPONENTS AN/ASM-127
(NSN 1610-00-967-9651)

Current as of 28 June 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Illus	
		Page	Figure
SECTION	I. Introduction	1	
	II. Repair parts list	5	
Group	00 Test Set, Propeller Synchrophasor Components AN/ASM-1275	5	1
	01 Test Set, Propeller Synchrophasor Components TS-1982/ASM-127	7	2
	0101 Panel assembly, test (A1)	9	3
	010101 Plate assembly electrical (A1A1)	11	4
	01010101 Circuit card assembly (A1A1A1)	13	5
	010102 Panel assembly (A1A2)	15	6
	02 Cable Assembly, Power Electrical CX-9130/ASM-127 (W1)	17	7
	03 Cable Assembly, Power Electrical CX-9129/ASM-127 (W2)	17	7
	04 Cable Assembly, Power Electrical CX-9128/ASM-127 (W3)	17	7
	05 Case assembly combination (MP1)	19	8
SECTION	III. Special tools list (Not applicable)		
	IV. National stock number and part number index	20	

*This manual supersedes TM 11-6625-549-45P, 14 November 1969.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of general support maintenance of the AN/ASM-127. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

PA- Item procured and stocked for anticipated or known usage.

XD- A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

O- Support item is removed, replaced, used at the organizational level.

H- Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

H- The lowest maintenance level capable of complete repair of the support item is the general support level.

Z- Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

codes Definition

Z- Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

H- Reparable item. When uneconomically repairable, condemn and dispose at the general support level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item. When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

The following publications pertain to the AN/ASM- 127 and its components:

TM 11-6625-549-12, Test Set Propeller, Synchro-phaser Components AN/ASM-127

TM 11-6625-549-20P, Test Set, Preflight, Synchro-phaser Components AN/ASM-127

TM 11-6625-549-45, Test Set, Propeller Synchro-phaser Components AN/ASM-127

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)





Figure 1. Test Set, Propeller Synchrophaser Components AN/ASM-127.

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION (a) FIG NO.		(2) (b) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8) QTY INC IN UNIT U/M
1	1	PAOHH	1610-00-967-9649	TS- L982/AS-127	80058	TEST SET, PRCP	EA	1
1	2	PAHHH	6625-00-964-9906	CX-9129/ASM-127	80058	CABLE ASSEMBLY , POWER	EA	1
1	3	PAHHH	6625-00-964-9903	CX-9128/ASM-127	80058	CABLE ASSEMBLY, POWER	EA	1
1	4	PAHHH	6625-00-964-9905	CX-9L30/ASM-127	80058	CABLE ASSEMBLY, POWER	EA	1
1	5	XDHHH		SK622700	74284	CASE ASSY, CCMB	EA	1
6	6	XDHZZ		1345SEAV2516-1	26512	GAGE ASSENBLY	EA	1
1	7	XDHZZ		134SEAV2504-17	26512	NAMEPLATE	EA	1
1	8	XOHZZ		AN535-4-4	88044	SCREW	EA	4
					5			




ELIHMOO2

Figure 2. Test Set, Propeller Synchrophaser Components TS-1982/ASM-127.

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8) U/M	QTY INC IN UNIT
2	1XDHHH		34SEAV2508-1	26512	7	GROUP 00 TEST SET, PROPELLER SYNCHROPHASER COMPONENTS IS-1982/ASM-127 PANEL ASSY, TEST	EA	1




ELIHM003

Figure 3. Panel Assembly Test (A1).

SECTION II

TM 11-6625-549-40P

(1) (2) ILLUSTRATION		(3)	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE					QTY INC IN UNIT
3	1	XDHHH		134SEAV2508-3	26512	GROUP 0101 PANEL ASSEMBLY TEST (A1)	
3	2	XDHZZ	5305-00-889-3000	MS35206-230	96906	PLATE ELEC ASSY	EA 1
3	3	XDHZZ	5310-00-045-4007	MS35338-41	96906	SCREW, MACHINE	EA 5
3	4	XDHZZ	5340-00-057-7773	G398-16	26512	WASHER, LOCK	EA 5
3	5	XDHZZ		NAS1189-06P8	80205	SPACER	EA 5
3	6	XDHHH		1345SEAV259-1	26512	SCREEN, SELF-LOCKING	EA 1
					9	PANEL ASSEMBLY	



ELIHMO04

Figure 4. Plate Assembly Electrical (A1A1).

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION		(3)	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE					QTY INC IN UNIT U/M
4	1	XDHZZ	5305-00-889-2998	MS3526-216	96906	SCREW, MACHINE	EA 7
4	2	XDHZZ	5310-OD-187-2397	AN960PD4L	88044	WASHER, FLAT	EA 13
4	3	XOHZL	5310-00-807-1471	MS21042L04	96906	NUT, SELF-LOCKING, EX.....	EA 9
4	4	XDHHH		134SEAV2512-I	26512	CIRCUIT CARD ASSY.....	EA 1
4	5	PAHZZ	6625-00-051-3659	301-1	15309	RECTIFIER BEX REF DES MRI USED ON SERIAL NOS 1 THRU 75, REF	EA 1
						DES R8 USED ON SERIAL NOS 76 THRU 100 SCREWHMACHINE	EA 2
4	6	XDH2Z	5305-00-984-4977	MS352U6-220	96906	WASHERFLAT	EA 2
4	7	XOHZZ	5310-00-187-2397	AN96OPD4L	88044	NUT, SELF-LOCKING, EX.....	EA 2
4	8	XDHZZ	5310-00-807-1471	MS21042L04	96906	TRANSFORMER, POWER, S REF DES T2 ..USED ON SERIAL NOS 1 THRU 75,	EA 2
4	9	PAHZZ	5950-00-709-1085	4C14	97102	REF DES TI USED ON SERIAL NOS 76 THRU 100 SCREW, MACHINE	EA 1
4	10	XDHZZ	5305-00-993-0190	MS35206-214	96906	TRANSFORMER REF DES T1. USED ON SERIAL NOS THRU 75, REF DES.....	EA 4
4	11	PAHZZ	5950-00-042-6449	4C2	97102	T2 USED ON SERIAL NOS 76 THRU 100.....	EA 1
4	12	XDHZZ		1345EAV2515-11	26512	PLATE, MOUNTING	EA 1
4	13	PAHZZ	5905-00-542-8048	RV4NAYSB104A	81349	RESISTOR, VARIABLE	EA 1
					11		




Figure 5. Circuit Card Assembly (A1A1A1).

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION		(3)	(4)	(5)	(6)	(7) DESCRIPTION	(8)	
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	QTY INC IN	
						U/M UNIT		
5	1	PAHZZ	5961-00-581-8066	IN69A	81349	SEMICONDUCTOR, DEVICE.....	EA	4
5	2	PAHZZ	5905-00-1731-2003R	C20GF204J	81349	RESISTOR	EA	1
5	3	PAHZZ	5905-00-279-1926	RC42GF241J	81349	RESISTOR, FIXED, COMP	EA	1
5	4	PAHZZ	5940-00-4177-6353	GT11HBC	26512	TERMINAL, STUD	EA	23
5	5	PAHHH	5940-00-477-6357	134SEAV2514-1	26512	TERMINAL BOARD	EA	1
5	6	PAHZZ	5910-00-984-7512	109D106X9050C2	15629	CAPACITOR, FIXED, ELEC	EA	2
5	7	PAHZZ	5905-00-106-9344	RCR20GBO1JS	81349	RESISTOR	EA	1
5	8	PAHZZ	5910-00-807-5570	CPO5AIKEIJ4K3	81349	CAPACITOR, FIXED, PAP	EA	1
5	9	PAHZZ	5910-00-822-2581	CP05AIKE334K3	81349	CAPACITOR.....	EA	1
5	10	PAHZZ	5905-00-249-4256	RC20GF363J	81349	RESISTOR	EA	2
5	11	PAHZZ	5905-00-855-2544	Rb67V222	81349	RESISTOR, FIXED, WIRE.....	EA	1
					13			







Figure 6. Panel Assembly (A1A2).

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION (a) FIG NO.		(2) (b) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8) QTY INC IN UNIT U/M
							GROUP 010102 PANEL ASSEMBLY (A1A2)	
6	1	PAHZZ	6625-00-043-4539	301-0	15309	AMMETER.....	EA	1
6	2	PAOZZ	5355-00-556-0145	MS91528-1KZB	96906	KNOB	EA	2
6	3	PAHZZ	5930-00-014-1989	1-1909-286	91812	SWITCH ROTARY REF DES 53A USED ON SERIAL NOS.1 THRU 75, REF DES S3USED ON SERIAL NOS.76 THRU 100		
6	4	XDHZZ	5340-00-063-6858	415-211-03-02-00	71279	HANDLE	EA	1
6	5	XDHZZ	5305-00-174-0719	AN501-L032RB	88044	SCREW	EA	2
6	6	PAHZZ	5935-00-089-3190	CA3LO2R10SL4P	71468	CONNECTOR, RECEPTACL.....	EA	4
6	7	XDHZZ	5305-00-957-7815	MS2469354	96906	SCREW	EA	1
6	8	XDHZZ	5310-00-187-2397	AN960PD4L	88044	WASHER, FLAT	EA	4
6	9	XDHZZ	5310-00-807-1471	MNS21042LO4	96906	NUT, SELF-LOCKING, EX.....	EA	4
6	10	XDHZZ	5305-00-980 -4977	HS35206-220	96906	SCREW, MACHINE	EA	1
6	11	PAHZZ	5935-00-502-8155	MS25043-IOC	96906	COVER,ELECTRICAL CO.....	EA	1
6	12	PAHZZ	5935-00-721-0501	HS3102R24-28S	96906	CONNECTOR, RECEPTACL.....	EA	1
6	13	XDHZZ	5305-00-957-7818	MS24693527	96906	SCREW	EA	4
6	14	XDHZZ	5310-00-184-8988	AN960PD6L	88044	WASHER, FLAT	EA	4
6	15	XDHZZ	5310-00-807-1472	MS21042L06	96906	NUT, SELF-LOCKING, EX.....	EA	4
6	16	PAHZZ	5905-00-644-6693	RV4NAYSD104A	81349	RESISTOR.VARIABLENN	EA	1
6	17	XDHZZ		134SEAV2504-15	26512	NAMEPLATE	EA	1
6	18	XDHZZ		AN535-4-4	8B044	SCREW	EA	4
6	19	PAHZZ	5930-00-655-1514	HS35058-22	96906	SWITCH, TOGGLE	EA	1
6	20	PAOZZ	5920-00-280-8342	F02A250V1A	81349	FUSE, CARTRIDGE	EA	2
6	21	PAHZZ	5920-00-892-9311	HKP	71400	FUSEHOLDER, EXTRACTO	EA	2
6	22	PAOZZ	6210-00-519-0448	MS25041-6	96906	LIGHT, INDICATOR REF DES OSI USED ON SERIAL NOS.1 THRU 75, REF.....	EA	1
6	23	PAOZZ	6240-00-155-7836	NS25237-327	96906	DES XOSI USED ON SERIAL NOS.76.... THRU 100 LAMP, INCANDESCENT REF DES XDS1USED ON SERIAL NOS.1 THRU 75,	EA	1
6	24	PAHZZ	5325-00-641-0378	2700-2	71286	REF DES DSI USED ON SERIAL NOS.76THRU 100 STUD ASSEMBLY, TURNL	EA	10
6	25	PAHZZ	5310-00-639-7435	2600SW2	71286	WASHER	EA	10
6	26	PAHZZ	5930-00-655-1582	MS35059-23	96906	SWITCH, TOGGLE	EA	1
6	27	XDHZZ		1345SEAV2509-1	26512	PANEL.....	EA	1
					15			




ELIHM007

Figure 7. Cable Assemblies, Power Electrical CX-9130/ASM-127, CX-9129/ASM-127, CX-9128/ASM-127 (W1, W2, W3).

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION (a) FIG NO.		(2) (b) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8) QTY INC IN UNIT U/M
							GROUP 02 CABLE ASSEMBLY, POWER ELECTRICAL CX-9130/ASM-127 (W1)	
7	1	PAHZZ	5935-00-891-2671	7251	81091	CONNECTOR, PLUG. ELEC IAL N05.76THRU 100 0	EA	1
7	2	XDHZZ	10-109611-4S	77820		CONNECTOR, PLUG, ELEC REF DES P1USED ON SERIAL NOS.1 THRU 75.....	EA	1
7	3	PAHZZ	5935-00-060-3161	10-70506-10S	77820	REF DES W1P2 USED ON SERIAL NOS.76THRU 100 COVER, ELECTRICAL CO.....	EA	1
7	4	XDHZZ		10-90629-6	77820	INSULAION SLVG.....	EA	1
7	5	PAHZZ	5970-00-464-5880	10D-90182-7	77820	INSULATION TAPE	EA	1
7	6	XDHZZ		10-90629-10	77820	INSULA[ION SLVG	EA	1
						GROUP 03 CABLE ASSEMBLY, POWER ELECTRICAL CX-9129/ASM-127 (2)		
7	7	XDHZZ	5935-00-683-2148	10-91062-7	77820	SCREW, MACHINE	EA	4
7	8	PAHZZ	5935-00-258-2681	DP019745-1	71468	SHIELD, ELECTRICAL C	EA	1
7	9	PAHZZ		DPDB28-34PIBA120	71468	CONNECTOR, PLUG, ELEC REF DES J5USED ON SERIAL NOS.1 THRU 75.....	EA	1
7	10	PAHZZ	5970-00-464-5880	10-90182-7	77820	REF DES W2P2 USED ON SERIAL NOS.76THRU 100 INSULATION TAPE	EA	1
7	11	XOHZZ		10-90629-28	77820	INSULATION SLVG.....	EA	1
7	12	XDHZZ	4720-00-462-7758	10-90628-12	77820	TUBING, NONMETALLIC	EA	1
7	13	XDHZZ	4720-00-485-9287	10-90628-20	77820	TUBING, NONMETALLIC	EA	2
7	14	PAHZZ	5935-00-855-4441	10-70506-24	77820	COVER, ELEC, CONN	EA	1
7	15	XDHZZ	5935-00-787-2695	L0-109624-28P	717820	CONNECTOR, PLUG, ELEC REF DES P2USED ON SERIAL NOS.1 THRU 75,	EA	1
						REF DES W2P1 USED ON SERIAL NOS.76THRU 100 GROUP 04CABLE ASSEMBLY, POWER ELECTRICAL CX-9128/ASM-127 I13) -		
7	16	PAHZZ	5935-00-957-0800	10-109618-IS	77820	CONNECTOR, PLUG, ELEC REF DES J7USED ON NOS.I THRU 75,	EA	1
						REF DES H3PI USED ON SERIAL NOS.75THRU 100		
7	17	PAHZZ	4720-00-462-7768	10-90628-8	77820	TUBING, NONMETALLIC	EA	1
7	18	PAHZZ	4720-00-462-7770	10-90628-16	77820	TUBING, NONMETALLIC	EA	1
7	19	PAHZZ	4720-00-48-0581	10-90628-24	77820	TU8ING, NONMETALLIC	EA	1
7	20	PAHZZ	5970-00-464-5880	10-90182-7	77820	INSULATION TAPE	EA	1
7	21	XDHZZ		10-78289A	77820	INSULATION TAPE	EA	1
7	22	PAHZZ	5935-00-851-2881	OPB28-3351B	71468	CONNECTOR, RECEPTACL REF DES J8USED ON SERIAL NOS.1 THRU 75,	EA	1
						REF DES W3P2 USED ON SERIAL NOS.76 THRU 100		
7	23	PAHZZ	5935-00-518-6983	OPD33-11612	71468	SHIELD, ELECTRICAL C	EA	1
7	24	XDHZZ		10-91062-10	77820	SCREW, MACHINE	EA	4
7	25	XDHZZ		22FH632	80539	NUITSELF-LOCKING -	EA	4
7	26	PAHZZ	5340-00-577-8992	10-70506-18	77820	CAP, PROTECTIVE, DUST	EA	1
					17			



ELIHMO08

Figure 8. Case Assembly Combination (MP1).

SECTION II

TM 11-6625-549-40P

(1) ILLUSTRATION (a) FIG NO.		(2) (b) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) FSCM	(7) DESCRIPTION USABLE ON CODE	(8) QTY INC IN UNIT U/M
							GROUP 05 CASE ASSEMBLY COMBINATION (MP1)	
8	1	XDHZZ		8733	82240	PLATE KEEPER.....	EA 2	
8	2	XDHZZ	5320-00-234-1557	MS20426A3-6	96906	RIVET, SOLID	EA 24	
8	3	XOHZZ	5325-00-559-0334	212-12A	71286	RECEPTACLE,IURNLOCK.....	EA 12	
8	4	XDHHH		SKM544	742841	BUMPER ASSEMBLY	EA 4	
8	5	PAHZZ	5340-00-063-6713	SKM645	74284	BUMPER, RUBBER.....	EA 4	
8	6	XDHZZ	AN526C1032-7	188044		SCREW, TRUSS HEAD	EA 4	
8	7	XDHZZ	SKM58B	74284		TUBING, NONMETALLIC.....	EA 1	
8	8	XDHZZ	4820-00-594-7677	30AC	98021	VALVE AIR RELEASE	EA 1	
8	9	XDHZZ	5310-00-850-'137	SKM314	74284	WASHER, FLAT	EA 1	
8	10	XDHZZ	5340-00-063-0666	SKM637	74284	HANDLE, BAIL	EA 1	
8	11	XDHZZ		SKM689	74284	SCOTCHAL, WARNING	EA 1	
8	12	PAHZZ	5340-00-152-0466	81900-738	82240	CATCH	EA 2	
8	13	XDHHH		SKS2330	74284	BUMPER ASS EMBLY -	EA 8	
8	14	PAHZZ	5340-00-019-6CG9	SKM641	74284	BUMPER, RUBBER.....	EA 8	
8	15	XOHZZ		SEELSCREWS10-32X	97539	SCREW	EA 8	
8	16	XOHZZ	5310-00-270-8810	MS35650-104	96906	WASHER	EA 20	
8	17	XDHZZ		SKS2218	74284	WASHER, RUBBER8	EA 8	
8	18	XDHZZ		S516535-188	96906	RIVET, TUBULAR-	EA 4	
8	19	XDHZZ		81900-665	82240	CLAMP ASSEMBLY-	EA 2	
8	201	XDHZZ		KM729	74284	CLIP MANUAL.....	EA 2	
8	21	XDHZZ		SK622702	74284	FLYLAF ANGLE	EA 1	
8	22	XDHZZ		M516535-123	969106	RIVET, TUBULAR.....	EA 41	
8	23	XDHZZ		SKM638	74284	HINGEBUTTG	EA 2	
8	24	XDHHH		SK622703	74284	FLYLEAF ASSEMBLY -	EA 1	
8	25	XOHZZ		SK622715	74284	FLYLEAF	EA 1	
8	26	PAHZZ	5325-00-085-1746	2600-6SW	71286	STUD, TURNLOCK FASTE	EA 2	
8	27	PAHZZ	5310-00-243-2259	2600SW	71286	WASHER, SPLIT	- EA 2	
8	28	PAHZZ	5340-00-972-5299	SKM410	74284	CATCH, CLAMPING	- EA 1	
8	29	XDHZZ		SK622716	742841	HINGE -	EA 1	
8	30	XDHZZ		MS20470AD3	96906	RIVET	EA 3	
8	31	PAHZZ	5340-00-988-8144	MS17160-38	96906	CLIP SPRING TENSION	EA 1	
8	32	XDHZZ		SK622714	74284	GASKET, CASE	EA 1	
					19			

SECTION IV**NATIONAL STOCK NUMBER AND PART NUMBER INDEX**

NOTE: LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.
6625-00-043-4539	6	1	4720-00-484-0581	7	19
5310-00-045-4007	3	3	5935-00-518-6983	7	23
5935-00-060-3161	7	3	6210-00-519-0448	6	22
5340-00-063-0666	8	10	5355-00-556-0145	6	2
5340-00-063-6113	8	5	5325-00-559-0334	8	3
5340-00-C79-6009	8	14	5340-00-577-8992	7	26
5325-C0-085-1746	8	26	5310-00-639-7435	6	25
5935-CC-089-3190	6	6	5905-00-644-6693	6	16
			5930-00-655-1514	6	19
5340-00-152-0466	8	12	5930-00-655-1582	6	26
6240-00-1557836	6	23	5935-00-683-2148	7	8
5305-00-174-0719	6	5	5950-00-709-1085	4	9
5310-00-184-8988	6	14	5935-00-721-0501	6	12
5310-00-187-2397	4	2	5310-00-807-1471	4	3
5310-00-187-2397	4	7	5310-00-807-1471	4	8
5310-00-187-2397	6	8	5310-00-807-1471	6	9
5320-00-234-1557	8	2	5310-00-807-1472	6	15
5310-00-243-2259	8	27	5910-00-807-5570	5	8
			5310-00-850-7137	8	9
5310-00-270-8810	8	16	5935-00-851-2881	7	22
5905-00-279-1926	5	3	5905-00-855-2544	5	11
5935-00-280-2221	7	14	5305-00-889-2998	4	1
5920-00-280-8342	6	20	5305-00-889-3000	3	2
4720-00-462-7768	7	17	5920-00-892-9311	6	21
4720-00-462-1770	7	18	5935-00-957-0800	7	16
5970-00-464-5880	7	5	5340-00-972-5299	8	28
5970-00-464-5880	7	10	5305-00-984-4977	4	6
5970-00-464-5880	7	20	5305-00-984-4977	6	10
5940-00-477-6353	5	4	5305-00-993-0190	4	10
5940-00-477-6357	5	5			

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
AN507-1032R8	88044	6	5	MS35059-23	96906	6	26
				MS35206-214	96906	4	10
				MS35206-216	96906	4	1
AN526C1032-7	88044	8	6	MS35206-220	96906	4	6
AN535-4-4	88044	1	8	MS35206-220	96906	6	10
AN535-4-4	88044	6	18	MS35206-230	96906	3	2
				MS35338-41	96906	3	3
				MS35650-104	96906	8	16
B1900-665	82240	8	19	MS91528-LK2B	96906	6	2
81900-738	82240	8	12	NAS1189-06P8	80205	3	5
B733	82240	8	1	RC42GF241J	81349	5	3
CA3102RIOSL4P	71468	6	6	RV4NAYSD104A	81349	6	16
				RW67V222	81349	5	1i
				SEELSCREWSIO-32X	97539	8	15
CP05A1KE104K3	81349	5	8	SKM314	74284	8	9
CX-9128/ASN-127	80058	1	3	SKM410	74284	8	28
CX-9129/ASM-127	80058	1	2	SKM518	74284	8	7
CX-9130/ASM-127	80058	1	4	SKM544	74284	8	4
OPDB28-33S1B	71468	7	22	SKM637	74284	8	10
DP0828-34PIBA120	71468	7	9	SKM638	74284	8	23
DPD19745-1	71468	7	8	SKM645	74284	8	5
DPD33-11612	71468	7	23	SKM647	74284	8	14
F02A250VIA	81349	6	20	SKM689	74284	8	11
GTLIH8C	26512	5	4	SKM729	74284	8	20
G398-16	26512	3	4	SKS2218	74284	8	17
HKP	71400	6	21	SKS2330	74284	8	13
IN69A	81349	5	1	SK622700	74284	1	5
				SK622702	74284	8	21
				SK622703	74284	8	24
				SK622714	74284	8	32
MS16535-123	96906	8	22	SK622715	74284	8	25
MS16535-188	96906	8	18	SK622716	74284	8	29
MS17160-38	96906	8	31	TS-1982/ASM-127	80063	1	1
MS20426A3-6	96906	8	2	1-19C9-2B6	91812	6	3
MS20470AD3	96906	8	30	10-109611-4S	77820	7	2
MS21042L04	96906	4	3	10-109618-1S	77820	7	16
MS21042L04	96906	4	8	10-109624-28P	77820	7	[5
MS21042L04	96906	6	9	10-70506-IOS	77820	7	3
MS21042L06	96906	6	15	10-70506-18	77820	7	26
MS25041-6	96906	6	22	10-7C0506-24	77820	7	14
MS25043-10OC	96906	6	11	10-78289A	77820	7	21
MS25237-327	96906	6	23	10-9C182-7	77820	7	5
MS3102R24-28S	96906	6	12	10-9C182-7	77820	7	10
MS35058-22	96906	6	19	10-90182-7	77820	7	20

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
10-90628-12	77820	7	12	134SEAV2512-1	26512	4	4
10-90628-16	77820	7	18	134SEAV2514-L	26512	5	5
10-90628-20	77820	7	13	134SEAV2515-11	26512	4	12
10-90628-24	77820	7	19	134SEAV2516-1	26512	1	6
10-90628-8	77820	7	17	212-12A	71286	8	3
10-9C629-10	77820	7	6	22FH632	80539	7	25
10-90629-28	77820	7	11	2600-6Sn	71286	8	26
10-90629-6	71820	7	4	2600SW	71286	8	27
10-91062-10	77820	7	24	26005W2	71286	6	25
10-91062-7	77820	7	7	2700-12 30AC	71286	6	24
134SEAV2504-15	26512	6	17	301-0	15309	6	1
134SEAV2504-17	26512	1	7	301-1	15309	4	5
134SEAV2508-1	26512	2	1	4C14	97102	4	9
134SEAV2508-3	26512	3	1	4C2	97102	4	11
1345SEAV2509-1	26512	3	6	415-211-03-02-00	71279	6	4
134SEAV2509-1	26512	6	27	7251	81091	7	1

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.
5930-00-014-1989	6	3	5961-00-581-8066	5	1
5950-00-042-6449	4	11	4820-00-594-7677	8	8
6625-00-051-3659	4	5	5325-00-641-0378	6	24
5340-00-057-7773	3	4	5935-00-787-2695	7	15
5340-00-063-6858	6	4	5910-00-822-2581	5	9
5905-00-106-9344	5	7	5935-00-855-4441	7	14
5905-00-171-2003	5	2	5935-00-891-2671	7	1
5310-00-187-2397	4	7	6625-00-964-9903	1	3
5905-00-249-4256	5	10	6625-00-964-9905	1	4
4720-00-462-7758	7	12	6625-00-964-9906	I	2
4720-00-485-9287	7	13	1610-00-967-9649	1	1
5935-00-502-8155	6	11	5910-00-984-7512	5	6
5905-00-542-8048	4	13	5340-00-988-8144	8	31

LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
AN960PD4L	88044	4	2	RC20GF204J	81349	5	2
AN960PD4L	88044	4	7	RC20GF36J	81349	5	10
AN960PD4L	88044	6	8	RCR20G101JS	81349	5	7
AN960PD6L	88044	6	14	RV4NAYS104A	81349	4	13
CP05A1KE334K3	81349	5	9	109D106X9050C2	56289	5	6

ADDITIONAL LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.
5935-00-258-2681	7	9
5305-00-957-7815	6	7
5305-00-957-7818	6	13

ADDITIONAL LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FSCM	FIG. NO.	ITEM NO.
MS24693527	96906	6	13
MS2469354	96906	6	7

By Order of the Secretary of the Army:

BERNARD W. ROGERS
General, United States Army
Chief of Staff

Official:

J. C. PENNINGTON
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-36A, Direct and General Support maintenance requirements for AN/ASM-127.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

THEN... JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:PAGE
NO.PARA-
GRAPHFIGURE
NO.TABLE
NO.

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 JUL 78

PREVIOUS EDITIONS
ARE OBSOLETE.P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 037692-000

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](http://chicagomachinerymovers.com)