TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

MODULAR COLLECTIVE PROTECTION EQUIPMENT (MCPE) (NSN 4240-00-229-2610)

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS, MISSOURI, TO MEET YOUR NEEDS WHILE WE REPLENISH OUR REGULAR STOCK.

HEADQUARTERS, DEPARTMENT OF THE ARMY

10 SEPTEMBER 1985

TECHNICAL MANUAL

No. 11-7440-294-24P

HEADQUARTERS DEPARTMENT OF THE ARMY Washington, DC, 10 September 1985

ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

MODULAR COLLECTIVE PROTECTION EQUIPMENT (MCPE) (NSN 4240-00-229-2610)

Current as of 1 April 1985

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-ME-MP, Fort Monmouth, New Jersey 07703-5007. A reply will be furnished direct to you.

TABLE OF CONTENTS

			Illus
		Page	Figure
Section I.	Introduction	1	
II.	Repair Parts List	5	
Group 00	Modular Collective Protection Equipment	5	1
. 01	Duct Assembly, Transition	7	2
02	Platform Assembly	9	3
03	Support Assembly (No parts authorized)		
04	Bracket Assembly, Cradle	. 11	4
Section III.	Special Tools List (Not applicable)		
IV.	National Stock Number and Part Number Index	. 12	

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support and general support maintenance of the MCPE. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

- PA Item procured and stocked for anticipated or known usage.
- XB Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

- 0 Support item is removed, replaced, used at the organizational level.
- F Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

- F The lowest maintenance level capable of complete repair of the support item is the direct support level.
- Z Nonreparable. No repair is authorized.

(3) *Recoverability code*. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Code

Definition

- Z Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- F Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.

c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced. f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. Items that are included in kits and sets are listed below the name of the kit or set indicated in the quantity incorporated in unit column.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a twocharacter alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publication pertains to the MCPE and its components:

TM 11-7440-294-14, Modular Collective Protection Equipment (MCPE)

b. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN'S are established and published, submit exception requisitions to Commander: US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-MM, Fort Monmouth, NJ 07703-5007 for the part required to support your equipment.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings and divided into the same groups.

(2) Second. Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.


(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, crossreferenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4.1)



EL8X0001

Figure 1. Modular Collective Protection Equipment (MCPE) (Sheet 1 of 2).





Figure 1. Modular Collective Protection Equipment (MCPE) (Sheet 2 of 2).

	REPAIN	R PARTS 1	LIST						
(1) ILLU	5-	(2)	(3)	(4)	(5)	(6)		(7)	(8) QTY
TRAT	ION (b)	SMR CODE	NATIONAL STOCK	FSCM	PART NUMBER	DESCRIPTION	USABLE	U∖M	INC IN
FIG. NO.	ITEM NO.		NUMBER				ON CODE		UNIT
	101					GROUP 00 MODULAR COLLECTIVE F			
1	1	PAFZZ	4240-01-145-4714	81361	M10	ENTRANCE, PROTECTIVE		EA	1
			1210 01 115 1711						
1	2	XBFZZ		81361	D5-19-6628	VALVE ASSY, AIR FLOW		EA	1
1	3	XBFZZ		81361	C5-19-6170-40	CABLE ASSY, SP ELECT		EA	1
1	4	XBFZZ		81361	C5-19-6162-10	CABLE ASSY, SP ELECT		EA	1
1	5	PAFZZ	4720-01-063-4567	81361	C5-19-6181-2030	HOSE,AIR DUCT		EA	2
1	6	PAFZZ	4240-01-057-3378	81361	E5-19-6376	CONTROL MODULE UNIT		EA	1
1	7	PAFZZ	4730-01-049-0805	81361	C5-19-6182	COUPLING, AIR DUCT		EA	1
1	8	PAFZZ	4720-01-074-9220	81361	C5-19-6181-10	HOSE, AIR DUCT		EA	6
1	9	PAFZZ	4240-01-068-8645	81361	E5-19-6387	POWER DISTRIBUTION		EA	1
1	10	PAFZZ	4240-00-237-0227	81361	М56	FLTR UNIT, GAS PARCLT		EA	1
1	11	XBOFF		80063	SC-D-913385	DUCT ASSY, TRANS (SEE FIGURE	2 FOR BREAKDOWN)	EA	1
1	12	XBOFF		80063	SC-D-913383	PLATFORM ASSEMBLY (SEE FIGUE	RE 3 FOR BREAKDOWN)	EA	1
1	13	XBFZZ		80063	SC-D-913366	SUPPORT ASSEMBLY		EA	1
1	14	PAFZZ	5305-01-014-7483	96906	MS35307-306	SCREW, CAP, HEXAGON H		EA	8
1	15	PAFZZ	5310-00-933-8121	96906	MS35338-139	WASHER,LOCK		EA	18
1	16	PAFZZ	5310-00-582-5677	96906	MS15795-810	WASHER, FLAT		EA	18
1	17	XBFZZ		80063	SC-D-681076-38	NUT, BLIND		EA	8
1	18	XBFFF		80063	SC-D-913400	BRACKET ASSY,CRADLE (SEE FIG	GURE 4 FOR BREAKDOWN)	EA	1
1	19	PAFZZ	5306-00-637-9674	96906	MS35307-336	BOLT, MACHINE		EA	12
1	20	PAFZZ	5310-00-974-6623	96906	MS35338-140	WASHER,LOCK		EA	12
1	21	PAFZZ	5310-00-802-4701	96906	MS15795-813	WASHER, FLAT		EA	12
1	22	XBFZZ		80063	SC-D-681076-54	NUT,BLIND		EA	12
1	23	PAFZZ	5305-00-021-3668	96906	MS35307-310	SCREW, CAP, HEXAGON H		EA	8
1	24	XBFZZ		80063	SC-D-681076-46	NUT, BLIND		EA	8
1	25	PAFZZ	5305-00-207-8253	96906	MS35307-308	SCREW, CAP, HEXAGON H		EA	8
1	26	XBFZZ		80063	SC-D-681076-44	NUT, BLIND		EA	8




EL8X0003

Figure 2. Duct Assembly, Transition.

SECTI	ON II					TM11-7440-294-24P		
(1) ILLUS	_	(2)	(3)	(4)	(5)	(6)	(7)	(8) QTY
TRATI	ON	SMR	NATIONAL	FSCM	PART	DESCRIPTION	U∖M	INC
(a)	(b)	CODE	STOCK		NUMBER	USABLE		IN
FIG.	ITEM		NUMBER			ON		UNIT
NO.	NO.					CODE		
						GROUP 01 DUCT ASSEMBLY. TRANSITION		
2	1	XBFZZ		80063	SC-D-913387	BRACKET, TRANSITION	EA	1
2	2	XBFZZ		80063	SC-D-913389	HOUSING, TRANSITION	EA	1
2	3	XBFZZ		80063	SC-C-913388	PLATE, TRANSITION	EA	1
2	4	XBFZZ		80063	SC-B-913386	GASKET, DUCT	EA	1

TM 11-7440-294-24P



ET87.0004

1

Figure 3. Platform Assembly.

						TM11-7440-294-24P			
(1)	ON II	(2)	(3)	(4)	(5)	(6)		(7)	(8)
ILLUS TRATI (a) FIG. NO.		SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	U\M	QTY INC IN UNIT
						GROUP 02 PLATFORM A	ASSEMBLY		
3	1	XBFZZ		80063	SC-C-913406-002	SNAP CHAIN ASSEMBLY	ζ.	EA	1
3	2	XBFZZ		80063	SC-C-913406-001	SNAP CHAIN ASSEMBLY	Z	EA	1
3	3	XBFZZ		56996	B4024798	PLATFORM WLD ASSY		EA	1
3	4	XBFZZ		80063	SC-C-913415	PIPE,WELDED ASSY		EA	1
3	5	PAFZZ	5306-00-655-6170	96906	MS35307-338	SCREW		EA	8
3	6	XBFZZ		80063	SC-D-913378-001	STEP SUPPORT ASSY		EA	1
3	7	PAFZZ	5310-00-880-5977	96906	MS15795-811	WASHER, FLAT		EA	18
3	8	PAFZZ	5310-00-974-6623	96906	MS35338-140	WASHER, LOCK		EA	18
3	9	PAFZZ	5310-00-767-0445	96906	MS51971-2	NUT, PLAIN HEXAGON		EA	18
3	10	XBFZZ		80063	SC-D-913377	STEP		EA	1
3	11	XBFZZ		96906	MS24693-C118	SCREW,FLAT HEAD		EA	1
3	12	XBFZZ		80063	SC-D-913378-002	STEP SUPORT ASSY		EA	1
3	13	XBFZZ		80063	SC-C-866485	LANYARD ASSEMBLY		EA	1
3	14	PAFZZ	5305-00-854-9351	96906	MS24630-23	SCREW PAN HEAD		EA	1
3	15	XBFZZ		96906	MS17988 C812	PIN QUIK RELEASE		EA	1
3	16	XBFZZ		56996	B4024797	PLATFORM WLD ASSY		EA	
3	17	XBFZZ		80063	SC-D-913414	GRATE WELDED ASSY		EA	
3	18	XBFZZ		80063	SC-C-913409	PIPE WELDED ASSY		EA	
3	19	XBFZZ		56996	B4024796	PLATFORM WLD ASSY		EA	
3	20	XBFZZ		80063	SC-D-913382	PLATFORM SUB ASSY		EA	
3	21	XBFZZ		96906	MS24693096	SCREW		EA	8
3	22	XBFZZ		56996	B4024799	CLINCH NET		EA	18
3	23	XBFZZ		80063	SC-C-913411	FLOOR BLANGE		EA	8
3	24	XBFZZ		80063	SC-C-913363	ARM BRACKET		EA	
3	25	PAFZZ	5306-00-637-9675	96906				EA	




Figure 4. Bracket Assembly, Cradle.

SECTI	ON II					TM11-7440-294-24P			
(1) ILLUS	-	(2)	(3)	(4)	(5)	(6)		(7)	(8) QTY
TRATI (a) FIG. NO.	CON (b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	U∕M	INC IN UNIT
						GROUP 04 BRACKET ASSE	BLY CRADLE		
4	1	XBFZZ		80063	SC-C-913397	GASKET		EA	1
4	2	XBFZZ		80063	SC-C-913391	GASKET		EA	1
4	3	XBFZZ		80063	SC-C-913396	GASKET		EA	1
4	4	XBFZZ		80063	SC-C-913392	GASKET		EA	1
4	5	XBFZZ		80063	SC-D-913399	CRADLE BRACKET		EA	1
4	6	XBFZZ		80063	SC-C-913393	GASKET		EA	1
4	7	XBFZZ		80063	SC-C-913395	GASKET		EA	1
4	8	XBFZZ		80063	SC-C-913394	GASKET		EA	1

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL	FIGURE	ITEM
STOCK NUMBER	NO.	NO.
5305-00-021-3668	1	23
5305-00-207-8253	1	25
4240-00-237-0227	1	10
5310-00-582-5677	1	16
5306-00-637-9674	1	19
5306-00-637-9675	3	25
5306-00-655-6170	3	5
5310-00-767-0445	3	9
5310-00-802-4701	1	21
5305-00-854-9351	3	14
5310-00-880-5977	3	7
5310-00-933-8121	1	15
5310-00-974-6623	1	20
5310-00-974-6623	3	8
5305-01-014-7483	1	14
4730-01-049-0805	1	7
4240-01-057-3378	1	6
4720-01-063-4567	1	5
4240-01-068-8645	1	9
4720-01-074-9220	1	8
4240-01-145-4714	1	1

TM11-7440-294-24P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX


FSCM	PART NUMBER	NATIONAL STOCK NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	NATIONAL STOCK NUMBER	FIGURE NO.	ITEM NO.
56996	B4024796		3	19	80063	SC-D-913399		4	5
56996 56996	B4024797		3 3	16 3	80063	SC-D-913400		1 3	18
56996	B4024798 B4024799		3	3 22	80063	SC-D-913414		3	17
81361	C5-19-6162-10		1	4					
81361	C5-19-6170-40		1	3					
81361	C5-19-6181-10	4720-01-074-9220	1	8					
81361	C5-19-6181-2030	4720-01-063-4567	1	5					
81361	C5-19-6182	4730-01-049-0805	1	7					
81361	D5-19-6628		1	2					
81361	E5-19-6376	4240-01-057-3378	1	6					
81361	E5-19-6387	4240-01-068-8645	1	9					
96906	MS15795-810	5310-00-582-5677	1	16					
96906	MS15795-811	5310-00-880-5977	3	7					
96906 96906	MS15795-813 MS17988-C812	5310-00-802-4701	1 3	21 15					
96906 96906	MS17988-C812 MS24630-23	5305-00-854-9351	3	14					
96906	MS24693-C118	5565 66 651 5551	3	11					
96906	MS24693-C96		3	21					
96906	MS35307-306	5305-01-014-7483	1	14					
96906	MS35307-308	5305-00-207-8253	1	25					
96906	MS35307-310	5305-00-021-3668	1	23					
96906	MS35307-332	5306-00-637-9675	3	25					
96906	MS35307-336	5306-00-637-9674	1	19					
96906	MS35307-338	5306-00-655-6170	3	5					
96906	MS35338-139	5310-00-933-8121	1	15					
96906 96906	MS35338-140	5310-00-974-6623	1	20 8					
96906 96906	MS35338-140 MS51971-2	5310-00-974-6623 5310-00-767-0445	3 3	9					
81361	M10	4240-01-145-4714	1	1					
81361	M56	4240-00-237-0227	1	10					
80063	SC-B-913386		2	4					
80063	SC-C-866485		3	13					
80063	SC-C-913363		3	24					
80063	SC-C-913388		2	3					
80063	SC-C-913391		4	2					
80063	SC-C-913392		4	4					
80063 80063	SC-C-913393		4 4	6 8					
80063	SC-C-913394 SC-C-913395		4	° 7					
80063	SC-C-913396		4	3					
80063	SC-C-913397		4	1					
80063	SC-C-913406-001		3	2					
80063	SC-C-913406-002		3	1					
80063	SC-C-913409		3	18					
80063	SC-C-913411		3	23					
80063	SC-C-913415		3	4					
80063	SC-D-681076-38		1	17					
80063	SC-D-681076-44		1 1	26 24					
80063 80063	SC-D-681076-46 SC-D-681076-54		1	24 22					
80063	SC-D-913366		1	13					
80063	SC-D-913377		3	10					
80063	SC-D-913378-001		3	6					
80063	SC-D-913378-002		3	12					
80063	SC-D-913382		3	20					
80063	SC-D-913383		1	12					
80063	SC-D-913385		1	11					
80063	SC-D-913387		2	1					
80063	SC-D-913389		2	2					

	\sim		ĺ		HANGES T	EQUIPMENT TECHN				
7	2"1	\backslash		SOM	THINE	WRONG WITH	THIS PUBLICATION?			
			DOPE AL FORM. C	JOT DOWN THE BOUT IT ON THIS AREFULLY TEAR I LD IT AND DROP MAIL'		: (PRINT YOUR UNIT'S C Commander Stateside Arm ATTN: AMST Stateside, N.J. SENT 10 July	y Depot A-US 07703-5007			
PUBLICA	ATION NU	MBER		PUBLICAT	ION DATE	PUBLICATION TITLE				
	TM 11-7	440-294-3	24P	23 J	an 78	Modular Collective Pro	otection Equipment (MCPE)			
		POINT WH	ERE IT IS	IN THIS SPACE TE			· ·			
PAGE NO	PARA- GRAPH	FIGURE NO	TABLE NO	AND WHAT SHOU	ILD BE DON	E ABOUT IT:				
33				For item 2, c. Reason: Acc	hange the NS suracy.	SN to read: 5835-00-134	-9186.			
44		19			Identify the cover on the junction box (item no. 5). Reason: It is a separate item and is not called out on figure 19.					
45				Add the cove Reason: Sam		on box as an item in th	e listing for figure 19.			
					•					
						. E				
						SAMPLE				
						SAI				
RINTED		ADE OR T		D TELEPHONE NUMB 999-1776		RE M. De	Spirit of			
A . 50	RM 20	28-2		EVIOUS EDITIONS			TS TO KNOW ABOUT YOUR			


AND GIVE IT TO YOUR HEADQUARTERS

REVERSE OF DA FORM 2028-2 TEAR ALONG PERFORATED LINE FILL IN YOUR UNIT'S ADDRESS τ FOLD BACK DEPARTMENT OF THE ARMY AND F TENT OF T BOOD 314 POSTAGE AND FEES PAID DEPARTMENT OF THE ARMY U.S. MAIL OFFICIAL BUSINESS 1 OFFICIAL BUSINESS PENALTY FOR PRIVATE USE \$300 S AMP ł 1 Z Commander US Army Communications-Electronics Command and Fort Monmouth ATTN: AMSEL-ME-MP Fort Monmouth, New Jersey 07703-5007


	\sim			RECOM	MENDED C	HANGES T	D EQUIPMENT TECHNICAL PUBLICATIONS
$\overline{7}$	2111				SOM	ETHING	WRONG WITH THIS PUBLICATION?
$\left(\right)$)	THEN	107.00			: (PRINT YOUR UNIT'S COMPLETE ADDRESS)
5			DOPE AL	BOUT IT	WN THE ON THIS LY TEAR	, _T	
\square		Z		LD IT A	ND DROP		SENT
PUBLIC	ATION NU TM 11	MBER •7440-294	-74P			t 1985	PUBLICATION TITLE Modular Collective Protection Equipment (MCPE)
BE EXAC	T PIN-						
PAGE NO	PARA- GRAPH	FIGURE	TABLE NO				E ABOUT IT:
				:			
PRINTED	NAME GR	ADE OR T	ITLE AND	TELED		ER SIGN HE	DC
	. , on		···, Aidb	- 1666FM		LA BIGN ME	nc
	AM 304	20.2	PA	EVIOUS	DITIONS		
DA . 🕄	L 79 ZU	۲0-۲		EOBSOL		RE	SIF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR ECOMMENDATION MAKE A CARBON COPY OF THIS ND GIVE IT TO YOUR HEADQUARTERS



	\sim			RECOMM	ENDED CHAI	NGES T	D EQUIPMENT 1	ECHNICAL PUBLICATIO)NS
//	511	\mathbf{N}			Somet	NING	WRONG	WITH THIS PUBLICATIO	DN?
			DOPE AL FORM. C	BOUT IT AREFUL LD IT AI	WN THE ON THIS LY TEAR IT ND DROP IT	FROM		NIT'S COMPLETE ADDRESS	
PUBLIC	ATION NU	MBER			PUBLICATION	DATE	PUBLICATION TI	TLE	
	TM 11	-7440-294	-24P		10 Sept 1		Modular Collec	tive Protection Equipment (MCPE
BE EXAC	T PIN-	POINT WH	ERE IT IS		S SPACE TELL				
NO	GRAPH	NO	NO						
RINTED	NAME, GRA	ADE OR TI	TLE, AND	TELEPHO		SIGN HE	RE		
)A , FO	202	28-2		EVIOUS E		RE	COMMENDATION I	WANTS TO KNOW ABOUT Y MAKE A CARBON COPY OF TI IR HEADQUARTERS	'OUR HIS



/	\sim	· · · · · · · · · · · · · · · · · · ·	1	RECOMM	IENDED CHAN	IGES TO	D EQUIPMENT TECHNICAL PUBLICATIONS		
$\overline{7}$	5.1				SOMET	NINE	WRONG WITH THIS PUBLICATION?		
$(\langle$) (THEN	IOT DO	W'N THE	FROM	: (PRINT YOUR UNIT'S COMPLETE ADDRESS)		
2		3	DOPE AL	BOUT IT	ON THIS LY TEAR IT				
\bigcap		1 T		LD IT AI	ND DROP IT	DATE	SENT		
DATE SENT									
PUBLIC	ATION NU				PUBLICATION		PUBLICATION TITLE		
	<u></u>	7440-294-			10 Sept 1		Modular Collective Protection Equipment (MCPE)		
PAGE	PARA-	FIGURE	TABLE		S SPACE TELL HAT SHOULD				
NO	GRAPH	NO	NO						
1									
		l i							
PRINTED	NAME, GR	ADE OR T	ITLE, AND	TELEPH	ONE NUMBER	SIGN HE	RE		
				EVICINE					
)A . 50	*** 20	28-2		E OBSOL	EDITIONS ETE.	96	SIF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR COMMENDATION MAKE A CARBON COPY OF THIS ID GIVE IT TO YOUR HEADQUARTERS		



By Order of the Secretary of the Army:

JOHN A. WICKHAM JR. General, United States Army Chief of Staff

Official:

DONALD J. DELANDRO Brigadier General, United States Army The Adjutant General

Distribution:

To be distributed in accordance with special list.

* U.S. GOVERNMENT PRINTING OFFICE : 1987 0 - 181-421 (70497)

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<u>http://www.liberatedmanuals.com/</u>>Free Military and Government Manuals

Sincerely
Igor Chudov
<u>http://igor.chudov.com/</u>
Chicago Machinery Movers