#### **Supersedes Copy Dated December 1990**

## COMBAT VEHICLE PRE-COMBAT CHECKLIST FOR:

LAUNCHER, ROCKET, ARMORED VEHICLE MOUNTED: M270 (1055-01-192-0357, 1055-01 -192-0358, 1055-01-251-9756 and 1055-01-329-6826) AND

CARRIER, MULTIPLE LAUNCH ROCKET SYSTEM, M993 (2350-01-091-5405)

#### **MULTIPLE LAUNCH ROCKET SYSTEM**

#### **WARNING**

THIS CHECKLIST IS TO BE USED ONLY WHEN AUTHORIZED BY THE COMMANDER, IT IS NOT INTENDED TO BE USED IN PLACE OF THE PMCS.

#### NOTE

THIS CHECKLIST CONTAINS CHECKS TO BE PERFORMED BEFORE COMBAT TO ASSURE VEHICLE IS MISSION CAPABLE. THE CHECKLIST SEQUENCE NUMBERS HEREIN CORRESPOND TO THOSE PMCS CHECKS IN THE OPERATOR'S TM.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

By order of the Secretary of the Army

CARL E. VUONO General, United States Army Chief of Staff

#### Official:

PATRICIA P. HICKERSON
Brigadier General, United States Army
The Adjutant Genera/

#### Distribution:

To be distributed in accordance with DA Form 12-32E, Block 3215 requirements for operator/crew maintenance level for TM 9-1425-646-PCL.

DEPARTMENT OF THE ARMY 29 JULY 1991

#### TM9-1425-646-PCL

#### TM 9-1450-646-10

- 1. VEHICLE EXTERIOR: Check Exterior Fire Extinguisher Handle For Lacing And Seal. Walk Around And Check For Fluid Leaks, Damage, Tampering, And Missing Parts That Prevent Operation.
- 3. FIXED FIRE EXTINGUISHER SYSTEM: All Bottles Are Present And Secure. Check For Seal And Pressure.
- VENTILATION SYSTEM CHECK: Check Fan Control Switch In LO, MED, And H1. Check Vent Fan Override Switch.
- **8.** ENGINE/INSTRUMENTS: Start Engine. Check Instruments/Warning Lights.
- **10. COMMUNICATION SYSTEM:** Intercom Operational.

#### 11. NBC SYSTEM CHECK

TM 9-1425-646-10 (1055-01-192-0357 & 1055-01-192-0358) TM 8-1425-646-10-1 (1055-01-251-9756 & 1055-01-328-6826)

- LLM EXTERIOR: Walk-around And Check For Fluid Leaks, Obvious Damage, Tampering And Missing Parts.
- 2. LLM STARTUP:

# NOTE: INSURE CARRIER ENGINE IS RUNNING\*\*\*\*

- Perform Startup Procedures.
- Check LRU Bit Lights.
- Ž Check For Fault Prompt On FCP.
- 3. RESOLVER CHECK:
  - Azimuth Resolver Readout Between -1.8 Mils And + 1.8 Mils.
  - Elevation Resolver Readout Between -2.0 Mils And + 2.0 Mils,
- 4. COMM CHECK: Check For Fault Prompt On FCP.

PIN: 047514-000

### This fine document...

Was brought to you by me:



### <u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=http://www.liberatedmanuals.com/>Free Military and Government Manuals</A>

- SincerelyIgor Chudov<a href="http://igor.chudov.com/">http://igor.chudov.com/</a>
- Chicago Machinery Movers