

**\*TM 1-1520-228-CL**

**OPERATOR'S AND CREWMEMBER'S  
CHECKLIST  
OH-58A/C HELICOPTER  
10 May 2006**

**DISTRIBUTION STATEMENTS A: Approved for public release; distribution is unlimited.**

\* This manual supersedes TM 1-1520-228-CL, 29 July 2005.

**HELICOPTER AND SYSTEMS**

**BEFORE EXTERIOR CHECK**

1. Publications – Check.
2. Covers, locking devices, tiedowns (except main rotor), and grounding cables – Removed and secured.
3. Ignition Switch – On.
4. Cockpit – Check.

**EXTERIOR CHECK**

1. Cabin interior – Check.
2. Fuselage (Area 1) – Check.
3. Tailboom (Area 2) – Check, tiedown removed.
4. Main rotor blade (Area 2) – Check, tiedown removed.
5. Tail rotor gear box – Check.
6. Tail rotor – Check.
7. Tailboom (Area 3) – Check.
8. Fuselage (Area 4) – Check.
9. Main rotor blade (Area 4) – Check.
10. Fuselage top – Check.
11. Main rotor system – Check.
12. Fuselage (Area 5) – Check.
13. Cockpit – Check.
14. Fuselage (Area 6) – Check.
15. Crew and passenger briefing – Complete.

**BEFORE STARTING ENGINES**

1. Shoulder harness lock(s) – Check.
2. Overhead switches and circuit breakers – Set.
3. GPU – Connect for GPU – start.
4. Avionics – Off and set.
5. Instrument panel instruments & switches – Check and set.
6. Flight controls – Check and set.
7. Throttle – Check. Move to open, then to idle stop; press idle release and close.

**STARTING ENGINE**

1. Fireguard – Post if available.
2. Rotor Blades – Check clear and untied.
3. Engine – Start.
4. GPU – Disconnect; then BAT switch – BAT, if required.
5. N2 – Stabilized.
6. THROTTLE ADJUST – 70 percent N1.
7. GEN switch – GEN.
8. DC amps – check 60 or less.
9. INV switch – INV.
10. Avionics – On.

**ENGINE RUNUP**

1. Engine and transmission instruments – Check.

2. Throttle – Slowly increase to open. Set N2 to 100 percent.
3. HEAT and DEICE systems – Check if use is anticipated; then set as required.
4. Avionics – Check as required.
5. Flight Instruments – Check and set.
6. Doors, armor side panels, and seat belts – Secure.
7. Health Indicator Test (HIT) – Check.
8. Deceleration check – Perform if required.

**BEFORE TAKEOFF**

1. N2 – 100 percent.
2. Systems – Check.
3. Crew, passengers, mission equipment, and seat belts – Check.
4. Avionics – As required.

**HOVER CHECK**

1. Flight controls – Check.
2. Engine and transmission instruments – Check.
3. Flight instruments – Check as required.
4. Power – Check.

**BEFORE LANDING**

1. Crew, passenger, and mission equipment – Check.
2. Landing light – As required.

**ENGINE SHUTDOWN**

1. Throttle – Engine idle: stabilize TOT for two minutes.
2. FORCE TRIM switch – FORCE TRIM.
3. FUEL BOOST switch – OFF.
4. NGV/LDG LTS – OFF.
5. Control frictions – On.
6. Avionics – OFF.
7. Overhead switches and circuit breakers – Set.
8. Battery charge – Check.
9. Throttle – Close.
10. Overhead switches – OFF as required.
11. Ignition switches – OFF (Keys as required).

**O12. Doors – Close immediately after exiting.**

**BEFORE LEAVING THE HELICOPTER**

1. Main rotor blades – Tie down as required.
2. Walk-around – Complete.
3. DA Form 2408-12 and 2408-13-1 – Complete.
4. Secure helicopter – As required.

**THRU-FLIGHT CHECKLIST**

**PREFLIGHT**

1. Covers, locking devices, tiedowns (except main rotor), and grounding cables – Removed and secured.
2. Ignition switch – On.
- 3. Cargo/loose equipment – Check.
- 4. Auxiliary fuel cell – Check.
5. Passenger and seat belts – Check.
6. Hydraulic reservoirs/servos and flight controls – Check.
7. Transmission compartment – Check.
8. Fuel – Check quantity.
9. Main rotor blade – Check, tiedown removed.
10. Tail rotor gearbox – Check.
11. Tail rotor – Check.

12. Engine Oil Level – Check.
13. Main rotor system – Check condition.
14. Crew and passenger briefing – Complete.

**BEFORE STARTING ENGINE**

1. ANTI COLL LTS switch – As required.
2. POS LTS switch – As required.
3. BAT switch – As required.
4. GPU – Connect for GPU start.
5. Flight control – Check and set.
6. Throttle – Check. Move to open, then to idle stop; press idle release and close.

**STARTING ENGINE**

1. Fireguard – Post if available.
2. Rotor Blades – Check clear and untied.
3. Engine – Start.
4. GPU – Disconnect; then BAT switch – BAT, if required.
5. N2 – Stabilized.
6. THROTTLE ADJUST – 70 percent N1.
7. GEN switch – GEN.
8. DC amps – Check 60 or less.
9. INV switch – INV.
10. Avionics – On.

**ENGINE RUNUP**

1. Engine and transmission instruments – Check.
2. Throttle – Slowly increase to open. Set N2 to 100 percent.
3. Flight instruments – Check and set.
4. Doors, armor side panels; and seat belts – Secure.

**BEFORE TAKEOFF**

1. N2 – 100 percent.
2. Systems – Check.
3. Crew, passengers, mission equipment, and seat belts – Check.
4. Avionics – As required.

By Order of the Secretary of the Army:

**PETER J. SCHOOMAKER**  
*General, United States Army*  
*Chief of Staff*

Official:

  
JOYCE E MORROW

*Administrative Assistance to the  
Secretary of the Army*

0612303

To be distributed in accordance with initial Distribution Number (IDN) 310239, requirements for TM 1-1520-228-CL.

**TM 1-1520-228-CL**  
**EMERGENCY PROCEDURES**

**ENGINE MALFUNCTION**

**ENGINE FAILURE – HOVER**

AUTOROTATE

**ENGINE FAILURE – LOW ALTITUDE/LOW AIRSPEED OR CRUISE**

1. AUTOROTATE.
2. EMER SHUTDOWN.

**ENGINE RESTART – DURING FLIGHT**

1. Throttle – Close.
2. Attempt start.
3. LAND AS SOON AS POSSIBLE.

**ENGINE COMPRESSOR STALL**

1. Collective – Reduce.
2. ENG DEICE AND HTR switches – OFF.
3. LAND AS SOON AS POSSIBLE.

**ENGINE OVERSPEED**

1. Collective – Increase.
2. Throttle – Adjust.
3. LAND AS SOON AS POSSIBLE.

If RPM cannot be controlled manually:

4. AUTOROTATE.

When over a safe landing area, while simultaneously closing the throttle.

5. EMER SHUTDOWN.

**ENGINE UNDERSPEED**

If powered flight with rotor in the green can be accomplished:

LAND AS SOON AS POSSIBLE.

If engine underspeed below 94% N2, then:

1. AUTOROTATE.
2. EMER SHUTDOWN.

**ENGINE SURGES**

If surges in engine RPM are experienced:

1. GOV RPM switch – INCR.
2. Throttle – Adjust to 98% N2.
3. LAND AS SOON AS POSSIBLE.

If engine surges are not controlled in steps 1 and 2 above:

4. AUTOROTATE.
5. EMER SHUTDOWN.

Accomplish during descent, if time permits.

**ROTORS, TRANSMISSION, AND DRIVE SYSTEMS MALFUNCTION**

**LOSS OF TAIL ROTOR EFFECTIVENESS (LTE)**

1. Pedal – Full Left.
2. Cyclic – Forward.
3. As recovery is effected, adjust controls for normal flight.

**MAIN DRIVESHAFT FAILURE**

1. AUTOROTATE – Establish power on autorotational glide.
2. EMER SHUTDOWN after landing.

**CLUTCH FAILS TO DISENGAGE**

1. Throttle – Open.
2. LAND AS SOON AS POSSIBLE.

**MAST BUMPING**

LAND AS SOON AS POSSIBLE.

**FIRE**

**HOT START**

1. STARTER switch – Press.

Continue to press and hold until TOT is less than 200°C.

2. Throttle – Close.

**ENGINE/FUSELAGE/ELECTRICAL FIRE - GROUND**

EMER SHUTDOWN

**ENGINE/FUSELAGE/FIRE-IN-FLIGHT**

If Power-On landing:

1. LAND AS SOON AS POSSIBLE.
2. EMER SHUTDOWN after landing.

If Power – Off landing:

3. AUTOROTATE.
4. EMER SHUTDOWN.

**ELECTRICAL FIRE – FLIGHT**

1. BAT and GEN switches – OFF.
2. LAND AS SOON AS POSSIBLE.
3. EMER SHUTDOWN after landing.

**SMOKE AND FUME ELIMINATION**

1. Vents – Open.
2. DEFOG & vent SWITCH – ON.

**ELECTRICAL SYSTEM MALFUNCTIONS**

**GENERATOR FAILURE – NO OUTPUT**

1. GEN FIELD and GEN & BUS RESET circuit breakers – Check in.
2. GEN switch – RESET, then GEN – Do not hold the switch in the RESET position.

If the generator is not restored, or if it goes off the line again:

3. GEN switch – OFF.
4. Turn OFF all unnecessary electrical equipment.
5. LAND AS SOON AS PRACTICABLE.

**OVERHEATED BATTERY**

1. BAT switch – OFF.
2. LAND AS SOON AS POSSIBLE.
3. EMER SHUTDOWN after landing.

**HYDRAULIC SYSTEM MALFUNCTION**

**HYDRAULIC POWER FAILURE**

1. Airspeed – Adjust.
2. HYD BOOST SOL circuit breaker – Out.

If hydraulic power is not restored:

3. HYD BOOST SOL circuit breaker – in.
4. HYD BOOST switch – OFF.
5. LAND AS SOON AS PRACTICABLE.

**LANDING AND DITCHING**

**DITCHING – POWER ON**

1. Doors – Jettison at a hover.

2. Crew (except pilot) and passengers – Exit.
3. Hover at a safe distance away from personnel.
4. AUTOROTATE.
5. Pilot – Exit when the main rotor stops.

**DITCHING – POWER OFF**

1. AUTOROTATE.
2. Doors – Jettison.
3. Crew and passengers – Exit when the main rotor stops.

**FLIGHT CONTROL MALFUNCTIONS**

1. LAND AS SOON AS POSSIBLE.
2. EMER SHUTDOWN after landing.

**LIGHTNING STRIKE**

LAND AS SOON AS POSSIBLE

**IN-FLIGHT WIRE STRIKE**

LAND AS SOON AS POSSIBLE.

**WARNING PANEL LIGHTS**

<u>WARNING LIGHT</u>	<u>CORRECTIVE ACTION</u>
ROTOR RPM	<u>Verify condition. Adjust collective.</u>
MASTER CAUTION	Check for Caution Panel segment light illumination. If none, <u>LAND AS SOON AS POSSIBLE.</u>
ENGINE OUT	<u>Verify condition. AUTOROTATE.</u>
XMSN OIL PRESS (Red)	<u>LAND AS SOON AS POSSIBLE.</u>
XMSN OIL HOT (Red)	<u>LAND AS SOON AS POSSIBLE.</u>

**CAUTION PANEL LIGHTS**

<u>CAUTION LIGHT</u>	<u>CORRECTIVE ACTION</u>
FUEL BOOST	<u>LAND AS SOON AS PRACTICABLE.</u>
20 min fuel	<u>LAND AS SOON AS PRACTICABLE.</u>
FUEL FILTER	<u>LAND AS SOON AS POSSIBLE.</u>
ENG OIL BYPASS	<u>LAND AS SOON AS POSSIBLE.</u>
ENG CHIP DET	<u>LAND AS SOON AS POSSIBLE.</u>
XMSN CHIP DET	<u>LAND AS SOON AS POSSIBLE.</u>
T/R CHIP DET	<u>LAND AS SOON AS POSSIBLE.</u>
INST INVERTER	Information/System status.
DC GENERATOR	Refer to emergency procedures.
HYD PRESS	Refer to emergency procedures.
IFF	Information/System status.
SPARE	<u>LAND AS SOON AS POSSIBLE.</u>

**PIN: 078043-000**

This fine document...

Was brought to you by me:



## [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)