TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

RADIO SETS

AN/ARC-134 (NSN 5821-00-937-1086)

AN/ARC-134A (NSN 5821-00-879-1377)

AND

AN/ARC-134B (NSN 5821-00-181-0430)

HEADQUARTERS, DEPARTMENT OF THE ARMY

DECEMBER 1978

TECHNICAL MANUAL

No. 11-5821-277-20P

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, DC, 5 December 1978

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR RADIO SETS AN/ARC-134 (NSN 5821-00-937-1086) AN/ARC-134A (NSN 5821-00-879-1377)

AND

AN/ARC-134B (NSN 5821-00-181-0430) Current as of 3 July 1978

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Pa	ige F	Figure
S ECTION	I.	Introduction	1	
	II.	Repair parts list		
Group	00	Radio Sets AN/ARC-134, AN/ARC-134A, and AN/ARC-134B	. 5	1
	01	Receiver-Transmitter, Radio RT-857/ARC-134.	7	2
		0101 Cable assembly, radio frequency (3W1) (No parts authorized)		
		0102 Power supply subassembly (3A7) (No parts authorized)		
		0103 Receiver-transmitter, exciter subassembly (3A8) (No parts authorized)		
		0104 Receiver-transmitter, power amplifier subassembly (3A9) No parts authorized)		
		010401 Antenna filter subassembly (3A9A1) (No parts authorized)		
		010402 Driver assembly (3A9A5) (No parts authorized)		
		010403 Motor transmission control subassembly (3A9A6) (No parts authorized)		
		0105 Receiver assembly (3A10) (No parts authorized)		
		010501 Hundreth MHz oscillator subassembly (3A10A2) (No parts authorized)		
		010502 Tenths MHz oscillator subassembly (3A10A3) (No parts authorized)		
		010503 Units MHz oscillator subassembly (3A10A4) (No parts authorized)		
		010504 Tens MHz oscillator subassembly (3A10A5) (No parts authorized)		
		010505 3.045-MHz oscillator subassembly (3A10A6) (No parts authorized)		
		01050501 3.045-MHz oscillator circuit card assembly (3A10A6A3) (No parts authorized)		
		010506 IF and AGC subassembly (3A10A7) (No parts authorized)		
		010507 Squelch and receiver audio subassembly (3A10A8) (No parts authorized)		
		010508 Bias tuning matrix subassembly (3A10A9) (No parts authorized)		
		0106 Modulator input subassembly (3A11) (No parts authorized)		
		0107 Power control and sidetone amplifier subassembly (3A12) (No parts authorized)		
	02	Radio Set Control C-7197/ARC-134	9	3
	03	Mountings MT-3791 A1ARC-134 and MT-3791B/ARC-134 (No Parts authorized		
SECTION		Special tools list (Not applicable)		
	IV.	National stock number and part number index	0	

•This manual supersedes TM 11-5821-277-20P, 22 June 1970.

Illus

Code

Code

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the AN/ARC-134, AN/ARC-134A, and AN/ARC-134B. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are crossreferenced to each illustration figure and item number appearance.

3. Explanation of Columns

Code

a. Illustration. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown.

(2) *Item number*. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Definition

- PA —Item procured and stocked for anticipated or known usage.
- PD —Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
- XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code*. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(*a*) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Application/Explanation

O —Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Application/Explanation

- O —The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F —The lowest maintenance level capable of complete repair of the support item is the direct support level.
- H —The lowest maintenance level capable of complete repair of the support item is the general support level.
- Z Nonreparable. No repair is authorized.

(3) *Recoverability code*. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability codes

Definition

- Z —Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- O —Reparable item. When uneconomically reparable, condemn and dispose at organizational level.
- F —Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.
- H —Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. Usable on codes are shown in the description column. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are:

Code	Used on
5DE	AN/ARC-134
2AU	AN/ARC-134A
5DF	AN/ARC-134B

b. The illustrations in this manual are identical to those published in TM 11-5821-277-34P. Only those parts assigned the third position SMR maintenance code "C" or "O" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

c. The following publication pertains to the AN/ARC-134, AN/ARC-134A, and AN/ARC- 134B and its components:

TM 11-5821-277-20, Radio Sets AN/ARC-134 and AN/ARC-134A and AN/ARC-134B.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second*. Find the illustration covering the functional group to which the item belongs.

(3) *Third*. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth*. Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers. find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second*. After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)




Figure 1. Radio Sets AN/ARC-134, AN/ARC-134A and AN/ARC-134B.

TM11-5821-277-20P

	:	SECTION	II			TM11-5821-277-20P		
(1) LUSTR		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG	(b) ITEM	SMR	NATIONAL STOCK	PART		DESCRIPTION		QTY INC IN
NO.	NO	CODE	NUMBER	NUMBER	FSCM	USABLE ON CODE	0/М	
						GROUP OO RADI O SET S AN/ ARC-134, AN/ ARC-134A		
						AND AN/ARC-1 348 RECEIVER-XHTRRADIO		
1			5821-00-072-6108			RECEIVER-XNTRADIO	EA EA	1
1			5975-00-177-2077			BASE, SMOCK MT , ELEC	EA	1
						5		
	l							
I		-	ļ	ļ	I	1		1

CR1810 43 42 44 62 63 45 = \mathbb{O} O G \odot G) لأمام МІ 46 \bigcirc 900 ن C -47,48 m 49 ê) 19 6 $\langle \rangle$ **SI9**02 50 6 0 - 51 \mathbb{Z} J3 9 52 ลิล 6 10 λ) ō อ อ J2 53 7 0

> LIBOI CIBO2 56 55

54

61

W95 60

59

58~

CRI602 44

₩96 57



CI804 55 TM11-5821-277-20P

10

ELIJN004

7

;

Ĵ.

ADDITIONAL PARTS LOCATION

TM11-5821-277-20P

SECTION II

		SECTION				10111-	5821-277-20P		
(1)	(2)	(3)	(4)	(5)	(6)		(7)	(8)
ILLUS	TIO					DESCRIPTION			
(a) FiG			NATIONAL			DESCRIPTION		4	OTY INC
NO.	NO	SMR CÓDE	STOCK NUMBER	PART NUMBER	FSCM				IN
					<u> </u>		13:481 FON CODE	1/141	UNIT
						GROUP O1 RECEIVER-TRANSMITTER, RADIO		ļİ	
								1	
						RT-857/ARC-134			
2	- 4	22002	30 5-00-8 05-974	1551053-112	6901	SET SCRE H		A	2
2	5	AOZZ	355-00-588-309	0-5-2	9951	KNQB		A	1
								1	
								1	
						7			
_		-							





Figure 3. Radio Set Control C-7197/ARC-134, Front Panel.

TM 11-5821-277-20P

	:	SECTION	П			TM 11-5821-277-20P		
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
LUSTR						DESCRIPTION		QTY
(a) FIG	(b) ITEM	SMR	STOCK	PART				INC IN
NO.	NO.	CODE	NUMBER	NUMBER	FSCM	USABLE ON CODE	U/M	UNIT
						GROUP OZ RADIO SET CONTROL C-7197/ARC-134		-
3	16	PA000	5355-00-913-9601	60825-2	65597		EA	2
3	17	XDOZZ	5305-00-959-2727	MS35191-201	96906	SCREW, MACHINE	EA	4
3	18	XDOZZ		60828-1	65597	POINTER, KNOB	EA	2
3	19	XDOZZ		60825-1	65597	K NOB	EA	z
3	20	XDOZZ	5305-00-719-5330	MS51963-21	96906	SET SCREW	EA	8
3	21	PA000	5355-00-728-6448	60827-2	65597	KNOB ASSEMBLY	EA	z
3		XDOZZ		NS351053-127	96906	SET SCREW	EA	4
						KN08		1
3		X0022		60827-1	65597		EA	
3			6210-00-832-7216		65597		EA	3
3	25	PAOZZ	6210-00-725-6530	80050-2	87034	LANPHOLDER	EA	3
3	26	PAOZZ	5330-00-971-7983	2-1106147-7	83259	PACKING, PREFORMED	EA	3
3	27	PAOZZ	5310-00-245-8804	276344-1	65597	WASHER, NONMETALLIC	EA	3
3	28	PADZZ	6240-00-080-2012	327AS15	71744	LAMP: INCANDESCENT	EA	3
							1	
							1	
							1	
							1	
							1	
							1	
							1	
							1	
						9	1	
							1	
							1	
J				1				

SECTION IV NOTE:	NATIONAL STO	DCK NUME	ER AND I	PART ER ASSIGNMENT	INCLUDED AT END OF INDE	ХТМ11-5	821-277	20P
STOCK NUMBER	FIGURE NO.	IT EM NG		STOC	K NUMBER	FIGURE NO.		ITEM NO.
6240-00-080-2012 5975-00-177-2077	3 1	28 3	ŀ	6210	i-00-805-9748 i-00-832-7216	2 3		49 24
5310-00-245-8804 5355-00-588-3095	32	27 51		5821	5-00-913-9601 1-00-936-0924	3 1		16 3
6210-00-725-6530 5355-00-728-6448	3 3	25 21			-00-959-2727 -00-971-7983	3 3		17 26
PAR		FIG.			PART		FIG.	ITEM
NUMBER	R FSCN	NO.	NO.		NUMBER	FSCM	NO.	NO .
M\$351053-127	9690		22	276344-1	L	65597	3	27
MS35191-201	9690		17	327AS15		71744	3	28
MS51053-112	9690	0 2	49	60825-1 60825-2		65597 65597	3	19
MT-3791A/ARC-134	8005	8 1	3	60827-1		65597	3	16 23
MT3791BARC134	8005		3	60827-2		65597	3	21
RT-857/ARC-134	8005		1	60828-1		65597	3	18
117670-1	6559		24	70-5-2		49956	2	51
2-1100147-7	8325	93	26	80050-2		87034	3	25
	LATI	ST NATION	AL STOCK	NUMBER ASSIGN	MENT_			
	STOCK !	IUMBER		FIG. NO.	ITEM NO.			
)0726108)7195330		1 3	1 20			
		LATEST PA	rt number	ASSIGNMENT				
	PAR	r		FIG.	ITEM			

PART	FSCM	FIG.	ITEM
NUMBER		NO.	NO.
MS51963-21	96906	3	20



SOMETHING WBONG with this manual? THENJOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL! PUBLICATION NUMBER TM 112-5821-277-20P BE EXACTPIN-POINT WHERE IT IS NO. PAGE PAGE NO. CRAPH PIGURE TABLE NO. CRAPH PAGE PAGE
THENJOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL! DATE PUBLICATION NUMBER TM 11-5821-277-20P DATE TITLE RADIO SETS AN/ARC-134; AN/ARC-134A; AND AN/ARC-134B BE EXACTPIN-POINT WHERE IT IS PAGE IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DOME ABOUT IT:
TM 11-5821-277-20P RADIO SETS AN/ARC-134, AN/ARC-134A, AND AN/ARC-134B BE EXACTPIN-POINT WHERE IT IS PAGE IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
BE EXACT PIN-POINT WHERE IT IS IN THIS SPACE TELL WHAT IS WRONG PAGE PARA FIGURE TABLE AND WHAT SHOULD BE DONE ABOUT IT:
PAGE PARA- FIGURE TABLE
TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER SIGN HERE:

FILL IN YOUR FOLD BACK DEPARTMENT OF THE ARMY OFFICIAL BUSINESS

Commander US Army Communications and Electronics Materiel Readiness Command ATTN: DRSEL-ME-MQ Fort Monmouth, New Jersey 07703 1

TEAR ALONG DOTTED LINE

1

ł

FOLD BACK

REVERSE OF DA FORM 2028-2

						WRONG WITH THIS MANUAL?		
	THEN JOT DOWN DOPE ABOUT IT ON FORM, TEAR IT OU IT AND DROP IT IN MAIL!					OM: (YOUR UNIT'S COMPLETE ADDRESS)		
			······································	DATE	DATE	TITLE		
PUBLICATION NUMBER TM 11-5821-277-20P					RADIO SETS AN/ARC-134,			
			IN THIS SPA	L CE TELL	WHAT IS	AN/ARC-134A, AND AN/ARC-134B WRONG		
E, GRADE	OR TITLE	, AND TE	LEPHONE NUM	BER	SIGN H	IERE:		
	PIN-PC PARA- GRAPH	PARA- GRAPH FIGURE NO.	PARA- GRAPH FIGURE TABLE NO. TABLE NO.	E. GRADE OR TITLE, AND TELEPHONE NUM	PIN-POINT WHERE IT IS IN THIS SPACE TELL PARA FIGURE TABLE AND WHAT SHOULD B	PARA FIGURE TABLE GRAPH NO. NO. NO.		

FILL IN YOUR	FOLD BACK
DEPARTMENT OF THE ARMY	
OFFICIAL BUSINESS	
	Commander US Army Communications and Electronics Materiel Readiness Command

ATTN: DRSEL-ME-MQ Fort Monmouth, New Jersey 07703 1

1

I

TEAR ALONG DOTTED LINE

1 1 1

۱

ł

FOLD BACK

REVERSE OF DA FORM 2028-2

/%		۱	S	OME	1061	ŊG	WRONG WITH THIS MANUAL?
		X	THEN. DOPE A	JOT DOWN BOUT IT ON TEAR IT OUT DROP IT IN	THE THIS C. FOLD		(YOUR UNIT'S COMPLETE ADDRESS)
UBLICAT	ION NUMBE	R			DATE	DATE	
TM 1	1-5821-	277-20	Р				RADIO SETS AN/ARC-134, AN/ARC-134A, AND AN/ARC-134E
PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.				
YPED NA	ME, GRADE	OR TITL	E, AND T	ELEPHONE NUN	4BER	SIGN	HERE:

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander US Army Communications and Electronics Materiel Readiness Command ATTN: DRSEL-ME-MQ Fort Monmouth, New Jersey 07703 TEAR ALONG DOTTED LINE

ł

FOLD BACK

REVERSE OF DA FORM 2028-2

Official:

J. C. PENNINGTON

Brigadier General, United States Army The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-36, Organizational requirements for AN/ARC-1 34.

*U.S. GOVERNMENT PRINTING OFFICE: 1992 - 311-831/61076

BERNARD W. ROGERS

General, United States Army Chief of Saff

PIN : 023012-000

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<u>http://www.liberatedmanuals.com/</u>>Free Military and Government Manuals

Sincerely
 Igor Chudov
 <u>http://igor.chudov.com/</u>
 Chicago Machinery Movers