TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR RADAR TEST SET AN/UPM-98 (NSN 6625-00-580-3771)

HEADQUARTERS, DEPARTMENT OF THE ARMY

FEBRUARY 1977

TECHNICAL MANUAL .
No. 11-6625-403-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 3 February 1977

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS FOR

RADAR TEST SET AN/UPM-98 (NSN 6625-00-580-3771) Current as of 20 September 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN.: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

			_	IIIUS.
05051011			Page	Figure
SECTION	l.	Introduction		
_	II.	Repair parts list		
Group	00	RadarTestSetAN/UPM-981	5	
	01	Radar Test Set TS- 1253/UP (No parts authorized)		
		0101 Display unit	6	2,3
		0102 Sweep and intensity mark		4
		0103 Crystal mark and sync unit		5
		0104 SIF coder unit		6
		0105 Main chassis assembly	11	7,8
	02	Coder Simulator SM-197/UPM-98 (No parts authorized)		
		0201 Panel chassis assembly	13	9
		0202 CAL control unit.		10
		0203 Mark X coder unit	15	11
	03	Test Lead Assembly MX-2681/U (No parts authorized)		
	04	Electrical Equipment Case CY-2726/UPM-98	16	12
	05	Cable Assembly, Radio Frequency CG-530B/U (No parts authorized)		
	06	Cable Assembly, Radio Frequency CG-409E/U (No parts authorized)		
	07	Cable Assembly, Special Purpose, Electrical CX-4963/UPM (No parts authorized)		
	08	Cable Assembly, Special Purpose, Electrical CX-6092/U (No parts authorized)		
	09	Cable Assembly, Radio Frequency CG-530B/U (No parts authorized)		
	10	Cable Assembly, Radio Frequency CG-409E/U (No parts authorized)		
SECTION	III.	Special tools list (Not applicable)		
	IV.	National stock number and part number index	17	

^{*}This manual supersedes TM 11-25403-20P, 2 July 193.

SECTION I INTRODUCTION

XD-

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the AN/VPM-98. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.
 - b. Section III. Special Tools List. Not applicable.
- c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

- a. Illustration. This column is divided as follows:
- (1) Figure number. Indicates the figure number of the illustration on which the item is shown.
- (2) Item number. The number used to identify item called out in the illustration.
- b. Source, Maintenance, and Recoverability (SMR) Codes.
- (1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

PA-Item procured and stocked for anticipated or known usage.

PD-Support item, excluding support equipment. procured for initial issue or outfitting and stocked only for subsequent or additional initial issues

Definition Code

> or outfittings. Not subject to automatic

replenishment.

A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation O-Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Application/Explanation Code

H-The lowest maintenance level capable of complete repair of the support item is the general support level.

Z-Nonreparable. No repair is authorized.

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Definition codes

Z When unserviceable, Nonreparable item. condemn and dispose at the level indicated in position 3.

Н Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

- c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.
- d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

- e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.
- f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.
- g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- h. Quantity Incorporated in Unit. Indicated the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publication pertains to the AN/UPM-98 and its components:

TM 11-6625-403-14, Radar Test Set AN/UPM-98

b. The illustrations in this manual are identical to those published in TM 11-6625-403-40P. Only those parts assigned the third position SMR maintenance code "C" or "0" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

5. How to Locate Repair Parts

- a. When National stock number or part number is unknown.
- (1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.
- (2) *Second.* Find the illustration covering the functional group to which the item belongs.
- (3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.
- (4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- b. When National stock number or part number is known.
- (1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphanumeric sequence, cross-referenced to the illustration figure number and item number.
- (2) Second. After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 5)

2/3/4 (Blank)




Figure 1. Radar Test Set AN/UPM-98.

('	1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
1 1 1	3 4 5 8	XDOHH	5995-00-889-1047 5995-00-503-0470 5995-00-889-1048		80058 80058 80058 80058	GROUP 00 RADAR TEST SET AN/UPH98 CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL CABLE ASSEMBLY, RADIO FREQUENCY CABLE ASSEMBLY, RADIO FREQUENCY CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL	EA EA EA	1 2 2 1




Figure 2. Display Unit, Front View.

(1	(1)		(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
2 2 2 2	2 3 4	PAOZZ PAOZZ PAOZZ	5355-00-739-8152 5355-00-753-5164 5355-00-819-0067		70117 75376 70117	GROUP 0101 DISPLAY UNIT KNOB KNOB KNOB	EA EA EA	3 4 1




Figure 3. Display Unit, Right Side View.

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		071
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
3	37	PAOZZ	6240-00-274-4015	328R	24455	LAMP, INCANDESCENT	EA	1





Figure 4. Sweep and Intensity Mark Unit, Front View.


(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	uoc	U/M	QTY INC IN UNIT
						GROUP 0102 SWEEP & INTENSITY MARK UNIT		
4	1	XDOZZ		5645-52BB	75376	KNOB SWEEP SPEED ADJUST AND INTENSITY MARKS LEVEL	EA	2
4	2	PAOZZ	5355-00-819-0067	533A98-3	70117	KNOB SWEEP SPEED RANGE AND INTENSITY MARKS RANGE	EA	2



ELOGC005

Figure 5. Crystal Mark and Sync Unit.

(1	1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	uoc	U/M	QTY INC IN UNIT
5 5 5	1 3 4	PAOZZ XDOZZ PAOZZ		\$647-4LBB \$645-5LBB 533A98-3	75376 75376 70117	GROUP 0103 CRYSTAL MARK AND SYNC UNIT KNOB KNOB KNOB	EA EA EA	2 4 4



ELOGCO06

Figure 6. SIF Coder Unit, Front View.

(1	1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
						GROUP 0104 SIF CODER UNIT		
6	5 6	PAOZZ PAOZZ	5355-00-668-4634 5355-00-519-9375	S647-3LBB	75376 75376	KNOB KNOB KNOB	EA EA EA	1 4
6	,	PAOZZ	5355-00-474-3849	3330100	70117	INVOD	EA	ı




Figure 7. Main Chassis Assembly, Front View.

(1))	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	ILLUSTRATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	uoc	U/M	QTY INC IN UNIT
						GROUP 0105 MAIN CHASSIS ASSEMBLY		
7	1	PAOZZ	6240-00-155-8706	TB14	81349	LAMP, INCANDESCENT	EA	1
7	3	PAOZZ	5920-00-060-2424	F02G5ROOA	81349	FUSE, CARTRIDGE	EA	3




Figure 8. Main Chassis Assembly, Top View.

(1))	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	uoc	U/M	QTY INC IN UNIT
8	7	XD0ZZ		63231-2	80058	LAMP, GLOW	EA	2




Figure 9. Panel Chassis Assembly, Front View.

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	ILLUSTRATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
9 9 9 9	5 7 8 9	PAOZZ XDOZZ PAOZZ PAOZZ	6240-00-155-8706 5920-00-474-5743 5355-00-813-5386	63231-2 F02G3ROOA	81349 80058 81349 75376	GROUP 0201 PANEL CHASSIS ASSEMBLY LAMP, INCANDESCENT LAMP, GLOW FUSE, CARTRIDGE KNOB	EA EA EA EA	1 2 3 1




Figure 10. CAL Control Unit, Front View.

(1	(1)		(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	ILLUSTRATION					DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
10 10	1 2	XDOZZ PAOZZ	5355-00-819-0067	S645-5LBB 533A98-3	75376 70117	GROUP 0202 CAL CONTROL UNIT KNOB KNOB	EA EA	3 2




Figure 11. Mark X Coder Unit, Front View.

(1	1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUST	RATION					DESCRIPTION		0.T)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	uoc	U/M	QTY INC IN UNIT
						GROUP 0203 MARK X CODER UNIT		
11 11 11 11	1 2 3 4	PAOZZ XDOZZ PAOZZ PAOZZ	5355-00-819-0067	533B106 S645-5LBB 533A98-3 S647-3LBB	70117 75376 70117 75376	KNOB KNOB KNOB	EA EA EA EA	1 1 1 1




Figure 12. Electrical Equipment Case CY-2726/UPM-98.

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION						DESCRIPTION		OTV
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	UOC	U/M	QTY INC IN UNIT
12 12	1 6	PAOZZ PAOZZ	4130-00-725-4823 4130-00-779-0845		82866 82866	GROUP 04 ELECTRICAL EQUIPMENT CASE CY-2726/UPM-98 FILTER, AIR CONDITIONING FILTER, AIR CONDITIONING	EA EA	1 1

NOTE: LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

	FIGURE		ITEM		FIGURE		ITEM
STOCK NUMBER	NO.		NO.	STOCK NUMBER	NO.		NO.
5920-00-060-2424	7		3	5355-00-739-8152	2		2
6240-00-155-8706	7		1	5355-00-753-5164	2		3
5355-00-474-3849	6		7	5355-00-819-0067	2		4
5355-00-474-3849	11		1	5355-00-819-0067	4		2
5920-00-474-5743	9		8	5355-00-819-0067	5		4
5995-00-503-0470	1		5	5355-00-819-0067	10		2 3 3
5355-00-519-9375	6		6	5355-00-819-0067	11		3
5355-00-519-9375	11		4	5995-00-889-1047	1		3
5355-00-668-4634	6		5	5995-00-889-1048	1		8
4130-00-725-4823	12		1				
PART	FSCM	FIG.	ITEM	PART	FSCM	FIG	ITEM
NUMBER	1 00111	NO.	NO.	NUMBER	1 00111	NO.	NO.
AF1952B	82866	12	1	S649-3LBB	75376	6	5
CG409EU	80058	1	5	TB14	81349	7	1
CG530BU	80058	1	4	TB14	81349	9	5
CX4963UPM	80058	1	3	328R	24455	3	37
CX6092U	80058	1	8	533A98-1	70117	2	2
F02G3ROOA	81349	9	8	533A98-3	70117	2	4
FO2GSROOA	81349	7	3	533A98-3	70117	4	2
SCH309-65BB	75376	9	9	533A98-3	70117	5	4
S645-5LBB	75376	5	3	533A98-3	70117	10	2
S645-5LBB	75376	10	1	533A98-3	70117	11	3
S645-5LBB	65376	11	2	533B106	70117	6	7
S645-5LBB538	75376	2	3	533B106	70117	11	1
S645-52BB	75376	4	1	63231-2	80058	8	7
S647-3LBB	75376	6	6	63231-2	80058	9	7
S647-3LBB	75376	11	4	9200X	82866	12	6

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

	FIGURE	ITEM	
STOCK NUMBER	NO.	NO.	
6240-00-155-8706	9	5	
6240-00-274-4015	3	37	
5355-00-473-5857	5	1	
4130-00-779-0845	12	6	
5355-00-813-5386	9	9	

LATEST PART NUMBER ASSIGNMENT

PART	FIGURE	ITEM	
NUMBER	FSCM	NO.	NO.
S647-4LBB	75376	5	1

17/(18 blank)

By Order of the Secretary of the Army:

Official: PAUL T. SMITH Major General, United States Army The Adjutant General **DISTRIBUTION:** Active Army: USASA (2) COE (1) TSG(1) **USAARENBD (1)** DARCOM (1) MICOM (2) TECOM (2) USACC (4) TRADOC (2) OS Maj Comd(4) LOGCOMD (3) MDW (1) Armies (2) Corps (2) Instl (2) except Ft Gillem (10) Ft Gordon (10) Ft Huachuca (10) Ft Carson (5) **SAAD (30)** LBAD (14) TOAD (14) SHAD (3) HISA (Ft Monmouth) (33) Ft Richardson (ECOM Ofc) (2) Svc Colleges (1) USASIGS (5) USAICS (3) USAADS (2) USAFAS (2) USAARMS (2) USAIS (2) USAES (2) MAAG (1) USARMIS (1) **USAERDAA (1) USAERDAW (1)** Sig FLDMS (1) Units org under fol TOE:- 1 ea. 11-16 11-117 11-500(AA AC) ARNG: State AG (3). USAR: None. For explanation of abbreviations used, see AR 310-50. General, United States Army Chief of Staff

BERNARD W. ROGERS

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS SOMETHING WRONG WITH THIS PUBLICATION? FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) THEN. . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL! DATE SENT **PUBLICATION NUMBER** PUBLICATION DATE PUBLICATION TITLE BE EXACT. . . PIN-POINT WHERE IT IS IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT: FIGURE NO TABLE NO. PARA-GRAPH

SIGN HERE:

DA , 500% 2028-2

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

PREVIOUS EDITIONS • ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 023228

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers