

## D E P A R T M E N T O F T H E A R M Y T E C H N I C A L M A N U A L

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL  
SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL  
TOOLS LISTS (INCLUDING DEPOT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS)  
TEST SET, RESOLVER AN/ASM-101  
FSN 6625-086-7843

Headquarters, Department of the Army, Washington, D.C.  
8 March 1974

*Current as of June 1973*

	Paragraph	Page
Section I. INTRODUCTION		
Scope . . . . .	1-1	2
General . . . . .	1-2	2
Explanation of columns . . . . .	1-3	2
Special information . . . . .	1-4	5
Location of repair parts . . . . .	1-5	5
Abbreviations (Not applicable) . . . . .	1-6	5
Reporting of equipment publication improvements . . . . .	1-7	5
II. PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III. REPAIR PARTS LIST . . . . .		6
IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V. REPAIR PARTS LIST . . . . .		7
VI. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
VII. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER . . . . .		11

\*This manual supersedes TM 11-6625-492-25P, 9 February 1965.

**SECTION I**  
**INTRODUCTION**

---

**1-1. Scope**

This manual lists repair parts and special tools required for the performance of organizational, direct support, general support, and depot maintenance of the AN/ASM-101. The PCCN for the AN/ASM-101 is GANADW for all models.

**1-2. General**

This repair parts and special tools list is divided into the following sections:

*a. Prescribed Load Allowance (PLA) - Section II.* Not applicable.

*b. Repair Parts List - Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

*c. Special Tools, Test and Support Equipment - Section IV.* Not applicable.

*d. Repair Parts List - Section V.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

*e. Special Tools, Test and Support Equipment - Section VI.* Not applicable.

*f. Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section VII.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphabetic sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

**1-3. Explanation of Columns**

The following provides an explanation of columns found in the tabular list.

*a. Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are -

<i>Code</i>	<i>Explanation</i>
PA-	Item procured and stocked for anticipated or known usage.

<i>Code</i>	<i>Explanation</i>
PB-	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC-	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD-	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE-	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF-	Support equipment which will not be stocked but which will be centrally procured on demand.
PG-	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD-	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF-	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB-	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO-	Item to be manufactured or fabricated at organizational level.
MF-	Item to be manufactured or fabricated at direct support maintenance level.

Code	Explanation
MH-	Item to be manufactured or fabricated at general support maintenance level.
MD-	Item to be manufactured or fabricated at depot maintenance level.
AO-	Item to be assembled at organizational level.
AF-	Item to be assembled at direct support maintenance level.
AH-	Item to be assembled at general support maintenance level.
AD-	Item to be assembled at depot maintenance level.
XA-	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB-	Item is not procured or stocked. If not available through salvage, requisition.
XC-	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
XD-	Support items can be requisitioned with justification.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows :

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

Code	Application/Explanation
O-	Support item is removed, replaced, used at the organizational level of maintenance.

Code	Application/Explanation
------	-------------------------

**NOTE**

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- |    |  |
|----|--|
| F- | Support item is removed, replaced, used at the direct support maintenance level. |
| H- | Support item is removed, replaced, used at the general support maintenance.      |
| D- | Support items that are removed, replaced, used at depot only.                    |

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multiservice equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code:

Code	Application/Explanation
O-	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F-	The lowest maintenance level capable of complete repair of the support item is direct support.
H-	The lowest maintenance level capable of complete repair of the support item is general support.
D-	The lowest maintenance level capable of complete repair of the support item is the depot level.
L-	Repair restricted to designated Specialized Repair Activity.
Z-	Nonrepairable. No repair is authorized.
B-	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code

is entered in the fifth position of the uniform SMR Code Format as follows:

Code	Explanation
Z-	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O-	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F-	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H-	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D-	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L-	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A-	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

*b. Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

*c. Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

*d. Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

*e. Quantity Incorporated in Unit.* This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

*f. 15-Day Organizational Maintenance Allowances.*

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-AN, Fort Monmouth, N.J., 07703.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other support equipment.

*g. 30-Day DS/GS Maintenance Allowances.*

#### NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for DS and GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

*h. 1-Year Allowances Per 100 Equipments/Contingency Planning Purposes.* Column intentionally left blank.

*i. Depot Maintenance Allowance Per 100 Equipments.* This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.

*j. Illustration.*

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-6625-492-35.

(2) *Item number.* Indicates the item number or reference designation used to reference the item in the illustration.

**1-4. Special Information**

*a.* Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

<i>Code</i>	<i>Used on</i>
BKH	AN/ASM-101

*b.* The following publications pertain to the AN/ASM-101 and its components:

TM 11-6625-492-12 Operator and Organizational Maintenance Manual: Test Set, Resolver AN/ASM-101.

TM 11-6625-492-35 Field and Depot Maintenance Manual: Test Set, Resolver AN/ASM-101.

**1-5. Location of Repair Parts**

*a.* This manual contains one cross-reference index (sec VII) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

*b.* When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec VII), and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III and V) and locate the figure number (col 7a-20P, 10a-34P) and item number or reference designation (col 7b-20P, 10b-34P) as noted in the FSN index.

*c.* When the figure and item number or reference designation are known, scrutinize columns 7a and 7b-20P and 10a and 10b-34P, of the repair parts list (sec III and V) until the item is located.

*d.* When the FSN, reference number, figure number, and item number are not known, scrutinize column 3 of the repair parts list (sec III and V), which is arranged in alphabetical order.

**1-6. Abbreviations**

Not applicable.

**1-7. Reporting of Equipment Publication Improvements**

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-AN, Fort Monmouth, N.J., 07703.

(Next printed page is 6)

SECTION III			TM11-6625-492-24P						
(1)	(2)	(3)	(4)	(5)	(6)	(7)			
SMR	FEDERAL	DESCRIPTION	UNIT	QTY	15-DAY ORGANIZATIONAL	ILLUSTRATION			
CODE	STOCK		OF	INC	MAINTENANCE ALW	(A)	(B)		
	NUMBER	REFERENCE NUMBER & MFR CODE	MEAS	UNIT	(A) (B) (C) (D)	FIGURE	ITEM		
					1-5 6-20 21-50 51-100	NO	NO		
PAOZZ	5935-201-3090	ADAPTER, CONNECTOR UG-201/U NO-REF-DESIG 2 CONTS, 2 CONN MATING MATING ENDS, LOCK TYPE, O/A 1-5/16 IN LG BY 13/16 IN DIA SCD72309 (80063)	EA	1	* * *				
PAOZZ	5935-149-4066	CONNECTOR, PLUG, ELECTRICAL CG-409/U UG88U (80058)	EA	1	* * *				
PAOZZ	5935-223-0572	CLAMP, ELECTRICAL NO-REF-DESIG 3057-12 (80044)	EA	1	* * *				
PAOZZ	5935-284-3967	CONNECTOR, PLUG, ELECTRICAL CX-8376/ASM-101 AN3106A18-1S (81349)	EA	3	* * *			1	
PAOZZ	5935-636-6606	JACK, TIP NO-REF-DESIG BLK, BANA STRAIGHT TYPE 2 IN LG O/A 274ND (24655)	EA	1	* * *				
PACZZ	5355-284-5666	KNOB NO-REF-DESIG SETSCREW, PLAIN, 1 3/4 IN OD BY 7/8 IN THK O/A 503-2377-002 (13499)	EA	3	* * *			1	

SECTION V				TM11-6625-492-24P													
(1)	(2)	(3)		(4)	(5)	(6)			(7)			(8)	(9)	(10)			
		DESCRIPTION		UNIT	QTY	30-DAY	DS	MAINT	30-DAY	GS	MAINT	1-YR	DEPOT	ILLUSTRATION			
SMR	FEDERAL			OF	INC	ALLOWANCE	(A)	(B)	(C)	ALLOWANCE	(A)	(B)	(C)	ALW PER	MAINT	(A)	(B)
CODE	NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	EQUIP	100	FIGURE	100	NO	ITEM
												CNTGCY					NO
PAOZZ	5935-201-3090	ADAPTER, CONNECTOR UG-201/U NO-REF-DESIG 2 CONTS, 2 CONN MATING ENDS, LOCK TYPE, O/A 1-5/16 IN LG BY 13/16 IN DIA SCD72309 (80063)		EA	1	*	*	*	*	*	*			4			
PAOZZ	5935-149-4066	CONNECTOR, PLUG, ELECTRICAL CG-409/U UG88U (80058)		EA	1	*	*	*	*	*	*			3			
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C1 10,000 UUF PORM2PCT CM35E102G (81350)		EA	7				*	*	*			3	9		C1
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C2 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C2
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C3 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C3
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C4 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C4
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C5 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C5
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C6 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C6
PAHZZ	5910-101-4063	CAPACITOR, FIXED, MICA DIELECTRIC C7 10,000 UUF PORM2PCT CM35E103G (81350)		EA	REF				*	*	*				9		C7
PAHZZ	5910-813-1491	CAPACITOR, FIXED, PAPER DIELECTRIC C12 47,000 UUF PORM10PCT, 200 VDCW 65P47392 (56289)		EA	2				*	*	*			3	10		C12
PAHZZ	5910-813-1491	CAPACITOR, FIXED, PAPER DIELECTRIC C13 47,000 UUF PORM10PCT, 200 VDCW 65P47392 (56289)		EA	REF				*	*	*				10		C13
PAHZZ	5910-161-1625	CAPACITOR, FIXED, PAPER DIELECTRIC C11 100,000 UUF PORM10PCT, 200 VDC R2001-1108PCC1 (98571)		EA	1				*	*	*			3	10		C11
PAHZZ	5935-223-0574	CLAMP, ELECTRICAL NO-REF-DESIG 3057-10 (80044)		EA	3				*	*	*			3			
PAOZZ	5935-223-0572	CLAMP, ELECTRICAL NO-REF-DESIG 3057-12 (80044)		EA	1	*	*	*	*	*	*			3			
PAHZZ	5935-823-0487	CONNECTOR, PLUG, ELECTRICAL J1 UG88EU (80058)		EA	4				*	*	*			3	9		J1
PAHZZ	5935-823-0487	CONNECTOR, PLUG, ELECTRICAL J2 UG88EU (80058)		EA	REF				*	*	*				9		J2
PAHZZ	5935-823-0487	CONNECTOR, PLUG, ELECTRICAL J3 UG88EU (80058)		EA	REF				*	*	*				9		J3
PAHZZ	5935-823-0487	CONNECTOR, PLUG, ELECTRICAL J4 UG88EU (80058)		EA	REF				*	*	*				9		J4
PAHZZ	5935-681-5685	CONNECTOR, PLUG, ELECTRICAL NO-REF-DESIG UG88CU (80058)		EA	1				*	*	*			3			
PAHZZ	5935-201-3511	CONNECTOR, RECEPTACLE, ELECTRICAL, UG- 290A/U J1 MS35174 (96906)		EA	4				*	*	*			3	9		J1

SECTION V				TM11-6625-492-24P											
(1)	(2)	(3)		(4)	(5)	(6)			(7)			(8)	(9)	(10)	
		DESCRIPTION		UNIT	QTY	30-DAY DS ALLOWANCE	MAINT		30-DAY GS ALLOWANCE	MAINT		1-YR ALW PER EQUIP	DEPOT MAINT	(A)	(B)
SMR CODE	FEDERAL STOCK NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	OF MEAS	IN UNIT	(A)	(B)	(C)	(A)	(B)	(C)	100 EQUIP CNTGCT	100 EQUIP	FIGURE NO	ITEM NO
PAHZZ	5935-201-3511	CONNECTOR, RECEPTACLE, ELECTRICAL, UG-290A/U J2 MS35174 (96906)		EA	REF				*	*	*			9	J2
PAHZZ	5935-201-3511	CONNECTOR, RECEPTACLE, ELECTRICAL, UG-290A/U J3 MS35174 (96906)		EA	REF				*	*	*			9	J3
PAHZZ	5935-201-3511	CONNECTOR, RECEPTACLE, ELECTRICAL, UG-290A/U J4 MS05174 (96906)		EA	REF				*	*	*		*	9	J4
PAOZZ	5935-284-3967	CONNECTOR, PLUG, ELECTRICAL CX-8376/ASM-101 AN3106A18-1S (81349)		EA	3	*	*	*	*	*	*		3	1	
PAHZZ	5935-193-3550	CONNECTOR, RECEPTACLE, ELECTRICAL J5 3102-18-1P (80044)		EA	1				*	*	*		3	10	J5
PAHZZ	5915-842-3857	FILTER, LOW PASS F-769/ASM-101 F-769/ASM-101 35 CPS CUT OFF FREQ, 380 K INPUT, 100 K OUTPUT W/2 CIRCUIT PHONE PLUG TRIM NO 78803 OR MALLORY NO 90201, NO 540-7244-00 540-7244-00 (13499)		EA	1				*	*	*		3	10	
PAHZZ	5325-281-1557	GROMMET, RUBBER NO-REF-DESIG 931-10-14 (88044)		EA	1				*	*	*		4	10	
PAOZZ	5935-636-6606	JACK, TIP NO-REF-DESIG BLK, BANA STRAIGHT TYPE 2 IN LG O/A 274ND (24655)		EA	1	*	*	*	*	*	*		1		
PACZZ	5355-284-5666	RNOB NO-REF-DESIG SETSCREW, PLAIH, 1 3/4 IN OD BY 7/8 IN THK O/A 503-2377-002 (13499)		EA	3	*	*	*	*	*	*		3	1	
PAHZZ	5935-500-9734	PLUG, TELEPHONE F-769/ASM-101 STRAIGHT TYPE, BLK 361-1040-00 (46859)		EA	1				*	*	*		5		
PAHZZ	5940-269-2219	POST, BINDING J11 B179589-005 (54294)		EA	1				*	*	*		1	10	J11
PAHZZ	5940-269-2219	POST, BINDING J12 B179589-005 (54294)		EA	1				*	*	*		1	10	J12
PAHZZ	5950-645-3278	REACTOR L11 0.034 HEWRY IND, 22,000 OHMS DC RESIS, HERMATIALLY SEALED 678-0303-00 (13499)		EA	1				*	*	*		2	10	L11
PAHZZ	5905-195-6761	RESISTOR, FIXED, COMPOSITION R22 100 000 OHMS PORM5PCT, 1/2W RC20GF104K (81349)		EA	1				*	*	*		3	10	R22
PAHZZ	5905-258-8686	RESISTOR, FIXED, FILM R14 267 OHMS PORM1PCT RN20X26700F (81349)		EA	1				*	*	*		3	9	R14
PAHZZ	5905-725-9145	RESISTOR, FIXED, FILM R14 267 OHMS PORM1PCT, 1/4W RN65B26700F (81349)		EA	1				*	*	*		3	9	R14
PAHZZ	5905-518-5989	RESISTOR, FIXED, FILM R4 1,820 OHMS PORM1PCT 1/2W RN70B1821F (81349)		EA	1				*	*	*		3	9	R4
PAHZZ	5905-552-3521	RESISTOR, FIXED, FILM R2 200 OHMS PORM1PCT, 1/2W RN70B2001F (81349)		EA	1				*	*	*		3	9	R2



SECTION V				TM11-6625-492-24P													
(1)	(2)	(3)		(4)	(5)	(6)			(7)			(8)	(9)	(10)			
		DESCRIPTION		UNIT	QTY	30-DAY DS MAINT			30-DAY GS MAINT			1-YR	DEPOT	ILLUSTRATION			
				OF	INC	ALLOWANCE	(B)	(C)	ALLOWANCE	(B)	(C)	ALW PER	MAINT	ALW PER	(A)	(B)	
SMR	FEDERAL			MEAS	IN	(A)	(B)	(C)	(A)	(B)	(C)	100	100	100	FIGURE	ITEM	
CODE	STOCK	REFERENCE NUMBER & MFR CODE	USABLE ON CODE		UNIT	1-20	21-50	51-100	1-20	21-50	51-100	EQUIP	EQUIP	EQUIP	NO	NO	
	NUMBER											CNTGCT					
PAHZZ	5905-500-6917	RESISTOR, FIXED, FILM R12 2740 OHMS PORM1PCT, 1/2W RN20X4751F (81349)		EA	1				*	*	*				3	9	R12
PAHZZ	5905-583-6240	RESISTOR, FIXED, FILM R12 4750 OHMS PORM1PCT, 1/4W RN65B4751F (81349)		EA	1				*	*	*				3	9	R12
PAHZZ	5905-279-4792	RESISTOR, FIXED, FILM R9 10,000 OHMS PORM1PCT, 1/2W RN20X1002F (81349)		EA	1				*	*	*				3	9	R9
PAHZZ	5905-552-4832	RESISTOR, FIXED, FILM R5 12,100 OHMS PORM1PCT, 1/2W RN20X1212F (81349)		EA	1				*	*	*				3	9	R5
PAHZZ	5905-583-4163	RESISTOR, FIXED, FILM R5 12,100 OHMS PORM1PCT, 1/4W RN65B1212F (81349)		EA	1				*	*	*				3	9	R5
PAHZZ	5905-283-8621	RESISTOR, FIXED, FILM R7 26,700 OHMS PORM1PCT RN20X2672F (81349)		EA	1				*	*	*				3	9	R7
PAHZZ	5905-583-6241	RESISTOR, FIXED, FILM R7 26,600 OHMS PORM1PCT, 1/4W RN65B2672F705-73* 0-00 (81349)		EA	1				*	*	*				3	9	R7
PAHZZ	5905-665-7433	RESISTOR, FIXED, FILM R3 47,500 OHMS PORM1PCT, 1/2W RN20X4752F (81349)		EA	1				*	*	*				3	9	R3
PAHZZ	5905-583-6224	RESISTOR, FIXED, FILM R3 47,500 OHMS PORM1PCT, 1/4W RN65B4752F (81349)		EA	1				*	*	*				3	9	R3
PAHZZ	5905-557-4473	RESISTOR, FIXED, FILM R10 267,000 OHMS PORM1PCT RN20X2673F (81349)		EA	3				*	*	*				3	9	R10
PAHZZ	5905-557-4473	RESISTOR, FIXED, FILM R11 267,000 OHMS PORM1PCT RN20X2673F (81349)		EA	REF				*	*	*					9	R11
PAHZZ	5905-557-4473	RESISTOR, FIXED, FILM R15 267,000 OHMS PORM1PCT RN20X2673F (81349)		EA	REF				*	*	*					9	R15
PAHZZ	5905-842-2234	RESISTOR, VARIABLE R8 WIRE WOUND, 10 000 OHMS PORM5PCT, 5W SA1080 (73138)		EA	1				*	*	*				3	9	R8
PAHZZ	5905-577-7330	RESISTOR, VARIABLE R1 WIRE WOUND, 1 SECT 500 OHMS PORM10PCT 4W RA30NASD502A (81349)		EA	1				*	*	*				3	9	R1
PAHZZ	5905-192-0958	RESISTOR, VARIABLE R6 WIRE WOUND, 1 SECT, 10,000 OHMS PORM10PCT 4W M10MPK (37942)		EA	1				*	*	*				3	9	R6
PAHZZ	5905-064-2795	RESISTOR, VARIABLE R1 1 SECT, 500 OHMS RES PORM10PCT 4W PW 377-0009-000 (13499)		EA	1				*	*	*				3	9	R1
PAHZZ	5905-686-3544	RESISTOR, VARIABLE, LINEAR PRECISION R13 1,000 OHMS PORM5PCT TOL, PORMO.1PCT LINEARITY 2W, 2-1/8 IN DEEP BY 1-49/64 IN		EA	1				*	*	*				3	9	R13
CONTINUED																	

CONTINUED

SECTION V				TM11-6625-492-24P									
(1)	(2)	(3)		(4)	(5)	(6)	(7)			(8)	(9)	(10)	
		DESCRIPTION				30-DAY DS MAINT	30-DAY GS MAINT			1-YR	DEPOT	ILLUSTRATION	
SMR	FEDERAL			UNIT	QTY	ALLOWANCE	ALLOWANCE			ALW PER	MAINT	(A)	(B)
CODE	STOCK			OF	INC	(A)	(B)	(C)	(A)	(B)	(C)	100	100
	NUMBER	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	EQUIP	EQUIP
		CONTINUED											
PAHZZ	5940-060-2525	377-0012-00 (13499) TERMINAL, STUD NO-REF-DESIG BRASS COND 0.788 IN LG BY 0.250 IN ACROSS HEX FLATS O/A 2B1DB12 (92825)		EA	11				*	*	*	1	10

STOCK NUMBER	NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5325-281-1557	10		5910-101-4063	9	C5
5355-284-5666	1		5910-101-4063	9	C6
5905-064-2795	9	R1	5910-101-4063	9	C7
5905-192-0958	9	R6	5910-161-1625	10	C11
5905-195-6761	10	R22	5910-813-1491	10	C12
5905-258-8686	9	R14	5910-813-1491	10	C13
5905-279-4792	9	R9	5915-842-3857	10	
5905-283-8621	9	R7	5935-149-4066		
5905-500-6917	9	R12	5935-193-3550	10	J5
5905-518-5989	9	R4	5935-201-3090		
5905-552-3521	9	R2	5935-201-3511	9	J1
5905-552-4832	9	R5	5935-201-3511	9	J2
5905-557-4473	9	R10	5935-201-3511	9	J3
5905-557-4473	9	R11	5935-201-3511	9	J4
5905-557-4473	9	R15	5935-223-0572	9	
5905-577-7330	9	R1	5935-223-0574		
5905-583-4163	9	R5	5935-284-3967	1	
5905-583-6224	9	R3	5935-500-9734		
5905-583-6240	9	R12	5935-636-6606		
5905-583-6241	9	R7	5935-681-5685		
5905-665-7433	9	R3	5935-823-0487	9	J1
5905-686-3544	9	R13	5935-823-0487	9	J2
5905-725-9145	9	R14	5935-823-0487	9	J3
5905-842-2234	9	R8	5935-823-0487	9	J4
5910-101-4063	9	C1	5940-060-2525	10	
5910-101-4063	9	C2	5940-269-2219	10	J11
5910-101-4063	9	C3	5940-269-2219	10	J12
5910-101-4063	9	C4	5950-645-3278	10	L11

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS  
*Major General, United States Army*  
*The Adjutant General*

CREIGHTON W. ABRAMS  
*General, United States Army*  
*Chief of Staff.*

Distribution:

To be distributed in accordance with DA Form 12-36A (qty rqr block no. 860),  
Organizational maintenance requirements for AN/ASM-101.

This fine document...

Was brought to you by me:



### [Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to [liberatedmanuals.com](http://liberatedmanuals.com), so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals</A>

- Sincerely  
Igor Chudov  
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)