

TECHNICAL MANUAL
ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)
FOR
CHARGER, RADIAC DETECTOR
PP-4370/PD
(NSN 6665-01-042-0382)

HEADQUARTERS, DEPARTMENT OF THE ARMY

5 JULY 1983

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS)**

FOR

CHARGER, RADIACT DETECTOR PP-4370/PD

(NSN 6665-01-042-0382)

Current as of 28 March 1983

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 20282 located in the back of this manual direct to Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-ME-MP, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
SECTION	I. Introduction	1	
	II. Repair Parts List.....	5	
GROUP	00 Charger, Radiac Detector PP-4370/PD	5	1
	01 Front Panel Assembly	9	2
	0101 Component Assembly, Printed Wiring Board (No parts authorized)		
	0102 Component Assembly, Power Supply.....	13	3
	0103 Socket Assembly, Charging.....	17	4
	0104 Socket Assembly, Pumping (No parts authorized)		
	0105 Magnet Assembly (No parts authorized)		
	02 Case Assembly, Charger.	21	5
	03 Case Assembly 24 VDC (No parts authorized)		
	04 Adapter Assembly (No parts authorized)		
SECTION	III. Special Tools List (Not applicable)		
	IV. National Stock Number and Part Number Index.....	22	

SECTION I**INTRODUCTION****1. Scope**

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the PP-4370/PD. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National Item identification number (NIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code Definition

PA - Item procured and stocked for anticipated or known usage.

XB - Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

O - Support item is removed, replaced, used at the organizational level.

H - Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

H - The lowest maintenance level capable of complete repair of the support item is the general support level.

Z - Nonrepairable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

*Recoverability
codes Definition*

Z - Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in position 3.

H - Reparable item. When uneconomically repairable, condemn and dispose at the general support level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5-digit numeric code listed in SB 708-41/42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair parts received may have a different part number than the part being replaced.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publications pertain to the PP-4370/PD and its components:

TM 11-6665-234-12, Charger, Radiac Detector, PP-4370/PD (To be published).

b. National stock numbers (NSN's) that are missing from P source coded items have been applied for and will be added to this TM by future change/revision when they are entered in the Army Master Data File (AMDF). Until the NSN's are established and published, submit exception requisitions to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR-SEL-MM, Fort Monmouth, NJ 07703 for the part required to support your equipment.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)





Figure 1. Charger, Radiac Detector PP-4370/PD (Sheet 1 of 3).



PARTIAL INTERNAL (TOP)

Figure 1. Charger, Radiac Detector PP-4370/PD (Sheet 2 of 3).




Figure 1. Charger, Radiac Detector PP-4370/PD (Sheet 3 of 3).





Figure 2. Front Panel Assembly (Sheet 1 of 2).




EL7U0005

Figure 2. Front Panel Assembly (Sheet 2 of 2).

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION USABLE ON CODE	(7)	(8) QTY INC IN UNIT
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER		U/M	
2	38	PAHZZ	5315-00-847-3735	96906	MS16562-190	PIN, SPRING	EA	1
2	39	PAHZZ	5975-00-296-0534	88044	AN3066-6	LOCKNUT, ELECTRICAL	EA	2
2	40	PAHZZ	5935-00-238-6419	96906	MS25043-12D	COVER, ELECTRICAL CU	EA	2
2	41	PAHZZ	5330-00-248-3848	96906	MS29513-018	PACKING, PREFORMED	EA	2
2	42	XBHZZ		80063	SM-D-68829	TRANSFORMER, POWER	EA	1
2	43	PAHHH		80063	SM-D-688774	POWER SUPPLY ASSY	EA	1
2	44	PAHZZ		80173	44-MY-231524	SWITCH, ROTARY	EA	1
2	45	PAHZZ		88044	AN960C6166	WASHER, FLAT	EA	1
2	46	XBHZZ		80063	SM-D-688806	PANEL, FRONT	EA	1
2	47	XBHZZ		80063	SM-B-688850	STANDOFF	EA	3
2	48	XBHZZ		80063	SM-D-688806-1	PANEL	EA	1
2	49	XBHZZ		46384	FHS-6-32-6	STUD, SELF-CLINCHING	EA	5
2	50	PAHZZ	5310-00-753-5315	46384	BS-440-2	FASTENER, BLIND	EA	1
2	51	XBHZZ		46384	BSOS-832-14	STANDOFF	EA	4
2	52	XBHZZ		46384	BS-05-632-20	STANDOFF	EA	4
2	53	PAHZZ	5310-00-905-5454	88044	AN936A716S	WASHER, LOCK	EA	1
2	54	XBHZZ		80063	SM-C-688833	BUSHING	EA	1
2	55	XBHZZ		80063	SM-C-688834	NUT, HEXAGON	EA	1
2	56	PAHZZ	5365-00-215-7421	30327	60-FL-1/4	BUSHING, RUBBER	EA	1
2	57	PAHZZ	5330-00-248-3840	96906	MS29513-014	PACKING, PREFORMED	EA	1
2	58	PAHZZ	5310-00-616-2973	96906	MS25082-21	NUT, HEXAGON	EA	1

10/(11 BLANK)




NOTE: FOR COMPLETE REFERENCE
DESIGNATION, PREFIX WITH A3

REF. DES.	ITEM NO.								
C14	1	CRI6	4	F2	6	Q5	11	S8	17
C15	2	CRI7	4	F3	7	R45	12	U3	18
C16	2	CRI8	4	J2	8	R46	13		
C17	3	CRI9	4	L1	9	R47	14		
CRI4	4	CR23	4	L2	10	R53	15		
CRI5	4	F1	5	L3	10	R56	16		

EL7U0006

Figure 3. Component Assembly, Power Supply.



EL7U0007

Figure 4. Socket Assembly, Charging (Sheet 1 of 2).






Figure 4. Socket Assembly, Charging (Sheet 2 of 2).



FRONT VIEW


EL7U0009

Figure 5. Case Assembly, Charger (Sheet 1 of 3).



EL7UOOIO

Figure 5. Case Assembly, Charger (Sheet 2 of 3).



COVER, INTERNAL VIEW

EL7U00II

Figure 5. Case Assembly, Charger (Sheet 3 of 3).

By Order of the Secretary of the Army:

Official:

JOHN A. WICKHAM JR.
General, United States Army
Chief of Staff

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with special list.

*U.S. GOVERNMENT PRINTING OFFICE: 1987-754-030/65060

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN... JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR IT
OUT, FOLD IT AND DROP IT
IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 1 JUL 78 2028-2

PREVIOUS EDITIONS
• ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS.

PIN: 053548-000

This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](http://chicagomachinerymovers.com)