TECHNICAL LIBRARY US ARMY MAINT BOARD

Operator and Organizational Maintenance Repair PARTS and Special Tools List and Maintenance Allocation Chart

LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ

TM 11-6695-201-lQP)

CHANGES No. 1

HEADQUARTERS, DEPARTMENT OF THE ARMY WASHINGTON 25, D.C., December 1960

TM 11-6695-201-12P,25 January 1960, is changed as follows:

Page 2, 1ine 9. Change a to e.

Paragraph 1e(2) superseded.

(2) (Superseded) *Federal stock* number. The stock number column lists the n-digit Federal stock number.

Pages 4 and 5. Delete ‡L9Wc33-1, column 4. Add FSN 6695-715-6120, column 2.

By Order of Wilber M. Brucker, Secretary of the Army:

G. H. DECKER, General, United States Army, Chief of Staff.

Official:

R. V. LEE, Major General, United States Army, The Adjutant General.

Distribution:

Active *Army:* To be distributed in accordance with DA Form 12-7 requirements for TM 11 Series (Unclas) Plus the following formula:

the following formula.		11500(AAAE)(4)
USASA (2)	Units organised under following	11-500 (AA-AE) (4)
CNGB (1)	TOES:	11-557
Tech Stf, DA (1) except	(2 copies each except as indc)	11-587
CSig0 (36)	11-7	11-592
DASA (6)	11–16	11-597
US ARADCOM (2)	11-57	17
US ARADCOM Rgn (2)	11-97	17-17
MDW (1)	11-117	19-29
Seventh US Army (2)	11-155	19-500 (AA-AE)
EUSA (2)		
NG: None.		
USAR: None.		
For explanation of abbreviations used, s	ee AR 320-50.	

TAGO 3463.1- Dec. 570470° -60

U.S. GOVERNMENT PRINTING OFFICE: 1960

OPERATOR AND ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST AND MAINTENANCE ALLOCATION CHART

LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ

Headquarters, Department of the Army, Washington 25, D. C.

25 January 1960

SECTION I. INTRODUCTION

		-
	parts for maintenance	2
	Requisitioning information	2
		4
	Critical items	- 3
	Batteries	3
	Additional repair parts	3
	Comments or suggestions	3
II.	FIRST ECHELON FUNCTIONAL PARTS LIST	4
III.	SECOND ECHELON FUNCTIONAL PARTS LIST.	5
IV.	MAINTENANCE ALLOCATION	6
	General	6
	Maintenance by using organizations	7
	Mounting hardware	7
	MAINTĚNANCE ALLOCATION CHART	8
	ALLOCATION OF TOOLS FOR MAINTENANCE FUNCTIONS	9

SECTION I

INTRODUCTION

1. Scope

a. This manual includes operator's maintenance repair parts and special tools list. organizational maintenance repair parts and special tools list. and maintenance allocation chart.

b. The operator's maintenance repair parts and special tools list lists items supplied for initial operation and for running spares. The list includes accesso~ies. parts. and material issued as part of the major end item. All items authorized for basic operator maintenance of the equipment are also listed.

c. The organizational maintenance repair parts and special tools list lists the quantities of repair parts authorized for organizational maintenance and is a basis for requisitioning by organizations which are authorized the major item of equipment. End items of equip-

Paragraph Page

1

^{*}This 'manual supersedes the first and second echelon portion of DA Supply Manual SIG 7 & 8 MX-1291/PAQ. 1 October 1956.

ments are issued on the basis of allowances prescribed in equipment authorization tables and other documents that are a basis for requisitioning.

d. The maintenance allocation chart assigns maintenance functions and repair operations to be performed by the lowest appropriate maintenance echelon.

- a. Columns are as follows:
 - (1) Source, maintenance, and recoverability code. Not used.
 - (2) Federal stock number. The stock number column lists the n-digit Federal stock number. In the absence of a Federal Stock Number an interim i.e. ††L8Ra41c-12, appears in the description column. This indicates an applicable Federal stock number is in the process of assignment. The L number may be used in emergencies to identify items.
 - (3) Designation by model. Not used.
 - (4) *Description.* Nomenclature or the standard item name and brief identifying data for each item is listed in this column. When requisitioning, enter the nomenclature and description on the requisition.
 - (5) Unit of issue. The unit Of issue is tile supply term applied to the smallest quantity by which the individual item is counted for procurement, storage, requisitioning, allowances, and issue purposes.
 - (6) Expenability.Expendable items are indicated by the letter X; nonexpendable items are indicated by NX
 - (7) Quantity authorized. Under "Items Comprising an Operable Equipment" the column lists the quantity of items supplied for the initial operation of the equipment. Under "Running Spares and Accessories" the quantities listed are those issued initially with the equipment as spare parts. The quantities are authorized to be kept on hand by the operator for maintenance of the equipment.
 - (8) Quantity incorporated in unit. This column lists the quantity of each particular part found in a given assembly, component, or equipment.

- (9) Organizational The quantities indicated in this column are maximum levels of repair parts authorized to be kept on hand by units performing organizational maintenance. The quantities are based on 100 equipments to be maintained for a 15-day period.
- (10) *Illustration*. The item No. column lists the reference designations used for identification of the items in the illustration or text of the manual.

2. Parts for Maintenance

When this equipment is used by signal service organizations organic to the theater headquarters or communication zones to provide theater communications, those repair parts authorized up to and including fourth echelon are authorized for stockage by the organization operating this equipment.

3. Requisitioning Information

a. The allowance factors are based on 100 equipments. In order to determine the number of parts authorized for initial stockage for the specific number of equipments supported, the following formula will be used and carried out to two decimal places:

Specific number of equipments supported allowance factor

Number of parts authorized.

b. Fractional values obtained from above computation will be rounded to whole numbers as follows:

- (1) When the total number of Parts orized is less than one, the quantity authorized will be one,
- (2) For all values above one, fractional values below 0.5 will revert to the next lower number, fractional values of 0.5 or larger will advance to the next higher whole number.

c. The number of parts authorized, determined after application of a and b above, represent one prescribed load for a 15-day period. The items and computed quantities thereof must be on hand or on order at all times.

d. Major commanders will determine the number of prescribed loads second echelon units and organizations will carry. Units and organizations authorized additional prescribed loads will utilize the formula explained in a above but will multiply the number of equipments supported by the number of authorized prescribed loads before completing the formula. Fractional values will be rounded to whole numbers as described above.

4. Critical Items

A zero slash (0) in the description column indicates items that are expected to fail during the first year; also items that will make the equipment inoperative if they fail.

5. Batteries

Dry batteries shown are used with the equipment but are not considered part of the equipment. They will not be preshipped automatically but are to be requisitioned in quantities necessary for the particular organization, in accordance with SB 11-6.

6. Additional Repair Parts

Additional repair parts Which may be required for performing organizational maintenance, but are not authorized for stockage in the prescribed load are identified by an asterisk (*) and are to be requisitioned as required, for immediate use only. Refer to AR 700-18.

7. Comments or Suggestions

Any comments concerning omissions and discrepancies in this Manual will be prepared on DA Form 2028 and forwarded direct to Commanding Officer, U. S. Army Signal Equipment Support Agency, Fort Mommouth, N. J. ATTN : SIGFM/ES-ML.

SECTION II FIRST (1) SOURCE	ECHELON FUNCTIONAL (2)	PARTS LIST (3)	(4)	(5)	(6)	(7)	(8)	(9)
MAINTENANCE AND RECOVERABILITY CODE	FEDERAL STOCK NUMBER	DESIGNATION BY MODEL	I DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QUANTITY AUTHORIZED	FIGURE	RATIONS ITEM NO
			TING CONTRIBUTION NIN ORDANATO CONTRIBUTI					
			LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ					
	6695-537-8948 ORD THRU AGC ORD THRU AGC 6135-125-5257 6150-392-6831		LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ: TECHNICAL MANUAL TM 11-5542 TECHNICAL MANUAL: TM11-6695-201-12P BATTERY BA-419/U: (REQUIRED FOR D-C OPERATION) CABLE ASSEMBLY, POWER, ELECTRICAL: TWO NO. 18 AWG STRANDED COND; 6 FT LG; SIRCHIE FINGERPRINT LAB NO. 6681 RUNNING SPARES AND ACCESORY ITEMS LIGHT ASSEMBLY, ELECTRIC MX-1291/PAO	EA EA EA EA	NX X X X X	2 2 1 1		
			FILTER, LIGHT, ULTRAVIOLET: CRAIG INSTRUMENT PART/DWG NO. B-13-1 (USED ON ORDER	EA	х	1		01
	6695-393-2155		9144-PP-59) ^^L9WC33-1 FILTER, LIGHT, ULTRAVIOLET: SIRCHIE FINGERPRINT LAB PART NO. 6666 (USED ON ORDER	EA	х	1		01
	6240-151-7641 6240-299-3404 5120-277-9489		39192-P-52) \$ LAMP, FLUORESCENT: SYLVANIA PROD PART NO. F-6T5/BLB \$ LAMP, MERCURY VAPOR: SYLVANIA PROD PART NO. G4T4/1 SCREWDRIVER TL-22	EA EA EA	X X X	1 1 1		I1 I2 H40

SECTION III SECOND ECHELON FUNCTIONAL PARTS LIST

4

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8) ORGANI-	(9)	(10)
SOURCE MAINTENANCE AND RECOVERABILITY CODE	FEDERAL STOCK NUMBER	DESIGNATION BY MODEL	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QUANTITY INCORPORATED IN UNIT	ZATIONAL 15 DAYS MAINTENANCE ALLOWANCE	FIGURE	
	6695-537-8948		LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ	EA	NX		2110		

6695-53/-8948	LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ	EA	NX			
6250-377-0135	\$ BALLAST, LAMP: SIRCHIE FINGERPRINT LAB NO. 6621	EA	х	1	*	т1
6250-283-9386	\$ BALLAST, LAMP: GE NO. 89G435	EA	Х	1	*	т2
6135-125-5257	BATTERY BA-419/U: (REQUIRED FOR D-C OPERATION)	EA	Х	1		
6145-112-8623	CABLE, POWER, ELECTRICAL: 2 STRANDED NO. 18 AWG COND; 300V; SPEC	FT	х	6	*	W201
	NO. 62,					
	TYPE SJ MODIFIED (AUTHORIZED QUANTITY WILL BE MINIMUM OR A MULTIPLE	OF				
	FT IN USE)					
5935-149-4013	CONNECTOR, PLUG, ELECTRICAL: HUBBELL PART NO. 7057	EA	Х	1	*	P2
5935-149-3628	CONNECTOR, PLUG, ELECTRICAL: HUBBELL PART NO. 7464	EA	Х	1	*	P1
5935-237-6663	CONNECTOR, PLUG, ELECTRICAL: EBY PART NO. 9706-3	EA	X	1	*	P3
5935-161-9653	CONNECTOR, RECEPTACLE, ELECTRICAL: HUBBELL PART NO. 7466	EA	Х	1	*	J1
6695-392-8512	DOOR, CABINET, ELETRICAL: SIRCHIE FINGERPRINT LAB PART NO. 6678	EA	Х	1	*	A6
	FILTER, LIGHT, ULTRAVIOLET: CRAIG INSTRUMENT PART/DWG NO. B-13-1	EA	X	1	*	01
	(USED ON					
	ORDER 9144-PP-59) ^^L9WC33-1					
6695-393-2155	FILTER, LIGHT, ULTRAVIOLET: SIRCHIE FINGERPRINT LAB PART NO. 6666	EA	X	1	*	01
	(USED ON					
	ORDER 39192-P-52)					
6240-151-7641	\$ LAMP, FLUORESCENT: SYLVANIA PROD PART NO. F-6T5/BLB	EA	Х	1	4	I1
6240-299-3404	\$ LAMP, MERCURY VAPOR: SYLVANIA PROD PART NO. G4T4/1	EA	X	1	4	12
6250-299-4253	LAMPHOLDER: HOLDERS FOR LAMP I1 SYLVANIA PROD PART NO. S-100	EA	Х	2	*	J2
6695-377-0167	REFLECTOR, LIGHT: SIRCHIE FINGERPRINT LAB PART NO. 6680	EA	X	1	*	02
5120-277-9489	SCREWDRIVER TL-22	EA	X	1	*	H40
5935-246-5280	SOCKET, ELECTRON TUBE: AMPHENOL PART NO. 78-S4	EA	Х	1	*	J203
5930-050-2708	SWITCH, TOGGLE: JAN TYPE NO. ST52P	EA	X	1	*	S1
5930-666-0260	SWITCH, TOGGLE: JAN TYPE NO. ST42C	EA	X	2	*	S2,S3

SECTION IV

MAINTENANCE ALLOCATION

8. General

a. This section assigns maintenance functions and repair. operations to be performed by the lowest appropriate maintenance echelon.

b. Columns in the maintenance allocation chart are as follows:

- (1) Part or component. Only the nomenclature or standard item name is shown in this column. Additional descriptive data is included only where clarification is necessary to identify the part. Components and parts comprising a major end item are listed alphabetically. Assemblies and subassemblies are in alphabetical sequence with their components listed alphabetically immediately below the assembly listing.
- (2) *Maintenance function*. This column indicates the various maintenance functions allocated to the echelon capable of performing tile operation. These are defined as follows:
 - (a) *Service*. To clean, to preserve, and to replenish fuel and lubricants.
 - (b) *Inspect.* To verify serviceability and to detect incipient electrical or mechanical failure by scrutiny.
 - (c) *Test.* To verify serviceability and to detect incipient electrical or mechanical failure by use of special equipment such as gages, meters, etc.
 - (d) Replace. To substitute serviceable assemblies, subassemblies, and parts for unserviceable components.
 - (e) *Rebuild.* To restore to a condition comparable to new by disassembling the item to determine the condition of its component parts and reassembling it using serviceable,

rebuilt, or new assemblies, subassemblies, and parts.

- (3) 1st, 2d, 3d, 4th, and 5th echelon. The symbol X indicates the echelon responsible for performing that particular maintenance operation, but does not necessarily indicate that repair parts will be stocked at that Ievel. Echelons higher than the echelon marked by X are authorized to perform the indicated operation.
- (4) tools required. This colmn indicates codes assigned to each individual tool equipment, test equipment, and maintenance equipment referenced. The grouping of codes this this column indicate the tools, test, and maintenance equipment required to perform the maintenance function.
- (5) Remark. Entries in this column will be utilized when necessary to clarify any of the data cited in the preceding columns.

c. Columns in the allocation of tools for maintenance functions are as follows:

- (1) *Tools required for maintenance functions.* This column lists tools, test, and maintenance equipment required to perform the maintenance functions.
- (2) 1st, 2d, 3d, 4th, 5th echelon. A dagger
 (†) symbol indicates the echelons allocated the facility.
- (3) *Tool code*. This column lists the tool code assigned.
- (4) *Remarks*. Entries in this column are used to clarify data in the other columns.

9. Maintenance by Using Organizations When this equipment signal serv-

ice organizations organic to theater headquar-

ters or communication zones to provide theater communications, those maintenance functions allocated up to and including fourth echelon are authorized to the organization operating this equipment.

10. Mounting Hardware

The basic entries of this maintenance allocation chart do not include mounting hardware such as screws, nuts, bolts, washers, brackets, clamps, etc.

MAINTENANCE ALLOCATION CHART

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)
						[
PART OR COMPONENT	MAINTENANCE				4 TH	1	TOOLS	REMARKS
	FUNCTION	ЕСН	ECH	ECH	ЕСН	ECH	REQUIRED	REMARKS
						<u> </u>		
LIGHT ASSEMBLY, ELECTRIC MX-1291/PAQ				ł				
	service	X						Clean
	inspect		X		ļ		1	Visual, operational
	test	1	<u> </u>			[1, 2	Circuits
	rebuild					X	2	
BALLAST, LAMP	replace	-	X				2	
BATTERY BA-419/U	replace	X						
CABLE ASSEMBLY		1-						
CABLE, POWER, ELECTRICAL	replace		X	-				
CONNECTOR, PLUG: P1, P2	replace	1	X					
CONNECTOR	replace	-	X				2	
DOOR, CABINET, ELECTRICAL	replace	X						
FILTER	replace		x			- ·	·	
LAMP, FLUORESCENT	replace	x					······	
LAMP, MERCURY VAPOR	replace	1	X					
LAMPHOLDER	replace	1	<u>X</u>				2	
REFLECTOR, LIGHT	replace		<u>x</u>		-			+
SOCKET, ELECTRON TUBE	replace	1	X				2	+
SWITCH	replace	1	X				2	

MX-1291/PAQ

ALLOCATION OF TOOLS FOR MAINTENANCE FUNCTIONS

(1)	(z)	(3)	(4)	(5)	(6)	(7)	(8)
TOOLS REQUIRED FOR MAINTENANCE FUNCTIONS					5тн ЕСН		REMARKS
MX-1291/PAQ (continued)		<u> </u>	-				
MULTIMETER AN/URM-105	<u> </u>	+	+	+	+	1	Will replace TS-297/U and TS-352/U when available
TOOL KIT TK-77/GF		+	+	+	F	2	

MX-1291/PAQ

L. L LEMNITZER, General, United States Army, Chief of Staff.

Official : R. V. LEE, *Major General, United States Army, The* Adjutant Gerneral.

DISTRIBUTION :

Active Army: USASA (2) CNGB (1) Tech Stf. DA (1) except CSigO (18) Tech Stf Bd (1) USCONARC (5) USA Arty Bd (1) USA Armor Bd (1) USA Armor Bd Test Sec (1) USA Inf Bd (1) USA Air Def Bd (1) USA Air Def Bd Test See (1) USA Abn & Elet Bd (1) USA Avn Bd (1) USATB (1) USARADCOM (2) USARADCOM Rgn (2) OS Maj Comd (5) OS Base Comd (5) Log Comd (5) MDW (1) Armies (5) except First US Army (7) Corps (2) Div (2) USATC (2) Ft Belvoir (5) Def Atomic Spt Agey (5) Yuma Tet Sta (2) USA Elct PG (1) Svc Colleges (5) Br Sve Sch (5) except USASCS (25) Gen Dep. (2) except Atlanta Gen Dep (None) Sig Sec, Gen Dep (10) Sig Depots (17) AFIP (1)

WRAMC (1) AMS (1) Engr Maint Cen (1) USA Comm Agey (3) USA Sig Engr Agcy (1) USA Sig Eqp Spt Agcy (7) USA Sig Msl Spt Agcy (13) Trans Terminal Comd (1) Army Terminals (1) Pelt of Emb (0S) (2)OS Sup Agey (1) Sig Id Maint Shops (3) Sig Lab (5) USA Corps (Res) (1) USASSA (15) Midwestern Rgn Ofc (USASSA) (1) JBUSMC (2) USA Sig Pubs Agcy (8) Army Pictorial Cen (2.) USA Ord Msl Comd (3) Units org under fol TOE: 11-7(2)11-16(2)11-57 (2) 11-97 (2) 11-117 (2) 11-155 (2) 11-500 AA-AE (2) 11-557 (2) 11-587 (2) 11-592 (2) 11-597 (2) 17-17 (2) 19-27 (2) 19-29 (2) 19-500 AA-AE (2)

NG: None. USAR: None. For explanation of abbreviations used, see AR 320-50. This fine document...

Was brought to you by me:



Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<u>http://www.liberatedmanuals.com/</u>>Free Military and Government Manuals

Sincerely
 Igor Chudov
 <u>http://igor.chudov.com/</u>
 Chicago Machinery Movers