AIR TRANSPORTABILITY GUIDANCE M151 1/4-TON TRUCK AND M100 1/4-TON TRAILER IN CH-17 HELICOPTER

Headquarters, Department of the Army, Washington, D.C. 21 February 1966

	Paragraph	Page
Purpose and scope	1	1
Applicability	2	1
Responsibilities		1
Load description		2
Preparation and loading		2
Unloading		3
Appendix. References		5

1. Purpose and Scope

a. This manual provides transportability guidance for movement of the M151 1/4-ton truck and the M100 1/4-ton trailer (also referred to as "item") in the CH-47 helicopter. The text prescribes procedures. materials, and manpower to prepare, load, tie down, and unload the item.

b. Users of this manual are encouraged to submit recommended changes or comments to improve the document. Comments should be keyed to the specific page, paragraph, and line of the text in which a change is recommended. Reasons should be provided for each comment to insure understanding and complete evaluation. Comments should be forwarded direct to Commanding Officer, U.S. Army Transportation Engineering Agency, ATTN: TCTEA-TG, Fort Eustis, Va., 23604.

2. Applicability

a. These instructions apply when the item is located and tied down as shown in the loading diagram and tiedown data table. A transported unit can, with the consent of the helicopter commander, add additional cargo within allowable load limits and restrictions prescribed by pertinent safety regulations (app.).

b. For operational reasons, or to accommodate additional cargo, the helicopter commander may designate a location other than that shown in the

loading diagram. If the item is relocated, the helicopter commander must insure that-

- (1) The number and load capacity of the tiedown devices are as prescribed in this manual.
- (2) The tiedown devices restraining the item are secured to tiedown fittings of at least the same strength and in the same location relative to the item as those fittings used in the loading diagram.

Warning: Transport of the M151 1/4-ton truck and M100 1/4-ton trailer in the CH-47 helicopter is prohibited if the item is not loaded and tied down in accordance with the instructions in this manual.

3. Responsibilities

Commanders of the transported and transporting units are responsible for the following:

- a. Transported Unit.
 - (1) Preparing unit equipment for air transport, with supervision and assistance as required from appropriate field support units
 - (2) Loading, tying down, and unloading unit equipment transported aboard the helicopter, subject to approval by the helicopter commander or his authorized representative. Such approval is to insure

- that loading, tie down, and unloading are accompli shed as prescribed by this manual.
- (3) Effecting advance coordination with the transporting unit. This coordination will include a request for the tiedown devices required.
- (4) Providing manpower and the necessary shoring, padding, vehicles, and other materials required to accomplish item preparation, loading, and unloading.
- (5) Providing guidance to the helicopter commander relative to safety and to any technical peculiarities of the item which may affect its safe and reliable air transport.

b. Transporting Unit.

- (1) Supplying a sufficient quantity of the type of tiedown devices requested.
- (2) Operating helicopter-associated equipment and monitoring loadling, tiedown, and unloading procedures to insure conformance with this manual.
- (3) Inspecting the helicopter for serviceability appropriate to the mission and complying with pertinent aviation directives.

4. Load Description

The approximate dimensions and weight of tile item are as follows:

	Length	Width	Height	Weight
	(in.)	(in.)	(in.)	(lb.)
M151 Truck	132	63	53	2, 350
M100 Trailer	108	57	43	*1,090
• Weight includes 500 pounds of car	go secured	in traile	er.	

5. Preparation and Loading

a. *Material*. Four small clevis assemblies (FSN 1670-360-0304) .

b. Procedures.

- (1) Remove truck top and store in vehicle; strap down the top supports.
- (2) Lower and lock windshield.

- (3) Insure that fuel tank contents of truck do not exceed 3/4-tank capacity.
- (4) Attach small clevis assembly to each wheel hub of M151 1/4-ton truck.
- (5) Position guides in helicopter and at left front of item to observe clearances and to signal truck driver as necessary.
- (6) Back item into helicopter to tiedown posit ion; truck and trailer remain coupled.
- (7) Place truck transmission in gear: set brakes on truck and trailer.
- (8) Tie down the item in accordance with figures 1, 2, 3, and 4 and the tiedown data table. Six MB-1 and six CGU-1/B tiedown devices are required.
- (9) Three men can prepare, load, and tie down the item in approximately 25 minutes.

Note. It is emphasized that the times given for the operations described in this manual are for guidance purposes only and may vary, dependent upon existing conditions.



Figure 1. Typical tiedown of M100 1/4-ton trailer. (View through main cabin entrance door.)

2 TAGO 1369A




Figure 2. M151 1/4-ton truck and M100 1/4-ton trailer positioned and tied down. (View loking aft in helicoper.)




Figure 3. Head-on view of M151 1/4-ton truck positioned and tied down. (View looking forward in helicopter.)

Tiedown. Data Table


M151 1/4- Ton Truck and M100 1/4- Ton Trailer In CH-47 Helicopter

	1				
Item No.	Tie- down fitting No.	Capacity of tiedown fitting in 1.000 lb.	Type device	Attach to item	
1	A2	5	CGU-1/B*	Left axle.	
1	E2	5	CGU-1/B	Right axle.	
	A9	5	MB-1**	Right front tie- down point.	
	E9	5	MB-1	Left front tiedown point.	
2	A8	5	CGU-1/B	Right rear wheel clevis.	
	E8	5	CGU-1/B	Left rear wheel clevis.	
	A11	10	MB-1	Right rear wheel clevis.	
	E11	10	MB-1	Left rear wheel clevis.	
	A13	5	CGU-1/B	Right front wheel clevis.	
	E13	5	CGU-1/B	Left front wheel clevis.	
	A19	10	MB-1	Right front wheel	
	E19	10	MB-1	Left front wheel clevis.	

^{*}MC-1 tiedown device may be substituted for the CGU-1/B. ** C-2 tiedown device may-be substituted for the MB-1.

6. Unloading

The item is unloaded by reversing the loading procedures. Position guides and drive item from the helicopter. Three men can unload the item in approximately 20 minutes.



NOTE: FLOOR AREA BOUNDED BY ROWS 11 AND 13 AND COLUMNS B AND D INCCOSE UTILITY HATCH.

Figure 4. Loading diagram for M151 1/4-ton truck and M100 1/4-ton trailer in CH-47 helicopter.

Item	Description of item	Item facing	Location of reference point		Location of C.G.	Approx. wt (lb)
			Reference point	Station		
$\frac{1}{2}$	M100 ¼-ton trailer M151 ¼-ton truck	AftAft	Axle Front axle	218 401	224 364	1, 090 2, 350

APPENDIX

REFERENCES

1. Field Manual

FM 1-100 - - - - - - - Army Aviation.

2. Technical Bulletin

T B 5 5 - 4 6 - - - - - - Standard Characteristics (Dimensions, Weight, and Cube) for Transportability of Military Vehicles and Equipment.

3. Technical Manuals

TM 9-2320-218-10 - - - - - Operator's Manual, Truck, Utility: 1/4-Ton, 4 x 4, M151.
T M 9 - 8 7 1 A - - - - - Operator, Organizational and Field Maintenance Manual: Trailer, Cargo: 1/4-Ton, 2 Wheel, M100.

TM 55-1520-209-10 - - - - Operator's Manual, Army Model CH-47A Helicopter.

TM 57-210 - - - - - - - Air Movement of Troops and Equipment.

4. Army Regulation

AR 385-40 - - - - - - - - Accident Reporting and Records.

By Order of the Secretary of the Army:

HAROLD K. JOHNSON,

General, United States Amy, Chief of Staff.

Official:

J. C. LAMBERT,

Major General, United States Army, The Adjutant General.

Distribution:

To be distributed in accordance with DA. Form 12-31, Section 1b, requirements for Operator and Crew for CH-47 Helicopter and DA Form 12-38 requirements for Operator (249) for Truck Utility, 1/4-Ton, M151 and DA Form 12-39 requirements for Operator (49) for Trailer, Cargo, 1/4-Ton, M100.

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

- SincerelyIgor Chudovhttp://igor.chudov.com/
- Chicago Machinery Movers